

Service Manual

Temperature Chamber (Industrial Oven)

PV(H)-211, 221, 231, 331

4022105000330



This Service Manual has been compiled specifically for service-people trained or certified by ESPEC ENGINEERING CORP. Because of the dangers involved, service described herein should not be performed by other persons.

ESPEC ENGINEERING CORP.

Introduction

This service manual provides a clear, comprehensible description of the types of troubles which may possibly arise with your temperature chamber. There are also some suggested actions to be taken.

In the event of trouble, do not panic and stick closely to the appropriate procedure. You may use User's Manual in conjunction with this service manual to gain a more comprehensive understanding of the unit as a whole. For details not contained in this manual, and when trouble reoccurs despite taking the prescribed remedial action, contact ESPEC CORP.

Contents

Chapter 1 Fault diagnosis

- * This chapter contains a list of precautions to observe when trouble occurs and while troubleshooting.

Chapter 2 Chamber configuration

- * This chapter explains equipment configuration. When trouble occurs with your chamber, read this section carefully before investigating the cause or taking remedial action.

2-1 Temperature chamber models	2
2-2 Names of chamber parts	3
2-3 Control systems	7

Chapter 3 Troubleshooting

- * This chapter uses flow charts to explain how to deal with troubles occurring in equipment usage. Investigate the cause and take remedial action in accordance with the appropriate flow chart.

3-1 Faults displayed with an alarm code	9
(1) Temperature sensor disconnection or broken wire (AL-00)	9
(2) The indicated temperature is 10°C higher than the temperature setting. (AL-01)	10
(3) The indicated temperature is higher than the upper limit temperature setting. (AL-02)	12
(4) The indicated temperature is below the lower limit temperature setting. (AL-03)	13
(5) Blown thermal fuse or tripped overheat protector (AL-06)	15
(6) The temperature switch protecting the fan motor coil tripped. (AL-07)	17
(7) Tripped door switch (AL-09)	18
(8) Memory error (E1 or E2)	19

3-2 Faults without an alarm code	20
(1) Tripped leakage breaker	20
(2) Temperature fails to rise.	22
(3) Temperature rises too slowly.	23
(4) Overshoot is too large.	24
(5) Temperature rises too high.	25
(6) Temperature cannot be controlled.	26
(7) No indications appear on the display.	27

Chapter 4 Replacement and adjustment of parts

* This chapter explains how to replace and adjust parts including necessary preparations and incidental work.

4-1 Replacing the heater and thermal fuse	30
4-2 Replacing the blower wheel	31
4-3 Replacing the motor	32
4-4 Replacing the damper unit	33
4-5 Repositioning the lock	34
4-6 Repositioning door hinges	35
4-7 Replacing the door gasket	36
4-8 Replacing the temperature controller circuit board (control board)	37
4-9 Replacing the overheat protector circuit board (OHP board)	38
4-10 Replacing the temperature sensor	39
4-11 Replacing the SSR	40
4-12 Replacing the main power switch (leakage breaker) and electrical compartment	41
door switch	
4-13 Resetting the temperature indicator-controller	42
4-14 Replacing the ROM	45
4-15 Replacing the battery	47
4-16 Temperature calibration	48

Chapter 1 Fault diagnosis

1. When a fault occurs during operation, first check whether an alarm code has been displayed or not.
2. If an alarm code is displayed, diagnose the fault according to the troubleshooting flow charts given in Chapter 3, 3-1.
3. If an alarm code is not displayed, diagnose the fault according to the troubleshooting flow charts given in Chapter 3, 3-2.

Note 1: Investigate the cause of a fault systematically, according to the appropriate flow chart indicated in this manual. Do not skip over steps to solve problems more quickly.

Note 2: Safety precautions

Take the necessary safety precautions and be sure to ground equipment where instructed in troubleshooting procedures to check the chamber under power before proceeding.


Note 3: Where parts need to be replaced, contact ESPEC CORP. with the part name. When delivered, replace parts as described in this manual.

Note 4: If trouble reoccurs despite your taking the prescribed remedial action, contact ESPEC CORP.


Chapter 2 Chamber configuration

2-1 Temperature chamber models


Explanations given in this manual may regard functions not provided with your chamber. You should therefore, familiarize yourself with the type and model of chamber(s) you are using.




2-2 Names of chamber parts




Chamber front view



Chamber rear view




Electrical compartment



Temperature controller circuit board (control board)

2-3 Control system

The basic system is shown in the below figure. For details, check your schematic circuit diagrams.



Chapter 3 Troubleshooting

This chapter uses flow charts to explain troubles that may occur with your chamber during usage and the corresponding remedial action. The flow charts themselves name various parts, some of which may not pertain to the type of chamber you are using. Read "Chapter 2 Chamber configuration" carefully, before attempting to investigate the cause of a fault. Refer to "2-2 Names of chamber parts" to locate parts mentioned in the flow charts.


Note also that the position of certain parts may vary depending on the model of chamber you are using.

3-1 Faults displayed with an alarm code

AL00


Temperature sensor disconnection or broken wire

[Diagnostic method]



- Check temperature sensor leads connections.
No disconnection nor faulty contact should be detected in connector TD₁ of temperature indicator-controller TC₁.

- Check the temperature sensor leads for broken wires.
Disconnect connector TD₁ from temperature indicator-controller TC₁, and measure resistance at both sensor terminals.




Power ON/OFF	Measured terminal		Passing mark
OFF	⊕	⊖	Good: approx. 10Ω
	Red	White	Bad: ∞Ω

- For details on replacing the temperature sensor, refer to chapter 4.
- For details on resetting the temperature indicator-controller, refer to chapter 4.
- For details on replacing the temperature indicator-controller, refer to chapter 4.


AL01 The indicated temperature is 10°C higher than the temperature setting. (1/2)

[Diagnostic method]



• For details on resetting the temperature indicator-controller, refer to chapter 4.

• Check the temperature sensor is sufficiently penetrating the chamber.




• Check heater output. Check heater output as explained under "Monitoring" in User's Manual (Standard-/M-instrumentation)


Heater OFF: 0%
Heater ON :1-100%

FL0 : The indicated temperature is 10°C higher than the temperature setting. (2/2)

[Diagnostic method]




- Check SSR drive output (DC range) from the temperature indicator-controller. Measure input voltage at SSR input terminals ③ and ④.



Power ON/OFF	Measured terminal	Passing mark
Heater ON	+ -	Approx. 24V DC
Heater OFF	Terminal ③ ④	Approx. 0V DC

- Check the SSR is functioning properly. Measure voltage at SSR output terminals (1) and (2).




Power ON/OFF	Measured terminal	Passing mark
Heater ON	Terminal ① ②	0V AC
Heater OFF	Wire No. (4) (5)	200-240V AC

- For details on replacing the SSR, refer to chapter 4.
- For details on replacing the temperature indicator-controller, refer to chapter 4.

AL02	The indicated temperature is higher than the upper limit temperature setting.	[Diagnostic method]			
AL-02 Is the upper limit temperature setting correct? No Reset the limit. Yes Go to AL-01.		Set the upper limit temperature as described under "Temp. limit settings" in User's Manual (Standard-/M-instrumentation). <table><tr><td>Test chamber</td><td>set temp.</td><td>Max. temp. < allowable with specimen</td></tr></table> * In normal usage, make your upper limit setting no more than 15°C higher than max. test temperature.	Test chamber	set temp.	Max. temp. < allowable with specimen
Test chamber	set temp.	Max. temp. < allowable with specimen			

AL03 The indicated temperature is below the lower limit temperature setting. (1/2)

[Diagnostic method]




- Set the lower limit temperature. Set the lower limit temperature as described under "Temp. limit settings" in User's Manual (Standard-/M-instrumentation).

- Check heater output. Check heater output as explained under "Monitoring" in User's Manual (Standard-/M-instrumentation).
Heater OFF: 0%
Heater ON : 1-100%

* When the temperature setting stabilizes, heater output will rise and the panel indication will change in range from 1% to 99%.


- Check the heater for broken wires. Measure resistance across heater terminals. Disconnect all heater leads before testing.



Passing mark: 200Ω or less

AL03 The indicated temperature is below the lower limit
temperature setting. (2/2)


[Diagnostic method]



- Check power relay X₁ (X₂, X₃) is functioning properly. Check contact on the temperature indicator-controller circuit board is properly made.


Power ON/OFF	Passing mark
ON	0V AC
OFF	200V~240V AC

- For details on checking SSR drive output and SSR functioning, refer to AL-01.




- Check whether the overhear protector has tripped or not.
- (1) Check the overhear protector OHP₁ for continuity (200V AC).
- (2) Check the overhear protector is functioning properly. Check the contact output.

Connector for setting device



OHP₁ detail




Overheat protector alarm function

* Refer to diagnostic method on the next page.


AL06

Blown thermal fuse or tripped overhear protector (2/2)

[Diagnostic method]



- Disconnect thermal fuse connector CN11 and measure resistance on the thermal fuse side.



Power ON/OFF	Measured terminal		Passing mark
OFF	Connector No.	① ②	Good: Continuity detected
	Wire No.	17D-19D	Bad: Continuity not detected

- Check connector CN5 of temperature indicator-controller TC1. Check for disconnection and faulty contacts in connector CN5 of temperature indicator-controller TC1.

- If a faulty contact occurs at CN5, alarms AL-07 and AL-09 may be generated at the same time.


- Check the temperature sensor for faulty contacts and broken wires. Check wires are properly connected to the input terminal on the overhear protector setting device. Disconnect the temperature sensor from the terminal and measure resistance at both ends. If the temperature sensor is disconnected or there is an open circuit in the sensor, a burnout indication appears on the setting device display.

Power ON/OFF	Measured terminal		Passing mark
OFF	⊕ Red	⊖ White	Good: approx. 10Ω
			Bad: ∞Ω

AL07


The temperature switch protecting the fan motor coil tripped.

[Diagnostic method]



• Check whether temperature switch inside the fan motor has tripped or not.

Disconnect relay connector CN12, and measure resistance at terminals (2) and (4) (wire Nos. 13D and 15D) on the motor side.




Power ON/OFF	Measured terminal		Passing mark
OFF	Connector No.	②—④	0Ω: Not tripped
	Wire No.	13D-15D	∞Ω: Tripped

AL09

Tripped door switch.


[Diagnostic method]



• AL-09 is displayed if the door is left open for 3 minutes or more.


• Check connector CN5 on the temperature controller circuit board.

• Check the door switch is functioning properly. Disconnect the door switch wires and check the switch for continuity.



Good: 0Ω


E 1	Memory error	[Diagnostic method]
E 2		




3-2 Faults without an alarm code


Tripped leakage breaker (1/2)	[Diagnostic method]
<pre> graph TD Start(()) --> D1{Is the electrical compartment door closed?} D1 -- No --> A1([Close the door.]) D1 -- Yes --> D2{Is electrical compartment door switch DS, functioning properly?} D2 -- No --> A2[Replace the switch.] D2 -- Yes --> D3{Are contact terminals free from moisture and dirt?} D3 -- No --> A3([Dry or clean parts as necessary.]) D3 -- Yes --> D4{Is heater insulation resistance 1MΩ or more?} D4 -- No --> A4[Replace the heater.] D4 -- Yes --> D5{Is fan motor insulation resistance 1MΩ or more?} D5 -- No --> A5[Replace the fan motor.] D5 -- Yes --> End(()) </pre>	• Check switch contact when the electrical compartment door is closed. • A catching sound should be heard when pressing the door switch by your hand, but it is better to check operation by measuring resistance at both ends of the switch with a tester. • If moisture has penetrated the equipment, find and eliminate the cause and prevent its reoccurrence. • Check heater insulation. Measure resistance across the heater terminal and the heater with a 500V DC insulation resistance tester. Good: 1MΩ or more. • Check fan motor insulation. Measure resistance across the fan motor terminal and the motor with a 500V DC insulation resistance tester. Good: 1MΩ or more.

Tripped leakage breaker (2/2)	[Diagnostic method]
Continued from the previous page <pre> graph TD Start([Continued from the previous page]) --> D1{Are other insulated points intact?} D1 -- No --> A1[Replace poorly insulated parts.] D1 -- Yes --> D2{Are terminal contacts on the heater circuit tight and unscorched?} D2 -- No --> A2([Fix or replace parts as necessary.]) D2 -- Yes --> A3[Replace the leakage breaker.] </pre> After replacing the leakage breaker, press the test button and check the breaker trips properly. Leakage breaker trouble carries the risk of electric shock or burned parts, therefore, if the described diagnostic method fails to remedy the situation, promptly contact TABAI ESPEC CORP.	NOTE: When measuring insulation (500V DC insulation resistance tester), be sure to disconnect the connector and measure at the loaded side. NOTE: After replacing the leakage breaker, make sure terminal connections are sufficiently tight.






Temperature rises too high.	[Diagnostic method]
-----------------------------	---------------------



• For details on checking heater output, refer to AL-01.



• For sensor positioning, refer to AL-01.


• Check SSR drive output (DC range) from the temperature indicator-controller.
Measure input voltage at SSR input terminals (3) and (4).



Power ON/OFF	Measure terminal	Passing mark
ON	+ -	Approx. 24V DC
OFF	Terminal ③ ④	Approx. 0V DC

* A short may have occurred on the SSR output side (load). In such case, check the power relay X₁ (X₂, X₃) contact of the temperature indicator-controller for abnormality.

No indications appear on the display. (1/2)	[Diagnostic method]
 <pre> graph TD Start(()) --> D1{Is power being supplied to the leakage breaker?} D1 -- No --> A1(Activate the primary power supply.) D1 -- Yes --> D2{Is fuse F1 intact?} D2 -- No --> A2[Replace the fuse. *F1: 3A 5A (PV(H)-331)] D2 -- Yes --> D3{Is the fuse holder making proper contact?} D3 -- No --> A3[Replace the fuse holder.] D3 -- Yes --> End((Continued)) </pre> Continued	• Check whether power is ON or OFF. Press the button on the breaker. If the breaker trips, then power is being supplied. However, check voltage satisfies specifications (rated voltage $\pm 10\%$), with a tester. • Check the fuse. Remove glass body fuse F_1 from the electrical chassis, and check visually and check it for continuity. 



Chapter 4 Replacement and adjustment of parts

In the preceding chapter, troubleshooting with your chamber was explained. Now, this chapter explains the specifics of how to replace and adjust parts.

Make note of the fact that some items will be unnecessary depending on the type of chamber you use. Read "Chapter 2 Chamber configuration" carefully, before attempting to make changes to your equipment.

Be sure to turn the main power switch (leakage breaker) OFF before replacing parts.

4-1 Replacing the heater and temperature fuse

1. Remove the machine screws from the heater access port cover. Phillips screwdriver
2. Remove the caps from the heater terminals.
3. Remove the hexagonal nuts (M4) from the heater terminals, followed by the heater (rounded terminal head) and thermal fuse leads. Boxhead screwdriver (M4)
4. Remove the machine screws anchoring the heater unit, followed by the unit. Phillips screwdriver
5. Install a new heater.




Fig. 1 Heater unit

4-2 Replacing the blower wheel

1. Remove the heater unit. Refer to 4-1.
2. Remove the machine screws from the ceiling of the inner chamber. Phillips screwdriver




Fig. 2-1 Removing the ceiling of the inner chamber.

3. Remove the machine screws holding the air intake port in place.
..... Phillips screwdriver
4. Loosen the loose-preventing nut locking the blower wheel to the motor shaft,
and pull the blower wheel downward and out. Wrench (M12), spanner (Special
tool, width across flat 27 mm)
- * • Be careful not to apply excessive force on the fan blades to prevent their
deforming.
- * • If fixing screws have soldered over, use a loosening agent like WD-40 (Rocket
Chemical Co., INC.) rather than applying force to free parts.
5. Remove the blower wheel.
6. Install a new blower wheel.




Fig. 2-2 Blower wheel

4-3 Replacing the motor

1. Remove the blower wheel. Refer to 4-2
2. Remove the machine screw holding the rotor blade in place, followed by the rotor blade. Phillips screwdriver
3. Disconnect the capacitor leads and remove the nut. Boxhead screwdriver (M4)
4. Remove the bolts ($\times 4$) anchoring the motor. Boxhead screwdriver (M6)
5. Remove the motor.
6. Install a new motor.




Fig. 3 Motor

4-4 Replacing the damper unit

1. Remove the damper knob. Slotted screwdriver. Cushion the chamber to protect from scratches.
2. Remove the push-nut from the link, followed by the pin. Slotted screwdriver for push-nut
3. Remove the machine screws holding the damper unit in place. Phillips screwdriver
4. Install a new damper unit.




Fig. 4 Damper unit

4-5 Repositionins the lock

1. Remove the machine screws fixing the lock stopper in place Phillips screwdriver.
2. Loosen and then adjust the machine screw fixing the lock holder so that 10 to 12 mm of space are found between the chamber door. Phillips screwdriver.




Fig. 5 Lock

4-6 Replacing door hinges

1. Remove the damper unit as described on 4-4.
2. Loosen and then adjust the bolts (top: $\times 3$, bottom: $\times 4$) holding the hinges in place so that 10 to 12 mm are found between the chamber and door. Boxhead screwdriver (M5)
3. Tighten the bolts (top and bottom hinges) once positioned properly. Boxhead screwdriver (M5)
4. Reinstall the damper unit.




Fig. 6 Hinges

4-7 Replacing the door gasket

1. Pull hard on the cut end of the door gasket, at the bottom center of the chamber.
2. Pull off the rest of the door gasket. Be careful of the gasket remaining stuck in spots.
3. Attach a new gasket Push hard in the direction of the arrow to insert.

NOTE: • Door gasket for PV models: Indian red

• Door gasket for PVH models: Black, double gasket




Fig. 7 Door gasket

4-8 Replacing the temperature controller circuit board (control board)

1. Turn the main power switch OFF.
2. Open the electrical compartment door.
3. Disconnect all connectors from the temperature controller.
4. Remove the connectors attached to the temperature controller.
5. Remove the circuit board while pressing on the tip of the board spacers (plastic) with nippers or similar tool.
6. Set the rotary switch on the new board to the same position as that on the old board.
Refer to Table 4-1.
7. Install the new board and connect all connectors.
8. Initialize the board once installed, as described in "Initializing the temperature controller."




Fig. 8 Spacer

4-9 Replacing the overheat protector circuit board (OHP board)

1. Turn the main power switch OFF.
2. Open the electrical compartment door.
3. Disconnect all wires to the terminal board and the connector for setting device.
4. Remove the circuit board while pressing on the tip of the board spacers (plastic) with nippers or similar tool.
5. Install a new board and reassemble parts in reverse order.




Fig. 9 Spacer

4-10 Replacing the temperature sensor

1. Turn the main power switch OFF.
 2. Open the electrical compartment door.
 3. Disconnect all wires to the temperature controller circuit board. Disconnect connectors before wiring.
 4. Disconnect all wires to the overheat protector circuit board.
 5. Pull out the temperature sensor from the electrical compartment side.
 - Make note that rubber bushings are coated with a silicon base sealant.
 6. Adjust a new sensor as necessary and install.
 - After inserting the sensor, check the outer and inner rubber bushings are securely in place. Coat bushings with sealant.
- Check the temperature sensor is properly positioned.




Fig. 10 Temperature sensor

4-11 Replacing the SSR

1. Disconnect all wires to the SSR. Phillips screwdriver
2. Remove the screws (× 2) fixing the SSR in place, followed by the SSR.
..... Phillips screwdriver
3. Install a new SSR.
 - Coat the heat sinker on the back side of the SSR before installing.
 - Keep tightening torque to 12 kg · cm.
 - Tighten screws evenly.




Fig. 12 SSR

4-12 Replacing the main power switch (leakage breaker) and electrical compartment door switch

1. Turn OFF the primary power supply.
2. Remove the machine screws fixing the chassis on the rear of the chamber, followed by the chassis. (Fig. 12-1) Phillips screwdriver
3. Detach the electrical compartment door switch from its installation plate at the chassis bottom, and disconnect the soldered leads. (Fig. 12-2) Soldering iron
4. Disconnect the cord on the main power switch (leakage breaker) and load sides. (Fig. 12-3) Phillips screwdriver
5. Remove the machine screws ($\times 2$) fixing the main power switch in place, followed by the switch. Phillips screwdriver
6. Install a new switch.




Fig. 12-1 Chamber rear





Fig. 12-2 Electrical compartment

4-13 Resetting the temperature indicator-controller


The temperature indicator-controller can be reset from the manufacturer maintenance mode.

(Engaging the manufacturer maintenance mode)


1. Turn ON the power to the panel, and select the constant mode (standby state).
2. Hold down the ◁ and ▷ keys simultaneously for 3 seconds or more. The chamber will enter the user maintenance mode.



3. Press the NEXT key and call up the E-BUS baud rate display (second display of user maintenance mode).




4. Hold down the ◁ and ▷ keys simultaneously for 3 seconds or more. The chamber will enter the manufacturer maintenance mode.



(Resetting)

1. Engage the manufacturer maintenance mode, and from the upper limit setting display, press the NEXT key until the initial settings display is called up (9th screen).




2. Make settings with the $\triangle$ and ∇ keys, as shown below. Setting will be active after power has been turned off and then reactivated.

Initial setting	Reset operation
0 0 0 0	Starts up normal power supply.
0 0 0 1	Initializes the above operation and user-set variables (temperature settings, etc.).
0 0 1 1	Initializes the above operation and manufacturer-set variables (PID coefficient, etc., with exception to temperature calibration data).
0 1 1 1	Initializes all variables (including temperature calibration data).

(Adjustments after resetting)

After resetting the chamber, make the following adjustments and/or settings.

1. Engage the manufacturer maintenance mode and press the NEXT key until instrumentation type setting display is called up (8th screen).




2. Select from standard instrumentation and M-instrumentation with the Δ and ∇ keys.
3. Press the NEXT once more and call up the initial settings display.
4. Set "0011" with Δ and ∇ keys and switch the main breaker OFF and then ON again.

This will initialize the instrumentation settings.

If your chamber is equipped with the time-up output option, make the following adjustments and/or settings.

1. Engage the manufacturer maintenance mode and press the NEXT key until the relay 1 display is called up (5th screen).



2. Set "2" with Δ and ∇ keys.
3. Press the POWER key and turn OFF power to the operation panel.

This will initialize the time-up output setting.

If key input is ineffective, then resetting can be forced at the rotary switch.

1. Turn the breaker OFF.
2. Set the rotary switch to "0" (refer to the temperature controller in "2-2 Names of chamber parts").
3. Turn the breaker ON and check the COND. SET and STANDBY lamps light up. Then, turn the breaker OFF again and then ON.
4. Check a numerical figure is displayed at STEP indication and the buzzer is emitted. Then, return the rotary switch to the correct setting, and turn the breaker OFF and ON again.

This will make the equipment respond to key input.

4-14 Replacing the ROM

Replace the ROM according to the following procedure.

1. Turn the breaker OFF.
2. Remove the ROM from the temperature controller (refer to the temperature indicator-controller in "2-2 Names of chamber parts").
3. Install a new ROM.
Check the ROM is oriented correctly and pins are properly inserted into place.
4. Check the rotary switch setting.
Refer to Table 4-1 Rotary switch and chamber type.
5. Close the distribution panel, and turn the breaker ON.
6. Press POWER and check the equipment starts up properly.
7. Reset the chamber (refer to "Resetting the temperature indicator-controller" on the previous section).

Table 4-1 Rotary switch and chamber type

Rotary switch	Chamber model	Upper limit temperature
0	Detection mode at factory set (Do not use in normal operation.)	
1	Temperature chamber (PV)	210℃
	Sterilizer (KPV)	
2	Temperature chamber (PVH)	310℃
	Sterilizer (KPVH)	
3	Temperature chamber (PH)	210℃
	Anaerobic temperature chamber (IPH)	
	Temperature chamber with rotating specimen rack (GPH)	
	Sterilizer (KPH)	
4	Temperature chamber (PHH)	310℃
	Anaerobic temperature chamber (IPHH)	
	Temperature chamber with rotating specimen rack (GPHH)	
	Sterilizer (KPHH)	
5	High temperature chamber (STPH)	510℃
6	High temperature chamber (SSPH)	710℃
7	Temperature chamber with safety door (explosion vent) (SPH)	210℃
	With fin heater	
	Temperature chamber (PH)	
	Anaerobic temperature chamber (IPH)	
8	Temperature chamber with safety door (explosion vent) (SPHH)	310℃
	With fin heater	
	Temperature chamber (PHH)	
	Anaerobic temperature chamber (IPHH)	
9	Clean oven (PVHC)	360℃
A(10)	Clean oven (PHHC) S type	310℃
B(11)	Clean oven (PVC)	210℃
C(12)	Temperature chamber (PHH) 350℃ specification	360℃
D(13)	Temperature chamber (PHH) 350℃ specification with fin motor	360℃
E(14)	FA clean oven (FTC)	210℃
F(15)	FA clean oven (FTHC)	310℃

4-15 Replacing the battery

Replace the battery according to the following procedure.

1. Turn the breaker OFF and remove the temperature indicator-controller.
2. Replace the battery (lithium). Specification: 3V, 650 mA
3. Reconnect the temperature indicator-controller.
4. Turn the breaker ON and check the chamber resets itself
(refer to "4-13 Resetting the temperature indicator-controller").

Temperature calibration data is initialized when the battery is replaced, therefore be sure to perform temperature calibration again.

Refer to "Temperature calibration" on the next page.

4-16 Temperature calibration

Wire your chamber as shown in Fig. 16-1.





Fig. 16-1 Connections

Calibrate temperature according to the following procedure.

1. Start up all units and wait till power stabilizes (30 minutes to 1 hour).
2. Initialize the chamber's memory.
Set "0111" on the initial settings display (manufacturer maintenance mode) and reset the chamber (refer to "4-13 Resetting the temperature indicator-controller").

3. Engage the temperature calibration mode.

In the constant mode, and with the regular monitoring display STANDBY called up, press the NEXT key until the heater output monitor display is called up. Then, hold down the ◁ and ▷ keys simultaneously for 3 seconds or more and check the zero adjustment display is called up.




4. Perform zero adjustment.

Input "0 μ V" with the zero controller as an equivalent to the 0°C of the K-type thermocouple, read at the generator. Then, press the Δ key.

Registration is complete when "0" is displayed.

5. Call up the span adjustment display.

With the zero adjustment display called up, press the NEXT key once and check the span adjustment display is called up.



6. Perform span adjustment.

Input "33277 μ V" with the zero controller as an equivalent to the 800°C of the K-type thermocouple, read at the generator. Then, press the Δ key.

Registration is complete when "800" is displayed.

This completes temperature calibration. Press the COND. SET key to return to the monitoring display.

Service Manual

**Temperature Chamber
(Industrial Oven)**

PV(H)-211, 221, 231, 331

March 20, 2006 Sixth Edition

Edited and Published by:

ESPEC ENGINEERING CORP.

23-12, Taima Higashimachi, Neyagawa 572-0072, Japan
Tel:81-72-834-1191 Fax:81-72-834-7755

Printed in Japan