


Setup Screen Reference

Agilent 4155C Semiconductor Parameter Analyzer
Agilent 4156C Precision Semiconductor Parameter Analyzer



Agilent Technologies

Agilent Part No. 04156-90030

Printed in Japan January 2001

Edition 1

Legal Notice

The information contained in this document is subject to change without notice.

Copyright © 2001 Agilent Technologies

This document contains information which is protected by copyright. All rights are reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

- **Product Warranty**

Agilent Technologies warrants Agilent Technologies hardware, accessories and supplies against defects in materials and workmanship for the period of one year from the warranty start date specified below. If Agilent Technologies receives notice of such defects during the warranty period, Agilent Technologies will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or like-new.

Warranty service of this product will be performed at Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies does not warrant that the operation of Agilent Technologies products will be uninterrupted or error free. If Agilent Technologies is unable, within a reasonable time, to repair or replace any product to a condition as warranted, customer will be entitled to a refund of the purchase price upon prompt return of the product.

The Agilent Technologies products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.

The warranty period begins on the date of delivery or on the date of installation if installed by Agilent Technologies. If customer schedules or delays Agilent Technologies installation more than 30 days after delivery, warranty begins on the 31st day from delivery.

Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by Agilent Technologies, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

To the extent allowed by local law, the above warranties are exclusive and no other warranty or condition, whether written or oral, is expressed or implied and Agilent Technologies specifically disclaims any implied warranties or conditions of merchantability, satisfactory quality, and fitness for a particular purpose.

Agilent Technologies will be liable for damage to tangible property per incident up to the greater of \$300,000 or the actual amount paid for the product that is the subject of the claim, and for damages for bodily injury or death, to the extent that all such damages are determined by a court of competent jurisdiction to have been directly caused by a defective Agilent Technologies product.

To the extent allowed by local law, the remedies in this warranty statement are customer's sole and exclusive remedies. Except as indicated above, in no event will Agilent Technologies or its suppliers be liable for loss of date or for direct, special, incidental, consequential (including lost profit or date), or other damage, whether based in contract, tort, or otherwise.

For consumer transactions in Australia and New Zealand: the warranty terms contained in this statement, except to the extent lawfully permitted, do not exclude, restrict or modify and are in addition to the mandatory statutory rights applicable to the sale of this product to you.

- **Assistance**

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales Office.

- **Certification**

Agilent Technologies, Inc. certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the National Institute of Standards and Technology (NIST), to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Printing History

Edition 1: January 2001

In This Manual

This manual is a reference for the setup screens of the Agilent 4155C/4156C Semiconductor Parameter Analyzers, and provides the following information:

- Screen Structure

This chapter introduces the structure of the 4155C/4156C's setup screens.

- Screen Operation

This chapter explains how to enter the setup values into the entry fields displayed on the setup screens, and explains the usage of the blue front-panel key and the green front-panel key.

- Setup Screens

This chapter explains the entry fields and softkeys displayed on the screens used for the measurement setups.

- System Screens

This chapter explains the entry fields and softkeys on the SYSTEM screens.

Text Conventions

The following text conventions are used in this manual:

Screen Text	Represents text that appears on screen of the 4155C/4156C.
<i>Italic</i>	Refers to a related document, or is used for emphasis.

Contents

1. Screen Structure

2. Screen Operation

Data Input or Edit.	2-3
Option fields.	2-4
Comment and Name fields.	2-4
Numeric data fields.	2-4
Blue front-panel key usage	2-5
Green front-panel key usage	2-6
Edit front-panel keys	2-7
Status Indicators	2-8

3. Setup Screens

CHANNELS Screen Group	3-3
CHANNELS: CHANNEL DEFINITION screen	3-4
CHANNELS: USER FUNCTION DEFINITION screen	3-10
CHANNELS: USER VARIABLE DEFINITION screen	3-12
CHANNELS: E5250A PROPERTIES screen	3-14
CHANNELS: E5250A CONNECTION SETUP screen	3-20
MEASURE Screen Group	3-24
MEASURE: SWEEP SETUP screen	3-25
MEASURE: SAMPLING SETUP screen	3-30
MEASURE: PGU SETUP screen	3-34
MEASURE: MEASURE SETUP screen	3-37
MEASURE: OUTPUT SEQUENCE screen	3-40
MEASURE: QSCV SETUP screen	3-43
MEASURE: QSCV MEASURE SETUP screen	3-46
DISPLAY Screen Group	3-48
DISPLAY: DISPLAY SETUP screen for graphic results	3-49

Contents

DISPLAY: DISPLAY SETUP screen for list results	3-51
DISPLAY: ANALYSIS SETUP screen	3-53
GRAPH/LIST Screen Group	3-59
On the GRAPHICS result screen	3-59
On the LIST result screen	3-59
GRAPH/LIST: GRAPHICS screen	3-60
GRAPH/LIST: LIST screen	3-75
STRESS Screen Group	3-86
STRESS: CHANNEL DEFINITION screen	3-87
STRESS: STRESS SETUP screen	3-91
STRESS: STRESS FORCE screen	3-95
KNOB SWEEP Screen	3-97
Cursor	3-97
X axis setting	3-97
Y axis setting	3-97
Y-AXIS ASSIGN Softkey	3-98
SETUP COPY Softkey	3-98
DISPLAY SETUP Softkey	3-99
VAR1 SETUP Softkey	3-101
VAR2 SETUP Softkey	3-104
CONST SETUP Softkey	3-106
 4. System Screens	
SYSTEM: FILER	4-3
DISK	4-3
FILE CATALOG	4-4
FUNCTION	4-5
SAVE	4-6
GET	4-9
PURGE	4-11

Contents

RENAME	4-13
COPY	4-15
MAKE DIRECTORY	4-17
DISK OPERATION	4-18
SYSTEM: MISCELLANEOUS	4-19
4155C is, 4156C is	4-19
GPIB ADDRESS	4-19
REMOTE CONTROL	4-19
CLOCK	4-20
POWER LINE FREQUENCY	4-20
SYSTEM SETUP	4-20
NETWORK SETUP	4-21
NETWORK PRINTER SETUP	4-23
NETWORK DRIVE SETUP	4-24
SYSTEM: CONFIGURATION	4-25
ETHERNET ADDRESS	4-25
SOFTWARE REVISION	4-25
CONFIGURATION	4-25
CPU REVISION	4-25
SYSTEM: SELF-CALIBRATION/DIAGNOSTICS	4-26
CALIB/DIAG	4-26
AUTO CALIB	4-26
CATEGORY	4-26
SYSTEM: PRINT/PLOT SETUP	4-29
DESTINATION	4-29
FORM FEED	4-29
LINE	4-29
COLUMN	4-29
COLOR/ B/W	4-30
PAPER	4-30

Contents

OUTPUT ITEM	4-31
INIT STRING / TRAILER STRING	4-32
SYSTEM: COLOR SETUP.....	4-33
CATEGORY	4-33
HUE, SATURATION, LUMINOSITY	4-34
COLOR SAMPLE	4-34
PLOTTER PEN NO.	4-35
BRIGHTNESS	4-35

1 Screen Structure

Screen Structure

The 4155C/4156C has seven screen groups, as shown in the following table.

Screen Group	Display Screen
Channels	CHANNELS: CHANNEL DEFINITION
	CHANNELS: USER FUNCTION DEFINITION
	CHANNELS: USER VARIABLE DEFINITION
	CHANNELS: E5250A PROPERTIES
	CHANNELS: E5250A CONNECTION SETUP
Measure	MEASURE: SWEEP SETUP
	MEASURE: SAMPLING SETUP
	MEASURE: PGU SETUP
	MEASURE: MEASURE SETUP
	MEASURE: OUTPUT SEQUENCE
	MEASURE: QSCV SETUP
	MEASURE: QSCV MEASURE SETUP
Display	DISPLAY: DISPLAY SETUP
	DISPLAY: ANALYSIS SETUP
Graph/List	GRAPH/LIST: GRAPHICS
	GRAPH/LIST: LIST
Stress	STRESS: CHANNEL DEFINITION
	STRESS: STRESS SETUP
	STRESS: STRESS FORCE
System	SYSTEM: FILER
	SYSTEM: MISCELLANEOUS
	SYSTEM: CONFIGURATION
	SYSTEM: SELF-CALIBRATION/DIAGNOSTICS
	SYSTEM: PRINT/PLOT SETUP
	SYSTEM: COLOR SETUP
Knob Sweep	KNOB SWEEP

CHANNELS screen group	Defines the measurement modes, measurement channels, and user functions.
MEASURE screen group	Sets the measurement parameters.
DISPLAY screen group	Sets up the display of measurement results.
GRAPH/LIST screen group	Displays the measurement results.
STRESS screen group	Sets and monitors the stress force.
SYSTEM screen group	Controls mass storage, sets system parameters for the 4155C/4156C, sets the print/plot parameters, and so on.
KNOB SWEEP screen group	Displays the measurement results when the knob sweep function is used.

You can use the front-panel keys in the PAGE CONTROL key group to display the desired screen. The PAGE CONTROL key group has the following keys:

Chan	Displays the CHANNELS screen group.
Meas	Displays the MEASURE screen group.
Disp	Displays the DISPLAY screen group.
Graph/List	Displays the GRAPH/LIST screen group.
Stress	Displays the STRESS screen group.
System	Displays the SYSTEM screen group.

To display the KNOB SWEEP screen, press the green front-panel key and then Single key.

2 Screen Operation

Screen Operation

This chapter explains how to fill in the entry fields on a screen, and the function of the blue, green and Edit front-panel keys. This chapter contains the following sections:

- “Data Input or Edit”
- “Blue front-panel key usage”
- “Green front-panel key usage”
- “Edit front-panel keys”
- “Status Indicators”

Data Input or Edit

When you move the pointer to a field on a setup screen, you can fill in the field by entering characters or selecting a softkey. See figure below. This figure shows an example which sets the current output mode for SMU2. Line above the primary softkeys is called as the *data entry field*. The line displays the value of the entry field the pointer specifies, or is used to enter the value.

CHANNELS: CHANNEL DEFINITION01JAN10 07:05PM

*MEASUREMENT MODE

SWEEP

*CHANNELS

MEASURE					STBY	SERIES RESISTANCE
UNIT	VNAME	INAME	MODE	FCTN		
SMU1:HR	V1	I1	COMMON	CONST		0 ohm
SMU2:HR	V2	I2	I	VAR2		
SMU3:HR	V3	I3	V	VAR1		
SMU4:HR	V4	I4	V	CONST		
SMU5:HP						0 ohm
VSU1	VSU1	-----	V	CONST		
VSU2	VSU2	-----	V	CONST		
VMU1	VMU1	-----	V	-----	----	DISCHARGE
VMU2	VMU2	-----	V	-----	----	ON
PGU1		-----				
PGU2		-----				
GNDU		-----			----	

SWEEP

SAM-PLING

QSCV

DEFAULT MEASURE SETUP

MEM1 M
B-Tr
VCE-IC

MEM2 M
FET
VDS-ID

MORE
1/2

← Data Entry Field →

Select Measurement Mode with softkey or rotary knob.

CHANNEL DEF

USER FCTN

USER VAR

S

E5250A PROP

B

NEXT PAGE

The 4155C/4156C has three types of fields. The following describes the methods for entering or editing input data of these field types:

Option fields

When pointer is in an option field, selectable input items for field are displayed on secondary softkeys. You select desired softkey. The item appears in the field.

For example, when pointer is in the MODE field for SMU2 as shown in the above figure, V, I, VPULSE, IPULSE, COMMON, and DELETE ROW softkeys appear in secondary softkey area. Then select one you desire.

In the screens except for the CHANNEL DEFINITION screen, if pointer is located in a field that requires a variable name, all available variable names are displayed on secondary softkeys. So you can select desired variable name by using a secondary softkey. Available variable names are names you already set up as measurement variables or user function variables. If more than six variable names are available, MORE secondary softkey appears, which display more available variable names.

Comment and Name fields

When the pointer is located in a comment or name field, you input the desired characters by using the ENTRY front-panel key group. You press the desired characters. The characters appear in the **data entry area**.

For name fields, you can enter alphanumeric characters. For comment fields, you can also enter non-alphanumeric characters. You can enter uppercase or lowercase alphabet characters by using *blue* and *green* front-panel keys. You can enter special (non-alphanumeric) characters by using the *green* front-panel key.

If a comment or name is already entered in the field, it appears in the data entry area. You can edit it using Edit front-panel keys.

After editing or entering the comment or name, press the **Enter** front-panel key to enter the name or comment into the field at the pointer location.

Numeric data fields

When pointer is in a numeric data field, input numeric data as follows:

- Type the numeric value by pressing numeric front-panel keys (value appears in the data entry area). Then, press **Enter** front-panel key (value is entered into the numeric data field at the pointer location).
- Rotate the rotary knob to increase or decrease the value. Rotate clockwise to increase value. Rotate counterclockwise to decrease value.

Blue front-panel key usage

The blue front-panel key has three states:

- Non-shift** B, b, or G is not displayed in the lower-right corner of the screen. You can enter numeric values.
- Uppercase shift** B is displayed in the lower-right corner of the screen. G is not displayed. You can enter uppercase alphabet characters.
- Lowercase shift** b is displayed in the lower-right corner of the screen. You can enter lowercase alphabet characters.

To change between these states:

- toggle between the non-shift/shift state by pressing the blue key.
- toggle between the upper/lowercase shift state by pressing the green key, then the blue key.

The following is a detailed description about changing between these states:

Present Status	Next Status	Key to be pressed
non-shift	Uppercase blue-key shift	blue key
Uppercase blue-key shift	non-shift	blue key
non-shift	Lowercase blue-key shift	green key, then blue key
Lowercase blue-key shift	non-shift	blue key
Uppercase blue-key shift	Lowercase blue-key shift	green key, then blue key
Lowercase blue-key shift	Uppercase blue-key shift	green key, then blue key

Green front-panel key usage

You can use the green front-panel key to enter special (non-alphanumeric) characters, which are printed in green above the keys.

The green key action is momentary. That is, after you press the green key, only the next keystroke is effective. For example, to enter “#§”, press the green key, 0, green key, and 1.

The green key mode has special functions for entering data, as shown in the following table.

The front-panel green key can also be used to perform dump (Plot/Print key), knob

Keys	Label	Function
Green, ⇐	⇐	Moves the cursor to the first character.
Green, ⇒	⇒	Moves the cursor to the last character.
Green, Recall↓	Recall↑	Recalls the oldest input from the key buffer. The key buffer stores the 10 most recent entries in the data entry area.
Green, Clear	Clr→End	Clears the entered data from the present cursor position to the end.
Green, Enter	Calc	Calculates any expression entered in the data entry area.

sweep (Single key), and zero offset cancel (Stop key) operations.

Edit front-panel keys


There are six keys in the Edit front-panel key group. Four of these keys also have other functions in the green-key shift mode. The following table shows the function of each key:

Key	Label	Functions
⇐		Moves the cursor left by one column in the data entry area.
⇒		Moves the cursor right by one column in the data entry area.
Delete		Deletes one character where the cursor is located.
Insert		Toggles the input mode in the data entry area between <i>insert</i> and <i>overtyping</i> modes.
Recall↓		Recalls the newest input from the key buffer.
Clear		Deletes all the characters in the data entry area.
Green, ⇐	⇐	Moves the cursor to the first column in the data entry area.
Green, ⇒	⇒	Moves the cursor to the last column of the present entry in the data entry area.
Green, Recall↓	Recall↑	Recalls the oldest input from the key buffer.
Green, Clear	Clr→End	Deletes the characters from the present cursor position to the end of the entry.

The key buffer stores the 10 most recent entries from the data entry area. You can recall the stored entries using Recall key, as described above.

Status Indicators

The status indicators indicate the present status of the 4155C/4156C. The display contains the following status indicators.



(1) indicates the following status:

TRG	The 4155C/4156C is waiting for trigger input from an external instrument.
DRW	The 4155C/4156C is drawing a measurement curve.
ANA	The 4155C/4156C is performing auto-analysis or regression calculation.

(2) indicates the following status:

- | | |
|---|--|
| C | The 4155C/4156C is performing auto-calibration. |
| Z | The 4155C/4156C is performing an offset measurement for the zero offset cancel function. |

(3) displays **L** when the screen is locked by an GPIB command.

(4) indicates the following status:

- | | |
|---|---|
| S | The 4155C/4156C is in the SCPI command control mode. |
| F | The 4155C/4156C is in the FLEX command control mode. |
| 4 | The 4155C/4156C is in the 4145 syntax command control mode. |

Screen Operation
Status Indicators

3 Setup Screens

Setup Screens

This chapter is a reference for operating Agilent 4155C/4156C by using the front-panel controls. The 4155C/4156C is operated by setup screens and results screen displayed on the screen. The following sections explain these setup screen structure.

- “CHANNELS Screen Group”
- “MEASURE Screen Group”
- “DISPLAY Screen Group”
- “GRAPH/LIST Screen Group”
- “STRESS Screen Group”

CHANNELS Screen Group

CHANNELS screen group has the following screens:

Channel Definition:	For defining the measurement mode and measurement channels of the 4155C/4156C.
User Function Definition:	For defining the user functions.
User Variable Definition:	For defining the user variables.
E5250A Properties:	For defining the control mode of Agilent E5250A Low Leakage Switch Mainframe.
E5250A Setup:	For defining the input-output connection of the E5250A.

To move to the CHANNELS screen group, press Chan front-panel key.

The following primary softkeys are available for the CHANNELS screen group. where, E5250A SETUP softkey is displayed when the CONTROL field on the E5250A PROPERTIES screen is set to ON.

CHANNEL	USER	USER		E5250A	E5250A	PREV	NEXT
DEF	FCTN	VAR		PROP	SETUP	PAGE	PAGE

- Select CHANNEL DEF softkey to move to CHANNELS: CHANNEL DEFINITION screen.
- Select USER FCTN softkey to move to CHANNELS: USER FUNCTION DEFINITION screen.
- Select USER VAR softkey to move to CHANNELS: USER VARIABLE DEFINITION screen.
- Select E5250A PROP softkey to move to CHANNELS: E5250A PROPERTIES screen. On this screen, PREV PAGE and NEXT PAGE softkeys are not available.
- Select E5250A SETUP softkey to move to CHANNELS: E5250A CONNECTION SETUP screen. On this screen, PREV PAGE and NEXT PAGE softkeys are not available.

CHANNELS: CHANNEL DEFINITION screen

CHANNELS: CHANNEL DEFINITION01JAN10 07:05PM

← User Comment →

*MEASUREMENT MODE
SWEEP

*CHANNELS

MEASURE					STBY	SERIES RESISTANCE
UNIT	VNAME	INAME	MODE	FCTN		
SMU1:HR	V1	I1	COMMON	CONST		0 ohm
SMU2:HR	V2	I2	I	VAR2		
SMU3:HR	V3	I3	V	VAR1		
SMU4:HR	V4	I4	V	CONST		
SMU5:HP						
VSU1	VSU1	-----	V	CONST		0 ohm
VSU2	VSU2	-----	V	CONST		
VMU1	VMU1	-----	V	-----	DISCHARGE	
VMU2	VMU2	-----	V	-----		ON
PGU1		-----			----	
PGU2		-----				
GNDU		-----				

SWEEP

Select Measurement Mode with softkey or rotary knob.

CHANNEL
DEF

USER
FCTN

USER
VAR

S

E5250A
PROP

NEXT
PAGE

MEM1 M
B-Tr
VCE-IC

MEM2 M
FET
VDS-ID

MORE
1 / 2

On the "CHANNELS: CHANNEL DEFINITION" screen, you define the measurement mode and how to use each channel.

User Comment

In this field, you can enter a desired comment. The comment you enter here is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

MEASUREMENT MODE

MEASUREMENT MODE field sets measurement mode to sweep measurement mode, sampling measurement mode, or quasi-static CV measurement mode. In this field, select:

- SWEEP secondary softkey to set sweep measurement.
- SAMPLING secondary softkey to set sampling measurement.
- QSCV secondary softkey to set quasi-static CV measurement.

To change settings (except for system screen group) to default initial settings, select DEFAULT MEASURE SETUP secondary softkey.

NOTE

Application setup data in internal memories

MEM secondary softkeys indicate that setup or measurement result data is in the internal memory. When you turn on the 4155C/4156C without a diskette or network disk, the following secondary softkeys are displayed:

MEM1 M

B-Tr VCE-IC measurement setup data for bipolar transistor Vce-Ic characteristics.

MEM2 M

FET VDS-ID measurement setup data for FET (field effect transistor) Vds-Id characteristics.

MEM3 M

FET VGS-ID measurement setup data for FET (field effect transistor) Vgs-Id characteristics.

MEM4 M

DIODE VF-IF measurement setup data for diode Vf-If characteristics.

M on the softkey means measurement setup data.

Select softkey to get the desired application measurement setup data. This minimizes the time for setting up the measurement conditions.

See *User's Guide General Information*.

CHANNELS

UNIT.

This column lists all the units that are installed in the 4155C/4156C.

VNAME.

VNAME field assigns a variable name for voltage that will be forced or measured. You can use this name as a reference on the other screens. If channel does neither V force nor V measurement, you can omit VNAME.

In this field, enter a name by using the keyboard or front panel keys. where,

- VNAME must be 6 or less alphanumeric characters. First character must be alphabet character.
- Name must be different from other names.

The DELETE ROW softkey deletes the VNAME, INAME, MODE, FCTN, and STBY entries for the unit. Unit is disabled.

NOTE

To switch the unit definitions

To switch the VNAME, INAME, MODE, FCTN, and STBY assignment for units, do as follows:

1. Position pointer in top field of VNAME column. CHANNEL ASSIGN secondary softkey appears.
2. Select CHANNEL ASSIGN softkey. Pointer moves to the top field of UNIT column.
3. Use arrow keys in the MARKER/CURSOR key group to move pointer to desired row.
4. Select the secondary softkey of the desired unit. The selected unit appears at the pointer.

Perform steps 3 and 4 until you assign units as desired. Make sure that the same unit is not assigned to multiple rows. Then, select the EXIT CHANNEL ASSIGN softkey.

INAME.

INAME field assigns a variable name for current that will be forced or measured. You can use this name as a reference on the other screens. If channel does neither I force nor I measurement, you can omit INAME.

In this field, enter a name by using the keyboard or front panel keys. where,

- INAME must be 6 or less alphanumeric characters. First character must be alphabet character.
- Name must be different from other names.

The Select DELETE ROW softkey deletes the VNAME, INAME, MODE, FCTN, and STBY entries for the unit. Unit is disabled.

MODE.

You define an output mode for SMUs, VSUs, PGUs, and GNDU, and measurement mode for VMUs. When the pointer is located in this column, allowable modes appear in the secondary softkey area. You select a softkey to set a mode. The following table shows allowable modes for each unit:

	V	I	VPULSE	IPULSE	COMMON	DVOLT
SMU	Yes	Yes	Yes ^a	Yes ^a	Yes	
VSU	Yes					
PGU	Yes		Yes ^b			
GNDU					Yes	
VMU ^b	Yes					Yes

- Only for sweep measurements. Not available for sampling and QSCV. Only one pulsed source SMU is available for a channel setup. If VPULSE is set to a SMU, IPULSE cannot be set to another SMU in the same setup.
- Not available for QSCV.

To delete the VNAME, INAME, MODE, FCTN, and STBY entries for a unit, select the DELETE ROW secondary softkey. Unit is disabled.

Setup Screens

CHANNELS Screen Group

FCTN.

This field defines an output function for SMUs, VSUs, PGUs, and GNDU. When the pointer is located in this column, allowable output functions appear in the secondary softkey area. You select a softkey to set an output function.

	Var1 ^a	Var1' ^b	Var2 ^b	CONST
SMU	Yes	Yes	Yes	Yes
VSU	Yes ^b	Yes	Yes	Yes
PGU				Yes
GNDU				Yes

a. Not available for sampling.

b. Only for sweep measurements. Not available for sampling and QSCV.

where,

- You can set multiple CONST in a channel setup.
You *cannot* set multiple VAR1, VAR1', or VAR2 in a channel setup.
- VAR2 and VAR1' are available when VAR1 is set.
- The output modes of VAR1 and VAR1' must be same. That is, the MODE setting for both must be set to a voltage mode, or both must be set to a current mode.
For example, you can set VAR1 to V and VAR1' to VPULSE.
- For QSCV measurements, only one V mode SMU can be set to VAR1.

STBY.

STBY field specifies which channels output source values in the standby state.

- If STBY is set to ON, the unit forces a specified output value when in the standby state.
- If STBY is blank, the unit outputs 0 V in the standby state.

For details about the standby state, see *User's Guide: Measurement and Analysis*.

where,

- If both PGUs are set to VPULSE, the STBY setting of both PGUs must be the same.
- For STBY=ON channel, SERIES RESISTANCE setting must be 0 ohm.

SERIES RESISTANCE

In the SERIES RESISTANCE fields, you select the value that you want to set in Agilent 16441A R-Box. When the pointer is located in this field, allowable resistance values are shown in the secondary softkey area. You select the desired series resistance.

Normally, SMU1 and SMU2 have SERIES RESISTANCE fields. However, if your 4155C/4156C is installed with the Agilent 41501 Expander equipped with the HPSMU (high power SMU), SMU1 and SMU5 have SERIES RESISTANCE fields.

where,

- If the 16441A R-box is not connected, you must set 0 ohm.
- To use Kelvin connection for HRSMU or HPSMU, you must set 0 ohm.
- For STBY channels, you can set 0 ohm only.
- For COMMON channels, you can set 0 ohm only.

The R-box cannot be used for the quasi-static CV measurement.

DISCHARGE

In the DISCHARGE field, you control the connection of the VMU input discharge resistor. The discharge resistor prevents the VMU inputs from becoming charged when the inputs are opened.

ON connects the discharge resistors to VMU inputs immediately, and automatically breaks the connection only in the measurement state.

OFF disconnects the discharge resistors from VMU inputs immediately.

When the auto-calibration is executed, the setting is not changed.

VMU and this function are not available for the quasi-static CV measurement.

CHANNELS: USER FUNCTION DEFINITION screen

CHANNELS: USER FUNCTION DEFINITION01JAN15 06:07PM

←User Comment→

*USER FUNCTION		
NAME	UNIT	DEFINITION

DELETE ROW

Enter User Function Name. (max 6 chars.)B

CHANNEL	USER	USER		S	E5250A		PREV	NEXT
DEF	FCTN	VAR			PROP		PAGE	PAGE

On this screen, you define user functions. For details about user functions, refer to *User's Guide: Measurement and Analysis*.

User Comment

In this field, you can enter a desired comment, which is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

NAME

NAME field defines the user function name. In this field, you can enter a name by using the keyboard or front panel keys. Or you can select variables that are shown on the secondary softkeys. where,

- NAME must be 6 or less alphanumeric characters. First character must be alphabet character.
- NAME must be different from other names. The alphabet characters are case sensitive. For example, HFE is different from Hfe.

To delete a user function, you can select DELETE ROW softkey to delete the NAME, UNIT, and DEFINITION entries.

After defining a user function, you can use this variable name for reference on other screens.

UNIT (optional)

UNIT defines the unit of the user function. This unit is used on the graph and list result screens. where, UNIT must be 6 or less alphanumeric characters.

To delete a user function, you can select DELETE ROW softkey to delete the NAME, UNIT, and DEFINITION entries.

DEFINITION

You enter an expression that defines the user function. The expression can consist of numerical operators, constants, variables, built-in functions, and other user-defined functions.

By selecting secondary softkeys, you can enter VNAMEs or INAMEs that are set on the CHANNELS: CHANNEL DEFINITION screen.

For syntax, see *User's Guide: Measurement and Analysis*.

CHANNELS: USER VARIABLE DEFINITION screen

On this screen, you register user variables that were defined by GPIB. To use a user variable, you must register it on this screen. For details about user variables, refer to *User's Guide: Measurement and Analysis*.

CHANNELS: USER VARIABLE DEFINITION 01JAN15 06:08PM

← User Comment →

*USER VARIABLE		
NAME	UNIT	SIZE

DELETE ROW

Enter User Variable Name. (max 6 chars.) B

CHANNEL DEF	USER FCTN	USER VAR		S	E5250A PROP		PREV PAGE	NEXT PAGE
----------------	--------------	-------------	--	---	----------------	--	--------------	--------------

User Comment

In this field, you can enter a desired comment, which is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

NAME

NAME field defines the user variable name. You can enter a name by using the keyboard or front-panel keys. After defining a user variable, you can use this variable name for reference on other screens. where,

- NAME must be 6 or less alphanumeric characters. First character must be alphabet character.
- NAME must be different from other names. The alphabet characters are case sensitive. For example, HFE is different from Hfe.

To delete a user variable, select DELETE ROW softkey to delete the NAME, UNIT, and SIZE entries.

UNIT (optional)

UNIT defines the unit of the user variable. This unit is used on the graph and list result screens. You can enter the unit by using the keyboard or front-panel keys. where, UNIT must be 6 or less alphanumeric characters.

To delete a user variable, select DELETE ROW softkey to delete the NAME, UNIT, and SIZE entries.

SIZE

SIZE field sets the number of data for the user variable. The number of data must be 10001 or less (total for all measurement data and user variables). You can enter the size by using the keyboard or front-panel keys.

To delete a user variable, select DELETE ROW softkey to delete the NAME, UNIT, and SIZE entries.

CHANNELS: E5250A PROPERTIES screen

CHANNELS: E5250A PROPERTIES
01JAN15 05:04PM

←
→
User Comment

***E5250A SETUP**

GPIB ADDRESS	22
CONTROL	OFF
CARD TYPE	E5252A
CONFIG MODE	NORMAL

***MATRIX CONNECTION MODE**

	PORT FCTN	BIAS PORT	COUPLE 1	PORT 3	STATUS 5	CONN 7	CONN 9	RULE	CONN SEQ
CARD1	NO FCTN	----	----	----	----	----	----	FREE	BBM
CARD2	NO FCTN	----	----	----	----	----	----	FREE	BBM
CARD3	NO FCTN	----	----	----	----	----	----	FREE	BBM
CARD4	NO FCTN	----	----	----	----	----	----	FREE	BBM

***E5250A INPUT CONNECTION**

INPUT	SMU	INPUT	SMU
1	SMU1	5	SMU5
2	SMU2	6	SMU6
3	SMU3	7	VSU1
4	SMU4	8	VSU2
		9	VMU1
		10	VMU2

22

Enter GPIB address of E5250A (0 to 30).

CHANNEL	USER	USER		S	E5250A			B
DEF	FCTN	VAR			PROP			

The 4155C/4156C can control the Agilent E5250A Low Leakage Switch Mainframe if it has an E5252A matrix card installed. On the "CHANNELS: E5250A PROPERTIES" screen, you can define the E5250A setup and the connection modes for the E5252A.

NOTE

The E5250A must have the E5252A matrix cards installed continuously from slot 1. Only E5252As installed continuously from slot 1 on can be controlled by the 4155C/4156C.

If a blank card or another card is in slot 2, 3, or 4, the 4155C/4156C ignores the cards installed in those slots as well as the cards in following slots.

User Comment

Use this field to enter a desired comment. The comment you enter here is also displayed on the CHANNELS: E5250A CONNECTION SETUP screen.

E5250A SETUP

GPIB ADDRESS.

This field is used to set the GPIB address of the E5250A connected to, and controlled by, the 4155C/4156C. Available values: 0 to 30.

CONTROL.

This field is used to select the E5250A control mode. You can select either ON or OFF using the secondary softkey.

- ON : enables the E5250A control from the 4155C/4156C.
- OFF : disables the E5250A control.

Before setting the field to ON, the E5250A must be connected to the 4155C/4156C and turned on. Also the 4155C/4156C must be the SYSTEM CONTROLLER.

When you turn the CONTROL ON, the 4155C/4156C sends a query for the present setup of the E5250A, and displays it. In the E5250A control ON status:

- The E5250A SETUP primary softkey appears. Selecting the softkey displays the CHANNELS: E5250A CONNECTION SETUP screen.
- You can save/get/copy/purge/rename the E5250A setup file (extension: MAT) using the filer function.

CARD TYPE.

This field displays “E5252A” which is the Agilent model number of the matrix card. If the matrix card is not installed in the E5250A slot 1, you cannot set the CONTROL to ON and this field displays “-----”.

CONFIG MODE.

Use this field to select the E5250A configuration mode, either AUTO or NORMAL, and to initialize the E5250A, using the secondary softkey. Note that changing the mode resets the E5250A setup except for the configuration mode.

AUTO	Selects the auto configuration mode. In this mode, the installed cards are treated as one card. For example, if the E5252As are installed in slots 1 to 4, the E5250A works as a 48 output matrix.
NORMAL	Selects the normal configuration mode. Each card is considered independently. Each card works as a 12 output matrix. This is the default setting.
RESET E5250A	Initializes all of the E5250A setup including the configuration mode.

**MATRIX
CONNECTION
MODE**

CARD n .

Specifies the matrix card installed in the E5250A.

CARD1 Specifies the matrix card installed in the E5250A slot 1.

CARD2 Specifies the matrix card installed in the E5250A slot 2.

CARD3 Specifies the matrix card installed in the E5250A slot 3.

CARD4 Specifies the matrix card installed in the E5250A slot 4.

NOTE

The card numbers displayed are for the cards installed continuously from slot 1.

PORT FCTN.

Use this field to select the port function using the following softkeys:

NO FCTN Disables the port function. This is the default setting.

BIAS PORT Enables the bias port function that connects the input bias port to all output ports that are disconnected from other input ports. select the bias port using the BIAS PORT field.

Ignores the COUPLE PORT STATUS field. You cannot use the Coupled Port function and the Bias Port function simultaneously.

COUPLE PORT Enables the couple port function that is effective for the kelvin connection. Select the coupled ports in the COUPLE PORT STATUS field.

Ignores the BIAS PORT field. You cannot use the Bias Port function and the Couple Port function simultaneously.

NOTE

Connection after the port function was changed

Changing the port function does not change the connection setup of the E5250A. However, by way of exception, changing the port function from the bias port function to the couple port function or no function will disconnect the output ports from the input port that has been used as the bias port.

BIAS PORT.

Use this field to specify the E5250A input port to be used as the bias port. Enter the input port number. Available values: 1 to 10. The default value is 10.

The input bias port is connected to all output ports that are disconnected from other input ports. If you try to connect an output port to another input port, the output port will be disconnected from the bias port, and connected to the specified input port.

NOTE

Connection after the input bias port was changed

Changing the input port number of the bias port will disconnect the output bias ports from the previous input bias port and connect them to the new input bias port.

COUPLE PORT STATUS.

Use this field to select the coupled port. The following input ports can be coupled:

- INPUT1 and INPUT2 can be coupled port 1.
- INPUT3 and INPUT4 can be coupled port 3.
- INPUT5 and INPUT6 can be coupled port 5.
- INPUT7 and INPUT8 can be coupled port 7.
- INPUT9 and INPUT10 can be coupled port 9.

To select the coupled ports, select the ON or OFF secondary softkey for each coupled port (1, 3, 5, 7, or 9):

- ON : enables the coupled port.
- OFF : disables the coupled port. The default setting.

NOTE

Operation of the Couple Port

Coupled ports work as described below:

- When the coupled port is opened, *coupled* input ports INPUT $m-1$ and INPUT m are disconnected from all output ports.
- When the coupled port is closed, *coupled* input ports INPUT $m-1$ and INPUT m are connected as follows:

Input port INPUT $m-1$ is connected to output port $n-1$.

Input port INPUT m is connected to output port n .

Where, m and n are integer (even numbers). The maximum value is 10 for m , and 48 for n .

CONN RULE.

Use this field to select the connection rule using the secondary softkey. The following setups are available:

SROU Selects the single route connection rule. Each input port can be connected to only one output port on a matrix card.

When making a new connection for an input port, the previous connection for the port is automatically disconnected and the new connection is made. But if the normal configuration mode has been specified, the connection on another card is not changed.

FREE Selects the free connection rule. Each input port can be connected to multiple output ports and each output port can be connected to multiple input ports. This is the default setting.

CAUTION

Do not connect multiple inputs to an output

If the free connection rule has been specified, ensure multiple input ports are not connected to the same output port. Such configurations can cause damage to the instrument connected to the input terminals.

NOTE

Connection after the connection rule was changed

Changing the connection rule does not change the connection setup of the E5250A. So you may find the unmatched connections for the single rule on the CHANNELS: E5250A CONNECTION SETUP screen after you change the connection rule from free to single. Then select the APPLY OPEN ALL softkey to apply the open to all connections on the E5250A.

CONN SEQ.

Use this field to select the connection sequence using the secondary softkey. The following setups are available. The initial value is BBM.

BBM Selects the break-before-make sequence. This connection sequence breaks the previous connection, waits for an open status, and makes the new connection.

MBBR Selects the make-before-break sequence. This connection sequence makes the new connection, waits for a close status, and breaks the previous connection.

NSEQ Selects no sequence. This connection sequence breaks the previous connection, and then makes the new connection.

E5250A INPUT CONNECTION

This table defines the unit name, device terminal name, or any identification. The definitions are used to classify the E5250A input ports on the E5250A CONNECTION SETUP screen.

To define the unit name, the secondary softkeys are available.

NOTE

Value of INPUT n

The INPUT n fields are labels used to classify the E5250A input ports. You can use another name instead of the unit name. Enter the name using the front-panel keys or keyboard. A maximum four alpha-numeric characters are available. The first character must be an alpha character.

NOTE

INPUT 5 to INPUT 10

These input ports are connected internally as shown below.

- INPUT 5, INPUT 7, and INPUT 9 are connected
- INPUT 6, INPUT 8, and INPUT 10 are connected

Do not use these ports at the same time.

CHANNELS: E5250A CONNECTION SETUP screen

CHANNELS: E5250A CONNECTION SETUP01JAN20 04:13PM

← User Comment →

ARRAY

*SETUP DISPLAY MODE

ARRAY

*MATRIX CONNECTION STATUS

INPUT	111 111111122222 222223333333 333444444444
PORT	123456789012 345678901234 567890123456 789012345678
SMU1	X.....
SMU2	.X.....
SMU3	..X.....
SMU4	...X.....
SMU5	X.....
SMU6	
VSU1	
VSU2	
VMU1	
VMU2	

. : OPEN
X : CLOSE
_ : BIAS DISABLED
x : CLOSE ON BIAS PORT

ARRAY

Select Setup Display Mode with softkey or rotary knob.

CHANNEL

USER

USER

S

E5250A

E5250A

B

DEF

FCTN

VAR

PROP

SETUP

On the "CHANNELS: E5250A CONNECTION SETUP" screen, you can define the connection information for the E5252A matrix card.

User Comment

Use this field to enter a desired comment. The comment you enter here is also displayed on the CHANNELS: E5250A PROPERTIES screen.

SETUP DISPLAY MODE

Use this field to select the display mode, either array or list, for the matrix connection setup. The following secondary softkeys are available:

ARRAY

Selects the array display mode. You can define the matrix connections by selecting the softkeys.
The array displays · for opened status, X for closed status, _ for bias disabled output ports, or x for closed status on the bias port.

LIST

Selects the list display mode. You can define the matrix connections by specifying the output port numbers.

CARD NUMBER

This field is displayed only when the CONFIG MODE is NORMAL and the SETUP DISPLAY MODE is LIST. Select the card for which you are going to set up the connection information on the screen. Use the secondary softkey to select the card.

**MATRIX
CONNECTION
STATUS**

ARRAY display mode.

Move the pointer to the specified point, then select the OPEN or CLOSE softkey to change the connection status.

In this display mode, the following softkeys are available. The OPEN/CLOSE and BIAS DISABLE/ENABLE softkeys only change the setup on the screen. To apply the setup to the E5250A, press the APPLY SETUP softkey.

The BIAS DISABLE/ENABLE softkeys are shown on the bias port instead of the OPEN/CLOSE softkeys.

OPEN	Defines an open at this point. Displays · .
CLOSE	Defines a close at this point. Displays X .
BIAS DISABLE	Disables the bias port function for the specified output port. Displays _ .
BIAS ENABLE	Enables the bias port function for the specified output port. Displays x or · .
APPLY SETUP	Applies the connection information to the E5250A.
APPLY OPEN ALL	Immediately opens all connections on the E5250A.
CANCEL SETUP CHANGE	Cancels the changes you made on the screen.
ENABLE PORT	Available for INPUTs 5 to 10. Selects the enabled input port. Not available for the enabled input ports, the bias port, and the input ports connected internally to the bias port.

NOTE

INPUT PORT

INPUT 1 to INPUT 4 are always enabled. INPUT 5 to INPUT 10 are selectable. You can select one from INPUT 5, 7, and 9 and you can also select one from INPUT 6, 8, and 10.

For example, if you select the ENABLE PORT softkey on INPUT 7, then INPUT 5 and INPUT 9 are disabled, and INPUT 7 is enabled. The information for the disabled ports is cleared.

NOTE

Output port numbers

The output port numbers available depend on the configuration mode. In the NORMAL mode, numbers 1 through 12 are available for each card. In the AUTO mode, numbers 1 through 12 (with 1 card), 1 through 24 (with 2 cards), 1 through 36 (with 3 cards), or 1 through 48 (with 4 cards) are available.

Setup Screens

CHANNELS Screen Group

See Figure 3-1 for an example of the ARRAY display. In this example the E5250A controls four E5252As. Input port 6 (SMU6) is used as the bias port.

Figure 3-1

ARRAY Display

NORMAL configuration mode:

INPUT PORT	CARD1 111 123456789012	CARD2 111 123456789012	CARD3 111 123456789012	CARD4 111 123456789012
SMU1	X.....			
SMU2	.X.....			
SMU3	..X.....			
SMU4				
SMU5				
SMU6	...xxxxxx_			
VSU1				
VSU2				
VMU1				
VMU2				

AUTO configuration mode:

INPUT PORT	111 123456789012	111111122222 345678901234	222223333333 567890123456	333444444444 789012345678
SMU1	X.....			
SMU2	.X.....			
SMU3	..X.....			
SMU4				
SMU5				
SMU6	...xxxxxx_	xxxxxxxxxxxx	xxxxxxxxxxxx	xxxxxxxxxxxx
VSU1				
VSU2				
VMU1				
VMU2				

Array displays: · for opened status, X for closed status, _ for the bias disabled output ports, and x for closed status on the bias port.

LIST display mode.

Enter the output port numbers to be connected. Use a comma to specify multiple numbers. Use a hyphen for a continuous range of numbers. For example, 1, 6 specifies the output ports 1 and 6, and 1-12 specifies output ports 1 through 12.

To apply the setup to the E5250A, select the APPLY SETUP softkey.

To apply the open to all connections, select the APPLY OPEN ALL softkey.

To cancel the changes you made, select the CANCEL SETUP CHANGE softkey.

See Figure 3-2 for an example of the LIST display. In this example the E5250A controls four E5252As in the AUTO configuration mode.

Figure 3-2

LIST Display

INPUT PORT	OUTPUT PORT NO.
SMU1	1
SMU2	2
SMU3	3
SMU4	
SMU5	Can be replaced with input 7 or 9.
SMU6	4-48

Can be replaced with input 8 or 10.

NOTE

INPUT PORT

INPUT 1 through INPUT 4 are always enabled. INPUT 5 through INPUT 10 are selectable. You can select one from INPUT 5, 7, and 9 and you can also select one from INPUT 6, 8, and 10.

To change the enable input port, move the pointer to the INPUT 5 or INPUT 6 field (SMU5 or SMU6 in Figure 3-2). Then select the softkey that specifies the input port you want to enable. The softkeys have the label you defined in the E5250A INPUT CONNECTION fields on the CHANNELS: E5250A PROPERTIES screen. For the bias port, only the softkey that specifies the bias port is available.

NOTE

Output port numbers

Output port numbers 1 through 12 are available in the NORMAL mode. In the AUTO mode, the available numbers are 1 through 12 (with 1 card), 1 through 24 (with 2 cards), 1 through 36 (with 3 cards), or 1 through 48 (with 4 cards).

MEASURE Screen Group

MEASURE screen group has the following screens:

Sweep Setup,

Sampling Setup, or

QSCV Setup: For setting the parameters for sweep, sampling, or quasi-static CV measurement, which was defined in the CHANNELS: CHANNEL DEFINITION screen.

PGU Setup: For setting the PGU parameters. This screen is available when PGU is installed and the MODE and FCTN field of PGUs are set on the CHANNELS: CHANNEL DEFINITION screen.

Measure Setup: For setting the measurement range, integration time, zero cancel, and wait time.

Output Sequence: For setting the output sequence and triggering.

To move into the MEASURE screen group, press Meas front-panel key. The MEASURE: SWEEP SETUP, SAMPLING SETUP, or QSCV SETUP screen is displayed. And the following primary softkeys appear:

SWEEP	PGU	MEASURE	OUTPUT			PREV	NEXT
SETUP	SETUP	SETUP	SEQ			PAGE	PAGE

or

SAMPLNG	PGU	MEASURE	OUTPUT			PREV	NEXT
SETUP	SETUP	SETUP	SEQ			PAGE	PAGE

or

QSCV	PGU	MEASURE	OUTPUT			PREV	NEXT
SETUP	SETUP	SETUP	SEQ			PAGE	PAGE

- Select SWEEP SETUP to move to MEASURE: SWEEP SETUP screen.
- Select SAMPLNG SETUP to move to MEASURE: SAMPLING SETUP screen.
- Select QSCV SETUP to move to MEASURE: QSCV SETUP screen.
- Select PGU SETUP to move to MEASURE: PGU SETUP screen.
- Select MEASURE SETUP to move to MEASURE: MEASURE SETUP screen.
- Select OUTPUT SEQ to move to MEASURE: OUTPUT SEQUENCE screen.

MEASURE: SWEEP SETUP screen

MEASURE: SWEEP SETUP 01JAN15 06:11PM

← User Comment →

*VARIABLE	VAR1	VAR2		VAR1'
UNIT	SMU3:HR	SMU2:HR	UNIT	SMU4:HR
NAME	V3	I2	NAME	V4
SWEEP MODE	SINGLE	SINGLE	OFFSET	0.0000 V
LIN/LOG	LINEAR	LINEAR	RATIO	1.000
START	0.0000 V	20.00uA	COMPLIANCE	100.00mA
STOP	1.0000 V	100.0uA	POWER COMP	OFF
STEP	10.0mV	20.00uA	*SMU PULSE	
NO OF STEP	101	5	UNIT	SMU3:HR
COMPLIANCE	100.00mA	2.0000 V	NAME	V3
POWER COMP	-----	OFF	PERIOD	10.0ms
			WIDTH	1.0ms
			BASE	0.0000 V

*TIMING

HOLD TIME	0.0000 s
-----------	----------

*SWEEP CONTINUE AT ANY Status

*CONSTANT

	VSU1	VSU2		
UNIT	VSU1	VSU2		
NAME	VSU1	VSU2		
MODE	V	V		
SOURCE	0.0000 V	0.0000 V	-----	-----
COMPLIANCE	-----	-----	-----	-----

SINGLE

Select Sweep Mode with softkey or rotary knob.

SWEEP SETUP		MEASURE SETUP	OUTPUT SEQ	s			PREV PAGE	NEXT PAGE
----------------	--	------------------	---------------	---	--	--	--------------	--------------

On this screen, you set output parameters for each unit.

User Comment

In this field, you can enter a desired comment, which is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

VAR1 parameters

In this column, you set up output parameters for primary sweep unit. UNIT and NAME are defined on CHANNELS: CHANNEL DEFINITION screen.

• SWEEP MODE

SWEEP MODE field sets **single** or **double sweep mode**. In this field, select:

- SINGLE secondary softkey to specify the single sweep mode.
- DOUBLE secondary softkey to specify the double sweep mode.

Setup Screens

MEASURE Screen Group

- LIN/LOG

LIN/LOG field sets **linear** or **logarithmic sweep mode**. In this field, select:

- LINEAR secondary softkey to set linear sweep mode.
- LOG10, LOG25, or LOG50 secondary softkey to set logarithmic sweep mode. The number specifies the sweep points per decade.

- START, STOP, and STEP

In the START, STOP, and STEP fields, you specify the **start**, **stop**, and **step values**. The step value is used for the linear sweep mode *only*.

The following applies to logarithmic sweep mode only:

- STEP field has no meaning, so "-----" is shown in the STEP field.
- Start and stop values must be the same polarity.
- If you specify 0 (zero) for the start or stop value, the minimum output value for the unit is used.
- You specify the number of steps per decade in the LIN/LOG field.

- NO. OF STEP

For the linear sweep mode, the number of steps is calculated from the start, stop, and step values, and appears in the NO. OF STEP field.

For the logarithmic sweep mode, the number of steps is calculated from the start, stop, and LIN/LOG values, and appears in the NO. OF STEP field.

- COMPLIANCE

In the COMPLIANCE field, you set the **compliance value**. If a VSU is used for the VAR1 unit, this field *cannot* be set: compliance value is fixed to 100 mA.

- POWER COMP

In the POWER COMP field, you can set a **power compliance value** for SMUs. To disable the power compliance function, select the OFF secondary softkey. If *an* SMU is set to VPULSE or IPULSE mode and if the SMU is set to VAR1, you *cannot* set power compliance for the VAR1 SMU.

VAR2 parameters In this column, you set up the output parameters for the secondary sweep unit. UNIT and NAME are defined on the CHANNELS: CHANNEL DEFINITION screen.

SWEEP MODE and LIN/LOG fields are fixed to SINGLE and LINEAR.

- START, STEP, and NO. OF STEP

In the START, STEP, and NO OF STEP fields, you specify the start value, step value, and number of steps. The stop value is calculated from these values, and is shown in the STOP field.

- COMPLIANCE

In COMPLIANCE field, you set compliance value. If a VSU is used for VAR2 unit, this field *cannot* be set: compliance value is fixed to approximately 100 mA.

- POWER COMP

In POWER COMP field, you can set power compliance value for SMUs. To disable power compliance function, select OFF secondary softkey.

VAR1' parameters In this column, you set up the output parameters for the synchronous sweep unit. This VAR1' table is displayed only when VAR1' is set in the FCTN field on the CHANNELS: CHANNEL DEFINITION screen.

UNIT and NAME are defined on CHANNELS: CHANNEL DEFINITION screen.

- OFFSET and RATIO

In the OFFSET and RATIO fields, you specify the *offset* and *ratio* values. The offset and ratio values determine the VAR1' value as follows:

$$\text{VAR1' output} = \text{VAR1 output} \times \text{ratio} + \text{offset}$$

- COMPLIANCE

In COMPLIANCE field, you set compliance value. If a VSU is used for VAR1' unit, this field *cannot* be set: compliance value is fixed to 100 mA.

- POWER COMP

In the POWER COMP field, you can set the power compliance value. To disable the power compliance function, select OFF secondary softkey. If an SMU is set to VPULSE or IPULSE mode and if the SMU is set to VAR1', you *cannot* set power compliance for the VAR1' SMU.

TIMING

- HOLD TIME

In the HOLD TIME field, you set the **hold time**. The output unit waits this time after forcing the start value. Range: 0 to 655.35 s. Resolution: 10 ms.

- DELAY TIME In DELAY TIME field, you set the **delay time**. The output unit waits this time after each step, then starts measurement. If an SMU is set up to be a pulse source, DELAY TIME field is not displayed because each step is synchronized with pulse output. Range: 0 to 65.535s. Resolution: 100 μ s.

SWEEP Status

- Select CONT AT ANY secondary softkey (sweep will continue even if an abnormal status occurs). Abnormal status means the following:
 - SMU reaches its compliance setting.
 - Current of VSU exceeds approximately ± 100 mA.
 - SMU or VSU oscillates.
 - A/D converter overflow occurs.
 - Average current of PGU exceeds ± 100 mA.
- Select STOP AT ANY ABNORM secondary softkey (sweep will stop if any abnormal status occurs).
- Select STOP AT COMPLIANCE secondary softkey (sweep will stop only if SMU reaches its compliance setting).

STOP AT COMPLIANCE is automatically set when power compliance is set for SMUs, or when 10k Ω , 100k Ω , or 1M Ω is selected in the SERIES RESISTANCE field. If power compliance is set for an SMU, the CONT AT ANY secondary softkey is not displayed.

SMU PULSE

These parameters set the SMU pulsed source (IPULSE or VPULSE). The SMU pulsed source is defined on the CHANNELS: CHANNEL DEFINITION screen, so the UNIT and NAME fields are already set.

In the PERIOD, WIDTH, and BASE fields, you specify the pulse period, pulse width, and pulse base value. The pulse peak value is determined by the settings in the VAR1, VAR2, VAR1', or CONSTANT field.

Be aware that if any of following are true, pulsed SMU channel may not output the pulse period and pulse width you specified:

- Measurement range differs from compliance range (lowest range that includes compliance).
- Ranging mode is set to auto range or limited auto range.
- Multi-channel measurement is set.

CONSTANT

These parameters set the constant source units. UNIT, NAME, and MODE are defined on the CHANNELS: CHANNEL DEFINITION screen.

- SOURCE

In the SOURCE field, you specify the output value.

- COMPLIANCE

In this field, you set compliance value. If VSU is used for constant output unit, this field cannot be set: compliance value is fixed to 100 mA.

If you define more than four constant output units, the first four units appear in the CONSTANT fields. To show other units, select NEXT UNIT secondary softkey. To scroll the units, put field pointer in most right or left column, then press the right arrow or left arrow MARKER/CURSOR front-panel key.

MEASURE: SAMPLING SETUP screen

MEASURE: SAMPLING SETUP01JAN15 06:09PM

←User Comment→

*SAMPLING PARAMETER

MODE	LINEAR
INITIAL INTERVAL	4.00ms
NO. OF SAMPLES	101
TOTAL SAMP. TIME	AUTO
HOLD TIME	0.000000 s
FILTER	ON

*STOP CONDITION

ENABLE/DISABLE	DISABLE
ENABLE DELAY	0.0000000 s
NAME	
THRESHOLD	0.00000000
EVENT	Val > Th
EVENT NO.	1

LINEAR

LOG10

LOG25

LOG50

THINNED OUT

LINEAR

Select Sampling Mode with softkey or rotary knob.

SAMPLNG SETUP

MEASURE SETUP

OUTPUT SEQ

S

PREV PAGE

NEXT PAGE

B

On this screen, you set sampling parameters for each unit. For details, see *User's Guide: Measurement and Analysis*.

User Comment

In this field, you can enter a desired comment, which is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

SAMPLING PARAMETER

- **MODE**
MODE field sets the **sampling mode**. In this field, select:
 - LINEAR secondary softkey to specify the linear sampling mode.
 - LOG10, LOG25, or LOG50 secondary softkey to specify the logarithmic sampling mode. The number specifies how many samples to take per decade.
 - Select THINNED-OUT softkey to specify the thinned-out sampling mode, which discards less recent samples.

- INITIAL INTERVAL

In the INITIAL INTERVAL field, you set the **initial interval** which is the interval of measurement trigger. Not measurement interval. Measurement unit executes measurement if it is ready to measure at the trigger. If the unit is busy or in measurement, the unit waits for the next trigger.

- NO. OF SAMPLES

This field sets the **number of samples**. The number of samples must be 10001 or less (total for all units that make measurements plus size of all registered user variables). The number of units that make measurements is determined by the DISPLAY: DISPLAY SETUP screen.

- TOTAL SAMP. TIME (for linear and thinned-out sampling mode)

TOTAL SAMP. TIME field sets the **total sampling time**. The total sampling time must satisfy the following condition:

$$\text{total sampling time} \geq \text{initial interval} \times (\text{number of samples} - 1)$$

In this field, enter a value or select:

- NO LIMIT secondary softkey to continue the sampling until sampling completion condition is satisfied. For linear sampling mode, **initial interval** must be more than 480 μ s.
- (for linear sampling mode only) AUTO secondary softkey to set the total sampling time to *initial interval* $\times$ (*number of samples* -1).

- HOLD TIME

HOLD TIME field sets the **hold time**. The unit waits this time after forcing the specified constant value, then sampling starts.

Range: (for *initial interval* < 2 ms) -30ms to 655.35s with $100\ \mu\text{s}$ resolution.

(for *initial interval* ≥ 2 ms) 0 to 655.35s with $100\ \mu\text{s}$ resolution.

- FILTER This field specifies SMU filter to ON or OFF. If this field is set to ON, overshoot is decreased, but settling time takes several ms. Be aware of this if you set initial interval to a short time.

STOP CONDITION • ENABLE/DISABLE

This field defines whether the **stop conditions** are enabled. Cannot ENABLE if INITIAL INTERVAL < 2 ms. In this field, select:

- ENABLE secondary softkey to enable the stop conditions.
- DISABLE secondary softkey to disable the stop conditions.

• ENABLE DELAY

This field sets the **enable delay** time. The stop condition is ignored for the enable delay time after the sampling starts. The resolution of enable delay time is the initial interval time.

• NAME

NAME field sets the variable name or user function name that you want to monitor for the stop conditions. Allowable variable names and user function names are shown in the secondary softkey area.

• THRESHOLD

In the THRESHOLD field, you set the **threshold value**.

• EVENT

In the EVENT field, you set the event type as follows:

Val>Th event occurs when NAME value is greater than THRESHOLD.

Val<Th event occurs when NAME value is less than THRESHOLD.

|Val|>|Th| event occurs when absolute NAME value is greater than absolute THRESHOLD value.

|Val|<|Th| event occurs when absolute NAME value is less than absolute THRESHOLD value.

• EVENT NO.

EVENT NO. specifies sampling to stop if event occurs EVENT NO. times. EVENT NO. can be an integer from 1 to 200.

CONSTANT

This is for setting the output parameters of the constant source units. UNIT, NAME, and MODE are defined on the CHANNELS: CHANNEL DEFINITION screen.

- SOURCE

In the SOURCE field, you specify the output value.

- COMPLIANCE

In the COMPLIANCE field, you specify the compliance value. If a VSU is used for the constant output unit, this field cannot be set: compliance value is fixed to 100 mA.

If you define more than four constant output units, first four units appear in CONSTANT fields. To show other units, select NEXT UNIT secondary softkey. To scroll units, put field pointer in most right or left column, then press the right arrow or left arrow MARKER/CURSOR front-panel key.

MEASURE: PGU SETUP screen

MEASURE: PGU SETUP01JAN15 06:12PM

← User Comment →

*PULSE

UNIT	PGU1	PGU2
NAME	PGU1	
PERIOD	10.00ms	-----
WIDTH	5.00ms	
DELAY TIME	0.0000 s	
PEAK VALUE	100mV	
BASE VALUE	0.0000 V	
LEADING TIME	100ns	
TRAILING TIME	100ns	
IMPEDANCE	LOW	LOW
PULSE COUNT	FREE RUN	-----

*CONSTANT

UNIT	PGU1	PGU2
NAME		PGU2
SOURCE		0.0000 V

0.01
Enter PGU Pulse Period (2E-06 to 10) .B

SWEEP
SETUP

PGU
SETUP

MEASURE
SETUP

OUTPUT
SEQ

S

PREV
PAGE

NEXT
PAGE

On the "MEASURE: PGU SETUP" screen, you set output parameters for each PGU. For more information about PGUs, see *User's Guide: Measurement and Analysis*.

User Comment

In this field, you can enter a desired comment. The comment you enter here is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

PULSE


You set the pulse output parameters in the PULSE area.

UNIT and NAME are defined on the CHANNELS: CHANNEL DEFINITION screen.

- PERIOD
PERIOD field specifies the pulse period of the PGU. Note that the pulse period of PGUs is independent from that of the SMUs.
- WIDTH
WIDTH field specifies the pulse width. The pulse width must be less than the pulse period.

- **DELAY TIME**

DELAY TIME field specifies the delay time from the pulse period start time. The delay time must be less than or equal to the pulse period.



- **PEAK VALUE and BASE VALUE**

PEAK VALUE and BASE VALUE fields specify the pulse peak and pulse base values.

- **LEADING TIME and TRAILING TIME**

LEADING TIME and TRAILING TIME fields specify the transition time of leading and trailing edges, which is time for pulse to change from 10% to 90% of pulse amplitude.

- **IMPEDANCE**

IMPEDANCE field specifies the PGU output impedance. In this field, select:

- LOW secondary softkey to set output impedance to about 0 Ω
- 50 ohm secondary softkey to set output impedance to 50 Ω

- **PULSE COUNT**

PULSE COUNT field specifies the number of pulses for the sampling measurement (for sweep measurements, only **FREE RUN** is available).

- Enter a pulse count value (only for sampling measurements).
- Select **FREE RUN** or enter 0 (zero) to set continuous pulse output. If either PGU1, PGU2, or both are set to standby ON on the CHANNELS: CHANNEL DEFINITION screen, this field is automatically set to *free run* mode.

Setup Screens
MEASURE Screen Group

CONSTANT

UNIT and NAME are defined on CHANNELS: CHANNEL DEFINITION screen.
In the SOURCE field, you specify the output value.

MEASURE: MEASURE SETUP screen

MEASURE: MEASURE SETUP 01JAN15 05:40PM

← User Comment →

AUTO

FIXED

LIMITED
AUTO

*MEASUREMENT RANGE

UNIT	NAME	RANGE	
SMU1:HR	I1	LIMITED	1nA
SMU2:HR	V2	AUTO	-----
SMU3:HR	I3	LIMITED	1nA
SMU4:HR	I4	LIMITED	1nA
VMU1:HR	VMU1	AUTO	-----

ZERO

CANCEL

OFF

OFF

[10pA]

OFF

[10pA]

OFF

[10pA]

OFF

[0.2V]

(*:Old data is used.)

*INTEG TIME

	TIME	NPLC
SHORT@	640us	0.0384
MED	16.7ms	1
LONG	266*ms	16

*WAIT TIME

1

*(DEFAULT WAIT TIME)

LIMITED

Select Range Mode with softkey or rotary knob.

SWEEP

MEASURE

OUTPUT

S

PREV

NEXT

SETUP

SETUP

SEQ

PAGE

PAGE

On the "MEASURE: MEASURE SETUP" screen, you set measurement range, zero cancel, integration time, and wait time.

User Comment

In this field, you can enter a desired comment. The comment you enter here is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

MEASUREMENT RANGE

You can set the measurement range for each unit.

- UNIT

The UNIT field shows all the installed measurement units. Only measurement units are shown, so VSU, PGU, and GNDU are not shown.

- NAME

The NAME field shows all names for the measurement units, which you defined on the CHANNELS: CHANNEL DEFINITION screen. For example, when the SMU1 is set to V mode, current value is measured. So the current name (INAME) is shown in the NAME field.

- RANGE

The left field of RANGE specifies the **ranging mode**. In this field, select:

- AUTO secondary softkey to set **auto-ranging** mode.
- FIXED secondary softkey to set **fixed-ranging** mode.
- LIMITED AUTO secondary softkey to set **limited auto-ranging** mode.

The right field of RANGE specifies the **range value**. For auto-ranging mode, "-----" appears. For the fixed-ranging and limited auto-ranging modes, allowable range values are shown in the secondary softkey area. You select a softkey to set the range value.

For details, see *User's Guide: Measurement and Analysis*.

- ZERO CANCEL

ZERO CANCEL field specifies **zero offset cancel mode**. Select ZERO CANCEL ON/OFF to toggle the zero offset cancel mode between on and off.

If the zero offset cancel mode is set to OFF, then OFF appears in all the ZERO CANCEL fields. If zero offset cancel mode is set to ON, then ON or OFF appear automatically in each field depending on the measurement range.

For details, see *User's Guide: Measurement and Analysis*.

INTEG TIME

INTEG TIME area shows integration time and corresponding number of power line cycles (NPLC) for short, medium, and long modes. You can change integration time for short and long modes, but not for medium mode.

The selected integration time is indicated by @, and is used for all measurement units. You select the integration time by using the Short, Medium, or Long front panel keys from any screen.

- SHORT

The TIME field for SHORT shows the integration time of the short mode. You can change this integration time. NPLC value is calculated from the integration time and power line frequency.

- MED

The TIME field for MED shows the integration time of the medium mode, which is calculated from the power line frequency and NPLC value. NPLC value is always 1. You cannot change it.

- LONG

The TIME field for LONG shows the integration time of the long mode, which is calculated from the NPLC and power line frequency. You can change the NPLC value.

For details, see *User's Guide: Measurement and Analysis*.

WAIT TIME

For each unit, the 4155C/4156C automatically uses a wait time that depends on the range value. This is the default wait time. In the WAIT TIME field, the value you specify is multiplied times the default wait time. Allowed values are 0.0 to 10.0 with 0.1 step.

The wait time is the time that a unit waits after forcing a value. During the wait time, the unit cannot start the measurement.

The default wait time is recommended. It is not easy to determine the best wait time. If you specify a wait time that is too short, the measurement may start before the output is stable. If too long, time will be wasted.

MEASURE: OUTPUT SEQUENCE screen

MEASURE: OUTPUT SEQUENCE01JAN13 03:50PM

← User Comment →

SMU1:MP

SMU2:MP

SMU3:MP

SMU4:MP

SMU5:HP

VSU1

MORE

1 / 2

*OUTPUT SEQUENCE

	UNIT	NAME	MODE
1	SMU1:MP	V1	COMMON
2	SMU2:MP	I2	I
3	SMU3:MP	V3	V
4	SMU4:MP	V4	V
5	SMU5:HP		
6	VSU1	VSU1	V
7	VSU2	VSU2	V
8	PGU1		
9	PGU2		

*TRIGGER SETUP

ENABLE/DISABLE	DISABLE
FUNCTION	TRIG OUT
STEP DELAY	0.000 s
POLARITY	POSITIVE

SMU1:MP

Select Output Sequence with softkey or rotary knob.

B

SWEEP

MEASURE

OUTPUT

PREV

NEXT

SETUP

SEQ

PAGE

PAGE

On this screen, you set the output sequence and triggering parameters for measurement state.

The output sequence set on this screen is also used when the state changes from idle state to stress force state.

For trigger setup for stress force state, see *User's Guide: Measurement and Analysis*.

User Comment

In this field, you can enter a desired comment, which is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

OUTPUT SEQUENCE

In the UNIT column, allowable units are shown in output sequence order. Only output units are shown, so VMU and GNDU are not shown. In the NAME and MODE fields, the output names and mode that you set up on the CHANNELS: CHANNEL DEFINITION screen are shown.

To change the output order of the units, enter unit names in desired order by selecting secondary softkeys.

TRIGGER SETUP

- **ENABLE/DISABLE**

ENABLE/DISABLE field defines whether the triggering function is used or not. In this field, select:

- **ENABLE** secondary softkey to enable the triggering function.
- **DISABLE** secondary softkey to disable the triggering function.

- **FUNCTION**

FUNCTION field sets the triggering mode.

- **Select TRIG OUT secondary softkey to enable the following functions:**

For a normal (non-pulse) sweep measurement, the 4155C/4156C outputs an edge-trigger signal when a measurement starts for each step.

For a pulsed sweep measurement, the 4155C/4156C outputs an edge-trigger signal synchronized with the pulse leading edge.

- **Select TRIG IN to enable the following function:**

Sweep measurement or sampling measurement starts when the 4155C/4156C receives a trigger signal from an external instrument.

- **STEP DELAY**

STEP DELAY field is available only for the SWEEP measurement mode. The step delay time is the time from when the trigger is output to when the next step occurs. For details about setup delay time, refer to *User's Guide: Measurement and Analysis*.

When you set **TRIG IN** in the FUNCTION field, this field has no meaning, so "-----" is displayed.

- **TRIG OUT DELAY**

TRIG OUT DELAY field is displayed when you set pulse sweep measurement. The trigger output delay time specifies how much to delay the trigger after the leading edge. For details about trigger output delay time, refer to *User's Guide: Measurement and Analysis*. When you set **TRIG IN** in the FUNCTION field, this field has no meaning, so "-----" is displayed.

- **POLARITY**

In the POLARITY field, select secondary softkeys to select trigger polarity as follows: **POSITIVE** or **NEGATIVE**.

Setup Screens
MEASURE Screen Group

**OUTPUT
SEQUENCE MODE
OF SAMPLING**

For a sampling measurement, you can set the output sequence to **sequential mode** or **simultaneous mode**. This field is displayed only when sampling mode is selected on the CHANNELS: CHANNEL DEFINITION screen. If you select sequential mode, OUTPUT SEQUENCE table determines the output order. If you select simultaneous mode, all the units force at the same time.

MEASURE: QSCV SETUP screen

MEASURE: QSCV SETUP

← User Comment →

*VARIABLE	VAR1
UNIT	SMU3:HR
NAME	V3
SWEEP MODE	SINGLE
START	0.0000 V
STOP	1.0000 V
STEP	200.0mV
NO OF STEP	6
COMPLIANCE	100.00mA

*QSCV MEAS VOLTAGE
100.0mV

*TIMING

HOLD TIME	0.0000 s
DELAY TIME	0.0000 s

*QSCV CONTINUE AT ANY Status

*CONSTANT

UNIT	SMU2:HR	SMU4:HR	VSU1	VSU2
NAME	I2	V4	VSU1	VSU2
MODE	I	V	V	V
SOURCE	0.0000 A	0.0000 V	0.0000 V	0.0000 V
COMPLIANCE	100.0mV	100.00mA	-----	-----

SINGLE
Select SWEEP Mode with softkey or rotary knob.

QSCV MEASURE OUTPUT S PREV NEXT
SETUP SETUP SEQ PAGE PAGE

On this screen, you set the output parameters for each unit used in the quasi-static CV measurements.

User Comment

Use this field to enter a desired comment, which is also displayed on the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screens.

VAR1 parameters

In this column, you set the output parameters for the sweep unit. The UNIT and NAME are defined on the CHANNELS: CHANNEL DEFINITION screen.

• SWEEP MODE

Use this field to select the sweep mode using the following secondary softkeys.

SINGLE Sweeps from the start value to the stop value.

DOUBLE Sweeps from the start value to the stop value to the start value.

Setup Screens

MEASURE Screen Group

- START, STOP, and STEP

Use the fields to set the sweep *start*, *stop*, and *step* values respectively. Minimum value of *step* is double the resolution of the output range.

In the QSCV measurement, the 4155C/4156C executes the capacitance measurement at the sweep steps except for the sweep start voltage and stop voltage. At each sweep step, the capacitance measurement is executed over the voltage range: output voltage $\pm$ QSCV MEAS VOLTAGE/2.

- NO. OF STEP

The number of sweep steps is calculated from the equation (fractions below decimal point are rounded down): $|START-STOP| / |STEP| - 1$, and appears in this field. 1 to 1001. If the calculation result is 0, this value is set to 1.

If this value is set to 1, the measurement unit executes a one-point capacitance measurement between the START and STOP values.

- COMPLIANCE

Use this field to set the current compliance value of the sweep source.

QSCV MEAS VOLTAGE

Use this field to define the capacitance measurement voltage. Minimum value is double the resolution of the output range, and maximum value is 10 V. The value must be $\leq |STEP|$. If you enter a value greater than the $|STEP|$ value, this value is automatically set to the same value as the $|STEP|$ value.

If you enter the value $\geq |START-STOP|$, the measurement unit executes a one-point capacitance measurement between the START and STOP values.

NOTE

If you set the START, STOP, STEP, and QSCV MEAS VOLTAGE as shown below, the capacitance measurement is executed over the following voltage range.

START=0, STOP=5, STEP=1 (NO. OF STEP=4), QSCV MEAS VOLTAGE=1

Swee Step	Voltage Range of capacitance measurement	Measurement Data (Vn,Cn)
first step	0.5 to 1.5 V	(1, C1)
second step	1.5 to 2.5 V	(2, C2)
third step	2.5 to 3.5 V	(3, C3)
fourth step	3.5 to 4.5 V	(4, C4)

Vn is the voltage data, and Cn is the capacitance data at the nth sweep step.

TIMING

- HOLD TIME

Enter the hold time that is the time from the start of the first sweep step to the beginning of the delay time. Values: 0 to 655.35 s, 10 ms resolution.

- DELAY TIME

Enter the delay time that is the time from the start of each sweep step to the start of the measurement. Values: 0 to 65.535s, 100 μ s resolution.

QSCV Status

- Select the CONT AT ANY secondary softkey. The sweep will continue even if an abnormal status occurs.
- Select the STOP AT ANY ABNORM secondary softkey. The sweep will stop if an abnormal status occurs.
- Select the STOP AT COMPLIANCE secondary softkey. The sweep will stop if an abnormal status 2 or 3 occurs.

An abnormal status is defined as follows:

1. Compliance on the non-measurement unit.
2. Compliance on the leakage current measurement unit.
3. Integration time too short at the capacitance measurement.
4. Overflow on ADC.
5. Oscillation on any unit.

CONSTANT

- SOURCES

Use this field to set the constant source output value.

- COMPLIANCE

Use this field to set the compliance value. If a VSU is used as the constant output unit, this field cannot be set. The compliance value is fixed to 100 mA.

If you define more than four constant output units, the first four units appear in the fields. To show other units, select the NEXT UNIT secondary softkey. To scroll through the units, use the right arrow or left arrow MARKER/CURSOR front-panel key.

MEASURE: QSCV MEASURE SETUP screen

MEASURE: QSCV MEASURE SETUP

← User Comment →

*MEASUREMENT UNIT

UNIT	FCTN	RANGE	CNAME	INAME
SMU1:HR	VAR1	1nA	CAP00	LEAK00

*INTEG TIME

	TIME	NPLC
QSCV	100ms	5
LEAK	100ms	5

*LEAK COMPENSATION

ON

*ZERO CANCEL

ON	0.0000000 F
----	-------------

SMU1:HR

Select Measurement Unit with softkey.

QSCV

MEASURE

OUTPUT

S

PREV

NEXT

SETUP

SETUP

SEQ

PAGE

PAGE

B

On the "MEASURE: QSCV MEASURE SETUP" screen, you select the measurement units, range, integration time, leakage current compensation, and QSCV zero cancel.

User Comment Use this field to enter a desired comment. The comment you enter here is also displayed on the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screens.

MEASUREMENT UNIT You can select the measurement units, measurement range, capacitance measurement data name, and leakage current measurement data name.

- UNIT
Use this field to select the measurement units for the quasi-static CV measurement using the secondary softkey.
- FCTN
This field shows the function of the unit. VAR1 or CONST is displayed.

- RANGE

Use this field to set the measurement range using the secondary softkey. The range is used by both the capacitance and leakage current measurements.

- CNAME

The CNAME field assigns a variable name for the capacitance measurement data. You can use this name as a reference on other screens.

- INAME

The INAME field assigns a variable name for the leakage current measurement data. You can use this name as a reference on other screens.

NOTE**CNAME and INAME**

CNAME and INAME must be six or less alphanumeric characters. The first character must be an alpha character. The name must be unique.

INTEG TIME

Use the fields to set the integration time.

- QSCV sets the integration time for the capacitance measurement. in seconds. 0.04 to 400 for 50 Hz, 0.033333 to 333.33 for 60 Hz.
- LEAK sets the integration time for the leakage current measurement. in seconds. 0.02 to 2 for 50 Hz, 0.016667 to 1.6667 for 60 Hz.

The value is rounded to the value calculated from NPLC/selected line frequency. where NPLC is integer in the range: 2 to 20000 for QSCV, and 1 to 100 for LEAK. NPLC means the number of power line cycle.

The **Short**, **Medium**, and **Long** front-panel keys have no effect for the quasi-static CV measurement.

**LEAK
COMPENSATION**

Use this field to turn the leakage current compensation on or off using the softkey.

ZERO CANCEL

Use this field to turn the offset capacitance cancel function on or off using the secondary softkey. The measurement setup must be completed before executing the offset measurement. The offset data is also displayed in the right field after the offset measurement.

If you change the UNIT or RANGE setting, the offset data will be deemed invalid. Then execute the offset measurement again. If you do not do it again, the old data will be used for the offset cancel.

DISPLAY Screen Group

DISPLAY screen group has the following screens:

- Display Setup: For setting the graphics/list display mode, the parameters for graphics/list screen, and measurement channels.
- Analysis Setup: For defining where to automatically display lines and marker after a measurement.

To move into the DISPLAY screen group, do one of the following:

- Press Display front-panel key in the PAGE CONTROL key group.
- Select NEXT PAGE primary softkey in the MEASURE: OUTPUT SEQUENCE screen.

Then, the following primary softkeys appear:

DISPLAY	ANLYSIS	_____	_____	_____	_____	PREV	NEXT
SETUP	SETUP	_____	_____	_____	_____	PAGE	PAGE

- Select DISPLAY SETUP softkey to move to the DISPLAY: DISPLAY SETUP screen.
- Select ANLYSIS SETUP softkey to move to DISPLAY: ANALYSIS SETUP screen.

DISPLAY: DISPLAY SETUP screen for graphic results

DISPLAY: DISPLAY SETUP

01JAN15 05:32PM

User Comment

*DISPLAY MODE

GRAPHICS

*GRAPHICS

	Xaxis	Ylaxis	Y2axis
NAME	V3	I3	
SCALE	LINEAR	LINEAR	
MIN	0.000000000 V	0.000000000 A	
MAX	1.0000000 V	100.0000000mA	

*GRID

ON

*LINE PARAMETER

ON

*DATA VARIABLES

*DATA DISPLAY RESOLUTION

NORMAL

GRAPHICS

Select Display Mode with softkey or rotary knob.

DISPLAY SETUP

ANLYSIS SETUP

S

PREV PAGE

NEXT PAGE

GRAPHICS

LIST

On the "DISPLAY: DISPLAY SETUP" screen for graphics results, you set axes, grid, and data variable names for the "GRAPHICS" screen. The channels that actually perform measurements are determined by the axis names and data variables that you set on this screen.

User Comment

In this field, you can enter a desired comment. The comment you enter here is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

DISPLAY MODE

This field specifies display mode. If present display mode is list mode, then select the GRAPHICS secondary softkey to change to graphics mode.

Agilent 4155C/4156C Setup Screen Reference, Edition 1

3-49

Setup Screens

DISPLAY Screen Group

GRAPHICS

In the GRAPHICS area, you set up the X, Y1, and Y2 axes. You must set up the X and Y1 axes. Y2 axis is optional.

- NAME

NAME fields specify the variable names that you want to assign to the axes, which will be plotted on the GRAPHICS screen. In this field, you can select the desired variable names in the secondary softkey area. The entries in these fields and the data variable fields determine which channels will actually make measurements.

- SCALE

The SCALE fields specify linear or logarithmic scale for the axis by selecting LINEAR or LOG secondary softkey.

- MIN and MAX

MIN and MAX fields specify the minimum and maximum values for the axis. The minimum and maximum values are automatically set according to the NAME and SCALE settings. You can modify these values if desired.

GRID

In the GRID field, you can specify whether to display the grid on the plotting area by selecting ON or OFF secondary softkey.

LINE PARAMETER

In the LINE PARAMETER field, you can specify whether to display X and Y intercepts and gradients of lines on the plotting area by selecting ON or OFF secondary softkey.

OFF The line parameters are not displayed.

ON The line parameters are displayed when lines are displayed on the graph.

DATA VARIABLES

In the DATA VARIABLES fields, you can enter two variable names. The numerical values of these variables will be shown on the GRAPHICS screen according to the marker position. In this field, you can select the desired variable names in the secondary softkey area.

Even if the setup data variables are defined using variables that are not set in the NAME field of the GRAPHICS table, the variables are automatically measured after pressing a measurement front-panel key.

DATA DISPLAY RESOLUTION

In this field, you set the resolution of the measurement data displayed on the screen by using the secondary softkey. In extend mode, 10 aA resolution at 10 pA range.

NORMAL resolution depends on the specifications. 1 fA resolution at 10 pA range.

EXTEND resolution is extended up to the full scale of the internal A/D converter.

DISPLAY: DISPLAY SETUP screen for list results

DISPLAY: DISPLAY SETUP

01JAN15 05:50PM

User Comment

*DISPLAY MODE

LIST

*LIST

No.	NAME
1	V3
2	I3
3	
4	
5	
6	
7	
8	

*DATA VARIABLES

*DATA DISPLAY RESOLUTION

NORMAL

GRAPH-ICS

LIST

LIST

Select Display Mode with softkey or rotary knob.

DISPLAY SETUP

ANLYSIS SETUP

S

PREV PAGE

NEXT PAGE

On the "DISPLAY: DISPLAY SETUP" screen for list results, you enter variable names for which you want results to be displayed numerically. The measurement channels are determined by the variable names that you set on this screen.

User Comment

In this field, you can enter a desired comment, which is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

DISPLAY MODE

This field specifies display mode. If present mode is graphics mode, select LIST secondary softkey to change to list mode. LIST table is displayed.

LIST

NAME fields of LIST area specify variables that you want to display on LIST screen. You can enter the desired variable names. Entries in this area and data variable area determine which channels will actually make measurements. You can enter up to eight variable names. When the pointer is located in NAME field, you can select desired variable names in secondary softkey area.

Agilent 4155C/4156C Setup Screen Reference, Edition 1

3-51

Setup Screens

DISPLAY Screen Group

DATA VARIABLES DATA VARIABLES fields specify the variable names that you want to display on the GRAPH/LIST: LIST screen. The numerical values of these variables will be shown on the LIST screen according to the marker position. In this field, you can select the desired variable names in the secondary softkey area.

Even if the setup data variables are defined using variables that are not set in the NAME field of the LIST table, the variables are automatically measured after pressing a measurement front-panel key.

DATA DISPLAY RESOLUTION In this field, you set the resolution of the measurement data displayed on the screen by using the secondary softkey. In extend mode, 10 aA resolution at 10 pA range.

NORMAL resolution depends on the specifications. 1 fA resolution at 10 pA range.

EXTEND resolution is extended up to the full scale of the internal A/D converter.

DISPLAY: ANALYSIS SETUP screen

DISPLAY: ANALYSIS SETUP	01JAN11 01:39PM	
User Comment		
*LINE1: []		NORMAL
*LINE2: []		GRAD
*MARKER: At a point where [] = [] []		TANGENT REGRES- SION
*Interpolate: [OFF]		DISABLE
Select Line Mode with softkey or rotary knob.		
DISPLAY SETUP	ANLYSIS SETUP	PREV PAGE
NEXT PAGE		

On the "DISPLAY: ANALYSIS SETUP" screen, you set up the automatic analysis function. When a measurement finishes, the function automatically draws lines, a marker, or both as specified on this screen.

You can set up two lines and one marker for the automatic analysis function. In the LINE1 and LINE2 fields, you can set up the lines to be drawn. In the MARKER field, you set up the marker.

For the automatic analysis function and the manual analysis function, four line modes can be used:

- Normal mode: drawing a line between *any two* points.
- Grad mode: drawing a line through *any point* with a specified gradient.
- Tangent mode: drawing a tangent to a *measurement* point.
- Regression mode: drawing a regression line for the area specified by *any two* points.

The following explains how to set up the lines and marker. For details about line modes, refer to *User's Guide: Measurement and Analysis*.

Setup Screens

DISPLAY Screen Group

User Comment In this field, you can enter a desired comment. This comment is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

Normal mode line In the first bracketed field after `LINE1` or `LINE2`, you select the line mode. Select the **NORMAL** secondary softkey to set the normal line mode. The pointer moves to the second bracketed field as shown:

```
LINE1: [NORMAL   ] LINE ON [Y1] between a point [AT   ]
```

In the second bracketed field, you specify which measurement curve you want to analyze by selecting the related axis: **Y1** or **Y2** secondary softkey.

In the third bracketed field, you specify how to select a point:

- Select **BY X-Y COORDINATE**. "AT" is displayed. Then, you enter the desired X-Y coordinate values or expressions in the **X:** and **Y:** fields.
- Select **BY DATA CONDITION**. "WHERE" is displayed. Then, you enter a variable name and condition expression to specify a measurement point.

```
LINE1: [NORMAL   ] LINE ON [Y1] between a point [AT   ]
X: [0                                                    ]
Y: [0                                                    ]
and a point [WHERE]
[DGM   ] = [MAX(DGM)*0.01]
[      ]
```

In addition, you can specify another condition if you position the pointer in the last bracketed field shown above. Select the **AFTER** secondary softkey. **AFTER** is displayed, and you can enter a second variable and condition expression. This sets up a search start condition for finding specified point. (This setup is optional.)

For example, you can specify the following expressions to search for a measurement point that satisfies the first condition after the second condition is satisfied.

```
LINE1: [NORMAL   ] LINE ON [Y1] between a point [AT   ]
X: [0                                                    ]
Y: [0                                                    ]
and a point [WHERE]
[DGM   ] = [MAX(DGM)*0.01]
[AFTER] [DGM   ] = [MAX(DGM)]
```

On GRAPH/LIST: GRAPHICS screen, *LINE secondary* softkey must be ON.

Gradient mode line In the first bracketed field after `LINE1` or `LINE2`, you select the line mode. Select the `GRAD` secondary softkey to set the gradient line mode. The pointer moves to the second bracketed field as shown:

```
LINE1: [GRAD      ] LINE ON [Y1] between a point [      ]
```

```
Gradient: [                                              ]
```

In the second bracketed field, you specify which measurement curve you want to analyze by selecting the related axis: `Y1` or `Y2` secondary softkey.

In the third bracketed field, you specify how to select a point:

- Select `BY X-Y COORDINATE`. "`AT`" is displayed. Then, you enter the desired X-Y coordinate values or expressions in the `X:` and `Y:` fields.
- Select `BY DATA CONDITION`. "`WHERE`" is displayed. Then, you enter a variable name and condition expression to specify a measurement point.

```
LINE1: [GRAD      ] LINE ON [Y1] between a point [WHERE]
[DGM      ] = [MAX(DGM)*0.01
[          ]
Gradient: [                                              ]
```

In addition, you can specify another condition if you position the pointer in the bracketed field above `Gradient`. Select the `AFTER` secondary softkey. `AFTER` is displayed, and you can enter a second variable and condition expression. This sets up a search start condition for finding specified point. (This setup is optional.)

For example, you can specify the following expressions to search for a measurement point that satisfies the first condition after the second condition is satisfied.

```
LINE1: [GRAD      ] LINE ON [Y1] between a point [WHERE]
[DGM      ] = [MAX(DGM)*0.01
[AFTER] [DGM      ] = [MAX(DGM)
Gradient: [                                              ]
```

In a field after `Gradient:`, you enter a gradient value or expression.

On `GRAPH/LIST: GRAPHICS` screen, `LINE secondary` softkey must be `ON`.

Setup Screens

DISPLAY Screen Group

Tangent mode line In the first bracketed field after `LINE1` or `LINE2`, you select the line mode. Select the `TANGENT` secondary softkey to set the tangent line mode. The pointer moves to the second bracketed field as shown:

```
LINE1: [TANGENT ] LINE ON [Y1] between a point where
[          ] = [          ]
[          ] [          ] = [          ]
```

In the second bracketed field, you specify which measurement curve you want to analyze by selecting the related axis: `Y1` or `Y2` secondary softkey.

Enter a variable name and condition expression to specify the measurement point for which you want to draw a tangent line.

```
LINE1: [TANGENT ] LINE ON [Y1] between a point where
[DGM    ] = [MAX(DGM)*0.01]
[          ] [          ] = [          ]
```

In addition, you can specify another condition if you position the pointer in the last bracketed field shown above. Select the `AFTER` secondary softkey. `AFTER` is displayed, and you can enter a second variable and condition expression. This sets up a search start condition for finding specified point. (This setup is optional.)

For example, you can specify the following expressions to search for a measurement point that satisfies the first condition after the second condition is satisfied.

```
LINE1: [TANGENT ] LINE ON [Y1] between a point where
[DGM    ] = [MAX(DGM)*0.01]
[AFTER] [DGM    ] = [MAX(DGM)]
```

On `GRAPH/LIST: GRAPHICS` screen, `LINE secondary` softkey must be `ON`.

Regression mode line

In the first bracketed field after `LINE1` or `LINE2`, you select the line mode. Select the `REGRESSION` secondary softkey to set the regression line mode. For details about regression calculation range, see *User's Guide: Measurement and Analysis*.

The pointer moves to second bracketed field as shown:

```
LINE1: [REGRESSION] LINE ON [Y1] between a point [AT  ]
X: [ ]
Y: [ ]
and a point [AT  ]
X: [ ]
Y: [ ]
```

In the second bracketed field, you specify which measurement curve you want to analyze by selecting the related axis: `Y1` or `Y2` secondary softkey.

In the third bracketed field, you specify how to select a point:

- Select `BY X-Y COORDINATE`. "AT" is displayed. Then, you enter the desired X-Y coordinate values or expressions in the `X:` and `Y:` fields.
- Select `BY DATA CONDITION`. "WHERE" is displayed. Then, you enter a variable name and condition expression to specify a measurement point.

```
LINE1: [REGRESSION] LINE ON [Y1] between a point [AT  ]
X: [0 ]
Y: [0 ]
and a point [WHERE]
[DGM  ] = [MAX(DGM)*0.01 ]
[ ]
```

In addition, you can specify another condition if you position the pointer in the last bracketed field shown above. Select the `AFTER` secondary softkey. `AFTER` is displayed, and you can enter a second variable and condition expression. This sets up a search start condition for finding specified point. (This setup is optional.)

For example, you can specify the following expressions to search for a measurement point that satisfies the first condition after the second condition is satisfied.

```
LINE1: [REGRESSION] LINE ON [Y1] between a point [AT  ]
X: [0 ]
Y: [0 ]
and a point [WHERE]
[DGM  ] = [MAX(DGM)*0.01 ]
[AFTER] [DGM  ] = [MAX(DGM) ]
```

On `GRAPH/LIST: GRAPHICS` screen, `LINE secondary` softkey must be `ON`.

Setup Screens

DISPLAY Screen Group

Marker

In the next line after **MARKER**: At a point where, you enter a variable name and a condition expression to specify where you want the marker to appear as shown in the following example:

```
MARKER: At a point where  
[DGM    ] = [MAX (DGM) *0.01  
[        ]
```

In addition, you can specify another condition if you position the pointer in the last bracketed field shown above. Select the **AFTER** secondary softkey. **AFTER** is displayed, and you can enter a second variable and condition expression. This sets up a search start condition for finding specified point. (This setup is optional.)

For example, you can specify the following expressions to search for a measurement point that satisfies the first condition after the second condition is satisfied.

```
MARKER: At a point where  
[DGM    ] = [MAX (DGM) *0.01  
[AFTER] [DGM    ] = [MAX (DGM)
```

Disabling entries

In the field after **LINE1**, **LINE2**, or **MARKER**, you can select the **DISABLE** secondary softkey to clear the entries, which disables the item for the automatic analysis function.

Interpolation mode

You can also use the interpolation mode for the automatic analysis function by selecting the **ON** secondary softkey in the **Interpolate** field. When interpolation mode is on, you can position marker between measurement points. Select **OFF** to turn interpolation mode to off.

GRAPH/LIST Screen Group

GRAPH/LIST screen group has the following screens:

Graphic Results: For displaying the measurement results graphically. You can use lines or a marker on the graphics screen to analyze the measurement results graphically.

List Results: For listing the measurement results.

To move into the GRAPH/LIST screen group, do one of the following:

- Press Graph/List front-panel key in the PAGE CONTROL key group (if present screen is not GRAPHICS or LIST screen).
- Press Single, Repeat, or Append front-panel key (if present screen is not GRAPHICS or LIST screen). Measurement is performed.

If the present screen is the GRAPHICS or LIST screen, you can toggle between these screens by pressing the Graph/List front-panel key.

On the GRAPHICS result screen

In the primary softkey area of the GRAPHICS screen, the following softkeys are available for performing the manual analysis functions:

For sweep measurements:

AXIS	MARKER/	LINE	SCALING	DISPLAY	SWEEP	TIMING	CONST
Y2	CURSOR			SETUP	SETUP	SETUP	SETUP

For sampling measurements:

AXIS	MARKER/	LINE	SCALING	DISPLAY	SAMPLNG	STOP	CONST
Y2	CURSOR			SETUP	SETUP	COND	SETUP

On the LIST result screen

In the primary softkey area of the LIST screen, the following softkeys are available for performing the manual analysis functions:


For sweep measurements:

AXIS	MARKER		SPREAD	RE-	SWEEP	TIMING	CONST
Y2			SHEET	SETUP	SETUP	SETUP	SETUP

For sampling measurements:

AXIS	MARKER		SPREAD	RE-	SAMPLNG	STOP	CONST
Y2			SHEET	SETUP	SETUP	COND	SETUP

GRAPH/LIST: GRAPHICS screen



On the "GRAPH/LIST: GRAPHICS" screen, measurement results are displayed, and you can analyze the measurement results graphically.

User Comment

In this field, you can enter a desired comment. This comment is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

Cursor/marker indicator

In these fields, the coordinate values of the cursor and marker locations are displayed. If cursor or marker is not displayed, these fields are blank. The three fields are for X, Y1, and Y2 coordinate values, respectively.

Data variable display

This area displays the numerical value of up to two variables that you set up on DISPLAY: DISPLAY SETUP screen. These are values at the marker position.

Plotting area

In this area, measurement curves are drawn according to measurement results.

You can analyze measurement results by using lines or marker in this area. If you use lines, the X and Y intercept points and gradient are displayed.

AXIS Y1 softkey Select AXIS primary softkey to toggle active axis between the Y1 and Y2 axes (this softkey is displayed only if Y2 axis is used). The active axis name is displayed on the AXIS primary softkey.

For tangent or regression lines, the active line selected by LINE SELECT softkey is independent for each axis.

MARKER/CURSOR softkey Select MARKER/CURSOR primary softkey to display secondary softkeys for performing analysis with marker and cursor.

- **MARKER softkey**

Select MARKER secondary softkey to toggle the marker on and off. Marker status is displayed on MARKER secondary softkey. If on, marker is displayed in the plotting area. If off, marker is not displayed.

For Y1 axis, marker is a circle (o). For Y2 axis, marker is an asterisk (*). Active marker is highlighted for the axis that is selected by AXIS softkey.

The 4155C/4156C remembers the location of marker. That is, when marker is turned off, then redisplayed, it appears at its previous location.

- **MARKER MIN/MAX softkey**

Select MARKER MIN/MAX secondary softkey to move the marker to the maximum or minimum measurement point. If this softkey moves the marker to the maximum point, pressing the softkey again moves it to the minimum point.

- **INTERPOLATE softkey**

Select INTERPOLATE secondary softkey to toggle the interpolation mode. If interpolation mode is on, marker can move on line between adjacent measurement points. If interpolation mode is off, marker can be positioned on measurement points only (not between measurement points).

Setup Screens

GRAPH/LIST Screen Group

- DIRECT MARKER/CURSOR softkey

Select DIRECT MARKER/CURSOR secondary softkey to display secondary softkeys for positioning the marker and cursor. A pointer appears in the CURSOR and MARKER coordinate fields. These fields are displayed only if cursor and marker are displayed in the plotting area.

You can move the pointer to the desired field by using the left arrow, upper arrow, right arrow and down arrow MARKER/CURSOR keys. To move marker and cursors to desired position, enter coordinate values into corresponding fields as follows:

- Enter the value by using numeric keys.
- Change the value by rotating rotary knob.

Select CANCEL primary softkey to move marker and cursor back to original position, and exit the direct marker and cursor function. Select EXIT primary softkey to exit the direct marker and cursor function.

The marker can move on the measurement curve *only*, so changing the X value automatically changes the Y value, and vice versa. If the interpolation mode is off, the marker moves to the measurement point that is closest to the specified coordinate.

If the pointer is in a MARKER coordinate field, the following softkeys appear:

- Select MIN/MAX secondary softkey to move marker to minimum measurement value. If marker is at minimum value, marker moves to maximum value.
- Select INTERPOLATE secondary softkey to toggle the interpolation mode on or off. The present mode is displayed on the INTERPOLATE softkey.
- Select SEARCH MORE secondary softkey to move marker to the next candidate (when more than one measurement point satisfies the specified value).
- Select MARKER SKIP secondary softkey to move the marker to the next measurement curve that was added by VAR2 variable or append measurement.

If the pointer is in a CURSOR coordinate field, the following softkey appears:

- Select MIN/MAX secondary softkey to move cursor to minimum axis point. If cursor is at minimum point, cursor moves to maximum point.

NOTE

When a specified value is inappropriate, marker or cursor is located as follows:

- marker
 - If the specified value for marker is greater or less than the maximum or minimum measurement value, the marker moves to the maximum or minimum *measurement point*.
- cursor
 - If a specified value for cursor is greater or less than maximum or minimum scale value, cursor moves to the maximum or minimum *axis point*.

-
- MARKER SKIP softkey

Select MARKER SKIP secondary softkey to move the marker to the next measurement curve that was added by VAR2 variable or append measurement.

- CURSOR softkey

Select CURSOR secondary softkey to toggle the cursor display. The cursor status changes between OFF, SHORT, and LONG, which is shown on the CURSOR softkey.

- AUTO ANALYSIS softkey

Select AUTO ANALYSIS secondary softkey to redisplay the auto-analysis that was originally displayed after the measurement was finished.

Setup Screens

GRAPH/LIST Screen Group

LINE softkey

Select LINE primary softkey to display the secondary softkeys for performing manual analysis that uses lines.

- CURSOR TO MARKER softkey

Select CURSOR TO MARKER secondary softkey to move the cursor to the marker position.

- LINE SELECT softkey

Selecting this secondary toggles as follows:

1 line 1 is selected, and can be operated on.

2 line 2 is selected, and can be operated on.

NONE no lines are selected. The line secondary softkeys disappear.

You use the following softkeys to operate on each line. LINE SELECT setting is not changed by auto-analysis function.

- LINE softkey

Select LINE secondary softkey to toggle the line mode between OFF and ON. You can set line on/off for line 1 and line 2 independently.

OFF Line selected by LINE SELECT softkey disappears.

ON Line selected by LINE SELECT softkey is displayed.

If ON is displayed on this softkey, and OFF is displayed on GRAD MODE, TANGENT MODE, and REGRESS MODE softkeys, the line mode is normal.

If you display lines by auto-analysis functions, you need to set LINE softkey to ON in advance.

- GRAD MODE softkey

Select GRAD MODE secondary softkey to change the line mode to gradient mode. If present mode is gradient mode, ON is displayed on the GRAD MODE softkey.

For gradient line mode, GRAD VALUE secondary softkey is displayed. If line mode is gradient mode, selecting GRAD MODE softkey changes to normal mode.

- TANGENT MODE softkey

Select TANGENT MODE secondary softkey to change the line mode to tangent mode. If present mode is tangent mode, ON is displayed on the TANGENT MODE softkey.

For tangent line mode, MARKER SKIP secondary softkey is displayed. When line mode is tangent mode, selecting TANGENT MODE softkey changes to normal mode.

- REGRESS MODE softkey

Select REGRESS MODE secondary softkey to change the line mode to regression mode. If present mode is regression mode, ON is displayed on the REGRESS MODE softkey.

For regression line mode, SELECT CURSOR secondary softkey is displayed. When line mode is regression mode, selecting REGRESS MODE softkey changes to normal mode.

- SELECT CURSOR softkey

Select SELECT CURSOR secondary softkey to exchange the active and non-active cursors. Active cursor is highlighted. This softkey is displayed only when line mode is normal or regression.

- GRAD VALUE softkey

Select GRAD VALUE secondary softkey to change the gradient value. The present gradient value is shown on this softkey and in the data entry area. This softkey is displayed only when line mode is gradient. You can change the value as follows:

- Enter number by using numeric keys.
- Change number by rotating rotary knob.

- MARKER SKIP softkey

Select MARKER SKIP secondary softkey to move the marker to the next measurement curve that was added by VAR2 variable or append measurement. This softkey is displayed only when line mode is tangent.

Setup Screens

GRAPH/LIST Screen Group

- SCALING softkey** Select SCALING primary softkey to display secondary softkeys for enlarging or reducing the plotting area.
- **AUTO SCALING softkey**

Select AUTO SCALING secondary softkey to change the X and Y scaling to fit the measurement curve in the plotting area. If Y2 axis is used, the measurement curve selected by AXIS primary softkey is auto scaled.
 - **ZOOM IN softkey**

Select ZOOM IN secondary softkey to change the X and Y scaling to half the present scaling. This enlarges measurement curve on the plot area. If the cursor is not displayed, long cursor appears at the center, then zoom is performed.
 - **ZOOM OUT softkey**

Select ZOOM OUT secondary softkey to change the X and Y scaling to double the present scaling. This reduces measurement curve on the plot area. If the cursor is not displayed, long cursor appears at the center, then zoom is performed.
 - **CENTER AT CURSOR softkey**

Select CENTER AT CURSOR secondary softkey to center the display around the cursor at the same resolution. If a cursor is not displayed, a long cursor appears at the center.
 - **CURSOR TO MARKER softkey**

Select CURSOR TO MARKER secondary softkey to move the cursor to the marker position. Both marker and cursor must be displayed.
 - **CANCEL SCALING softkey**

Select CANCEL SCALING secondary softkey to redraw the plotting area with the original settings (most recent DISPLAY: DISPLAY SETUP screen settings or RE-SETUP GRAPH settings).

DISPLAY SETUP softkey

Select DISPLAY SETUP primary softkey to display secondary softkeys for setting or changing the display.

- **RE-SETUP GRAPH softkey**

Select RE-SETUP GRAPH secondary softkey to change the user comments, variable name for each axis, minimum and maximum values for each axis, scale mode of each axis, and displayed data variables.

After you select this softkey, a pointer (highlight) appears on a setup parameter of the graph. You can move the pointer to the desired parameter by using the left arrow, upper arrow, right arrow and down arrow MARKER/CURSOR keys.

When the pointer is located in the user comment field, the present user comment is displayed in the data entry area, which you can edit by using the front panel keys.

When the pointer is located in the variable name field for X, Y1, or Y2 axis, allowable variable names are shown in the secondary softkey area. You can select secondary softkey to change the variable name for each axis.

Measurement units change automatically according to variable you select.

When the pointer is located in the maximum or minimum value field for an axis, the present maximum or minimum value is displayed in the data entry area, which you can change by using rotary knob, arrow keys, or numeric keys of the front panel.

When the pointer is located in the scale value field for an axis, LINEAR and LOG secondary softkeys are displayed. So, you can select linear or logarithmic axis mode.

When the pointer is located in the variable name field of the data variable display area, allowable variable names are shown in the secondary softkey area. Measurement units change automatically according to variable you select.

- **GRID softkey**

Select GRID secondary softkey to toggle the grid on or off in the plotting area. The present status of the grid is shown on the GRID softkey.

- **DATA VAR softkey**

Select DATA VAR secondary softkey to toggle on or off the display of data variable values. The present status of the display of the data variable display is shown on the DATA VAR softkey.

Setup Screens

GRAPH/LIST Screen Group

- LINE PRMTRS softkey

Select LINE PRMTRS secondary softkey to toggle on or off the display of line parameters (X and Y intercepts and gradients). Line parameters are displayed when *both* of the following are true:

- ON is set on this softkey
- line is displayed in the plotting area.

- OVERLAY PLANE softkey

Select OVERLAY PLANE to control which internal memory measurement curve is overlaid. This softkey toggles the internal memory number as follows:

OFF → 1 → 2 → 3 → 4 → OFF

- SHOW OVERLAY INFO softkey

Select SHOW OVERLAY INFO secondary softkey to display the following for the overlay plane: axes, cursor, marker, line, and data variables. Select EXIT primary softkey to remove information.

- SCALE TO OVERLAY softkey

Select SCALE TO OVERLAY secondary softkey to force the present scaling values to that of overlaid plane even if unit of axis is different.

SWEEP SETUP softkey

Select SWEEP SETUP primary softkey to display secondary softkeys for changing the sweep source parameters. This softkey is displayed only when SWEEP is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

To change the values on the secondary softkeys: enter number by *using numeric keys* or change number by *rotating rotary knob*.

- VAR1 START softkey

Select VAR1 START secondary softkey to change the start value of the primary sweep VAR1. The present start value is shown on this softkey and in the data entry area. Then you can change the value.

- VAR1 STOP softkey

Select VAR1 STOP secondary softkey to change the stop value of the primary sweep VAR1. The present stop value is shown on this softkey and in the data entry area. Then you can change the value.

- VAR1 STEP softkey

Select VAR1 STEP secondary softkey to change the step value of the primary sweep VAR1. The present step value is shown on this softkey and in the data entry area. Then you can change the value.

- COMP softkey

Select COMP secondary softkey to change the compliance and power compliance values of the primary sweep VAR1. The present V or I compliance value is shown on the middle line of this softkey, and the present power compliance value is shown on the last line of this softkey.

Selecting COMP softkey highlights this softkey, and the present I or V compliance value appears in the data entry area. Then you can change the value.

Then selecting COMP softkey *again* displays the present power compliance value in data entry area. Then you can change the value. To disable power compliance, you enter 0 (zero) or OFF.

- VAR2 START softkey (displayed only if VAR2 is defined)

Select VAR2 START secondary softkey to change the start value of the secondary sweep VAR2. The present start value is shown on this softkey and in the data entry area. Then you can change the value.

Setup Screens

GRAPH/LIST Screen Group

- VAR2 STEP softkey (displayed only if VAR2 is defined)

Select VAR2 STEP secondary softkey to change the step value of the secondary sweep VAR2. The present step value is shown on this softkey and in the data entry area. Then you can change the value.

- COMP softkey (displayed only if VAR2 is defined)

Select COMP secondary softkey to change the compliance and power compliance values of the secondary sweep VAR2. The present V or I compliance value is shown on the middle line of this softkey, and the present power compliance value is shown on the last line of this softkey.

Selecting COMP softkey highlights this softkey, and the present I or V compliance value appears in the data entry area. Then you can change the value.

Then selecting COMP softkey *again* displays the power compliance value in the data entry area. You can change the value. To disable the power compliance, enter 0 (zero) or OFF.

TIMING SETUP softkey

Select TIMING SETUP primary softkey to display secondary softkeys for changing the hold time, delay time, and SMU pulse parameters. This softkey is displayed only when SWEEP is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

To change the values on the secondary softkeys: enter number by *using numeric keys* or change number by *rotating rotary knob*.

- **HOLD TIME softkey**

Select HOLD TIME secondary softkey to change the hold time for the sweep measurement. The present hold time is shown on this softkey and in the data entry area. Then you can change the value. You can change the hold time while measurement is being performed.

- **DELAY TIME softkey**

Select DELAY TIME secondary softkey to change the delay time for the sweep measurement. The present delay time is shown on this softkey and in the data entry area. Then you can change the value. You can change the delay time while measurement is being performed. This softkey is not displayed when an SMU is set to VPULSE or IPULSE in the MODE field on the CHANNELS: CHANNEL DEFINITION screen.

- **PULSE BASE softkey (displayed only if SMU pulse source is defined)**

Select PULSE BASE secondary softkey to change the base value of SMU pulse. The present base value is shown on this softkey and in the data entry area. Then you can change the value.

- **PULSE PERIOD softkey (displayed only if SMU pulse source is defined)**

Select PULSE PERIOD secondary softkey to change the period of SMU pulse. The present period is shown on this softkey and in the data entry area. Then you can change the value.

- **PULSE WIDTH softkey (displayed only if SMU pulse source is defined)**

Select PULSE WIDTH secondary softkey to change the pulse width of SMU pulse. The present pulse width is shown on this softkey and in the data entry area. Then you can change the value.

**SAMPLNG SETUP
softkey**

Select SAMPLNG SETUP primary softkey to display secondary softkeys for changing the sampling parameters. This softkey is displayed only when SAMPLING is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

To change the values on the secondary softkeys: enter number by *using numeric keys* or change number by *rotating rotary knob*.

- SAMPLNG MODE softkey

Select SAMPLNG MODE secondary softkey to change the sampling mode. Selecting this softkey changes the sampling mode in the following order:

LINEAR → LOG10 → LOG25 → LOG50 → THINNED → LINEAR

- INITIAL INTRVAL softkey

Select INITIAL INTRVAL secondary softkey to change the initial interval time for sampling measurements. The present initial interval time is shown on this softkey and in the data entry area. You can change the value.

- NO. OF SAMPLES softkey

Select NO. OF SAMPLES secondary softkey to change number of samples. Present number of samples is shown on this softkey and in data entry area. Then you can change the value.

- TOT SAM TIME softkey

Select TOT SAM TIME secondary softkey to change the total sampling time for the sampling measurements. The present total sampling time is shown on this softkey and in the data entry area. Then you can change the value.

- HOLD TIME softkey

Select HOLD TIME secondary softkey to change the hold time for sampling measurements. The present hold time is shown on this softkey and in the data entry area. Then you can change the value. You can change the hold time while measurement is being performed.

STOP COND softkey

Select STOP COND primary softkey to display secondary softkeys for changing the sampling parameters. This softkey is displayed only when SAMPLING is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

To change the values on the secondary softkeys: enter number by *using numeric keys* or change number by *rotating rotary knob*.

- STOP COND softkey

Select STOP COND secondary softkey to enable or disable the stop condition. Selecting this softkey toggles between **ENABLE** and **DISABLE**.

- ENABLE DELAY softkey

Select ENABLE DELAY secondary softkey to change the enable delay time for the stop condition. The present enable delay time is shown on this softkey and in the data entry area. Then you can change the value.

- THRESHOLD softkey

Select THRESHOLD secondary softkey to change threshold value of the stop condition. The present threshold value is shown on this softkey and in the data entry area. Then you can change the value.

You can change the threshold value while measurement is being performed.

- EVENT TYPE softkey

Select EVENT TYPE secondary softkey to change the event type. Selecting this softkey changes the event type in the following order:

Val>Th → Val<Th → |Val|>|Th| → |Val|<|Th| → Val>Th

- EVENT NUMBER softkey

Select EVENT NUMBER secondary softkey to change the event number of stop condition. The present event number is shown on this softkey and in the data entry area. Then you can change the value.

Setup Screens

GRAPH/LIST Screen Group

CONST SETUP setup

Select CONST SETUP primary softkey to display secondary softkeys for changing the constant source parameters. This softkey is displayed only when CONST is set in the FCTN field on CHANNELS: CHANNEL DEFINITION screen.

Output source names appear on the secondary softkeys, and the present output value and compliance also appears. For example, when a output source named "Vce" is defined "5.0 V output with 100 mA compliance," the following softkey appears:

Vce
5.00 V
100.mA


Select the secondary softkey that you want to change. The selected softkey is highlighted, and the present output value appears in the data entry area. You can change the value.

Then selecting the same softkey *again* displays the present compliance in the data entry area. You can change the compliance.

Use the following methods to change the value:

- Enter number by using numeric keys.
- Change number by rotating rotary knob.

GRAPH/LIST: LIST screen



On the "GRAPH/LIST: LIST" screen, measurement results are displayed.

User Comment In this field, you can enter a desired comment. This comment is also displayed in the CHANNELS, MEASURE, DISPLAY, and GRAPH/LIST screen groups.

Sweep Range This field displays sweep start, stop, and step values of VAR1 primary sweep and VAR2 secondary sweep (if VAR2 sweep is selected).

List Index Number This column displays index number of each measurement point. Index number is assigned from 1 in increasing order.

For a VAR2 secondary sweep, the index continues to increase for each VAR2 step, that is, each VAR2 measurement does *not* start at index 1. For example, if VAR1 has 5 steps, then the first VAR2 step is index 1 to 5, second VAR2 step is index 6 to 10, and so on.

If you have appended measurements, index number for each append measurement starts at 1.

Setup Screens

GRAPH/LIST Screen Group

In this column head, you can confirm how many append measurements you have executed and which append you are currently viewing. Refer to the following example:

2 / 4

If the above appears in the column head, it means you have appended three measurements to the original measurement (total four measurements), and you are currently viewing the second measurement (first append measurement).

Measurement Results

These columns display measurement result data for the variables that you set up in the LIST area on the DISPLAY: DISPLAY SETUP screen. The GRAPH/LIST: LIST screen shows only four columns for the data. If you have defined more than four variable values, you can scroll right or left by using the left arrow or right arrow front-panel key.

Data Variable Display

This area displays the numerical value for the variables that you set up in the DATA VARIABLES area on DISPLAY: DISPLAY SETUP screen. This is the value of the variable at the marker position.

AXIS Y1 softkey

For GRAPH/LIST: GRAPHICS screen, this softkey is used to toggle active axis to analyze between the Y1 and Y2 axis.

For GRAPH/LIST: LIST screen, this softkey only has meaning for the data variable fields, which are just above the primary softkeys. If you set up a data variable that uses a line or marker read-out function, selecting this softkey changes displayed data variable value according to read-out function.

This softkey is displayed only if Y2 axis is set up.

MARKER softkey Select MARKER primary softkey to display secondary softkeys for operation with marker.

- **MARKER softkey**

Select MARKER secondary softkey to toggle marker display between ON and OFF. When ON is displayed on this softkey, the row at marker location is highlighted. When OFF is displayed on this softkey, no row is highlighted.

The marker on the GRAPH/LIST: LIST screen is linked to marker on the GRAPH/LIST: GRAPHICS screen. So, if marker is moved on the GRAPH/LIST: GRAPHICS screen, the marker also moves on the GRAPH/LIST: LIST screen.

The 4155C/4156C remembers the location of marker. So, if you turn marker display OFF, then the marker appears at the same location when you turn marker ON again.

- **DIRECT MARKER softkey**

Select DIRECT MARKER secondary softkey to move the marker to the specified value directly. When you select this softkey, a cell marker is displayed in the row of the marker, and the primary and secondary softkeys change as follows:

Primary softkeys:

EXIT							CANCEL
------	--	--	--	--	--	--	--------

Secondary softkeys:

	MARKER		SEARCH	MARKER			
	MIN/MAX		MORE	SKIP			

In this mode, you can move the marker to a specified value. You enter the value in the data entry area, then the marker moves to the value in list that is closest to the specified value. If you have executed append measurement, the marker moves within the append measurement you refer to.

You use the cell marker to specify the target variable (column). You can move this marker by using the left arrow, up arrow, right arrow, and down arrow MARKER/CURSOR keys.

Selecting EXIT primary softkey exits the DIRECT MARKER function.

Setup Screens

GRAPH/LIST Screen Group

Selecting CANCEL primary softkey returns the marker to the same position as before selecting the DIRECT MARKER secondary softkey.

- MARKER MIN/MAX softkey

Select MARKER MIN/MAX secondary softkey to move the marker to where the measured value is maximum or minimum value. If the marker is on the minimum value, selecting this softkey moves to the maximum value. Otherwise, selecting this softkey moves to the minimum value.

- SEARCH MORE softkey

Select SEARCH MORE secondary softkey to move marker to next candidate that satisfies specified value. If consecutive values also satisfy specified value, the next search starts after the consecutive values.

- MARKER SKIP softkey

Select MARKER SKIP secondary softkey to move the marker to the next VAR2 value or to the next appended measurement data.

- MARKER SKIP softkey

Select MARKER SKIP secondary softkey to move the marker to the next VAR2 value or to the next appended measurement data.

- NEXT APPEND softkey

Select NEXT APPEND secondary softkey to move the marker to the next appended measurement data.

SPREADSHEET softkey

Select SPREAD SHEET primary softkey to display ASCII SAVE window. The following entry fields appear:

FUNCTION:ASCII SAVE			
NAME			
	UNIT		
OUTPUT DATA (INDEX NO)	DELIMITER		
<-->	STRING MARK		

Also, the following softkeys appear:

- Select EXECUTE softkey to store result data to diskette file or network disk.
- Select EXIT softkey to exit the ASCII SAVE window.
- Select FILE CATALOG secondary softkey to list the names of all files that are on diskette or network disk. You can select a file name from the list.

ASCII SAVE function automatically adds TXT extension to specified file name.

- NAME

Enter the name of file (without extension) to which you want to save the result data.

- OUTPUT DATA

Enter numbers to specify range of data you want to save. These numbers correspond to NO. column of LIST screen.

- right field: upper limit
- left field: lower limit

Select ALL secondary softkey to specify all result data.

- UNIT

Specify whether to include units (for example, V or mS).

- ON secondary softkey to include units.
- OFF secondary softkey to not include units.

For ON, result data is saved as string data, not numeric data. So result data is saved with specified string marker. For string marker, see description of STRING MARK field. Ineffective value (----) is treated as string, even if you set this field to OFF.

Setup Screens

GRAPH/LIST Screen Group

- DELIMITER

Specify the data delimiter:

- SPACE secondary softkey to specify space.
- TAB secondary softkey to specify tab.
- COMMA secondary softkey to specify comma.

- STRING MARK

Specify the string marker:

- NONE secondary softkey to specify no string marker.
- " " secondary softkey to specify double quotes string marker.
- ' ' secondary softkey to specify single quotes string marker.

RE-SETUP softkey Select RE-SETUP primary softkey to change the user comments, variable name for each column, and displayed data variables.

After you select this softkey, a pointer (highlight) appears on the variable name of the first column. You can move the pointer to the desired parameter by using the left arrow, up arrow, right arrow, and down arrow MARKER/CURSOR keys.

When the pointer is located in the user comment field, the present user comment appears in the data entry area, and you can edit it using edit keys.

When the pointer is located in the variable name field, allowable variable names are shown in the secondary softkey area. Measurement units change automatically according to variable you select.

When the pointer is located in the data variable display area, allowable variable names are shown in the secondary softkey area. Measurement units change automatically according to variable you select.

**SWEEP SETUP
softkey**

Select SWEEP SETUP primary softkey to display secondary softkeys for changing the sweep source parameters. This softkey is displayed only when SWEEP is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

To change the values on the secondary softkeys: enter number by *using numeric keys* or change number by *rotating rotary knob*.

- VAR1 START softkey
Select VAR1 START secondary softkey to change the start value of the primary sweep VAR1. The present start value is shown on this softkey and in the data entry area. Then you can change the value.
- VAR1 STOP softkey
Select VAR1 STOP secondary softkey to change the stop value of the primary sweep VAR1. The present stop value is shown on this softkey and in the data entry area. Then you can change the value.
- VAR1 STEP softkey
Select VAR1 STEP secondary softkey to change the step value of the primary sweep VAR1. The present step value is shown on this softkey and in the data entry area. Then you can change the value.
- COMP softkey
Select COMP secondary softkey to change the compliance and power compliance values of the primary sweep VAR1. The present V or I compliance value is shown on the middle line of this softkey, and the present power compliance value is shown on the last line of this softkey.

Selecting COMP softkey highlights this softkey, and the present I or V compliance value appears in the data entry area. You can change the value.

Then selecting COMP softkey *again* displays the present power compliance value in the data entry area. You can change the value. To disable the power compliance, enter 0 (zero) or OFF.
- VAR2 START softkey (displayed only if VAR2 is defined)
Select VAR2 START secondary softkey to change the start value of the secondary sweep VAR2. The present start value is shown on this softkey and in the data entry area. Then you can change the value.
- VAR2 STEP softkey (displayed only if VAR2 is defined)
Select VAR2 STEP secondary softkey to change the step value of the secondary sweep VAR2. The present step value is shown on this softkey and in the data entry area. Then you can change the value.
- COMP softkey (displayed only if VAR2 is defined)
Select COMP secondary softkey to change the compliance and power compliance values of the secondary sweep VAR2. The present V or I compliance value is shown on the middle line of this softkey, and the present power compliance value is shown on the last line of this softkey.

Setup Screens

GRAPH/LIST Screen Group

Selecting COMP softkey highlights this softkey, and the present I or V compliance value appears in the data entry area. You can change the value.

Then selecting COMP softkey *again* displays the power compliance value in the data entry area. You can change the value. To disable the power compliance, enter 0 (zero) or OFF.

TIMING SETUP softkey

Select TIMING SETUP primary softkey to display secondary softkeys for changing the hold and delay time and SMU pulse parameters. This softkey is displayed only when SWEEP is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

To change the values on the secondary softkeys: enter number by *using numeric keys* or change number by *rotating rotary knob*.

- **HOLD TIME softkey**

Select HOLD TIME secondary softkey to change the hold time for the sweep measurement. The present hold time is shown on this softkey and in the data entry area. Then you can change the value. You can change the hold time while measurement is being performed.

- **DELAY TIME softkey**

Select DELAY TIME secondary softkey to change the delay time for the sweep measurement. The present delay time is shown on this softkey and in the data entry area. Then you can change the value. You can change the delay time while measurement is being performed. This softkey is not displayed when an SMU is set to VPULSE or IPULSE in the FCTN field on the CHANNELS: CHANNEL DEFINITION screen.

- **PULSE BASE softkey (displayed only if SMU pulse source is defined)**

Select PULSE BASE secondary softkey to change the base value of SMU pulse. The present base value is shown on this softkey and in the data entry area. Then you can change the value.

- **PULSE PERIOD softkey (displayed only if SMU pulse source is defined)**

Select PULSE PERIOD secondary softkey to change the period of SMU pulse. The present period is shown on this softkey and in the data entry area. Then you can change the value.

- **PULSE WIDTH softkey (displayed only if SMU pulse source is defined)**

Select PULSE WIDTH secondary softkey to change the pulse width of SMU pulse. The present pulse width is shown on this softkey and in the data entry area. Then you can change the value.

**SAMPLNG SETUP
softkey**

Select SAMPLNG SETUP primary softkey to display secondary softkeys for changing the sampling parameters. This softkey is displayed only when SAMPLING is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

- SAMPLNG MODE softkey

Select SAMPLNG MODE secondary softkey to change the sampling mode. Selecting this softkey changes the sampling mode in the following order:

LINEAR → LOG10 → LOG25 → LOG50 → THINNED → LINEAR

- INITIAL INTRVAL softkey

Select INITIAL INTRVAL secondary softkey to change the initial interval time for sampling measurements. The present initial interval time is shown on this softkey and in the data entry area. Then you can change the value.

- NO. OF SAMPLES softkey

Select NO. OF SAMPLES secondary softkey to change the number of samples. The present number of samples is shown on this softkey and in the data entry area. Then you can change the value.

- TOT SAM TIME softkey

Select TOT SAM TIME secondary softkey to change the total sampling time for the sampling measurements. The present total sampling time is shown on this softkey and in the data entry area. Then you can change the value.

- HOLD TIME softkey

Select HOLD TIME secondary softkey to change the hold time for sampling measurements. The present hold time is shown on this softkey and in the data entry area. Then you can change the value.

You can change the hold time while measurement is being performed.

STOP COND softkey

Select STOP COND primary softkey to display secondary softkeys for changing the sampling parameters. This softkey is displayed only when SAMPLING is selected in the MEASUREMENT MODE field on the CHANNELS: CHANNEL DEFINITION screen.

- STOP COND softkey

Select STOP COND secondary softkey to enable or disable the stop condition. Selecting this softkey toggles between ENABLE and DISABLE.

- ENABLE DELAY softkey

Select ENABLE DELAY secondary softkey to change the enable delay time for the stop condition. The present enable delay time is shown on this softkey and in the data entry area. Then you can change the value.

- THRESHOLD softkey

Select THRESHOLD secondary softkey to change threshold value of the stop condition. The present threshold value is shown on this softkey and in the data entry area. Then you can change the value.

You can change the threshold value while measurement is being performed.

- EVENT TYPE softkey

Select EVENT TYPE secondary softkey to change the event type. Selecting this softkey changes the event type in the following order:

Val>Th → Val<Th → |Val|>|Th| → |Val|<|Th| → Val>Th

- EVENT NUMBER softkey

Select EVENT NUMBER secondary softkey to change the event number of stop condition. The present event number is shown on this softkey and in the data entry area. Then you can change the value.

CONST SETUP softkey

Select CONST SETUP primary softkey to display secondary softkeys for changing the constant source parameters. This softkey is displayed only when CONST is set in the FCTN field on CHANNELS: CHANNEL DEFINITION screen.

Output source names appear on the secondary softkeys, and the present output value and compliance also appears. For example, when a output source named "Vce" is defined "5.0 V output with 100 mA compliance," the following softkey appears:

Vce
5.00 V
100.mA

Select the secondary softkey that you want to change. The selected softkey and is highlighted, and the present output value appears in the data entry area. You can change the value.

Then selecting the same softkey *again* displays the compliance value in the data entry area. You can change the compliance.

Use the following methods to change the value:

- Enter number by using numeric keys.
- Change number by rotating rotary knob.

STRESS Screen Group

STRESS screen group has the following screens:

- | | |
|----------------------------|--|
| Stress channel definition: | For defining the stress channels of the 4155C/4156C, setting up SMU/PG selector, and setting up the trigger. |
| Stress setup: | For setting the stress parameters. |
| Stress force: | For monitoring the progress of stress forcing. |

To move into the STRESS screen group, do the following:

- Press Stress front-panel key in the PAGE CONTROL key group.

Then the following softkeys appear in the primary softkey area:

CHANNEL	STRESS	STRESS				PREV	NEXT
DEF	SETUP	FORCE				PAGE	PAGE

- Select CHANNEL DEF softkey to move to the STRESS: CHANNEL DEFINITION screen.
- Select STRESS SETUP softkey to move to the STRESS: STRESS SETUP screen.
- Select STRESS FORCE softkey to move to the STRESS: STRESS FORCE screen.

When you press the **Stress** front-panel key in the MEASUREMENT key group, the STRESS: STRESS FORCE screen appears and stress forcing starts.

Setup Screens

STRESS Screen Group

- **MODE of STRESS**

Output mode for each unit that will be used during stress force state. In the MODE column, allowable modes are shown in the secondary softkey area as follows, and you select a softkey to set an output mode.

V dc voltage source

I dc current source

VPULSE ac voltage source

COMMON circuit common

DELETE ROW Deletes all entries in row of unit, so unit is not used during stress force. Output switch of unit is open.

Allowable modes for each unit are shown in the following table:

	V	I	VPULSE	COMMON	DELETE ROW
SMU	yes	yes		yes	yes
VSU	yes				yes
PGU	yes		yes		yes
GNDU				yes	yes

When pointer is at *top of this column*, CHANNEL ASSIGN softkey appears:

- **NAME of STRESS (optional)**

Defines stress name that is used as a reference on STRESS: STRESS SETUP screen. In this column, enter a desired name by using alphanumeric keys.

When pointer is in field of this column, DELETE ROW softkey is shown in secondary softkey area: clears all the entries for a unit where the pointer is located, and disables that unit.

Restriction:

- NAME must be 6 or less alphanumeric characters. First character must be alphabet character.

- FCTN of STRESS

This field defines channels to be stress force channels or non-stress force channels. In this field, select:

- SYNC secondary softkey to set channel to stress force channel.
- NSYNC secondary softkey to set channel to non-stress force channel.

The output timing is different for stress force channels and non-stress force channels:

- Non-stress force channels output the source values in the order specified on the MEASURE: OUTPUT SEQUENCE screen *when state changes from idle to stress*.
- Stress force channels output the stress source values simultaneously *when the stress start trigger is received*.

For details about output sequence, see *User's Guide: Measurement and Analysis*.

Restrictions:

- At least *one* channel must be set to SYNC.
- Up to four channels can be set to SYNC.
- If both PGUs are set to pulsed source (VPULSE), you cannot set one PGU to SYNC and other PGU to NSYNC. Both must be set to SYNC or both to NSYNC.

NOTE**Switching units**

To switch the STRESS MODE, NAME, and FCTN assignments for two units, do as follows:

1. Position pointer in top field of STRESS MODE column. CHANNEL ASSIGN softkey appears.
2. Select CHANNEL ASSIGN. Pointer moves to the top field of UNIT column.
3. Use arrow keys in the MARKER/CURSOR key group to move pointer to desired row.
4. Select the secondary softkey of the desired unit. The selected unit appears at the pointer.

Perform steps 3 and 4 until you assign units as desired. Make sure that the same unit is not assigned to multiple rows. Then select EXIT CHANNEL ASSIGN softkey.

Setup Screens

STRESS Screen Group

SMU/PG SELECTOR

Agilent 16440A SMU/PG selector's operation is defined in the SMU/PG SELECTOR table. Switches in the SMU/PG selector are controlled as defined in these fields. MEASURE column sets the switch connections for measurement state. STRESS column sets the switch connections for stress force state.

When the pointer is located in this table, the following softkeys appear:

SMU	Will connect DUT to SMU.
PGU	Will connect DUT to PGU.
OPEN	Will disconnect DUT from both SMU and PGU.
PGU OPEN	Will disconnect DUT from both PGU and SMU. But PGU is disconnected by using semiconductor switch. The normal relay switch for PGU stays closed. This is used to prevent the normal relay switch from being damaged. Semiconductor switch has longer life than normal relay switch. Note that CH2 and CH4 do not have this function.

For details about the SMU/PG selector, refer to *Agilent 16440A User's Guide*.

TRIGGER SETUP

In the TRIGGER SETUP table, you can set how to use the trigger function during the stress force state.

- **ENABLE/DISABLE**

In the ENABLE or DISABLE field, select:

- **ENABLE** secondary softkey to enable the trigger function.
- **DISABLE** secondary softkey to disable the trigger function.

- **POLARITY**

In this field, select:

- **POSITIVE** secondary softkey to set positive logic for the output trigger.
- **NEGATIVE** secondary softkey to set negative logic for the output trigger.

STRESS: STRESS SETUP screen

STRESS: STRESS SETUP01JAN15 06:39PM

User Comment

FREE RUN

*STRESS MODE

DURATION

1.0ms

*ACCUMULATED STRESS

0.000000 s

*HOLD TIME

0.000000 s

*FILTER

OFF

*STRESS

CONTINUE AT ANY

Status

*CONSTANT

UNIT	SMU2:HR	SMU3:HR	SMU4:HR	VSU1
NAME	V2	V3	V4	VSU1
MODE	V	V	V	V
SOURCE	0.0000 V	0.0000 V	0.0000 V	0.0000 V
COMPLIANCE	100.00mA	100.00mA	100.00mA	-----

*PULSE

UNIT	PGU1	PGU2
NAME	PGU1	PGU2
PERIOD	10.00ms	-----
WIDTH	5.00ms	5.00ms
DELAY TIME	0.0000 s	0.0000 s
PEAK VALUE	100mV	100mV
BASE VALUE	0.0000 V	0.0000 V
LEADING TIME	100ns	100ns
TRAILING TIME	100ns	100ns
IMPEDANCE	LOW	LOW

0.001

Enter Duration (0.0005 to 3.1536E+07).

B

CHANNEL

STRESS

STRESS

S

PREV

NEXT

DEF

SETUP

FORCE

PAGE

PAGE

On the "STRESS: STRESS SETUP" screen, you set the stress parameters.

User Comment

In this field, you can enter a desired comment. The comment you enter here is also displayed on the other STRESS screens.

STRESS MODE

STRESS MODE table specifies the stress mode. When the stress mode is pulse count mode, you specify the number of pulse counts, and when the stress mode is duration mode, you specify the stress duration in seconds. For details of stress mode, refer to *User's Guide: Measurement and Analysis*. In the first field, select:

- DURATION secondary softkey to set the duration mode. Then, enter the pulse stress duration in the next field by using numeric keys.
- PULSE COUNT secondary softkey to set the pulse count mode. Then, enter the pulse count in the next field by using numeric keys. This softkey appears only for ac stress: PGU set to VPULSE and SYNC.

In the next field, FREE RUN secondary softkey appears. Select the FREE RUN softkey to force stress *continuously*. Entering 0 (zero) also sets to free run mode.

Setup Screens

STRESS Screen Group

ACCUMULATED STRESS

The ACCUMULATED STRESS field on this screen and on STRESS: STRESS FORCE screen are linked. So, if value is changed on this screen, value is changed to same value on STRESS: STRESS FORCE screen and vice versa.

To change the displayed accumulated stress time, enter the time in this field. Selecting RESET ACCUM STRESS secondary softkey resets the displayed accumulated stress time to 0 (zero).

HOLD TIME

In the HOLD TIME, you can set the hold time. After the stress force state starts, the stress force channels wait the specified hold time, then start forcing stress at the same time.

For details about hold time, see *User's Guide: Measurement and Analysis*.

FILTER

FILTER field specifies SMU filter to ON or OFF. If this field is set to ON, overshoot decreases, but settling time takes several ms. If you set dc stress to short stress force time, set OFF in this field if you want the stress signal to be more pulse shaped.

STRESS Status

- Select CONT AT ANY secondary softkey (stress will continue even if an abnormal status occurs). Abnormal status means the following:
 - SMU reaches its compliance setting.
 - Current of VSU exceeds ± 100 mA.
 - SMU or VSU oscillates.
 - A/D converter overflow occurs.
 - Average current of PGU exceeds ± 100 mA.
- Select STOP AT ANY ABNORM secondary softkey (stress will stop if any abnormal status occurs).
- Select STOP AT COMPLIANCE secondary softkey (stress will stop only if SMU reaches its compliance setting).

STOP AT ANY ABNORM and STOP AT COMPLIANCE secondary softkeys are displayed only when specified duration is more than 10 s. If you set pulse count mode, these secondary softkeys are displayed only when *pulse period* $\times$ *pulse count* is more than 10 s.

Stress stop function is not effective until stress has been forced for 10 s.

CONSTANT

The UNIT, NAME, and MODE are defined on STRESS: CHANNEL DEFINITION screen.

On the STRESS: CHANNEL DEFINITION screen you set the SMUs and VSUs as follows:

- dc stress: MODE= I (SMUs only) or V, FCTN=SYNC
- dc non-stress: MODE=I (SMUs only) or V, FCTN=NSYNC

CONSTANT table is for setting the output parameters of SMUs, VSUs, and PGUs (V mode):

- SOURCE

In the SOURCE field, you specify the output value.

- COMPLIANCE

In the COMPLIANCE field, you specify the compliance value. For a VSU, this field cannot be set: compliance value is fixed to 100 mA.

If you define more than four VSUs, SMUs, and PGUs to be constant stress or non-stress units on the CHANNELS: CHANNEL DEFINITION screen, first four units appear in this table. To show other units, select NEXT UNIT secondary softkey. To scroll units, put field pointer in most right or left column, then press the left arrow or right arrow MARKER/CURSOR front-panel keys.

PULSE

UNIT and NAME are defined on STRESS: CHANNEL DEFINITION screen.

On the STRESS: CHANNEL DEFINITION screen you set the PGUs as follows:

- ac stress: MODE=VPULSE, FCTN=SYNC
- ac non-stress: MODE=VPULSE, FCTN=NSYNC
- dc stress: MODE=V, FCTN=SYNC
- dc non-stress: MODE=V, FCTN=NSYNC

PULSE table is for setting the pulse output parameters of PGUs:

- PERIOD

This field specifies the pulse period of the PGU. Both PGUs are set to same value.

- WIDTH

This field specifies pulse width, which must be less than pulse period.

Setup Screens

STRESS Screen Group

- DELAY TIME

This field specifies the delay time from the pulse start time. The delay time must be less than or equal to the pulse period.

- PEAK VALUE and BASE VALUE

These fields specify pulse peak and base values.


- LEADING TIME and TRAILING TIME

These specify transition time (10 to 90%) of leading and trailing edges.

- IMPEDANCE

This field specifies the PGU output impedance. In this field, select:

- LOW secondary softkey to set output impedance to about $0\ \Omega$
- 50 ohm secondary softkey to set output impedance to $50\ \Omega$



STRESS: STRESS FORCE screen

STRESS: STRESS FORCE01JAN15 06:40PM

User Comment

CHANGE COMMENT

*STRESS (DURATION)
1.0ms

CHANGE DURATON
1.0ms

*STATUS
0.000000000000 s 0.00000 %

*ACCUMULATED STRESS
0.000000000000 s

RESET STATUS

RESET ACCUM STRESS

CHANNEL DEF

STRESS SETUP

STRESS FORCE

S

PREV PAGE

B

On the "STRESS: STRESS FORCE" screen, you can monitor the stress status.

User Comment

In this field, you can enter a desired comment. The comment you enter here is also displayed on the other STRESS screens.

Select CHANGE COMMENT secondary softkey to enter or edit the comment in this field. When you select this softkey, you can enter or edit the comment in the data entry area.

Setup Screens

STRESS Screen Group

STRESS (DURATION)

STRESS (DURATION) field shows duration setting specified on the STRESS: STRESS SETUP screen. If the STRESS MODE is set to pulse count mode in the STRESS: STRESS SETUP screen, the duration is calculated by multiplying the pulse count by the pulse period.

Depending on the stress mode, select one of the following:

- CHANGE DURATON secondary softkey to change the stress duration.
- CHANGE PLS CNT secondary softkey to change the pulse count.

The stress mode and duration or pulse count were originally set on the STRESS: STRESS SETUP screen. The present stress duration or pulse count is shown on the softkey. When you select the softkey, the present value appears in the data entry area. You change the value as follows:

- Enter number by using numeric and edit keys.
- Change number by rotating rotary knob.

STATUS

In the STATUS field, the time that stress has been forced is displayed in seconds. And the percent completion is also displayed.

To reset stress status to 0, select RESET STATUS secondary softkey. Then, when you press the Stress front-panel key in the MEASUREMENT key group, the stress is forced for the specified duration.


If you press the Stress key after aborting the stress (pressing the Stop front-panel key), the stress is forced starting at the present status, that is, stress status is not reset to 0.

ACCUMULATED STRESS

As the time in the STATUS field increases, the time in the ACCUMULATED STRESS field on this screen and also on STRESS: STRESS SETUP screen increases by the same amount.

To reset accumulated stress on both screens to 0, select RESET ACCUM STRESS secondary softkey. To change to non-zero value, change accumulated stress on STRESS: STRESS SETUP screen.

KNOB SWEEP Screen



To start the knob sweep measurement, press the green key and then the Single front-panel key. The 4155C/4156C displays KNOB SWEEP screen, and starts measurements. To stop the knob sweep measurement, press the Stop front-panel key or a PAGE CONTROL group key.

Cursor

On the KNOB SWEEP screen, the long cursor is always displayed, and you cannot turn it off. In the CURSOR field, coordinate values of the cursor are displayed in X, Y order.

X axis setting

X axis always plots the VAR1 source value. Maximum value of X axis is the setting value of the VAR1 RANGE secondary softkey of VAR1 SETUP softkey group.

Y axis setting

Y axis always plots the measurement data of the measurement channel. You can select the measurement channel by using the secondary softkeys of the Y-AXIS ASSIGN softkey group. Maximum value of Y axis scale is the compliance value of the measurement channel.

Y-AXIS ASSIGN Softkey

This softkey is used to change the measurement channel. Before selecting this softkey, the knob sweep measurement must be stopped. So press the Stop front-panel key to change the measurement channel. To restart measurement, press the Single front-panel key.

If you connect R-box to the VAR1 channel, and set the VAR1 to V force mode, the measurement channel is automatically decided to the VAR1 channel. In this setup, this softkey is not be displayed.

Y-AXIS ASSIGN primary softkey displays secondary softkeys used to select the measurement channel. The measurement variable names of measurement channels are labeled on the softkeys. User function is not available for the knob sweep function. So there is no user function variable in the softkey label.

When you select a secondary softkey, the maximum absolute value(s) of the Y axis are changed to compliance value of the selected measurement channel.

SETUP COPY Softkey

This softkey is used to memorize measurement setups used in the knob sweep measurement mode. This function allows you to copy and use the setups in the normal-sweep measurement mode.

1. Select this softkey to memorize the measurement setups.
2. Quit the knob sweep measurement mode using a PAGE CONTROL group key. Then the measurement setups are copied to the normal-sweep setup screens.

The information memorized and copied is as following:

- Axis variables, axis values, and GRID settings:
copied to the DISPLAY: DISPLAY SETUP screen.
- Settings of VAR1, VAR2, CONST:
copied to the MEASURE: SWEEP SETUP screen.

Knob sweep measurement setup cannot be directly stored into a file. This function allows you to save the setup as a normal-sweep measurement setup file. But the setup data cannot be retrieved to the knob sweep mode.

DISPLAY SETUP Softkey

This softkey displays secondary softkeys for setting the display format of graphics.

X-AXIS REGION + Selects polarity of X-axis region displayed on the screen. This softkey displays present setting.

- setting

Pressing this softkey toggles polarity as follows:

+ → - → +/- → +

- default

If polarity of VAR1 stop and start value on MEASURE: SWEEP SETUP screen are same, default value is same as polarity of stop and start value.

If polarity of VAR1 stop and start value on MEASURE: SWEEP SETUP screen are different, default value is + / -.

Y-AXIS REGION + Selects polarity of Y-axis region displayed on the screen. This softkey displays present setting.

- setting

Pressing this softkey toggles the polarity in the following order:

+ → - → +/- → +

- default

polarity of VAR1 compliance value on the MEASURE: SWEEP SETUP screen

Setup Screens

KNOB SWEEP Screen

X-AXIS DISPLAY NORMAL

Selects direction of the X-axis. This softkey displays present setting.

- setting

Selecting this softkey toggles **NORMAL** or **REVERSE**.

When **NORMAL** is selected:

- *Minimum* axis value is at *left* end of X-axis.
- *Maximum* axis value is at *right* end of X-axis.

When **REVERSE** is selected:

- *Minimum* axis value is at *right* end of X-axis.
- *Maximum* axis value is at *left* end of X-axis.

- default : **NORMAL**

Y-AXIS DISPLAY NORMAL

Selects direction of the Y-axis. This softkey displays present setting.

- setting

Selecting this softkey toggles **NORMAL** or **REVERSE**.

When **NORMAL** is selected:

- *Minimum* axis value is at *bottom* of Y-axis.
- *Maximum* axis value is at *top* of Y-axis.

When **REVERSE** is selected:

- *Minimum* axis value is at *top* of Y-axis.
- *Maximum* axis value is at *bottom* of Y-axis.

- default : **NORMAL**

GRID ON

Selects grid on or off. This softkey displays present setting.

- setting

Pressing this softkey toggles the grid on or off in the plotting area.

- default : **ON**

VAR1 SETUP Softkey

This softkey displays secondary softkeys for setting the primary sweep source (VAR1) parameters.

SWEEP MODE SINGLE

Selects sweep mode. This softkey displays present setting.

- setting

Pressing this softkey toggles the sweep mode in the following order:

SINGLE → DOUBLE → SINGLE

- default

setting of the SWEEP MODE field on the MEASURE: SWEEP SETUP screen

POLAR-ITY POS

Selects polarity of sweep source. Changing the setting resets the sweep step to 0, so the sweep measurement curve goes back to 0 on the screen. This softkey displays present setting.

- setting

Pressing this softkey toggles the polarity of VAR1 channel in the following order:

POS → NEG → BIPOLAR → POS

- default

If polarity of VAR1 stop and start value on MEASURE: SWEEP SETUP screen are same, default value is same as polarity of stop and start value.

If polarity of VAR1 stop and start value on MEASURE: SWEEP SETUP screen are different, default value is BIPOLAR.

VAR1 RANGE 2V

Sets sweep range of VAR1 channel. This setting defines the maximum sweep range and resolution of VAR1 channel. This softkey displays present setting.

- setting

Select this softkey to display the VAR1 sweep range value in the data entry area, then rotate the knob to change the value. Setting value will be changed by 1-2-5 steps as shown below:

0.1 V → 0.2 V → 0.5 V → ... → 100 V → 200 V → 0.1 V

Setup Screens

KNOB SWEEP Screen

- setting range

The allowed sweep range (1-2-5) values depend on the output range of the measurement unit.

- default

Minimum value that includes *VAR1 start and stop value* that is set on the MEASURE: SWEEP SETUP screen. However the value must be 1-2-5 steps. For example, if start value is 0 V and stop value is 30 V on the MEASURE: SWEEP SETUP screen, default VAR1 range is 50 V.

NUM OF STEPS 101

Sets number of steps for VAR1 channel. For knob sweep, NO OF STEP setting on MEASURE: SWEEP SETUP screen has no meaning. This softkey displays present setting.

- setting

Press this softkey to display the number of steps in the data entry area, then you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range : 2 to 1001
- default : 101

COMPLI- ANCE 100.mA

Sets compliance value for VAR1 channel. This softkey displays present setting.

- setting

Press this softkey to display the compliance value in the data entry area. Then, you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range

Compliance range depends on measurement unit.

- default

VAR1 compliance value on the MEASURE: SWEEP SETUP screen

HOLD TIME 0.00s Sets hold time. This softkey displays present setting.

- setting

Press this softkey to display the hold time in the data entry area. Then, you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range : 0 to 655.35 s with 10 ms resolution
- default : hold time on the MEASURE: SWEEP SETUP screen

STEP TIME 500us Sets step time which is the time width of each sweep step. This softkey displays present setting.

- setting

Press this softkey to display the step time in the data entry area, then you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range : 500 μ s to 100 ms with 100 μ s resolution
- default : 500 μ s

VAR2 SETUP Softkey

This softkey displays secondary softkeys for setting the secondary sweep source (VAR2) parameters.

If VAR2 is not set for any channel on the CHANNELS: CHANNEL DEFINITION screen, this softkey is not displayed.

VAR2 START 20.0uA

Sets VAR2 start value. This softkey displays present setting.

- setting

Press this softkey to display the VAR2 start value in the data entry area. Then, you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range

Depends on the measurement unit.

- default

VAR2 start value on MEASURE: SWEEP SETUP screen

VAR2 STEP 20.0uA Sets VAR2 step value. This softkey displays present setting.

- setting

Press this softkey to display the VAR2 step value in the data entry area. Then, you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range

Depends on the measurement unit.

- default

VAR2 step value on MEASURE: SWEEP SETUP screen

VAR2 POINTS 5 Sets Number of steps for VAR2 channel. This softkey displays present setting.

- setting

Press this softkey to display the VAR2 number of steps in the data entry area. Then, you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range : 1 to 128

COMPLI-ANCE
2.00 V

- default

VAR2 number of steps on MEASURE: SWEEP SETUP screen

Sets compliance value for VAR2 channel. This softkey displays present setting.

- setting

Press this softkey to display the VAR2 compliance value in the data entry area. Then, you can change the setting value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range

Setting range depends on the measurement unit.

- default

VAR2 compliance value on MEASURE: SWEEP SETUP screen

CONST SETUP Softkey

This softkey displays the secondary softkeys for setting the constant voltage source parameter or the constant current source parameters. Secondary softkeys for PGUs set to V mode are also displayed.

If CONST is not set for any channel on the CHANNELS: CHANNEL DEFINITION screen, this softkey is not displayed.

If more than six constant channels are defined, press the MORE softkey to display softkeys for the other constant channels.

Secondary softkeys

The first line of each secondary softkey displays the variable name of the constant source. The second line displays *source output value*. For SMUs, the third line displays *compliance value*. For other units, the third line is blank.

- Example. If an SMU is set as follows, the following softkey appears:

```
Vce
  5.00V
 10.0mA
```

- Voltage source mode.
 - Variable name (VNAME): "Vce".
 - Output voltage value: 5.0 V.
 - Compliance value: 10 mA.
- source output value

Pressing the secondary softkey displays the source output value in the data entry area. You can change the value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- compliance value (only for SMU)

Pressing the secondary softkey twice displays the compliance value in the data entry area. You can change the compliance value by using the rotary knob, numeric keys, or arrow keys in the Edit key group.

- setting range

Each setting range depends on the measurement unit.

4 System Screens

System Screens

This chapter describes the SYSTEM screen group.

The SYSTEM screen group contains the following screens:

- “SYSTEM: FILER”

Executes the file operations (such as saving and getting files) on a diskette, in the internal memory, or on a network file system. This screen is displayed by pressing System key, or by selecting FILER softkey on a SYSTEM sub-screen.

- “SYSTEM: MISCELLANEOUS”

Miscellaneous system settings, such as GPIB addresses, the built-in clock, and network setup. This screen is displayed by selecting MISCELLANEOUS softkey on a SYSTEM sub-screen.

- “SYSTEM: CONFIGURATION”

Displays the software revision and units configuration. This screen is displayed by selecting CONFIG softkey on a SYSTEM sub-screen.

- “SYSTEM: SELF-CALIBRATION/DIAGNOSTICS”

Executes calibration and diagnostics. This screen is displayed by selecting CALIB/DIAG softkey on a SYSTEM sub-screen.

- “SYSTEM: PRINT/PLOT SETUP”

Sets the print/plot parameters. This screen is displayed by selecting PRINT SETUP softkey on a SYSTEM sub-screen.

- “SYSTEM: COLOR SETUP”

Sets the screen colors. This screen is displayed by selecting COLOR SETUP softkey on a SYSTEM sub-screen.

To move to the SYSTEM screen group, press the System key. FILER screen is displayed, and the following primary softkeys are available.

FILER	MISCEL-	CONFIG	CALIB/	PRINT	COLOR		
	LANEOUS		DIAG	SETUP	SETUP		

To start the save and get functions of the filer (SYSTEM: FILER) screen, press the Save key or Get key.

SYSTEM: FILER

On the "SYSTEM: FILER" screen, you can execute file operations from a diskette, internal memory, or the network file system.

The 4155C/4156C filer *cannot* operate on files that are created by another system. However, if the files satisfy the file name restrictions of the 4155C/4156C file system, you can use the following functions:

- purge
- rename
- copy from one diskette to another diskette

DISK

The DISK field specifies the mass storage device for the file operation. Choose the device by selecting one of the following:

FLOPPY	Specifies a diskette inserted in the built-in flexible disk drive.
drive name	The softkey label is not "drive name", but the strings entered into the LABEL field of the NETWORK DRIVE SETUP table on the SYSTEM:MISCELLANEOUS screen. See "NETWORK DRIVE SETUP" on page 4-24. When this softkey is selected, the 4155C/4156C mounts a directory on the NFS server, and displays a file catalog in the FILE CATALOG area. The directory is specified by the DIRECTORY field of the NETWORK DRIVE SETUP table. The name will be displayed in the area next to the DISK field. Before selecting this softkey, confirm that the NFS server has already exported the directory for the 4155C/4156C. To unmount the network file system, select the FLOPPY softkey, or turn off the 4155C/4156C.

FILE CATALOG

The FILE CATALOG field displays the file catalog (a maximum of 199 files) of the diskette or the network file system, and shows the following file information:

FORMAT	DOS or HP LIF format (diskette).
VOLUME	The volume name (diskette).
USED	The disk space occupied by the files (diskette).
AVAIL	The free disk space for data storage (diskette).
DIR	The name of the directory mounted by the 4155C/4156C (NFS).
FILE NAME	The file name used to identify the data.
SIZE	The file size (in bytes for DOS, in blocks for HP LIF).
DATE and TIME	The date and time when the file was created or last modified.
COMMENT	An optional comment, up to 16 characters long.

To scroll the catalog, use the rotary knob, or press the up or down arrow key.

When using the SAVE, GET, PURGE, RENAME, or COPY functions, you can specify a file name from the FILE CATALOG area. Move the pointer to the desired filename using the rotary knob or arrow keys, then press SELECT softkey.

To search for a specific file name, press the alphanumeric key for the first character of the file name. The field pointer moves to the first file name that starts with the character selected.

File Type

The following are file types (file suffixes) used by the 4155C/4156C:

MES	Measurement setup data file
STR	Stress setup data file
DAT	Measurement setup and result data file
MAT	E5250A setup data file
CST	Customized file (consists of settings from the SYSTEM screen group and the ASCII SAVE window)
PRO	4145B setup data file
PCL	Hard copy file for PCL format
PGL	Hard copy file for HP-GL format
TIF	Hard copy file for TIFF format
TXT	Measurement result data file for spreadsheets

FUNCTION

The FUNCTION field specifies the file operation. When the field pointer is on this field, the following softkeys, shown in Menu 1 and Menu 2, are available.

Menu 1:

FILE CATALOG	Reads and displays the file catalog. A maximum of 199 files can be listed. This softkey also changes the secondary softkeys to those shown in Menu 2.
SAVE	Saves the specified file.
GET	Gets the specified file.
PURGE	Purges the specified file/directory.
RENAME	Renames the specified file.
COPY	Copies the specified file.
MAKE DIRECTORY	Creates a new directory under the directory mounted by the 4155C/4156C (NFS only).
DISK OPERATION	Opens the Disk Operation screen used to initialize or copy the diskette (diskette only).

Menu 2:

FILE CATALOG	Reads and displays the file catalog. A maximum of 199 files can be listed.
EXIT FILE CATALOG	Changes the secondary softkeys to those shown in Menu 1.
CHANGE DIR	Changes the current directory to the directory specified by the pointer (NFS only).
UPPER DIR	Changes the current directory to one level higher than the current directory (NFS only).
ROOT DIR	Changes the current directory to the root directory. The root directory is always the directory specified by the NETWORK DRIVE SETUP table on the MISCELLANEOUS screen (NFS only).
READ COMMENT	Reads the COMMENT field for the specified file (diskette only).
READ COMMENT ALL	Reads the COMMENT field for all files on the diskette (diskette only).

SAVE

To start the save function, press the SAVE softkey or the Save key. Either key displays the following entry box and softkeys.

- Entry box:

FUNCTION: SAVE			
NAME			
TYPE		COMMENT	

- Softkeys:

EXECUTE	Saves the data.
EXIT	Exits the SAVE function.

TYPE field

The TYPE field specifies the data type. In this field, select:

MES	Specifies the measurement setup data.
STR	Specifies the stress setup data.
DAT	Specifies the measurement setup and result data.
MAT	Specifies the E5250A setup data.
CST	Specifies the customized system data. This softkey is <i>not</i> available for internal memory (MEM*).

For internal memory (MEM*), the first character of the TYPE (M, S or D) will be displayed in the upper-right corner of the MEM* softkey.

COMMENT field

The COMMENT field is used to enter file comments, which will be displayed in the FILE CATALOG area. A maximum of 16 characters are allowed.

For internal memory (MEM*), the comments are displayed on the MEM* softkey. A maximum of 14 characters are allowed.

NAME field

The NAME field specifies the file name of data to be saved. The file name must be:

- 6 characters (maximum) for HP LIF format. Do not use "_" as the last character of the filename.
- 8 characters (maximum) for DOS format.
- 36 characters (maximum) for a network file system, and 58 characters (maximum) including the directory path.

When the pointer is in the NAME field, the softkeys shown in Menu 1 and Menu 2 are available.

- Menu 1:

FILE

CATALOG

Reads and displays the file catalog. A maximum of 199 files can be listed. This softkey also changes the secondary softkeys to those shown in Menu 2.

MEM*

Selects the internal memory MEM1, MEM2, MEM3, or MEM4 for saving data.

- Menu 2:

FILE

CATALOG

Reads and displays the file catalog. A maximum of 199 files can be listed.

EXIT FILE

CATALOG

Changes the secondary softkeys to those shown in Menu 1.

SELECT

Selects a file name from the FILE CATALOG area. Used to update data in an existing file. The file name (NAME, TYPE and COMMENT) is specified by the pointer in the FILE CATALOG area.

System Screens

SYSTEM: FILER

Setup items that are saved to the customize (CST) file

The following setup items are stored when you set CST in the TYPE field.

- SYSTEM: PRINT/PLOT SETUP screen
 - DESTINATION
 - LANGUAGE
 - FORM FEED
 - COLOR/ B/W
 - LINE
 - COLUMN
 - RESOLUTION
 - PAPER
 - OUTPUT ITEM
 - INIT STRING
 - TRAILER STRING
- SYSTEM: COLOR SETUP screen
 - HUE
 - SATURATION
 - LUMINOSITY
 - PLOTTER PEN NO.
 - BRIGHTNESS
- SYSTEM: MISCELLANEOUS screen
 - REMOTE CONTROL
 - BEEP
 - NETWORK PRINTER SETUP
 - NETWORK DRIVE SETUP
- ASCII SAVE WINDOW
 - UNIT
 - DELIMITER
 - STRING MARK
- hard copy setup window
 - DESTINATION
 - FILE NAME
 - OUTPUT REGION
 - PRINT/PLOT COMMENT
 - OUTPUT PAGE
 - GRAPH TRACE ONLY
 - OUTPUT DATA
 - PRINT SETUP DATA
- INIT file start screen displayed after getting the INIT file

GET

To start the get function, press the GET softkey or the Get key. Either key will display the following entry box and primary softkeys.

- Entry box:

FUNCTION:GET

NAME

TYPE

- Softkeys:

EXECUTE	Gets (retrieves) the specified data.
EXIT	Exits the GET function.

TYPE field

The TYPE field specifies the data type. In this field, select:

MES	Specifies the measurement setup data.
STR	Specifies the stress setup data.
DAT	Specifies the measurement setup and result data.
MAT	Specifies the E5250A setup data.
CST	Specifies the customized system data.
PRO	Specifies the 4145B setup data.

NOTE

Number of Sweep Steps

The 4155C/4156C can also read the DAT file saved by the 4145B. When the 4155C/4156C reads the 4145B data file, if the number of primary sweep steps is more than 1001, the 4155C/4156C sets the number of sweep steps to 1001, and discards the corresponding measurement results.

System Screens
SYSTEM: FILER

NAME field

The NAME field specifies the file name to get. When the pointer is in this field, the softkeys shown in Menu 1 and Menu 2 are available.

- Menu 1:

FILE

CATALOG

Reads and displays the file catalog. A maximum of 199 files can be listed. This softkey also changes the softkeys to those shown in Menu 2.

MEM*

Selects the internal memory MEM1, MEM2, MEM3, or MEM4 for getting data.

On the softkey label, a notation in the upper-right corner shows the data type:

M: MES data or PRO data

S: STR data

D: DAT data

- Menu 2:

FILE

CATALOG

Reads and displays the file catalog. A maximum of 199 files can be listed.

EXIT FILE

CATALOG

Changes the secondary softkeys to those shown in Menu 1.

SELECT

Selects the file to get. The file is specified by the pointer in the FILE CATALOG area.

PURGE

To start the purge function, press PURGE. The following entry box and softkeys are displayed.

- Entry box:

FUNCTION: PURGE

NAME

TYPE

- Softkeys:

EXECUTE Purges (deletes) the specified data.

EXIT Exits the PURGE function.

TYPE field

The TYPE field specifies the data type. In this field, select:

- * Specifies all types of data.
- MES** Specifies the measurement setup data.
- STR** Specifies the stress setup data.
- DAT** Specifies the measurement setup and result data.
- MAT** Specifies the E5250A setup data.
- CST** Specifies the customized system data.
- PRO** Specifies the 4145B setup data.

System Screens

SYSTEM: FILER

NAME field

The NAME field specifies the file name or directory name to purge (delete). The directory to be purged must be empty. When the pointer is in this field, the softkeys shown in Menu 1 and Menu 2 are available.

- Menu 1:

FILE

CATALOG

Reads and displays the file catalog. A maximum of 199 files can be listed. This softkey also changes the secondary softkeys to those shown in Menu 2.

MEM*

Selects the internal memory MEM1, MEM2, MEM3, or MEM4 for deleting data.

On the softkey label, a notation in the upper-right corner shows the data type:

M: MES data or PRO data

S: STR data

D: DAT data

- Menu 2:

FILE

CATALOG

Reads and displays the file catalog. A maximum of 199 files can be listed.

EXIT FILE

CATALOG

Changes the secondary softkeys to those shown in Menu 1.

SELECT

Selects the file or directory to be purged. The file or directory is specified by the pointer in the FILE CATALOG area.

RENAME

This function is available for a file on the diskette or on the network file system mounted by the 4155C/4156C. This function is *not* available for the directory on the network file system.

The following entry box and primary softkeys are displayed.

- Entry box:

FUNCTION: RENAME

NAME

TYPE

NEW NAME

- Softkeys:

EXECUTE	Renames the file.
EXIT	Exits the RENAME function.

TYPE field

The TYPE field specifies the data type. In this field, select:

MES	Specifies the measurement setup data.
STR	Specifies the stress setup data.
DAT	Specifies the measurement setup and result data.
MAT	Specifies the E5250A setup data.
CST	Specifies the customized system data.
PRO	Specifies the 4145B setup data.

NAME field

The NAME field specifies the file to rename. The NEW NAME field specifies a new file name. The file name must be:

- 6 characters (maximum) for HP LIF format. Do not use "_" as the last character of the filename.
- 8 characters (maximum) for DOS format.
- 36 characters (maximum) to store on a network file system, and a total of 58 characters including the directory path.

System Screens

SYSTEM: FILER

When the pointer is in the NAME field, the softkeys shown in Menu 1 and Menu 2 are available.

- Menu 1:

FILE CATALOG	Reads and displays the file catalog. A maximum of 199 files can be listed. This softkey also changes the secondary softkeys to those shown in Menu 2.
-------------------------	---

- Menu 2:

FILE CATALOG	Reads and displays the file catalog. A maximum of 199 files can be listed.
-------------------------	--

EXIT FILE CATALOG	Changes the secondary softkeys to those shown in Menu 1.
------------------------------	--

SELECT SOURCE	Selects the file to be renamed. The file name (NAME and TYPE) is specified by the pointer in the FILE CATALOG area.
--------------------------	---

SELECT TARGET	Selects the new file name from the FILE CATALOG area. The file name (NEW NAME) is specified by the pointer in the FILE CATALOG area.
--------------------------	--

READ COMMENT	Reads the comments for the file specified by the pointer in the FILE CATALOG area (diskette only).
-------------------------	--

READ COMMENT ALL	Reads the comments for all files listed in the FILE CATALOG area (diskette only).
---------------------------------	---

COPY

This function is used to copy files between a diskette and internal memory, between two diskettes, within a diskette, within the network file system the 4155C/4156C mounts, or between the network file system and internal memory.

The following entry box and primary softkeys will be displayed.

- Entry box:

FUNCTION: COPY		
SOURCE NAME		
TYPE		TARGET DISK
TARGET NAME		

- Softkeys:

EXECUTE	Copies the data.
EXIT	Exits the COPY function.

TYPE field

The TYPE field specifies the data type. In this field, select:

- | | |
|------------|--|
| * | Specifies all types of data. |
| MES | Specifies the measurement setup data. |
| STR | Specifies the stress setup data. |
| DAT | Specifies the measurement setup and result data. |
| MAT | Specifies the E5250A setup data. |
| CST | Specifies the customized system data. |
| PRO | Specifies the 4145B setup data. |

TARGET DISK field

The TARGET DISK field specifies whether the source and target files are on the same diskette or different diskettes. The following secondary softkeys are available:

- | | |
|--------------|--|
| SAME | The target file is on the same diskette as the source file. |
| OTHER | The target file is on a different diskette than the source file. |

System Screens

SYSTEM: FILER

SOURCE NAME, TARGET NAME fields

The SOURCE NAME field specifies the file name to be copied. The TARGET NAME field specifies the new name for the file.

The file name must be:

- 6 characters (maximum) for HP LIF format. Do not use "_" as the last character of the filename.
- 8 characters (maximum) for DOS format.
- 36 characters (maximum) to store on a network file system, and a total of 58 characters including the directory path.

When the pointer is in this field, the softkeys shown in Menu 1 and Menu 2 are available.

- Menu 1:

FILE CATALOG	Reads and displays the file catalog. A maximum of 199 files can be listed. This softkey also changes the secondary softkeys to those shown in Menu 2.
MEM*	Specifies data in internal memory MEM1, MEM2, MEM3, or MEM4.

- Menu 2:

FILE CATALOG	Reads and displays the file catalog. A maximum of 199 files can be listed.
EXIT FILE CATALOG	Changes the secondary softkeys to those shown in Menu 1.
SELECT SOURCE	Selects the file to be copied. The file name (SOURCE NAME and TYPE) is specified by the pointer in the FILE CATALOG area.
SELECT TARGET	Selects the new file name from the FILE CATALOG area. The file name (TARGET NAME) is specified by the pointer in the FILE CATALOG area.
READ COMMENT	Reads the comment for the file specified by the pointer on the FILE CATALOG area (diskette only).
READ COMMENT ALL	Reads the comments for all files listed in the FILE CATALOG area (diskette only).

MAKE DIRECTORY

This function creates a subdirectory on the NFS server. The subdirectory will be under the directory mounted by the 4155C/4156C.

The following entry box and primary softkeys will be displayed.

- Entry box:

FUNCTION:MAKE DIRECTORY

NAME

- Softkeys:

EXECUTE Makes a directory with the specified name.

EXIT Exits the MAKE DIRECTORY function.

NAME field

The NAME field specifies the new directory name.

The directory name can be up to 36 characters, and 58 characters when including the directory path.

When the pointer is in this field, the softkeys shown in Menu 1 and Menu 2 are available.

- Menu 1:

FILE CATALOG Reads and displays the file catalog. A maximum of 199 files can be listed. This softkey also changes the secondary softkeys to those shown in Menu 2.

- Menu 2:

FILE CATALOG Reads and displays the file catalog. A maximum of 199 files can be listed.

EXIT FILE CATALOG Changes the secondary softkeys to those shown in Menu 1.

SELECT Selects the directory name. The directory is specified by the pointer in the FILE CATALOG area.

DISK OPERATION

This function allows you to initialize a diskette or to copy all the files on a diskette, and is available when the DISK field is set to FLOPPY DISK.

This softkey displays the disk operation function screen, which displays the following softkeys and fields.

EXECUTE Executes the specified operation for the diskette.

EXIT Exits the disk operation screen.

DISK OPERATION field The DISK OPERATION field selects the desired operation by using the following secondary softkeys.

DISK INIT Initializes the diskette. Initialization prepares the diskette so that the 4155C/4156C can use it for storing data.

DISK COPY Copies the entire contents of one diskette to another. This is typically used to make a backup copy. The diskettes must have the same format and capacity.

FORMAT field The FORMAT field (only for DISK INIT) selects the DOS or HP LIF format.

VOLUME LABEL field The VOLUME LABEL field (only for DISK INIT) specifies a volume label for the diskette. The default volume name is "4155" or "4156". You *cannot* specify a blank label.

The volume name can be up to 8 characters for DOS format or up to 6 characters for HP LIF format.

PROGRESS STATUS field The PROGRESS STATUS field displays the progress of the initialization or copy operation.

SYSTEM: MISCELLANEOUS

The SYSTEM: MISCELLANEOUS screen contains miscellaneous settings for the 4155C/4156C.

4155C is, 4156C is

This field specifies the GPIB operation mode for the 4155C/4156C. The following softkeys appear:

SYSTEM

CONTROLLER Selects the 4155C/4156C as the system controller. If you use IBASIC, select this softkey.

NOT SYSTEM

CONTROLLER Sets the 4155C/4156C for use with an external system controller.

GPIB ADDRESS

This field specifies the addresses of the 4155C/4156C and the output device.

4155C/4156C Enter the GPIB address of the 4155C/4156C.

HARD COPY Enter the GPIB address of the printer or plotter connected to the 4155C/4156C.

REMOTE CONTROL

This table specifies the remote control command set as follows. The DELIMITER and EOI entry fields are available for the 4145 command set.

COMMAND SET Select the 4155/4156 or 4145 command set.

DELIMITER Select a comma or a carriage return and line feed (CR/LF).

EOI Set EOI on or off.

NOTE

Changing the COMMAND SET Field

If you change the COMMAND SET field, the 4155C/4156C will be reset, and the setup data will be lost.

CLOCK

This table sets the present date and time. Change the date and time using the number keys, or UP/DOWN softkeys. Then press the SET softkey to apply the change.

POWER LINE FREQUENCY

This field selects the power line frequency. The selectable frequencies are 50 or 60 Hz.

SYSTEM SETUP

This table specifies the following parameters.

BEEP	This field turns the beep sound ON or OFF.
SCREEN SAVE	This field sets the time interval before the screen saver is activated (the screen does not display anything). The time interval can be 0 to 60 minutes. To release the screen saver, touch any key or the rotary knob. To disable the screen saver, enter 0 (zero).
LP TIMEOUT	This field sets the maximum time to confirm the connection with the printer server defined in the NETWORK PRINTER SETUP table. The 4155C/4156C waits for a response from the printer server when a hard copy is requested. If the 4155C/4156C does not receive a response within the time specified by this setting, a time-out error will occur. The time-out can be set from 1 to 32767 seconds.

NETWORK SETUP

This setup table specifies the network setup parameters. If you connect the 4155C/4156C to your local network, you must complete this table.

The 4155C/4156C stores the setup in its internal memory and keeps the setup data until you change it, even if you turn off the unit.

NOTE

Network Function

The 4155C/4156C can be an NFS client, and can use a remote printer to make hard copies. This allows you to access a file on a network file system on your NFS server, and to make hard copies using the remote printer via your printer server.

- To use the 4155C/4156C as an NFS client:
 1. Fill in the NETWORK SETUP table.
 2. Fill in the NETWORK DRIVE SETUP table.
 3. Access the file using the SYSTEM: FILER screen.
- To use a remote printer:
 1. Fill in the NETWORK SETUP table.
 2. Fill in the NETWORK PRINTER SETUP table.
 3. Fill in the SYSTEM: PRINT/PLOT SETUP screen.
 4. Make hard copies using the PRINT/PLOT dialog box.

NOTE

Network Setup

If you are uncertain as to your local network configuration, or have questions concerning the network setup parameters, contact your network system administrator.

System Screens

SYSTEM: MISCELLANEOUS

HOST NAME	The host name of the 4155C/4156C. A maximum of 15 characters is allowed.
IP ADDRESS	The IP address of the 4155C/4156C. String of up to 15 characters. The default setting is '0.0.0.0', which is an invalid number for the IP ADDRESS.
SUBNET MASK	The subnet mask of the network the 4155C/4156C connects. String of up to 15 characters. The value 255.255.255.255 is invalid. The string 0.0.0.0 automatically sets the default value of the class specified by the IP ADDRESS value. The default value is 255.0.0.0 for class A, 255.255.0.0 for class B, or 255.255.255.0 for class C. You cannot set the subnet mask to a higher class value than the class the 4155C/4156C belongs to.
GATEWAY	If you access a network out of the subnet, enter the IP address of the gateway. A string of up to 15 characters. If you access the network within the subnet, enter 0.0.0.0.
USER ID	Your user ID. This must be a positive integer, 0 (zero) is not allowed. The default setting is 200.
GROUP ID	Your group ID. The default setting is 100.

After you enter the HOST NAME, the 4155C/4156C displays two secondary softkeys for the HOST NAME field:

DISABLE	Disables the network function.
[]	Enables the network function and recalls the setup from memory. This softkey will be labeled with the HOST NAME you entered. For example, if you entered 'analyzer1' into the HOST NAME field, a softkey labeled analyzer1 will be displayed.

NETWORK PRINTER SETUP

This setup table specifies the setup parameters for a printer server and a printer connected to the server. After filling in this table, the setup must be stored in the internal memory. To store the setup in memory, press ADD softkey. The 4155C/4156C will use this printer as the remote printer.

The 4155C/4156C can store a maximum of four setups, and keeps the setup data until you update or delete the setup, even if the instrument is turned off.

PRINTER The printer name assigned to the remote printer, and defined on the printer server. A maximum of 15 characters is allowed.

IP ADDRESS The IP address assigned to the printer server. The default setting is '0.0.0.0', which is an invalid number for the IP ADDRESS.

TEXT OUT The text output option of the lpr command. The default setting is '-h'.

For BSD servers, this parameter must be entered as '*-option*', where *option* indicates the filtering option.

For SystemV servers, this parameter must be entered as '*-ooption*', where *option* indicates the printer option.

For more information regarding *option*, see the network operating and service manual.

GRAPH OUT The graphics output option of the lpr command. The default setting is '-h -l'.

See the TEXT OUT section above for more information.

SERVER TYPE The server type, BSD or SystemV. The default setting is BSD.

The NETWORK PRINTER SETUP table has the following softkeys available:

ADD Adds the printer setup information to the internal memory. A softkey will be created and labeled with the printer name. For example, if you enter 'printer1', and then press the ADD softkey, a printer1 softkey will be created. This key is used to call the setup information.

DELETE Deletes the setup information (on the screen and in the internal memory) specified by the PRINTER field.

UPDATE Updates the setup data in the internal memory. The setup data currently in memory is replaced with the new information in the NETWORK PRINTER SETUP table.

NETWORK DRIVE SETUP

This setup table specifies the IP address of the NFS server and the directory mounted by the 4155C/4156C. After filling in this table, the setup must be stored in the internal memory, by selecting the ADD softkey.

The 4155C/4156C can store a maximum of four setups, and keeps the data until you update or delete the setup, even if the instrument is turned off.

LABEL	The label or name of the setup information in the NETWORK DRIVE SETUP table. A maximum of 15 characters is allowed.
IP ADDRESS	The IP address of the NFS server. The default setting is '0.0.0.0', which is an invalid number for the IP ADDRESS.
DIRECTORY	The name of the directory mounted by the 4155C/4156C. A maximum of 58 characters are allowed. The default setting is '/' (the root directory). The 4155C/4156C mounts this directory and uses it as the root directory. Confirm that the NFS server has exported the directory to the 4155C/4156C.

The NETWORK DRIVE SETUP table has the following softkeys:

ADD	Adds the setup to the internal memory. After completing this table, press the ADD softkey to register the information in the internal memory. A softkey will be created and labeled. For example, if you enter 'mydir1' into the LABEL field, and then press the ADD softkey, the mydir1 softkey will be created. This softkey is used to call the setup information.
DELETE	Deletes the setup information (on the screen and in the internal memory) specified by the LABEL field.
UPDATE	Updates the setup data in the internal memory. The setup data currently in memory is replaced with the new information in the NETWORK DRIVE SETUP table.

SYSTEM: CONFIGURATION

The SYSTEM: CONFIGURATION screen contains the system firmware revision and hardware configuration for the 4155C/4156C.

ETHERNET ADDRESS

This field shows the ethernet address of the 4155C/4156C.

SOFTWARE REVISION

This table displays the following software revisions:

- host controller
- SMU controller
- A/D converter controller

CONFIGURATION

This table displays the hardware configuration for the 4155C/4156C.

CPU REVISION

This field shows the revision number of the 4155C/4156C CPU board.

SYSTEM: SELF-CALIBRATION/DIAGNOSTICS

The SYSTEM: SELF-CALIBRATION/DIAGNOSTICS screen is used to execute self-calibration and diagnostics.

While executing self-calibration or diagnostics, you *cannot* perform measurements.

CALIB/DIAG

This field allows you to choose self-calibration or diagnostics, by selecting CALIB or DIAG softkey.

The self-calibration tests are part of the MEAS UNIT diagnostics tests.

AUTO CALIB

This field determines if self-calibration will be executed automatically, by selecting ON or OFF softkey.

If this field is set to ON, self-calibration is performed automatically every 30 minutes. Self-calibration is performed only when the 4155C/4156C state is idle. Automatic self-calibration will *not* execute when performing extended stress forcing or measurements, or when using the standby state.

CATEGORY

When CALIB softkey is selected in the CALIB/DIAG field, the CATEGORY field is automatically set to MEAS UNIT.

When DIAG softkey is selected in the CALIB/DIAG field, the following choices may be selected:

MEAS UNIT	Displays tests for measurement units.
LCD	Displays test items for the LCD.
CPU	Displays test items for the CPU.
I/O PERIPH	Displays tests for the I/O and peripherals.
MATRIX	Displays tests for the E5250A connected to the 4155C/4156C via GPIB.

The columns in the table contain the following information.

STATUS

The STATUS column displays the following test results:

- Where the 4155C/4156C can detect whether the test passes or fails:

FAIL	Executed test failed.
PASS	Executed test passed.
blank	The test has not been performed.
- Where the 4155C/4156C cannot detect whether the test passes or fails:

DONE	Executed test is finished.
blank	Executed test is not finished.

ERROR

The ERROR column displays an error code if the executed test failed. Only the first error code is displayed in this field. To see if more errors have occurred, move the pointer to the test line. Up to seven error codes are displayed in the data entry field. For more information regarding error codes, see *If You Have a Problem* manual.

TARGET

The TARGET column displays the following information:

- test number
This number is used to execute the test by remote command. For more information, see *SCPI Command Reference* manual.
- (SELF) or (INT.)
(SELF) is displayed if the test can be executed automatically.
(INT.) is displayed if the test must be executed interactively, that is, the operator must connect cables or make decisions during the test.
- test items
Name of the tests.

System Screens

SYSTEM: SELF-CALIBRATION/DIAGNOSTICS

Executing the Tests

You can execute the tests as shown below:

1. Move the pointer to the desired test item.
2. Select the EXECUTE softkey.

If the pointer is at a (SELF) test, you can repeat the test continuously by selecting REPEAT TEST softkey. You can stop executing the test by selecting STOP softkey. The REPEAT TEST softkey is available for the diagnostics, not for self-calibration.

If you want to execute all tests automatically, select:

- CALIB ALL softkey to execute all self-calibration tests.
- DIAG SELFTST ALL softkey to execute all tests displaying (SELF) in the TARGET field.

If you execute the MATRIX tests, notify that:

- Test No. 801 executes all of the MATRIX test items (802 to 807).
- Front panel test (803) waits for pressing the Local/Self Test key on the E5250A front panel. Confirm that the LEDs on the E5250A front panel is blinking, and press the Local/Self Test key. If you do not press the key within 10 seconds, you get FAIL status.
- Relay test (804 to 807) needs the relay test adapter. The adapter must be attached to the E5250A input terminals.

To stop executing tests, select STOP softkey.

Test Adapter

The following tests require the following test adapters.

Test Item	Adapter
Test No. 312 (LAN interface test)	LAN Test Adapter (Agilent Part Number 04155-61631)
Test No. 401 (parallel I/F test)	Parallel Test Adapter (Agilent Part Number 04155-61632)
Test No. 801, 804 to 807 (E5250A/E5252A relay test)	Relay Test Adapter (Agilent Part Number E5250-60002)

SYSTEM: PRINT/PLOT SETUP

The SYSTEM: PRINT/PLOT SETUP screen is used to set the parameters of the printer or plotter. For more information regarding the print/plot functions, see *User's Guide: General Information*.

DESTINATION

This field sets the interface used to connect your printer or plotter. The following parameters (softkeys) are available:

- | | |
|------------------------|---|
| PARALLEL | Selects the parallel interface. |
| GPIB | Selects the GPIB interface. The GPIB address is set on the SYSTEM: MISCELLANEOUS screen. |
| network printer | The softkey label is not “network printer”, but the strings entered into the PRINTER field of the NETWORK PRINTER SETUP table on the SYSTEM:MISCELLANEOUS screen. See “NETWORK PRINTER SETUP” on page 4-23.

This softkey selects a printer connected to your printer server. |

FORM FEED

This field is used to select whether the printer or plotter formfeeds a sheet of paper after printing.

- | | |
|----------------|---------------------------------|
| ENABLE | Enables the formfeed function. |
| DISABLE | Disables the formfeed function. |

LINE

The LINE field sets the number of lines on a page.

COLUMN

The COLUMN field sets the number of characters in a line.

COLOR/ B/W

This field sets the color, fixed color, or monochrome (black/white) mode.

COLOR Sets the color mode. This mode is available only for HP-GL or PCL printers that have 16 color capability.

FIX CLR Sets the fixed color mode. This mode is for HP-GL pen plotters and PCL color printers that have 8 color capability. The assignment of colors are defined by COLOR PEN NO. on the SYSTEM: COLOR SETUP screen. For more information, see “SYSTEM: COLOR SETUP” on page 4-33.

B/W Sets the monochrome (black/white) mode.

PAPER

This table contains the paper settings, such as paper size, orientation, and so on. The paper settings consists of:

SIZE Sets the paper size. Available sizes are:

- CUSTOM
- A3 (297 × 420 mm)
- A4 (210 × 297 mm)
- B4 (257 × 364 mm)
- B5 (182 × 257 mm)
- A (letter: 8.5 × 11 inch)
- B (11 × 17 inch)

FEED DIR Sets the feed direction of the paper.

- SHORT SIDE: for portrait (width < length)
- LONG SIDE: for landscape (width > length).

This is not available for the CUSTOM paper size setting.

LENGTH Sets the vertical length of the paper. This is available for the CUSTOM paper size setting only.

WIDTH The horizontal width of the paper. This is available for the CUSTOM paper size setting only.

UNIT The units for the paper size. Select either inch or millimeter.

OUTPUT ITEM

This table is used to select the items to be printed. For HP-GL, you can enable or disable all items. For PCL, the GRAPH items are always enabled.

TITLE The title of the printout. This title is determined automatically according to the type of output information.

- *** Agilent 4156C SETUP DATA ***
- *** Agilent 4156C DATA LIST ***
- *** Agilent 4156C GRAPH PLOT ***

DATE&TIME The current date and time from the built-in clock.

PAGE NO. The page number of the printout.

USER COMMENT The user-defined comments from the MEASURE or STRESS screens.

PRINT/PLOT COMMENT The user-defined comments from the PRINT/PLOT SETUP DATA, PRINT/PLOT DATA LIST, or GRAPH PLOT screens.

GRAPH TRACE The graphics plot curve from the GRAPH/LIST: GRAPH screen (for HP-GL, HR PCL, HR TIFF).

GRAPH FRAME & GRID The frame and grid from the GRAPH/LIST: GRAPH screen (for HP-GL, HR PCL, HR TIFF).

GRAPH AXIS TEXT The names, units, and scale of the graph axis (for HP-GL, HR PCL, HR TIFF).

GRAPH TEXT The marker and cursor coordinate fields, data variables, and gradient and intercept line parameters (for HP-GL, HR PCL, HR TIFF).

In the above fields, the following softkeys are available:

ENABLE Enables the item specified by the pointer.

DISABLE Disables the item specified by the pointer.

INIT STRING / TRAILER STRING

To send an initialization command to the printer or plotter, enter the printer/plotter command in the INIT STRING field.

To send a command after printing or plotting is finished, enter the printer/plotter command in the TRAILER STRING field.

To enter commands, use the keyboard or ENTRY keys on the front panel. To enter an escape character (\0033), use ENTER ESCAPE CHAR softkey. For a list of available commands, see your printer/plotter user's manual.

Setup Examples:

- To print PCL data in landscape mode, enter the following commands:

*INIT STRING	<u>\0033&l10\0033*r0F</u>
*TRAILER STRING	<u>\0033&l00</u>

The INIT STRING sets the printer orientation to landscape and rotates the graphic images. The TRAILER STRING sets the orientation to portrait.

- To print HP-GL data in portrait mode, enter the following commands:

*INIT STRING	<u>\0033%0B</u>
*TRAILER STRING	<u>\0033%A</u>

The INIT STRING sets the printer to HP-GL/2 mode. The TRAILER STRING sets the printer to PCL5 mode.

- To print HP-GL data in landscape mode, enter the following commands:

*INIT STRING	<u>\0033&l10\0033%0B</u>
*TRAILER STRING	<u>\0033%A\0033&l00</u>

The INIT STRING sets the printer orientation to landscape and sets the printer to HP-GL/2 mode. The TRAILER STRING sets the printer to PCL5 mode and sets the printer orientation to portrait.

SYSTEM: COLOR SETUP

The SYSTEM: COLOR SETUP screen is used to set the screen colors, and to set colors for plotting or printing.

CATEGORY

The CATEGORY field lists the screen items for which you can specify color.

Background	Background color of the screen. If the Background and Graph Background are set to different colors, the graphic drawing speed will be slower.
Softkey Background	Softkey background color.
Active Background	Background color of a selected softkey or field.
Graph Background	Background color of a graph. If the Graph Background and Background are set to different colors, the graphic drawing speed will be slower.
Foreground	Color of the text (except titles and text related to Y1 and Y2 axes).
Active Foreground	Color of the text in a selected field.
Title	Color of the screen/table titles and the selected Y axis.
Frame	Color of the frames (table and graph plotting area).
Advisory	Background color of boxes that pop up (for example, to flag an incorrect setting).
Y1 Axis	Color of the Y1 axis text and curve.
Y2 Axis	Color of the Y2 axis text and curve.
Marker/Cursor/Line	Color of an inactive marker, cursor, or line.
Active Mkr/Csr/Lne	Color of an active marker, cursor, or line.

Overlay Plane	Color of an overlay plane.
Grid	Color of the grid.

HUE, SATURATION, LUMINOSITY

The HUE, SATURATION, and LUMINOSITY fields set the color value. You can specify a value from 0 to 1 in each field.

HUE	Pure color. As you change this value from 0 to 1, the color changes from red through orange, yellow, green, cyan (greenish blue), blue, magenta (purplish red), then back to red again (0 and 1 are both red).
SATURATION	Ratio of pure color to white, where 0 is no pure color (all white), and 1 is 100% pure color (no white). If this field is set to 0, the color is always white.
LUMINOSITY	Brightness, where 0 is no brightness, 1 is 100% brightness. If this field is set to 0, the color is always black.

To set a row to the desired color, select one of the following softkeys:

- **DEFAULT COLOR** sets all rows in the table to the default colors.
- **BLACK**
- **GREY**
- **WHITE**
- **RED**
- **ORANGE**
- **YELLOW**
- **GREEN**
- **CYAN** (greenish blue)
- **BLUE**
- **MAGENTA** (purplish red)

COLOR SAMPLE

This field displays the color the item will appear according to the selected HUE, SATURATION, and LUMINOSITY fields.

PLOTTER PEN NO.

This field is used for fixed-color mode hard copies only. See the COLOR/ B/W field in “SYSTEM: PRINT/PLOT SETUP” on page 4-29.

- For an HP-GL pen plotter, this field specifies which pen the plotter uses to draw each screen item. The appropriate pens should be loaded in the pen carousel.
- For a color printer, this field specifies which color the printer uses to print each screen item. The values and corresponding colors available are:

1	Black
2	Red
3	Green
4	Yellow
5	Blue
6	Magenta
7	Cyan
8	White

BRIGHTNESS

This field is used for the brightness of the entire screen. You can specify a value from 0.15 to 1.

System Screens
SYSTEM: COLOR SETUP