

Service Manual



TDS 500D, TDS 600C, TDS 700D & TDS 714L Digitizing Oscilloscopes

071-0627-02

Warning

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

www.tektronix.com

Copyright © Tektronix, Inc. All rights reserved.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

Tektronix, Inc., P.O. Box 500, Beaverton, OR 97077

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

WARRANTY

Tektronix warrants that this product will be free from defects in materials and workmanship for a period of three (3) years from the date of shipment. If any such product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; or c) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

THIS WARRANTY IS GIVEN BY TEKTRONIX WITH RESPECT TO THIS PRODUCT IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

Table of Contents

General Safety Summary	xi
Service Safety Summary	xiii
Preface	xv
Manual Structure	xv
Manual Conventions	xvi
Related Manuals	xvii
Contacting Tektronix	xviii
Introduction	xix
Service Strategy	xix
Service Offerings	xix
Before You Begin	xxi

Specifications

Product Description	1-1
User Interface	1-2
Signal Acquisition System	1-3
Horizontal System	1-3
Trigger System	1-5
Acquisition Control	1-6
On-Board User Assistance	1-7
Measurement Assistance	1-7
Storage	1-8
I/O	1-8
Display	1-9
Nominal Traits	1-11
Warranted Characteristics	1-19
Typical Characteristics	1-29

Operating Information

Installation	2-1
Supplying Operating Power	2-1
Operating Environment	2-3
Applying and Interrupting Power	2-4
Repackaging Instructions	2-5
Installed Options	2-5
Operating Instructions	2-7
Screen Layout	2-7
Basic Procedures	2-7

Theory of Operation

Theory of Operation	3-1
Logic Conventions	3-1
Module Overview	3-1

Performance Verification Procedures

Input Channels versus Model	4-2
Conventions	4-2
Brief Procedures	4-5
Self Tests	4-5
Functional Tests	4-7
Performance Tests	4-17
Prerequisites	4-17
Equipment Required	4-18
TDS 600C Test Record	4-21
TDS 500D/700D/714L Test Record	4-25
TDS 694C Test Record	4-29
TDS 794D Test Record	4-32
Signal Acquisition System Checks	4-35
Time Base System Checks	4-53
Trigger System Checks	4-59
Output Signal Checks	4-68
Option 05 Video Trigger Checks (Not Available on TDS 694C or TDS 794D)	4-77
Sine Wave Generator Leveling Procedure	4-94
Optical Filter Checks (Options 2C, 3C & 4C Only)	4-97

Adjustment Procedures

Adjustment Procedures	5-1
Requirements for Performance	5-1
Usage	5-2
Equipment Required	5-5
Adjustment Instructions	5-6
Probe Adjustment for the P6139A Probe	5-10
Display Assembly Adjustment	5-21

Maintenance

Maintenance	6-1
Related Maintenance Procedures	6-1
Preparation	6-2
Inspection and Cleaning	6-4
Removal and Installation Procedures	6-9
Preparation — Please Read	6-9
Access Procedure	6-15
Procedures for External Modules	6-16
Procedures for Outer-Chassis Modules	6-28
Procedures for Inner-Chassis Modules,	6-48
Disassembly for Cleaning	6-55

Troubleshooting	6–59
Diagnostics	6–59
Firmware Updates	6–60
Hard Disk Drive Maintenance	6–61

Options

Options and Accessories	7–1
Options	7–1
Standard Accessories	7–4
Optional Accessories	7–5

Electrical Parts List

Electrical Parts List	8–1
------------------------------------	------------

Diagrams

Diagrams	9–1
Symbols	9–1

Mechanical Parts List

Mechanical Parts List	10–1
Parts Ordering Information	10–1
Using the Replaceable Parts List	10–2

List of Figures

Figure 2–1: Map of display functions	2–8
Figure 4–1: Map of display functions	4–3
Figure 4–2: Verifying adjustments and signal-path compensation ..	4–6
Figure 4–3: Universal test hookup for functional tests – TDS 600C shown	4–8
Figure 4–4: Measurement of DC offset accuracy at zero setting – TDS 684C shown	4–37
Figure 4–5: Initial test hookup	4–38
Figure 4–6: Measurement of DC accuracy at maximum offset and position	4–41
Figure 4–7: Initial test hookup	4–43
Figure 4–8: Optional initial test hookup	4–43
Figure 4–9: Measurement of analog bandwidth	4–46
Figure 4–10: Initial test hookup	4–49
Figure 4–11: Measurement of channel delay – TDS 684C shown	4–51
Figure 4–12: Initial test hookup	4–53
Figure 4–13: Measurement of accuracy – long-term and delay time .	4–55
Figure 4–14: Delta time accuracy test hookup	4–56
Figure 4–15: Initial test hookup	4–60
Figure 4–16: Measurement of time accuracy for pulse and glitch triggering	4–61
Figure 4–17: Initial test hookup	4–64
Figure 4–18: Measurement of trigger sensitivity – 50 MHz results shown on a TDS 684C screen	4–65
Figure 4–19: Initial test hookup	4–68
Figure 4–20: Measurement of main trigger out limits	4–70
Figure 4–21: Initial test hookup	4–73
Figure 4–22: Measurement of probe compensator frequency	4–74
Figure 4–23: Subsequent test hookup	4–75
Figure 4–24: Measurement of probe compensator amplitude	4–76
Figure 4–25: Jitter test hookup	4–78
Figure 4–26: Jitter test displayed waveform – TDS 754D shown	4–79
Figure 4–27: Jitter test when completed – TDS 754D shown	4–80
Figure 4–28: Triggered signal range test – 300 mV	4–81
Figure 4–29: Triggered signal range test – 75 mV	4–82

Figure 4–30: 60 Hz Rejection test hookup	4–83
Figure 4–31: 60 Hz Rejection test setup signal	4–83
Figure 4–32: Subsequent 60 Hz Rejection test hookup	4–84
Figure 4–33: 60 Hz Rejection test result – TDS 684C shown	4–85
Figure 4–34: Line count accuracy test hookup	4–86
Figure 4–35: Line count accuracy test setup waveform – TDS 684C shown	4–87
Figure 4–36: Line count accuracy correct result waveform	4–88
Figure 4–37: Setup for sync duty cycle test	4–90
Figure 4–38: Sync duty cycle test: one-div neg pulse waveform	4–91
Figure 4–39: Sync duty cycle test: critically adjusted pulse	4–92
Figure 4–40: Sine wave generator leveling equipment setup	4–94
Figure 4–41: Equipment setup for maximum amplitude	4–96
Figure 4–42: Reference-receiver performance-verification set up ...	4–99
Figure 4–43: Optical impulse of Ch1 input from OA5022 Optical Attenuator (OIG501 / OIG502 fed into optical attenuator in Step 1)	4–101
Figure 4–44: Optical impulse response for OC–12 SONET Reference Receiver	4–104
Figure 4–45: Optical impulse response for OC–12 SONET Reference Receiver	4–105
Figure 5–1: Accessing the protection switch	5–9
Figure 5–2: Hookup for probe compensation	5–11
Figure 5–3: Performing probe compensation	5–12
Figure 5–4: Proper and improper probe compensation	5–12
Figure 5–5: Exposing the inner probe tip	5–13
Figure 5–6: Initial test hookup	5–14
Figure 5–7: Exposing the probe body	5–16
Figure 5–8: Initial test hookup	5–17
Figure 5–9: Locations of P6139A probe adjustments	5–19
Figure 5–10: Adjustments versus front-corner response	5–20
Figure 5–11: Five and ten percent luminance patches	5–22
Figure 6–1: External modules	6–12
Figure 6–2: Outer-chassis modules	6–13
Figure 6–3: Inner-chassis modules	6–14
Figure 6–4: Knob removal	6–17
Figure 6–5: Line fuse and line cord removal	6–18
Figure 6–6: Cabinet identification	6–20

Figure 6–7: Rear cover and cabinet removal	6–21
Figure 6–8: Front cover, trim ring, menu buttons, and attenuator panel removal (front cover not shown)	6–22
Figure 6–9: A12 Front-panel assembly removal	6–24
Figure 6–10: Cabinet modules removal	6–27
Figure 6–11: A14 D1 bus and analog-power and digital-power cables removal	6–29
Figure 6–12: Remove circuit board assembly from oscilloscope	6–30
Figure 6–13: Remove circuit board from assembly	6–31
Figure 6–14: Circuit board installed	6–33
Figure 6–15: Circuit board removal	6–34
Figure 6–16: A11 Processor/display removal	6–36
Figure 6–17: Hard disk removal	6–38
Figure 6–18: Board bracket removal	6–39
Figure 6–19: A10 Acquisition board removal	6–42
Figure 6–20: TDS 694C, A10 Acquisition board removal	6–43
Figure 6–21: Floppy disk drive removal	6–45
Figure 6–22: Rear chassis removal	6–47
Figure 6–23: A16 Low voltage power supply removal	6–49
Figure 6–24: Display assembly removal	6–51
Figure 6–25: Display driver board removal	6–52
Figure 6–26: Front subpanel removal	6–54
Figure 6–27: Accessing the protection switch	6–60
Figure 6–28: Primary troubleshooting procedure	6–62
Figure 6–29: Module isolation troubleshooting procedure	6–64
Figure 6–30: A16 Low voltage power supply module isolation troubleshooting procedure	6–65
Figure 6–31: Power supply voltage measurement locations	6–66
Figure 6–32: Color display troubleshooting procedure	6–67
Figure 6–33: Horizontal and vertical sync signals – color display ...	6–68
Figure 6–34: A video signal with white, black, and blanking levels – color display	6–68
Figure 6–35: Processor/acquisition troubleshooting procedure	6–69
Figure 6–36: Processor/front panel troubleshooting procedure	6–70
Figure 6–37: Attenuator/acquisition troubleshooting procedure	6–71
Figure 6–38: A11 DRAM Processor/Display module	6–72
Figure 6–39: A10 Acquisition module (test points)	6–73
 Figure 9–1: Interconnections	 9–2
Figure 9–2: Block diagram	9–4

Figure 10–1: External modules	10–8
Figure 10–2: Outer-chassis modules	10–12
Figure 10–3: Inner-chassis modules	10–14
Figure 10–4: Cables, bottom view	10–16
Figure 10–5: Cables, top view	10–18
Figure 10–6: Floppy disk drive	10–20
Figure 10–7: Accessories	10–22

List of Tables

Table 1–1: Key features of TDS 500D, 600C, 700D and 714L oscilloscopes	1–1
Table 1–2: Record length and divisions per record versus TDS model	1–4
Table 1–3: Nominal traits — Signal acquisition system	1–11
Table 1–4: Nominal traits — Time base system	1–12
Table 1–5: Nominal traits — Triggering system	1–13
Table 1–6: Nominal traits — Display system	1–15
Table 1–7: Nominal traits — GPIB interface, output ports, and power fuse	1–16
Table 1–8: Nominal traits — Data handling and reliability	1–16
Table 1–9: Nominal traits — Mechanical	1–17
Table 1–10: Warranted characteristics — Signal acquisition system	1–20
Table 1–11: Warranted characteristics — Time base system	1–22
Table 1–12: Warranted characteristics — Triggering system	1–23
Table 1–13: Warranted characteristics — Output ports, probe compensator, and power requirements	1–24
Table 1–14: Warranted characteristics — Environmental	1–25
Table 1–15: Certifications and compliances	1–27
Table 1–16: Typical characteristics — Signal acquisition system ...	1–29
Table 1–17: Typical characteristics — Time base system	1–32
Table 1–18: Typical characteristics — Triggering system	1–33
 Table 2–1: Power cord conductor identification	 2–2
Table 2–2: Power cord identification	2–2
Table 2–3: Effects of corrupted data	2–4
 Table 4–1: Test equipment	 4–18
Table 4–2: DC offset accuracy (zero setting)	4–36
Table 4–3: DC Voltage measurement accuracy	4–40
Table 4–4: Analog bandwidth	4–45
Table 4–5: Delay between channels worksheet	4–52
Table 4–6: Delta time measurement	4–58
Table 4–7: Available filters	4–97
Table 4–8: Reference receiver filter options	4–97
Table 4–9: Option 3C and 4C specifications	4–98

Table 4–10: Available receivers	4–98
Table 4–11: Bessel Thompson frequency response and reference receiver limits	4–106
Table 5–1: Calibration tests	5–3
Table 5–2: Adjustments and dependencies	5–4
Table 5–3: Adjustments required for module replaced	5–4
Table 5–4: Test equipment, fixtures, and supplies	5–5
Table 5–5: GPIB board configuration1	5–7
Table 6–1: Relative susceptibility to static-discharge damage	6–3
Table 6–2: External inspection check list	6–5
Table 6–3: Internal inspection check list	6–6
Table 6–4: Tools required for module removal	6–11
Table 6–5: Normal supply voltages (measured on J26 and J27 on the A11 DRAM Processor/Display module)	6–66
Table 6–6: No-load supply voltages (measured on J5 and J6 on the A17 Main LV Power Supply module)	6–66
Table 7–1: Options	7–1
Table 7–2: Standard accessories	7–4
Table 7–3: Optional accessories	7–5
Table 7–4: Recommended probe cross reference	7–6
Table 7–5: Accessory software	7–9

General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use this product only as specified.

Only qualified personnel should perform service procedures.

To Avoid Fire or Personal Injury

Use Proper Power Cord. Use only the power cord specified for this product and certified for the country of use.

Ground the Product. This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

Observe All Terminal Ratings. To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

Connect and Disconnect Properly. Do not connect or disconnect probes or test leads while they are connected to a voltage source.

Do Not Operate Without Covers. Do not operate this product with covers or panels removed.

Use Proper Fuse. Use only the fuse type and rating specified for this product.

Avoid Exposed Circuitry. Do not touch exposed connections and components when power is present.

Do Not Operate With Suspected Failures. If you suspect there is damage to this product, have it inspected by qualified service personnel.

Do Not Operate in Wet/Damp Conditions.

Do Not Operate in an Explosive Atmosphere.

Provide Proper Ventilation. Refer to the manual's installation instructions for details on installing the product so it has proper ventilation.

Symbols and Terms

Terms in this Manual. These terms may appear in this manual:



WARNING. *Warning statements identify conditions or practices that could result in injury or loss of life.*



CAUTION. *Caution statements identify conditions or practices that could result in damage to this product or other property.*

Terms on the Product. These terms may appear on the product:

DANGER indicates an injury hazard immediately accessible as you read the marking.

WARNING indicates an injury hazard not immediately accessible as you read the marking.

CAUTION indicates a hazard to property including the product.

Symbols on the Product. The following symbols may appear on the product:



WARNING
High Voltage



Protective Ground
(Earth) Terminal



CAUTION
Refer to Manual



Double
Insulated

Service Safety Summary

Only qualified personnel should perform service procedures. Read this *Service Safety Summary* and the *General Safety Summary* before performing any service procedures.

Do Not Service Alone. Do not perform internal service or adjustments of this product unless another person capable of rendering first aid and resuscitation is present.

Disconnect Power. To avoid electric shock, disconnect the mains power by means of the power cord or, if provided, the power switch.

Use Caution When Servicing the CRT. To avoid electric shock or injury, use extreme caution when handling the CRT. Only qualified personnel familiar with CRT servicing procedures and precautions should remove or install the CRT.

CRTs retain hazardous voltages for long periods of time after power is turned off. Before attempting any servicing, discharge the CRT by shorting the anode to chassis ground. When discharging the CRT, connect the discharge path to ground and then the anode. Rough handling may cause the CRT to implode. Do not nick or scratch the glass or subject it to undue pressure when removing or installing it. When handling the CRT, wear safety goggles and heavy gloves for protection.

Use Care When Servicing With Power On. Dangerous voltages or currents may exist in this product. Disconnect power, remove battery (if applicable), and disconnect test leads before removing protective panels, soldering, or replacing components.

To avoid electric shock, do not touch exposed connections.

X-Radiation. To avoid x-radiation exposure, do not modify or otherwise alter the high-voltage circuitry or the CRT enclosure. X-ray emissions generated within this product have been sufficiently shielded.

Preface

This preface contains information needed to properly use this manual to service the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes, as well as general information critical to safe and effective servicing of this oscilloscope.

The following models are covered:

TDS 500:	TDS 520D, TDS 540D, and TDS 580D
TDS 600:	TDS 654C, TDS 680C, TDS 684C, and TDS 694C
TDS 700:	TDS 714L, TDS 724D, TDS 754D, TDS 784D, and TDS 794D

Manual Structure

This manual is divided into sections, such as *Specifications and Theory of Operation*. Further, it is divided into subsections, such as *Product Description* and *Removal and Installation Procedures*.

Sections containing procedures also contain introductions to those procedures. Be sure to read these introductions because they provide information needed to do the service correctly and efficiently. The following is a brief description of each manual section.

- *Specifications* contains a product description of the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes and tables of the characteristics and descriptions that apply to it.
- *Operating Information* includes general information and operating instructions at the level needed to safely power on and service this oscilloscope. A statement of the service strategy that this manual supports, and instructions for shipment of the oscilloscopes are found in this section.
- *Theory of Operation* contains circuit descriptions that support general service and fault isolation.
- *Performance Verification* contains a collection of procedures for confirming that these oscilloscopes function properly and meet warranted limits.
- *Adjustment Procedures* contains a collection of procedures for adjusting these oscilloscopes to meet warranted limits.

- *Maintenance* contains information and procedures for doing preventive and corrective maintenance of these oscilloscopes. Instructions for cleaning, for module removal and installation, and for fault isolation to a module are found here.
- *Options* contains information on servicing any of the factory-installed options that may be present in your oscilloscope.
- *Electrical Parts List* contains a statement referring you to *Mechanical Replaceable Parts*, where both electrical and mechanical modules are listed.
- *Diagrams* contains a block diagram and an interconnection diagram useful for isolating failed modules.
- *Mechanical Parts List* includes a table of all replaceable modules, their descriptions, and their Tektronix part numbers.

Manual Conventions

This manual uses certain conventions which you should become familiar with before doing service.

Modules Throughout this manual, any replaceable component, assembly, or part of these oscilloscopes is referred to generically as a module. In general, a module is an assembly, like a circuit board, rather than a component, like a resistor or an integrated circuit. Sometimes a single component is a module; for example, each chassis part of the oscilloscope is a module.

Channels Some TDS models have two auxiliary channels called AUX 1 and AUX 2, instead of CH 3 and CH 4. References to these channels default to CH 3 and CH 4. If your oscilloscope is one of models TDS 520D, TDS 680C, or TDS 724D, read AUX 1 and AUX 2 respectively for all references to CH 3 and CH 4 in this manual.

Safety Symbols and terms related to safety appear in the Safety Summary found at the beginning of this manual.

Symbols Besides the symbols related to safety, this manual uses the following symbols:

STOP. The stop labels information which must be read in order to correctly do service and to avoid incorrectly using or applying service procedures.



The clock icon labels procedure steps which require a pause to wait for the oscilloscope to complete some operation before you can continue.



Various icons such as the example icon at the left are used in procedures to help identify certain readouts and menu functions on screen.

Related Manuals

The TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes come with the following manuals (see the *Options and Accessories* section for part numbers):

TDS 500D, TDS 600B & TDS 700D User Manual contains a tutorial to quickly show you how to operate the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes and an in depth discussion of how to more completely use their features. Applications are also discussed.

TDS 500D, TDS 600B & TDS 700D Reference contains a brief overview of oscilloscope operation.

TDS Family Programmer Manual (diskette, part of the *User Manual*) contains information for programmed operation via the GPIB interface. Included are the complete command set, setup information, and programming examples.

TDS 500D, TDS 600C, TDS 700D & TDS 714L Technical Reference contains performance verification procedures and specifications.

Contacting Tektronix

Phone	1-800-833-9200*
Address	Tektronix, Inc. Department or name (if known) 14200 SW Karl Braun Drive P.O. Box 500 Beaverton, OR 97077 USA
Web site	www.tektronix.com
Sales support	1-800-833-9200, select option 1*
Service support	1-800-833-9200, select option 2*
Technical support	Email: techsupport@tektronix.com 1-800-833-9200, select option 3* 1-503-627-2400 6:00 a.m. – 5:00 p.m. Pacific time

* This phone number is toll free in North America. After office hours, please leave a voice mail message.
Outside North America, contact a Tektronix sales office or distributor; see the Tektronix web site for a list of offices.

Introduction

Service Strategy

STOP. Throughout this manual, any field-replaceable component, assembly, or part of this oscilloscope is referred to generically as a module.

This manual contains all the information needed for periodic maintenance of the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. (Examples of such information are procedures for checking performance and for readjustment.) Further, it contains all information for corrective maintenance down to the module level. This means that the procedures, diagrams, and other troubleshooting aids help isolate failures to a specific module, rather than to components of that module. Once a failure is isolated, replace the module with a fresh unit obtained from the factory.

All modules are listed in *Mechanical Parts List*. To isolate a failure to a module, use the fault isolation procedures found in Section 6, *Maintenance Information*. To remove and replace any failed module, follow the instructions in *Removal and Installation Procedures*, also found in Section 6.

Service Offerings

Tektronix provides service to cover repair under warranty as well as other services that may provide a cost-effective answer to your service needs.

Whether providing warranty repair service or any of the other services listed below, Tektronix service technicians, trained on Tektronix products, are best equipped to service your TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. Tektronix technicians are apprised of the latest information on improvements to the product as well as the latest new options to the product.

Warranty Repair Service

Tektronix warrants this product for three years from date of purchase, excluding probes for which the warranty is one year. (The warranty appears after the title page and copyright page in this manual.) Tektronix technicians provide warranty service at most Tektronix service locations worldwide. Your Tektronix product catalog lists all service locations worldwide.

Repair or Calibration Service

The following services may be purchased to tailor repair and/or calibration of your TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes to fit your requirements.

At-Depot Service. Tektronix offers several standard-priced adjustment (calibration) and repair services:

- A single repair and/or adjustment.
- Calibrations using equipment and procedures that meet the traceability standards specific to the local area.
- Annual maintenance agreements that provide for either calibration and repair or calibration only of the oscilloscope.

Of these services, the annual maintenance agreement offers a particularly cost-effective approach to service for many owners of the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. Such agreements can be purchased to span several years.

On-Site Service. The annual maintenance agreement can be purchased with on-site service, with repair and calibration done at your facility. This service reduces the time your oscilloscope is out of service when calibration or repair is required.

Self Service

Tektronix supports repair to the module level by providing *Module Exchange* and *Module Repair and Return*.

Module Exchange. This service reduces down time for repair by allowing you to exchange most modules for remanufactured ones. Tektronix ships you an updated and tested exchange module from the Beaverton, Oregon service center, typically within 24 hours. Each module comes with a 90-day service warranty.

Module Repair and Return. This service returns to you within 10 days the same module that you shipped to Tektronix. The module shipped is repaired, tested, and returned to you from the Beaverton, Oregon service center. It is *not* updated to match current modules of the same type. Again, each module comes with a 90-day service warranty.

For More Information. Contact your local Tektronix service center or sales engineer for more information on any of the repair or adjustment services just described.

Before You Begin

This manual is for servicing the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. To prevent injury to yourself or damage to the oscilloscope, do the following tasks before you attempt service:

- Read the Safety Summary found at the beginning of this manual.
- Read *Service Strategy* in this section and *Supplying Operating Power* in section 2.

When using this manual for servicing, be sure to read and follow all warnings, cautions, and notes.

Specifications

This section begins with a general description of the traits of the TDS 500D, TDS 600C, TDS 700D and TDS 714L oscilloscopes. Three sections follow, one for each of three classes of traits: *nominal traits*, *warranted characteristics*, and *typical characteristics*.

Product Description

The TDS 500D, TDS 600C, TDS 700D and TDS 714L oscilloscopes are portable, four-channel instruments suitable for use in a variety of test and measurement applications and systems. Table 1–1 lists key features.

Table 1–1: Key features of TDS 500D, 600C, 700D and 714L oscilloscopes

Feature	TDS 600C	TDS 500D, TDS 700D & TDS 714L
Digitizing rate, maximum	TDS 684C: 5 GS/s on ea. of 4 ch TDS 680C: 5 GS/s on ea. of 2 ch TDS 654C: 5 GS/s on ea. of 4 ch TDS 694C: 10 GS/s on ea. of 4 ch	TDS 580D, TDS 784D, TDS 794D: 4 GS/s TDS 540D, 754D: 2 GS/s TDS 520D, 724D: 1 GS/s TDS 714L: 500 MS/s
Analog bandwidth	TDS 694C: 3 GHz TDS 794D: 2 GHz TDS 580D, TDS 680C, 684C, and 784D: 1 GHz TDS 520D, 540D, 654C, 714L, 724D and 754D: 500 MHz	
No. of Channels	TDS 654C, 684C & 694C: 4 TDS 680C: 2 + 2 ¹	TDS 540D, 580D, TDS 714L, 754D, 784D & 794D: 4 TDS 520D & 724D: 2 + 2 ¹
Record lengths, maximum	15,000 samples TDS 694C: 30,000 samples (120,000 with option 1M)	50,000 (250,000 on TDS 714L) samples (500,000 with option 1M, not available on TDS 714L) (8,000,000 with option 2M)
Acquisition modes	Sample, envelope, peak detect and average	Sample, envelope, average, high-resolution, and peak-detect

Table 1–1: Key features of TDS 500D, 600C, 700D and 714L oscilloscopes (cont.)

Feature	TDS 600C	TDS 500D, TDS 700D & TDS 714L
Trigger modes	Modes include: Edge, logic, and pulse. Video trigger, with option 05, modes include: NTSC, SECAM, PAL, HDTV, and FlexFormat. (Not available on TDS 694C/794D) Communications Trigger with option 2C (not available on TDS 600C and TDS 714L), modes include: AMI, CMI, and NRZ	
Display	TDS 520D, 540D, 580D, 680C: Monochrome TDS 645C, 684C, 694C, 714L, 724D, 754D, 784D, 794D: Color	
Storage	Floppy disk drive: 1.44 Mbyte, 3.5 inch, DOS 3.3-or-later floppy disk drive Internal hard disk drive (optional) Iomega Zip drive compatible NVRAM storage for saving waveforms, hardcopies, and setups	
I/O	Full GPIB programmability. Hardcopy output using GPIB, RS-232, or Centronics ports	

¹ **Two plus Two channel operation allows up to two of the four channels to be displayed simultaneously. Channels not displayed can be used to couple a triggering signal to the oscilloscope.**

User Interface

Use a combination of front-panel buttons, knobs, and on-screen menus to control the many functions of the oscilloscope. The front-panel controls are grouped according to function: vertical, horizontal, trigger, and special. Set a function you adjust often, such as vertical positioning or the time base setting, directly by its own front-panel knob. Set a function you change less often, such as vertical coupling or horizontal mode, indirectly using a selected menu.


Menus Pressing one (sometimes two) front-panel button(s), such as vertical menu, displays a *main* menu of related functions, such as coupling and bandwidth, at the bottom of the screen. Pressing a main-menu button, such as coupling, displays a *side* menu of settings for that function, such as AC, DC, or GND (ground) coupling, at the right side of the screen. Pressing a side-menu button selects a setting such as DC.

Indicators

On-screen readouts help you keep track of the settings for various functions, such as vertical and horizontal scale and trigger level. Some readouts use the cursors or the automatic parameter extraction feature (called measure) to display the results of measurements made or the status of the instrument.

General Purpose Knob

Assign the general purpose knob to adjust a selected parameter function. More quickly change parameters by toggling the **SHIFT** button. Use the same method as for *selecting* a function, except the final side-menu selection assigns the general purpose knob to *adjust* some function, such as the position of measurement cursors on screen, or the setting for a channel fine gain.

**GUI**

The user interface also makes use of a GUI, or Graphical User Interface, to make setting functions and interpreting the display more intuitive. Some menus and status are displayed using iconic representations of function settings, such as those shown here for full, 250 MHz and 20 MHz bandwidth. Such icons allow you to more readily determine status or the available settings.

Signal Acquisition System

The signal acquisition system provides up to four, full-featured vertical channels with calibrated vertical scale factors from 1 mV to 10 V per division, depending on TDS model. All channels can be acquired simultaneously.

Each of the full-featured channels can be displayed, vertically positioned, and offset, and their vertical coupling specified. Some models can have their bandwidth limited (250 MHz or 20 MHz). Fine gain can also be adjusted.

Besides these channels, up to three math waveforms and four reference waveforms are available for display. (A math waveform results when you specify dual waveform operations, such as add, on any two channels. A reference waveform results when you save a waveform in a reference memory).

Horizontal System

There are three horizontal display modes: main only, main intensified, and delayed only. You can select among various horizontal record length settings.

A feature called “Fit to Screen” allows you to view entire waveform records within the 10 division screen area. Waveforms are compressed to fit on the screen. See Table 1–2.

Both the delayed only display and the intensified zone on the main intensified display may be delayed by time with respect to the main trigger. Both can be set to display immediately after the delay (delayed runs after main mode). The delayed display can also be set to display at the first valid trigger after the delay (delayed-triggerable modes).

The delayed display (or the intensified zone) may also be delayed by a selected number of events. In this case, the events source is the delayed-trigger source. The delayed trigger can also be set to occur after a number of events plus an amount of time.

Table 1-2: Record length and divisions per record versus TDS model

Standard Models	Record length	Divisions per record	
		FTS ¹ Off ²	FTS ¹ On ³
All TDS 500D, TDS600C, TDS 694C, TDS 700D, & TDS 714L, all channels ⁴	500	10 div	10 div
	1,000	20 div	10 div
	2,500	50 div	10 div
	5,000	100 div	10 div
	15,000	300 div	10 div
TDS 694C, all channels	30,000	600 div	15 div
TDS 500D, TDS 700D, & TDS 714L, all channels	50,000	1,000 div	15 div
Models with Option 1M ⁵	Record length	Divisions per record	
		FTS ¹ Off ²	FTS ¹ On ³
TDS 694C, all channels	50,000	1,000 div	10 div
TDS 500D, TDS 694C, TDS 700D, & TDS 714L, all channels	75,000	1,500 div	15 div
TDS 500D, TDS 694C, TDS 700D, & TDS 714L, all channels	100,000	2,000 div	12 div
TDS 694C, all channels	120,000	2,400 div	13 div
TDS 500D, TDS 700D, TDS 714L, all channels	130,000	2,600 div	10 div
TDS 520D, one channel only	250,000	5,000 div	10 div
TDS 540D, TDS 580D, all TDS 700D, & TDS 714L, one or two channels			
TDS 540D, TDS 580D, & all TDS 700D, one channel only	500,000	10,000 div	10 div

Table 1–2: Record length and divisions per record versus TDS model (cont.)

Models with Option 2M	Record length	Divisions per record	
		FTS ¹ Off ²	FTS ¹ On ³
TDS 520D & TDS 724D, one or two channels	2,000,000	40,000 div	10 div
TDS 540D, TDS 580D, TDS 714L, TDS 754D, TDS 784D & TDS 794D, three or four channels			
TDS 520D & TDS 724D, one channel only	4,000,000	80,000 div	10 div
TDS 540D, TDS 580D, TDS 714L, TDS 754D, TDS 784D & TDS 794D, two channels			
TDS 540D, TDS 714L, TDS 754D, TDS 784D & TDS 794D, one channel only	8,000,000	160,000 div	10 div

¹ **Fit to Screen setting**

² **Fit to Screen off preserves 50 samples/division in a 1–2–5 sec/division sequence.**

³ **Fit to Screen on lets the samples/division and the sec/division sequence vary.**

⁴ **All channels means all that may be displayed at one time: four channels for some models, two for others. See Table 1–1 and its footnote.**

⁵ **1M is the standard record length on the TDS 714L.**

Trigger System

The triggering system supports a varied set of features for triggering the signal-acquisition system. Trigger signals recognized include:

- **Edge (main- and delayed-trigger systems):** This familiar type of triggering is fully configurable for source, slope, coupling, mode (auto or normal), and holdoff.
- **Logic (main-trigger system):** This type of triggering can be based on pattern (asynchronous) or state (synchronous). In either case, logic triggering is configurable for sources, for Boolean operators to apply to those sources, for logic pattern or state on which to trigger, for mode (auto or normal), and for holdoff. Time qualification may be selected in pattern mode. Another class of logic trigger, setup/hold, triggers when data in one trigger source changes state within the setup and hold times that you specify relative to a clock in another trigger source.

- **Pulse (main-trigger system):** Pulse triggering is configurable for triggering on runt or glitch pulses, or on pulse widths or periods inside or outside limits that you specify. It can also trigger on a pulse edge that has a slew rate faster or slower than the rate you specify. The timeout trigger will act when events do *not* occur in a defined time period. The pulse trigger is also configurable for source, polarity, mode, and holdoff.
- **Video (with option 05: Video Trigger):** Video triggering is compatible with standard NTSC, PAL, SECAM, and HDTV formats. An additional feature called FlexFormat™ (flexible format) allows the user to define the video format on which to trigger.
- **Comm (with option 2C):** is provided for triggering on AMI, CMI, or NRZ communications signals.

You can choose where the trigger point is located within the acquired waveform record by selecting the amount of pretrigger data displayed. Presets of 10%, 50%, and 90% of pretrigger data can be selected in the horizontal menu, or the general purpose knob can be assigned to set pretrigger data to any value within the 0% to 100% limits.

Acquisition Control

You can specify a mode and manner to acquire and process signals that matches your measurement requirements.

- Select the mode for interpolation (linear or sin (x)/x). This can increase the apparent sample rate on the waveform when the maximum real-time rate is exceeded.
- Use sample, envelope, average and peak detect modes to acquire signals. With the Oscilloscopes, also use high-resolution mode.
- Set the acquisition to stop after a single acquisition (or sequence of acquisitions if acquiring in average or envelope modes) or after a limit condition has been met.
- Select channel sources for compliance with limit tests. You can direct the TDS to signal you or generate hard copy output either to a printer or to a floppy-disk file based on the results. Also, you can create templates for use in limit tests.

On-Board User Assistance

Help and autoset can assist you in setting up the oscilloscope to make your measurements.

Help Help displays operational information about any front-panel control. When help mode is in effect, manipulating any front-panel control causes the oscilloscope to display information about that control. When help is first invoked, an introduction to help is displayed on screen.

Autoset Autoset automatically sets up the oscilloscope for a viewable display based on the input signal.

Measurement Assistance

Once you have set up to make your measurements, the cursor and measure features can help you quickly make those measurements.

Cursor Three types of cursors are provided for making parametric measurements on the displayed waveforms. Horizontal bar cursors (H Bar) measure vertical parameters (typically volts). Vertical bar cursors (V Bar) measure horizontal parameters (typically time or frequency). Paired cursors measure both amplitude and time simultaneously. These are delta measurements; that is, measurements based on the difference between two cursors.

Both H Bar and V Bar cursors can also be used to make absolute measurements. For the H Bars, either cursor can be selected to read out its voltage with respect to any channel's ground reference level. For the V Bars, the cursors measure time with respect to the trigger point (event) of the acquisition. The cursors can also control the portion of the waveform on which automatic measurements are made.

For time measurements, units can be either seconds or hertz (for 1/time).

With the video trigger option installed (Option 05), you can measure the video line number using the vertical cursors. You can measure IRE amplitude (NTSC) using the horizontal cursors with or without the video trigger option installed.

Measure Measure can automatically extract parameters from the signal input to the oscilloscope. Any four out of the 25 parameters available can be displayed to the screen. The waveform parameters are measured continuously with the results updated on-screen as the oscilloscope continues to acquire waveforms.

Digital Signal Processing (DSP)

An important component of the multiprocessor architecture of this oscilloscope is Tektronix' proprietary digital signal processor, the DSP. This dedicated processor supports advanced analysis of your waveforms when doing such compute-intensive tasks as interpolation, waveform math, and signal averaging. It also teams with a custom display system to deliver specialized display modes (See *Display*, later in this description).

Storage

Acquired waveforms may be saved in any of four nonvolatile REF (reference) memories or on a 3.5 inch, DOS 3.3-or-later compatible disk. Any or all of the saved waveforms may be displayed for comparison with the waveforms being currently acquired.

The Oscilloscopes instrument with option 2M can save waveforms to an internal hard disk drive. Any or all of the saved waveforms may be displayed for comparison with the waveforms being currently acquired.

The source and destination of waveforms to be saved may be chosen. You can save any of the four channels to any REF memory or move a stored reference from one REF memory to another. Reference waveforms may also be written into a REF memory location via the GPIB interface.

I/O

The oscilloscope is fully controllable and capable of sending and receiving waveforms over the GPIB interface (IEEE Std 488.1–1987/IEEE Std 488.2–1987 standard). This feature makes the instrument ideal for making automated measurements in a production or research and development environment that calls for repetitive data taking. Self-compensation and self-diagnostic features built into the oscilloscope to aid in fault detection and servicing are also accessible using commands sent from a GPIB controller.

The oscilloscope can also output copies of its display using the hardcopy feature. This feature allows you to output waveforms and other on-screen information to a variety of graphic printers and plotters from the TDS front panel, providing hard copies without requiring you to put the TDS into a system-controller environment.

You can make hardcopies in a variety of popular output formats, such as PCX, TIFF, BMP, RLE, EPS, Interleaf, and EPS mono or color. You can also save hardcopies in a disk file in any of the formats listed in the I/O section.

The hardcopies obtained are based on what is displayed on-screen at the time hardcopy is invoked. The hardcopies can be stamped with date and time and spooled to a queue for printing at a later time. You can output screen information via GPIB, RS-232-C, or Centronics interfaces.

Display

The TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes offer flexible display options. You can customize the following attributes of your display:

- Color (TDS 654C, TDS 684C, TDS694C, TDS 700D, and TDS 714L): Waveforms, readouts, graticule, and variable persistence with color coding
- Intensity: waveforms, readouts, and graticule
- Style of waveform display(s): vectors or dots, intensified or nonintensified samples, infinite persistence, and variable persistence
- Interpolation method: Sin(x)/x or Linear
- Display format: xy or yt with various graticule selections including NTSC and PAL to be used with video trigger (option 05)

This oscilloscope also provides an easy way to focus in on those waveform features you want to examine up close. By invoking zoom, you can magnify the waveform using the vertical and horizontal controls to expand (or contract) and position it for viewing.

Nominal Traits

Tables 1–3 through 1–9 list the various *nominal traits* that describe the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. Electrical and mechanical traits are included.

Nominal traits are described using simple statements of fact such as “Four, all identical” for the trait “Input Channels, Number of,” rather than in terms of limits that are performance requirements.

Table 1–3: Nominal traits — Signal acquisition system

Name	Description	
Bandwidth Selections	20 MHz, 250 MHz, and FULL (No BW limit on TDS 694C or TDS 794D)	
Samplers, Number of	TDS 540D, 580D, 654C, 684C, 694C, 714L, 754D, 784D, and 794D: Four, simultaneous TDS 520D, 680C, and 724D: Two, simultaneous	
Digitized Bits, Number of	8 bits ¹	
Input Channels, Number of	Four	
Input Coupling	DC, AC, or GND (TDS 694C/794D – DC or GND only)	
Input Impedance Selections	1 M Ω or 50 Ω (TDS 694C/794D – 50 Ω only)	
Ranges, Offset (All except TDS 694C/794D)	Volts/Div setting	Offset range
	1 mV/div – 100 mV/div	± 1 V
	101 mV/div – 1 V/div	± 10 V
	1.01 V/div – 10 V/div	± 100 V
Ranges, Offset (TDS 694C/794D only)	10 mV/div – 50 mV/div	± 0.50 V
	50.5 mV/div – 100 mV/div	± 0.25 V
	101 mV/div – 500 mV/div	± 5 V
	505 mV/div – 1 V/div	± 2.5 V
Range, Position	± 5 divisions	
Range, 1 M Ω Sensitivity ³	1 mV/div to 10 V/div ²	
Range, 50 Ω Sensitivity	1 mV/div to 1 V/div ² (10 mV/div – 1V/div on TDS 694C/794D)	

- ¹ Displayed vertically with 25 digitization levels (DLs) per division and 10.24 divisions dynamic range with zoom off. A DL is the smallest voltage level change of the oscilloscope input that can be resolved by the 8-bit A-D Converter. Expressed as a voltage, a DL is equal to 1/25 of a division times the volts/division setting.
- ² The sensitivity ranges from 1 mV/div to 10 V/div (for 1 M Ω) or to 1 V/div (for 50 Ω) in a 1–2–5 sequence of coarse settings with Fit-to-Screen off. Between coarse settings, the sensitivity can be finely adjusted with a resolution equal to 1% of the more sensitive coarse setting. For example, between 50 mV/div and 100 mV/div, the volts/division can be set with 0.5 mV resolution.
- ³ 1 M Ω not available on TDS 694C & TDS 794D oscilloscopes.

Table 1–4: Nominal traits — Time base system

Name	Description
Range, Sample-Rate ^{1,3}	TDS 684C: 5 Samples/sec to 5 GSamples/sec on four channels simultaneously TDS 680C: 5 Samples/sec to 5 GSamples/sec on two channels simultaneously TDS 654C: 5 Samples/sec to 5 GSamples/sec on four channels simultaneously TDS 694C: 5 Samples/sec to 10 GSamples/sec on four channels simultaneously TDS 520D, and 724D: 5 Samples/sec to 2 GSamples/sec when acquiring 1 channel, to 1 GSample/sec when acquiring 2 channels TDS 540D: 5 Samples/sec to 2 GSamples/sec when acquiring 1 or 2 channels, to 1 GSample/sec when acquiring 3 or 4 channels TDS 540D Opt. 1G: 5 Samples/sec to 1 GSample/sec when acquiring 1 to 4 channels TDS 714L: 5 Samples/sec to 500 MSamples/sec when acquiring 1 to 4 channels TDS 754D: 5 Samples/sec to 2 GSamples/sec when acquiring 1 or 2 channels, to 1 GSample/sec when acquiring 3 or 4 channels TDS 754D Opt 1G: 5 Samples/sec to 1 GSample/sec when acquiring 1 to 4 channels TDS 580D, 784D, and 794D: 5 Samples/sec to 4 GSamples/sec when acquiring 1 channel, to 2 GSamples/sec when acquiring 2 channels, or to 1 GSample/sec when acquiring 3 or 4 channels
Range, Interpolated Waveform Rate ^{2,3}	TDS 600C: 10 GSamples/sec to 250 GSamples/sec TDS 694C: 10 GSamples/sec to 500 GSamples/sec TDS 520D, 540D, 714L, 724D, and 754D: 1 GSample/sec to 100 GSamples/sec TDS 580D, 784D, and 794D: 2 GSamples/sec to 250 GSamples/sec
Range, Seconds/Division	TDS 600C: 0.2 ns/div to 10 s/div TDS 694C: 0.1 ns/div to 10 s/div TDS 500D, 714L, 724D, and 754D: 0.5 ns/div to 10 s/div TDS 580D, 784D, and 794D: 0.2 ns/div to 10 s/div

Table 1–4: Nominal traits — Time base system (cont.)

Name	Description
Record Length Selection	TDS 500D, TDS 700D & TDS 714L: 500, 1,000, 2,500, 5,000, 15,000 and 50,000 samples TDS 714L: 1 or 2-channels: up to 250,000 samples 3 or 4-channels: up to 130,000 samples TDS 694C: 500, 1,000, 2,500, 5,000, 15,000 30,000 with option 1M: 50,000, 75,000, 100,000 and 120,000 samples all channels In addition to the record lengths previously listed, the following record lengths are available with the following options: TDS 520D & TDS 724D with option 1M: 1-channel: up to 250,000 samples 2-channels: up to 130,000 samples TDS 520D & TDS 724D with option 2M: 1-channel: up to 4,000,000 samples 2-channels: up to 2,000,000 samples TDS 540D, TDS 580D, TDS 754D, TDS 784D & TDS 794D with option 1M: 1-channel: up to 500,000 samples 2-channels: up to 250,000 samples 3 or 4-channels up to 130,000 samples TDS 540D, TDS 580D, TDS 714L, TDS 754D, TDS 784D & TDS 794D with option 2M: 1-channel: up to 8,000,000 samples 2-channels: up to 4,000,000 samples 3 or 4-channels up to 2,000,000 samples

- ¹ The range of real-time rates, expressed in samples/second, at which a digitizer samples signals at its inputs and stores the samples in memory to produce a record of time-sequential samples.
- ² The range of waveform rates for interpolated (or equivalent-time on the TDS 700D) waveform records.
- ³ The Waveform Rate (WR) is the equivalent sample rate of a waveform record. For a waveform record acquired by real-time sampling of a single acquisition, the waveform rate is the same as the real-time sample rate; for a waveform created by interpolation of real-time samples from a single acquisition or, on applicable products, the equivalent-time sampling of multiple acquisitions, the waveform rate created is faster than the real time sample rate. For all these cases, the waveform rate is $1/(\text{Waveform Interval})$ for the waveform record, where the waveform interval (WI) is the time between the samples in the waveform record.

Table 1–5: Nominal traits — Triggering system

Name	Description
Range, Delayed Trigger Time Delay	16 ns to 250 s
Range, Events Delay	TDS 600C; 2 to 10,000,000 TDS 500D/700D/714L: 1 to 10,000,000

Table 1–5: Nominal traits — Triggering system (cont.)

Name	Description	
Range (Time) for Pulse-Glitch, Pulse-Width, Time-Qualified Runt, Timeout, or Slew Rate Trigger, Delta Time	1 ns to 1 s	
Ranges, Setup and Hold for TimeSetup/Hold Violation Trigger	Feature	Min to max
	Setup Time	–100 ns to 100 ns
	Hold Time	–1 ns to 100 ns –1 ns to 102 ns, TDS694C
	Setup + Hold Time	2 ns
	For Setup Time, positive numbers mean a data transition before the clock edge and negative means a transition after the clock edge. For Hold Time, positive numbers mean a data transition after the clock edge and negative means a transition before the clock edge. Setup + Hold Time is the algebraic sum of the Setup Time and the Hold Time programmed by the user.	
Ranges, Trigger Level or Threshold	Source	Range
	Any Channel	±12 divisions from center of screen
	Auxiliary	±8 V
	Line	±400 V
Video Trigger Modes of Operation (Option 05 Video Trigger, Not available on TDS 694C and TDS 794D)	Supports the following video standards: ■ NTSC (525/60) – 2 field mono or 4 field ■ PAL (625/50) – 2 field mono or SECAM, 8 field ■ HDTV – (787.5/60) (1050/60) (1125/60) (1250/60) ■ FlexFormat™ (user definable standards) User can specify: field rate, number of lines, sync pulse width and polarity, line rate, and vertical interval timing.	

Table 1-5: Nominal traits — Triggering system (cont.)

Name	Description		
Communication Trigger Modes of Operation (Option 2C Comm Trigger, Not available on TDS 600C and TDS 714L)	Standard Name	Code ¹	Bit Rate
	OC1/STM0	NRZ	51.84 Mb/s
	OC3/STM1	NRZ	155.52 Mb/s
	OC12/STM4	NRZ	622.08 Mb/s
	DS0 Sgl	Masks ²	64 kb/s
	DS0 Dbl	Masks ²	64 kb/s
	DS0 Data Contra	Masks ²	64 kb/s
	DS0 Timing	Masks ²	64 kb/s
	E1	AMI	2.048 Mb/s
	E2	AMI	8.44 Mb/s
	E3	AMI	34.368 Mb/s
	E4	CMI	139.26 Mb/s
	E5 (CEPT)	NRZ	565 Mb/s
	STM1E	CMI	155.52 Mb/s
	DS1	AMI	1.544 Mb/s
	DS1A	AMI	2.048 Mb/s
	DS1C	AMI	3.152 Mb/s
	DS2	AMI	6.312 Mb/s
	DS3/DS3 Rate	AMI	44.736 Mb/s
	DS4NA	CMI	139.26 Mb/s
	STS-1	AMI	51.84 Mb/s
	STS-3	CMI	155.52 Mb/s
	FC133	NRZ	132.8 Mb/s
	FC266	NRZ	265.6 Mb/s
	FC531	NRZ	531.2 Mb/s
	FC1063	NRZ	1.0625 Mb/s
	D2	NRZ	143.18 Mb/s
	D1	NRZ	270 Mb/s
	FDDI	NRZ	125 Mb/s
	4:2:2 SMPTE 259M-D	NRZ	360 Mb/s
	10 Base-T	NRZ	10 Mb/s
	100 Base-T	NRZ	125 Mb/s
	Gigabit Ethernet	NRZ	1.25 Gb/s

¹ AMI = Alternate Mark Inversion. CMI = Code Mark Inversion. NRZ = Non-return to Zero.

² These Telecom DS0 standards are automatically selected from the Mask Menu. The trigger uses Pulse/Width trigger.

Table 1-6: Nominal traits — Display system

Name	Description
Video Display	7 inch diagonal, with a display area of 5.04 inches horizontally by 3.78 inches vertically TDS 520D, 540D, 580D, and 680C: Monochrome display TDS 654C, 684C, 694C, 714L, 724D, 754D, 784D, and 794D: Color display
Video Display Resolution	640 pixels horizontally by 480 pixels vertically

Table 1–6: Nominal traits — Display system (cont.)

Name	Description
Waveform Display Graticule	Single Graticule: 401 × 501 pixels, 8 × 10 divisions, where divisions are 1 cm by 1 cm
Waveform Display Levels/Colors	TDS 520D, 540D, 580D, and 680C: Sixteen levels in infinite-persistence or variable persistence display TDS 654C, 684C, 694C, 714L, 724D, 754D, 784D, and 794D: Sixteen colors in infinite-persistence or variable persistence display

Table 1–7: Nominal traits — GPIB interface, output ports, and power fuse

Name	Description
Interface, GPIB	GPIB interface complies with IEEE Std 488-1987
Interface, RS-232	RS-232 interface complies with EIA/TIA 574 (talk only) Optional on the TDS 520D, 540D, 580D, and 680C
Interface, Centronics	Centronics interface complies with Centronics interface standard C332-44 Feb 1977, REV A Optional on the TDS 520D, 540D, 580D, and 680C
Interface, Video	VGA video output with levels that comply with EIA RS 343A standard. DB-15 connector
Logic Polarity for Main- and Delayed-Trigger Outputs	Negative TRUE. High to low transition indicates the trigger occurred.
Fuse Rating	Either of two fuses ¹ may be used: a 0.25" × 1.25" (UL 198.6, 3AG): 6 A FAST, 250 V or a 5 mm × 20 mm (IEC 127): 5 A (T), 250 V.
Fuse Rating TDS694C	Either of two fuses ¹ may be used: a 0.25" × 1.25" (UL 198.6, 3AG): 8 A FAST, 250 V or a 5 mm × 20 mm (IEC 127): 6.3 A (T), 250 V.

¹ Each fuse type requires its own fuse cap.

Table 1–8: Nominal traits — Data handling and reliability

Name	Description
Time, Data-Retention, Nonvolatile Memory ^{1, 2}	Battery life ≥ 5 years
Floppy disk drive	3.5 inch, 720 K or 1.44 Mbyte, DOS 3.3-or-later compatible
Internal hard disk drive (Option HD included in Option 2M)	2.1 Gbyte capacity
External data storage	Iomega Zip drive compatible

¹ The times that reference waveforms, stored setups, and calibration constants are retained.

² Data is maintained by small lithium-thionyl-chloride batteries internal to the memory ICs. At the time of manufacture, no special disposal requirements were in effect for these batteries as the amount of hazardous material contained was below the regulated threshold. Consult your local waste disposal agency for proper disposal.

Table 1–9: Nominal traits — Mechanical

Name	Description
Cooling Method	Forced-air circulation with no air filter. Clearance is required. Refer to your user manual for minimum clearance dimensions.
Construction Material	Chassis parts constructed of aluminum alloy; front panel constructed of plastic laminate; circuit boards constructed of glass laminate. Cabinet is aluminum and is clad in Tektronix Blue vinyl material.
Weight	Standard Oscilloscope 14.1 kg (31 lbs), with front cover. 24.0 kg (53 lbs), when packaged for domestic shipment Rackmount Oscilloscopes 14.1 kg (31 lbs) plus weight of rackmount parts, for the rackmounted Oscilloscopes (Option 1R). Rackmount conversion kit 2.3 kg (5 lbs), parts only; 3.6 kg (8 lbs), parts plus package for domestic shipping
Overall Dimensions	Standard Oscilloscope Height: 193 mm (7.6 in), with the feet installed Width: 445 mm (17.5 in), with the handle Depth: 434 mm (17.1 in), with the front cover installed Rackmount Oscilloscope Height: 178 mm (7.0 in) Width: 483 mm (19.0 in) Depth: 558.8 mm (22.0 in)

Warranted Characteristics

Tables 1–10 through 1–14 lists the various *warranted characteristics* that describe the TDS 500D, TDS 600C, TDS 700D and TDS 714L oscilloscopes. Electrical and environmental characteristics are included. Table 1–15 lists certifications and compliances.

Warranted characteristics are described in terms of quantifiable performance limits which are warranted.

NOTE. *In these tables, those warranted characteristics that are checked in the procedure Performance Verification appear in **boldface type** under the column Name.*

As stated above, this section lists only warranted characteristics. A list of *typical characteristics* starts on page 1–29.

The performance limits in this specification are valid with these conditions:

- The oscilloscope must have been calibrated/adjusted at an ambient temperature between +20° C and +30° C.
- The oscilloscope must be in an environment with temperature, altitude, humidity, and vibration within the operating limits described in these specifications.
- The oscilloscope must have had a warm-up period of at least 20 minutes.
- The oscilloscope must have had its signal-path-compensation routine last executed after at least a 20 minute warm-up period at an ambient temperature within $\pm 5^{\circ}$ C of the current ambient temperature.

Table 1–10: Warranted characteristics — Signal acquisition system

Name	Description		
Accuracy, DC Gain	TDS 600C: $\pm 1.5\%$ for all sensitivities from 2 mV/div to 10 V/div $\pm 2.0\%$ at 1 mV/div sensitivity TDS 500D, 700D, 714L: $\pm 1\%$ for all sensitivities from 1 mV/div to 10 V/div with offset from 0 V to ± 100V TDS 694C/794D: $\pm 1\%$ for all sensitivities from 10 mV/div to 1 V/div over permitted offset range		
Accuracy, DC Voltage Measurement, Averaged (using Average mode)	Measurement type	DC Accuracy	
	Average of ≥ 16 waveforms Delta volts between any two averages of ≥ 16 waveforms acquired under the same setup and ambient conditions	TDS 600C: $\pm((1.5\% \times \text{reading} - \text{Net Offset}^1) + \text{Offset Accuracy}) + (0.06 \text{ div} \times \text{V/div})$ TDS 500D, TDS 694C, 700D, 714L: $\pm((1.0\% \times \text{reading} - \text{Net Offset}^1) + \text{Offset Accuracy} + (0.06 \text{ div} \times \text{V/div}))$ TDS 600C: $\pm((1.5\% \times \text{reading}) + (0.1 \text{ div} \times \text{V/div}) + 0.3 \text{ mV})$ TDS 500D, TDS 694C, 700D, 714L: $\pm((1.0\% \times \text{reading}) + (0.1 \text{ div} \times \text{V/div}) + 0.3 \text{ mV})$	
Accuracy, Offset All except TDS 694C/794D	Volts/Div setting	TDS 600C Offset accuracy	TDS 500D/700D/714L Offset accuracy
	1 mV/div – 100 mV/div	$\pm((0.2\% \times \text{Net Offset}^1) + 1.5 \text{ mV} + (0.6 \text{ div} \times \text{V/div}))$	$\pm((0.2\% \times \text{Net Offset}^1) + 1.5 \text{ mV} + (0.1 \text{ div} \times \text{V/div}))$
	101 mV/div – 1 V/div	$\pm((0.25\% \times \text{Net Offset}^1) + 15 \text{ mV} + (0.6 \text{ div} \times \text{V/div}))$	$\pm((0.25\% \times \text{Net Offset}^1) + 15 \text{ mV} + (0.1 \text{ div} \times \text{V/div}))$
Accuracy, Offset TDS 694C and TDS 794D	1.01 V/div – 10 V/div	$\pm((0.25\% \times \text{Net Offset}^1) + 150 \text{ mV} + (0.6 \text{ div} \times \text{V/div}))$	$\pm((0.25\% \times \text{Net Offset}^1) + 150 \text{ mV} + (0.1 \text{ div} \times \text{V/div}))$
	Volts/Div setting	TDS 694C Offset accuracy	TDS 794D Offset accuracy
	10 mV/div – 100 mV/div	$\pm((0.2\% \times \text{Net Offset}^1) + 1.5 \text{ mV} + (0.1 \text{ div} \times \text{V/div}))$	$\pm((0.2\% \times \text{Net Offset}^1) + 1.5 \text{ mV} + (0.1 \text{ div} \times \text{V/div}))$
	101 mV/div – 1 V/div	$\pm((2.50\% \times \text{Net Offset}^1) + 15 \text{ mV} + (0.1 \text{ div} \times \text{V/div}))$	$\pm((0.25\% \times \text{Net Offset}^1) + 15 \text{ mV} + (0.1 \text{ div} \times \text{V/div}))$

Table 1–10: Warranted characteristics — Signal acquisition system (cont.)

Name	Description		
Analog Bandwidth, DC-50 Ω Coupled and Bandwidth selection is FULL, TDS 600C	Volts/Div	TDS 654C Bandwidth ²	TDS 680C & 684C Bandwidth ²
	10 mV/div – 1 V/div	DC – 500 MHz	DC – 1 GHz
	5 mV/div – 9.95 mV/div	DC – 450 MHz	DC – 750 MHz
	2 mV/div – 4.98 mV/div	DC – 300 MHz	DC – 600 MHz
	1 mV/div – 1.99 mV/div	DC – 250 MHz	DC – 500 MHz
	Volts/Div	TDS 694C Bandwidth ²	
Analog Bandwidth, DC-50 Ω Coupled and Bandwidth selection is FULL, TDS 500D/700D/714L	10 mV/div – 1 V/div	DC – 3 GHz	
	Volts/Div	TDS 520D, 540D, 714L, 724D & 754D Bandwidth ²	TDS 580D & TDS 784D Bandwidth ²
	10 mV/div – 1 V/div	DC – 500 MHz	DC – 1 GHz
	5 mV/div – 9.95 mV/div	DC – 500 MHz	DC – 750 MHz
	2 mV/div – 4.98 mV/div	DC – 500 MHz	DC – 600 MHz
	1 mV/div – 1.99 mV/div	DC – 450 MHz	DC – 500 MHz
	Volts/Div	TDS 794D Bandwidth ²	
	10 mV/div – 1 V/div	DC – 2 GHz	
Crosstalk (Channel Isolation)	$\geq 100:1$ at 100 MHz and $\geq 30:1$ at the rated bandwidth for the channel's Volt/Div setting, for any two channels having equal Volts/Div settings. TDS 694C: $\geq 100:1$ at rated bandwidth for any two channels having equal Volts/Div settings.		
Delay Between Channels, Full Bandwidth	TDS 600C: ≤ 100 ps for any two channels with equal Volts/Div and Coupling settings and both channels' deskew values set to 0 TDS 500D, TDS 694C, TDS 700D, TDS 714L: ≤ 50 ps for any two channels with equal Volts/Div and Coupling settings and both channel deskew values set to 0.0 μ s.		
Input Impedance, DC–1 M Ω Coupled	1 M Ω $\pm 0.5\%$ in parallel with 10 pF ± 3 pF (DC–50 Ω Coupled only on TDS 694C/794D)		
Input Impedance, DC–50 Ω Coupled	50 Ω $\pm 1\%$ with VSWR $\leq 1.3:1$ from DC – 500 MHz, $\leq 1.5:1$ from 500 MHz – 1 GHz		
Input Impedance, DC–50 Ω Coupled TDS 694C	50 Ω $\pm 1.25\%$ with VSWR $\leq 1.5:1$ from 100 MHz – 1 GHz, VSWR $\leq 1.7:1$ from 1 GHz – 2 GHz, VSWR $\leq 2.0:1$ from 2 GHz – 3 GHz		
Input Impedance, DC–50 Ω Coupled TDS 794D	50 Ω $\pm 1.25\%$ with VSWR $\leq 1.5:1$ from 100 MHz – 1 GHz, VSWR $\leq 1.7:1$ from 1 GHz – 2 GHz		
Input Voltage, Maximum, DC–1 M Ω , AC–1 M Ω , or GND Coupled	TDS 600C (except TDS 694C): ± 300 V CAT II, 400 V peak; derate at 20 dB/decade above 1 MHz TDS 500D/700D/714L (except TDS 794D): ± 300 V CAT II, 400 V peak; derate at 20 dB/decade above 1 MHz		

Table 1–10: Warranted characteristics — Signal acquisition system (cont.)

Name	Description
Input Voltage, Maximum, DC-50 Ω or AC-50 Ω Coupled	5 V _{RMS} , with peaks $\leq \pm 30$ V
¹ Net Offset = Offset – (Position $\times$ Volts/Div). Net Offset is the nominal voltage level at the oscilloscope input that corresponds to the center of the A-D converter's dynamic range. Offset Accuracy is the accuracy of this voltage level.	
² The limits given are for the ambient temperature range of 0°C to +30°C, range of 4°C to +30°C for a TDS694C. Reduce the upper bandwidth frequencies by 5 MHz for the TDS 600C, by 20 MHz for TDS 694C, by 2.5 MHz for the 500 MHz TDS 500D/700D/714L models, by 5 MHz for the 1 GHz TDS 500D/700D models, and by 10 MHz for the 2 GHz TDS 500D/700D models for each °C above +30°C.	
Input Voltage, Maximum, DC-50 Ω Coupled TDS 694C/794D ?	5 V _{RMS} , with peaks $\leq \pm 20$ V
Lower Frequency Limit, AC Coupled	≤ 10 Hz when AC-1 M Ω Coupled; ≤ 200 kHz when AC-50 Ω Coupled ³
³ The AC Coupled Lower Frequency Limits are reduced by a factor of 10 when 10X passive probes are used.	

Table 1–11: Warranted characteristics — Time base system

Name	Description
Accuracy, Long Term Sample Rate and Delay Time	TDS 600C: ± 100 ppm over any ≥ 1 ms interval TDS 694C: ± 10 ppm over any ≥ 1 ms interval TDS 500D/700D/714L: ± 25 ppm over any ≥ 1 ms interval
Accuracy, Delta Time Measurement (Except for Option 1G and TDS 714L)	The limits are given in the following table for signals having amplitude greater than 5 divisions, reference level = 50%, filter set to (sinX/X), acquired at 5 mV/div or greater. For the TDS 700D, pulse duration < 10 div. Channel skew not included. For the Single Shot condition, $1.4 \leq T_r \div S \leq 4$, where S is the sample rate and T_r is the displayed rise time. Extra error in the measurement will occur for two-channel measurements due to channel-to-channel skew. This is described elsewhere in these specifications.
Conditions for accuracy listed at right are: Single Shot or Sample mode (or HiRes mode on the TDS 500D/700D), with Full Bandwidth selected.	Time measurement accuracy
	TDS 600C: $\pm((0.20 \div \text{sample rate}) + (100 \text{ ppm} \times \text{Reading}))$
	TDS 500D/700D: $\pm((0.15 \div \text{sample rate}) + (25 \text{ ppm} \times \text{Reading}))$
	TDS 694C: $\pm((0.15 \div \text{sample rate}) + (10 \text{ ppm} \times \text{Reading}))$
	Example: at 5 GS/s, 5 ns/div, measuring a 40 ns wide pulse, accuracy = $\pm(40 \text{ ps} + 4 \text{ ps}) = \pm 44 \text{ ps}$.

Table 1–12: Warranted characteristics — Triggering system

Name	Description		
Sensitivity, Edge-Type Trigger, Coupling set to “DC” ¹	Trigger source	Sensitivity	
	Any Channel	TDS 694C: 0.35 division from DC to 50 MHz, increasing to 1 division at 3 GHz main, 1.5 GHz delayed	
		TDS 680C & 684C: 0.35 division from DC to 50 MHz, increasing to 1 division at 1 GHz	
		TDS 500D, 714L, 724D, & 754D: 0.35 division from DC to 50 MHz, increasing to 1 division at 500 MHz	
		TDS 580D & 784D: 0.35 division from DC to 50 MHz, increasing to 1 division at 1 GHz	
		TDS 794D: 0.35 division from DC to 50 MHz, increasing to 1 division at 1.5 GHz	
	Auxiliary	TDS 600C: 250 mV from DC to 50 MHz, increasing to 500 mV at 100 MHz	
		TDS 500D, 714L, 724D, & 754D: 400 mV from DC to 50 MHz, increasing to 750 mV at 100 MHz	
		TDS 580D & 784D: 250 mV from DC to 50 MHz, increasing to 500 mV at 100 MHz	
		TDS 794D: 250 mV from DC to 50 MHz, increasing to 500 mV at 100 MHz	
Width, Minimum Pulse and Rearm, for Pulse Triggering The minimum pulse widths and rearm widths and transition times ² required for Pulse-Type triggering.	For vertical settings > 10 mV/div. and ≤1 V/div at the BNC input		
	Pulse class	Minimum pulse width	Minimum re-arm width
	Glitch	1 ns	2 ns + 5% of Glitch Width Setting
	Runt	2 ns TDS 694C: 1 ns	2 ns
	Time-Qualified Runt	2 ns TDS 694C: 1 ns	TDS 694C & TDS 700D/714L: 8.5 ns + 5% of Width Setting
	Width	1 ns	2 ns + 5% of Width Upper Limit Setting
	Timeout	1 ns	2 ns + 5% of Width Upper Limit Setting
	Slew Rate	600 ps ²	TDS 694C & TDS 700D/714L: 8.5 ns + 5% of Delta Time Setting

Table 1–12: Warranted characteristics — Triggering system (Cont.)

Name	Description	
Accuracy (Time) for Pulse-Glitch or Pulse-Width Triggering	Time range	Accuracy
	2 ns to 500 ns	$\pm(20\% \text{ of setting} + 0.5 \text{ ns})$
	520 ns to 1 s	$\pm(100 \text{ ns} + 0.01\% \text{ of Setting})$
Input Signal Sync Amplitude for Stable Triggering, NTSC and PAL modes (Option 05 Video Trigger)	Field selection “Odd”, “Even”, or “All”: 0.6 division to 4 divisions Field selection “Numeric”: 1 division to 4 divisions (NTSC mode)	
Jitter (Option 05 Video Trigger)	60 ns _{p-p} on NTSC or PAL signal	

- ¹ The minimum sensitivity for obtaining a stable trigger. A stable trigger results in a uniform, regular display triggered on the selected slope. The trigger point must not switch between opposite slopes on the waveform, and the display must not “roll” across the screen on successive acquisitions. The TRIG'D LED stays constantly lighted when the SEC/DIV setting is 2 ms or faster but may flash when the SEC/DIV setting is 10 ms or slower.
- ² For Slew Rate Triggering, this is the minimum transition time, defined to be the time the user's signal spends between the two trigger threshold settings.

Table 1–13: Warranted characteristics — Output ports, probe compensator, and power requirements

Name	Description	
Logic Levels, Main- and Delayed-Trigger Outputs	Characteristic	Limits
	Vout (HI)	$\geq 2.5 \text{ V}$ open circuit; $\geq 1.0 \text{ V}$ into a 50Ω load to ground
	Vout (LO)	$\leq 0.7 \text{ V}$ into a load of $\leq 4 \text{ mA}$; $\leq 0.25 \text{ V}$ into a 50Ω load to ground
Output Voltage and Frequency, Probe Compensator	Characteristic	Limits
	Output Voltage	0.5 V (base-top) $\pm 1\%$ into a $\geq 50 \Omega$ load
	Frequency	$1 \text{ kHz} \pm 5\%$
Output Voltage, Signal Out (CH 3 ¹) Not on TDS 694C	For TDS 600C: $20 \text{ mV/division} \pm 20\%$ into a $1 \text{ M}\Omega$ load; $10 \text{ mV/division} \pm 20\%$ into a 50Ω load For TDS 500D/700D/714L: $22 \text{ mV/division} \pm 20\%$ into a $1 \text{ M}\Omega$ load; $11 \text{ mV/division} \pm 20\%$ into a 50Ω load	
Source Voltage	$100 \text{ to } 240 \text{ VAC}_{\text{RMS}}$, continuous range, CAT II	
Source Frequency	$45 \text{ Hz to } 440 \text{ Hz}$	
Power Consumption TDS 694C	$\leq 350 \text{ W}$ (450 VA) $\leq 450 \text{ W}$ (500 VA)	

- ¹ CH 3 signal out is present at the rear panel if CH 3 (AUX 1 on the TDS 680C) is selected as the trigger source for the main and/or delayed trigger systems. It is not available when a channel other than CH3 (AUX 1 on the TDS 680C) is the source for the Video Trigger when Option 05 is installed.

Table 1–14: Warranted characteristics — Environmental

Name	Description
Atmospherics	Temperature (no disk in floppy drive): TDS 600C: Operating: +4° C to +45° C TDS 694C: Operating: +4° C to +40° C Floppy disk drive: Operating: +10° C to +45° C Nonoperating: –22° C to +60° C TDS 500D/700D/714L: Operating: +0° C to +50° C Floppy disk drive: Operating: +10° C to +50° C Nonoperating: –22° C to +60° C Relative humidity (no disk in floppy drive): Operating: 20% to 80%, at or below +32° C, upper limit derates to 30% relative humidity at +45° C Operating: TDS 694C: 20% to 80%, at or below +32° C, upper limit derates to 30% relative humidity at +40° C Nonoperating: TDS 500D/700D/714L: 5% to 90%, at or below +31° C, upper limit derates to 20% relative humidity at 60° C TDS 600C: 5% to 90%, at or below +41° C, upper limit derates to 30% relative humidity at 60° C Altitude: To 4570 m (15,000 ft.), operating (excluding hard disk drive) To 3048 m (10,000 ft.), operating (including hard disk drive) To 12190 m (40,000 ft.), nonoperating
Dynamics	Random vibration (floppy disk not installed): 0.31 g rms, from 5 to 500 Hz, 10 minutes each axis, operating 2.46 g rms, from 5 to 500 Hz, 10 minutes each axis, nonoperating

Table 1–14: Warranted characteristics — Environmental (cont.)

Name	Description
Approvals	Conforms to and is certified where appropriate to: UL 3111–1 ² – Standard for electrical measuring and test equipment CAN/CSA C22.2 no. 1010.1 ² – Safety requirements for electrical equipment for measurement, control and laboratory use

- ² **UL 3111, CSA 22.2 no.1010 Safety Certification Compliance:**
Temperature (operating) 5 to +40 C
Altitude (maximum operating): 2000 meters
Equipment Type: Test and Measurement
Safety Class: Class I (as defined in IEC 1010–1, Annex H) – grounded product
Overvoltage Category: Overvoltage Category II (as defined in IEC 1010–1, Annex J)
Pollution Degree: Pollution Degree 2 (as defined in IEC 1010–1)
Note – Rated for indoor use only

Table 1–15: Certifications and compliances

EC Declaration of Conformity — EMC ³ (TDS 500D, TDS 700D, and TDS 714L)	Meets intent of Directive 89/336/EEC for Electromagnetic Compatibility. Compliance was demonstrated to the following specifications as listed in the Official Journal of the European Union: <table> <tr> <td>EN 55011</td><td>Class A Radiated and Conducted Emissions</td></tr> <tr> <td>EN 50081-1 Emissions:</td><td></td></tr> <tr> <td> EN 60555-2</td><td>AC Power Line Harmonic Emissions</td></tr> <tr> <td>EN 50082-1 Immunity:</td><td></td></tr> <tr> <td> IEC 801-2</td><td>Electrostatic Discharge Immunity</td></tr> <tr> <td> IEC 801-3</td><td>RF Electromagnetic Field Immunity</td></tr> <tr> <td> IEC 801-4</td><td>Electrical Fast Transient/Burst Immunity</td></tr> <tr> <td> IEC 801-5</td><td>AC Power Line Surge Immunity</td></tr> </table>	EN 55011	Class A Radiated and Conducted Emissions	EN 50081-1 Emissions:		EN 60555-2	AC Power Line Harmonic Emissions	EN 50082-1 Immunity:		IEC 801-2	Electrostatic Discharge Immunity	IEC 801-3	RF Electromagnetic Field Immunity	IEC 801-4	Electrical Fast Transient/Burst Immunity	IEC 801-5	AC Power Line Surge Immunity				
EN 55011	Class A Radiated and Conducted Emissions																				
EN 50081-1 Emissions:																					
EN 60555-2	AC Power Line Harmonic Emissions																				
EN 50082-1 Immunity:																					
IEC 801-2	Electrostatic Discharge Immunity																				
IEC 801-3	RF Electromagnetic Field Immunity																				
IEC 801-4	Electrical Fast Transient/Burst Immunity																				
IEC 801-5	AC Power Line Surge Immunity																				
EC Declaration of Conformity — EMC ³ (TDS 600C)	Meets intent of Directive 89/336/EEC for Electromagnetic Compatibility. Compliance was demonstrated to the following specifications as listed in the Official Journal of the European Union: <table> <tr> <td>EN 55011</td><td>Class A Radiated and Conducted Emissions</td></tr> <tr> <td>IEC 61000-3-2</td><td>AC Power Line Harmonic Emissions</td></tr> <tr> <td>EN 50082-1 Immunity:</td><td></td></tr> <tr> <td> IEC 61000-4-2</td><td>Electrostatic Discharge Immunity</td></tr> <tr> <td> IEC 61000-4-3</td><td>RF Electromagnetic Field Immunity</td></tr> <tr> <td> IEC 61000-4-4</td><td>Electrical Fast Transient/Burst Immunity</td></tr> <tr> <td> IEC 61000-4-5</td><td>AC Power Line Surge Immunity</td></tr> <tr> <td> IEC 61000-4-6</td><td>RF Conducted Immunity</td></tr> <tr> <td> IEC 1000-4-8</td><td>Magnetic Field Immunity</td></tr> <tr> <td> IEC 1000-4-11</td><td>AC Power Line Interruption Immunity</td></tr> </table>	EN 55011	Class A Radiated and Conducted Emissions	IEC 61000-3-2	AC Power Line Harmonic Emissions	EN 50082-1 Immunity:		IEC 61000-4-2	Electrostatic Discharge Immunity	IEC 61000-4-3	RF Electromagnetic Field Immunity	IEC 61000-4-4	Electrical Fast Transient/Burst Immunity	IEC 61000-4-5	AC Power Line Surge Immunity	IEC 61000-4-6	RF Conducted Immunity	IEC 1000-4-8	Magnetic Field Immunity	IEC 1000-4-11	AC Power Line Interruption Immunity
EN 55011	Class A Radiated and Conducted Emissions																				
IEC 61000-3-2	AC Power Line Harmonic Emissions																				
EN 50082-1 Immunity:																					
IEC 61000-4-2	Electrostatic Discharge Immunity																				
IEC 61000-4-3	RF Electromagnetic Field Immunity																				
IEC 61000-4-4	Electrical Fast Transient/Burst Immunity																				
IEC 61000-4-5	AC Power Line Surge Immunity																				
IEC 61000-4-6	RF Conducted Immunity																				
IEC 1000-4-8	Magnetic Field Immunity																				
IEC 1000-4-11	AC Power Line Interruption Immunity																				
Australia/New Zealand Declaration of Conformity – EMC	Complies with EMC provision of Radiocommunications Act per the following standard(s): <table> <tr> <td>AS/NZS 2064.1/2</td><td>Industrial, Scientific, and Medical Equipment: 1992</td></tr> </table>	AS/NZS 2064.1/2	Industrial, Scientific, and Medical Equipment: 1992																		
AS/NZS 2064.1/2	Industrial, Scientific, and Medical Equipment: 1992																				
EC Declaration of Conformity – Low Voltage	Compliance was demonstrated to the following specification as listed in the Official Journal of the European Communities: Low Voltage Directive 73/23/EEC, amended by 93/69/EEC <table> <tr> <td>EN 61010-1/A2:1995</td><td>Safety requirements for electrical equipment for measurement, control, and laboratory use</td></tr> </table>	EN 61010-1/A2:1995	Safety requirements for electrical equipment for measurement, control, and laboratory use																		
EN 61010-1/A2:1995	Safety requirements for electrical equipment for measurement, control, and laboratory use																				

³ To ensure compliance with EMC requirements, only high quality shielded cables having a reliable, continuous outer shield with full coverage and low impedance connections to shielded connector housings at both ends should be connected to this product. The following cables, or their equivalent, may be used:

GPIB: Tektronix P/N 012–0991–00, –01, –02, or –03

RS–232: Computer Accessories P/N CA 0294–9

Centronics: Tektronix P/N 012–1214–00

VGA: LCOM P/N CTL3VGAMM–5 (if connected, terminate the cable)

Typical Characteristics

Tables 1–16 and 1–18 list the various *typical characteristics* which describe the TDS 500D, TDS 600C, TDS 700D and TDS 714L oscilloscopes.

Typical characteristics are described in terms of typical or average performance. Typical characteristics are not warranted.

Table 1–16: Typical characteristics — Signal acquisition system

Name	Description	
Analog Bandwidth, DC-50 Ω Coupled with P6243 or P6245 Probe and Bandwidth selection is FULL TDS 520D, 540D, 714L, 724D & 754D	Volts/Div as read out on screen	520D, 540D, 714L, 724D & 754D Bandwidth¹
	10 V/div – 100 V/div	Not Applicable
	100 mV/div – 10 V/div	DC – 500 MHz
	50 mV/div – 99.5 mV/div	DC – 500 MHz
	20 mV/div – 49.8 mV/div	DC – 500 MHz
	10 mV/div – 19.9 mV/div	DC – 450 MHz (P6243) DC – 500 MHz (P6245)
Analog Bandwidth, DC-50 Ω Coupled with P6245 Probe and Bandwidth selection is FULL TDS 580D & TDS 784D	Volts/Div as read out on screen	TDS 580D & TDS 784D
	10 V/div – 100 V/div	(Not Applicable)
	100 mV/div – 10 V/div	DC – 1 GHz
	50 mV/div – 99.5 mV/div	DC – 750 MHz
	20 mV/div – 49.8 mV/div	DC – 600 MHz
	10 mV/div – 19.9 mV/div	DC – 500 MHz
Analog Bandwidth, DC-50 Ω Coupled with P6249 Probe TDS 694C	Volts/Div as read out on screen	TDS 694C¹
	100 mV/div – 10 V/div	DC – 3 GHz
Analog Bandwidth, DC-50 Ω Coupled with P6217 Probe TDS 794D	Volts/Div as read out on screen	TDS 794D
	100 mV/div – 10 V/div	DC – 2 GHz
Analog Bandwidth, DC-1 M Ω Coupled with P6139A Probe and Bandwidth selection is FULL TDS 520D, 540D, 580D, 714L, 724D, 754D & 784D	Volts/Div as read out on screen	TDS 520D, 540D, 714L, 724D, 754D & 784D Bandwidth¹
	10 V/div – 100 V/div	500 MHz
	100 mV/div – 10 V/div	500 MHz
	50 mV/div – 99.5 mV/div	500 MHz
	20 mV/div – 49.8 mV/div	500 MHz
	10 mV/div – 19.9 mV/div	500 MHz

Table 1–16: Typical characteristics — Signal acquisition system (cont.)

Name	Description		
Analog Bandwidth, DC-50 Ω Coupled with P6139A Probe (TDS 654C) or P6245 Probe (TDS 680C & 684C) and Bandwidth selection is FULL TDS 600C	Volts/Div as read out on screen	TDS 654C Bandwidth¹	TDS 680C & 684C Bandwidth¹
	10 V/div – 100 V/div	(Not Applicable)	(Not Applicable)
	100 mV/div – 10 V/div	DC – 500 MHz	DC – 1 GHz
	50 mV/div – 99.5 mV/div	DC – 450 MHz	DC – 750 MHz
	20 mV/div – 49.8 mV/div	DC – 300 MHz	DC – 600 MHz
	10 mV/div – 19.9 mV/div	DC – 250 MHz	DC – 500 MHz
Accuracy, Delta Time Measurement Conditions for accuracy listed at right are: ≥ 100 Averages, with Full Bandwidth selected, and for TDS 500D/700D/714L, repetitive mode.	The limits are given in the following table for signals having amplitude greater than 5 divisions, reference level = 50%, filter set to (sinX/X), acquired at 5 mV/div or greater. For the TDS 700D/714L, pulse duration < 10 division. Channel skew not included.		
	TDS 600C: For the averaged condition, $1.4 \leq T_r/W_i \leq 40$, where W_i is the Waveform Interval, as described elsewhere in these specifications.		
	Extra error in the measurement will occur for two-channel measurements due to channel-to-channel skew. This is described elsewhere in these specifications.		
	Time measurement accuracy		
	TDS 600C: $\pm(10 \text{ ps} + (100 \text{ ppm} \times \text{Reading}) + (0.2 \times W_i))$ TDS 500D/700D/714L: $\pm(20 \text{ ps} + (25 \text{ ppm} \times \text{Reading}) + (0.15 \times W_i))$ TDS 694C: $\pm(5 \text{ ps} + (10 \text{ ppm} \times \text{Reading}))$		
Calculated Rise Time, TDS 600C ² (except TDS 694C)	Volts/Div setting	TDS 654C Rise time	TDS 680C & 684C Rise time
	10 mV/div – 1 V/div	900 ps	450 ps
	5 mV/div – 9.95 mV/div	1 ns	600 ps
	2 mV/div – 4.98 mV/div	1.5 ns	750 ps
	1 mV/div – 1.99 mV/div	1.8 ns	900 ps
Calculated Rise Time, TDS 500D/700D/714L ²	Volts/Div setting	520D, 540D, 714L, 724D, & 754D Rise time	580D & 784D Rise time
	10 mV/div – 1 V/div	800 ps	400 ps
	5 mV/div – 9.95 mV/div	800 ps	530 ps
	2 mV/div – 4.98 mV/div	800 ps	600 ps
	1 mV/div – 1.99 mV/div	890 ps	800 ps
Calculated Rise Time, TDS 694C ²	Volts/Div setting	694C Rise time	
	10 mV/div – 1 V/div	133 ps	
Calculated Rise Time, TDS 794D ²	Volts/Div setting	794D Rise time	
	10 mV/div – 1 V/div	200 ps	

Table 1–16: Typical characteristics — Signal acquisition system (cont.)

Name	Description		
Effective Bits — TDS 694C The chart on the right gives the typical effective bits for a 9.2 divisions p-p sine wave input at 50 mV/div @ 25° C.	Input frequency	Sample rate	
		10 GS/s	
	1 MHz	6.6 bits	
	1 GHz	5.5 bits	
	2 GHz	4.5 bits	
Effective Bits — TDS 600C (except TDS 694C) The chart on the right gives the typical effective bits for a 9-division p-p sine-wave input, 50 mV/div, 10 ns/div (5 GS/s), with a record length of 1000 points	Input frequency		Effective bits
	98 MHz		6.3 bits
	245 MHz		6.0 bits
	490 MHz		5.5 bits
	990 MHz		5.2 bits (TDS 680C & 684C only)
Effective Bits — TDS 520D & 724D The chart on the right gives the typical effective bits for a sine wave adjusted to 9.2 divisions at 1 MHz, 50 mV/div @ 25° C.	Input frequency	Sample rate	
		1 GS/s	10 MS/s & HiRes
	1 MHz	6.8 bits	9.7 bits
	490 MHz	6.5 bits	N/A
Effective Bits — TDS 540D & 754D The chart on the right gives the typical effective bits for a sine wave adjusted to 9.2 divisions at 1 MHz, 50 mV/div @ 25° C.	Input frequency	Sample rate	
		2 GS/s	10 MS/s & HiRes
	1 MHz	6.8 bits	9.7 bits
	500 MHz	6.8 bits	N/A
Effective Bits — TDS 714L The chart on the right gives the typical effective bits for a sine wave adjusted to 9.2 divisions at 1 MHz, 50 mV/div @ 25° C.	Input frequency	Sample rate	
		500 MS/s	10 MS/s & HiRes
	1 MHz	6.8 bits	9.7 bits
	500 MHz	6.8 bits	N/A
Effective Bits — TDS 580D, 784D & 794D The chart on the right gives the typical effective bits for a sine wave adjusted to 9.2 divisions at 1 MHz, 50 mV/div @ 25° C.	Input frequency	Sample rate	
		4 GS/s	10 MS/s & HiRes
	1 MHz	6.6 bits	9.7 bits
	1 GHz	5.5 bits	N/A
	2 GHz – 6.5 divs (TDS 794D only)	4.5 bits	N/A
Frequency Limit, Upper, 250 MHz Bandwidth Limited	250 MHz		
Frequency Limit, Upper, 20 MHz Bandwidth Limited	20 MHz		

Table 1–16: Typical characteristics — Signal acquisition system (cont.)

Name	Description				
Step Response Settling Errors	Volts/Div setting	± Step amplitude	Settling error (%) ³ at		
			20 ns	100 ns	20 ms
	1 mV/div – 100 mV/div	≤2 V	≤0.5%	≤0.2%	≤0.1%
	101 mV/div – 1 V/div	≤20 V	≤1.0%	≤0.5%	≤0.2%
Step Response Settling Errors TDS 694C/794D	1.01 V/div – 10 V/div	≤200 V	≤1.0%	≤0.5%	≤0.2%
	10 mV/div – 100 mV/div	≤1.5 V	≤0.5%	≤0.2%	≤0.1%
	101 mV/div – 1 V/div	≤3 V	≤1.0%	≤0.5%	≤0.2%

¹ The limits given are for the ambient temperature range of 0°C to +30°C, TDS 694C 4°C to +30°C. Reduce the upper bandwidth frequencies by 5 MHz for the TDS 600C or by 2.5 MHz for the TDS 500D/700D/714L for each °C above +30°C. For the TDS 694C and TDS 794D reduce the upper bandwidth frequencies by 10 MHz for each °C above +30°C.

² The numbers given are valid 0°C to +30°C and will increase as the temperature increases due to the degradation in bandwidth. Rise time is calculated from the bandwidth. It is defined by the following formula:

$$TDS\ 600C\ Rise\ Time\ (ns) = \frac{450}{BW\ (MHz)} \quad TDS\ 500D/694C/700D\ Rise\ Time\ (ns) = \frac{400}{BW\ (MHz)}$$

Note that if you measure rise time, you must take into account the rise time of the test equipment (signal source, etc.) that you use to provide the test signal. That is, the measured rise time (RT_m) is determined by the instrument rise time (RT_i) and the rise time of the test signal source (RT_{gen}) according to the following formula:

$$RT_m^2 = RT_i^2 + RT_{gen}^2$$

³ The values given are the maximum absolute difference between the value at the end of a specified time interval after the midlevel crossing of the step and the value one second after the midlevel crossing of the step, expressed as a percentage of the step amplitude.

Table 1–17: Typical characteristics — Time base system

Name	Description
Accuracy, Delta Time Measurement (TDS 500D/700D Option 1G and TDS 714L)	The limits are given in the following table for signals having amplitude greater than 5 divisions, reference level = 50%, filter set to (sinX/X), acquired at 5 mV/div or greater. For the TDS 500D/700D Option 1G and the TDS 714L, pulse duration < 10 div. Channel skew not included.
Conditions for accuracy listed at right are: Single Shot, Sample or HiRes mode with Full Bandwidth selected.	For the Single Shot condition, $1.4 \leq T_r \div S \leq 4$, where S is the sample rate and T_r is the displayed rise time.
	Extra error in the measurement will occur for two-channel measurements due to channel-to-channel skew. This is described elsewhere in these specifications.
	Time measurement accuracy
	$\pm((0.15 \div \text{sample rate}) + (25 \text{ ppm} \times \text{Reading}))$

Table 1–18: Typical characteristics — Triggering system

Name	Description	
Accuracy, Trigger Level or Threshold, DC Coupled (for signals having rise and fall times ≥ 20 ns)	Trigger source	Accuracy
	Any Channel	$\pm((2\% \times \text{Setting} - \text{Net Offset}) + (0.3 \text{ div} \times \text{Volts/div Setting}) + \text{Offset Accuracy})$
	Auxiliary	Not calibrated or specified
Input, Auxiliary Trigger	The input resistance is $\geq 1.5 \text{ k}\Omega$; the maximum safe input voltage is $\pm 20 \text{ V}$ (DC + peak AC).	
Trigger Position Error, Edge Triggering	Acquisition mode	Trigger-position error^{1,2}
	Sample, Average	$\pm(1 \text{ Waveform Interval} + 1 \text{ ns})$
	Envelope	$\pm(2 \text{ Waveform Intervals} + 1 \text{ ns})$
Holdoff, Variable, Main Trigger	For all Time/Division ranges, the minimum holdoff is 250 ns and the maximum holdoff is 12 seconds. The minimum resolution is 8 ns for settings $\leq 1.2 \mu\text{s}$.	
Lowest Frequency for Successful Operation of “Set Level to 50%” Function	30 Hz TDS 694C: 50 Hz	
Trigger Jitter	TDS 580D, 680C, 684C, 784D, and 794D: $\sigma = 7 \text{ ps}$ TDS 520D, 540D, 654C, 694C, 714L, 724D, 754D: $\sigma = 8 \text{ ps}$ Provide a pulse with $T_{\text{rise}} \leq 350 \text{ ps}$ into one channel. Set the scope to 100 ps/div (250 GS/s TDS 580D, 680C, 684C, 784D, and 794D; 5 GS/s TDS 654C, 680C, 684C), with 6 div of signal, and the trigger level set to 50% of the rising edge. Turn on a horizontal histogram, with the box set to minimum height at the trigger point. Enable StdDev and Hits in Box histogram measurements. Wait for a least 1000 hits, then note the standard deviation of the trigger point.	
Sensitivity, Edge Trigger, Not DC Coupled ³	Trigger source	Typical signal level for stable triggering
	AC	Same as the DC-coupled limits for frequencies above 60 Hz. Attenuates signals below 60 Hz.
	Noise Reject	Three times the DC-coupled limits.
	High Frequency Reject	One and one-half times the DC-coupled limits from DC to 30 kHz. Attenuates signals above 30 kHz.
	Low Frequency Reject	One and one-half times the DC-coupled limits for frequencies above 80 kHz. Attenuates signals below 80 kHz.
Sensitivities, Logic Trigger and Events Delay, DC Coupled ⁴	1.0 division, from DC to 500 MHz, at vertical settings $> 10 \text{ mV/div}$ and $\leq 1 \text{ V/div}$ at the BNC input	
Sensitivities, Pulse-Type Runt Trigger ⁵	1.0 division, from DC to 500 MHz, at vertical settings $> 10 \text{ mV/div}$ and $\leq 1 \text{ V/div}$ at the BNC input	
Sensitivities, Pulse-Type Trigger Width and Glitch ⁶	1.0 division, at vertical settings $> 10 \text{ mV/div}$ and $\leq 1 \text{ V/div}$ at the BNC input	

Table 1–18: Typical characteristics — Triggering system (cont.)

Name	Description			
Width, Minimum Pulse and Rearm, for Logic Triggering or Events Delay	For vertical settings > 10 mV/div and ≤ 1 V/div at the BNC input			
	Triggering type	Minimum pulse width	Minimum re-arm width	Minimum time between channels ⁷
	Logic	Not Applicable	1 ns	1 ns
	Events Delay	1 ns (for either + or – pulse widths)	Not Applicable	2 ns
Width, Minimum Pulse and Rearm, for Pulse Triggering The minimum pulse widths and rearm widths and transition times ⁸ required for Pulse-Type triggering.	For vertical settings > 10 mV/div. and 3 1 V/div at the BNC input			
	Pulse class	Minimum pulse width	Minimum re-arm width	
	Glitch	1 ns	2 ns + 5% of Glitch Width Setting	
	Runt	2 ns	2 ns	
	Time-Qualified Runt	2 ns TDS 694C: 1 ns	TDS 500D/700D/714L: 8.5 ns + 5% of width setting TDS 600C: 7 ns + 5% of Width Setting TDS 694C: 8 ns + 5% of Width Setting	
	Width	1 ns	2 ns + 5% of Width Upper Limit Setting	
	Timeout	1 ns	2 ns + 5% of Width Upper Limit Setting	
	Slew Rate	600 ps ⁸	TDS 500D/700D/714L: 8.5 ns + 5% of delta time setting TDS 600C: 7 ns + 5% of Delta Time Setting	
Setup/Hold Time Violation Trigger, Minimum Clock Pulse Widths	For vertical settings > 10 mV/div and ≤ 1 V/div at the BNC input, the minimum requirements are:			
	Minimum Pulse Width, Clock Active ⁹		Minimum Pulse Width, Clock Inactive ⁹	
	User Hold Time + 2.5 ns ¹⁰ User Hold Time + 2.6 ns ¹⁰		2 ns	
Input Signal Sync Amplitude for Stable Triggering, HDTV and FLEXFMT modes (Option 05 Video Trigger)	All field selections: 0.6 division to 4 divisions			
Jitter for HDTV mode (Option 05 Video Trigger)	17 ns _{p-p}			
Sync Width Flex Format and HDTV modes (Option 05 Video Trigger)	min. 400 ns			
Sync Duty Cycle, Flex Format and HDTV modes (Option 05 Video Trigger)	min. 50 to 1			
Hum Rejection (Option 05 Video Trigger)	NTSC and PAL: –20 dB without any trigger spec deterioration. Triggering will continue down to 0 dB with some performance deterioration.			

Table 1–18: Typical characteristics — Triggering system (cont.)

Name	Description
¹	The trigger position errors are typically less than the values given here. These values are for triggering signals having a slew rate at the trigger point of ≥ 0.5 division/ns.
²	The waveform interval (WI) is the time between the samples in the waveform record. Also, see the footnote for the characteristics <i>Sample Rate Range or Interpolated Waveform Rates</i> in Table 1–4, on page 1–12.
³	The minimum sensitivity for obtaining a stable trigger. A stable trigger results in a uniform, regular display triggered on the selected slope. The trigger point must not switch between opposite slopes on the waveform, and the display must not “roll” across the screen on successive acquisitions. The TRIG'D LED stays constantly lighted when the SEC/DIV setting is 2 ms or faster but may flash when the SEC/DIV setting is 10 ms or slower.
⁴	The minimum signal levels required for stable logic or pulse triggering of an acquisition, or for stable counting of a DC-coupled, events-delay signal. Also, see the footnote for <i>Sensitivity, Edge-Type Trigger, DC Coupled</i> in this table. (Stable counting of events is counting that misses no events and produces no extra, phantom events).
⁵	The minimum signal levels required for stable runt pulse triggering of an acquisition. Also, see the footnote for <i>Sensitivity, Edge-Type Trigger, DC Coupled</i> in this table. (Stable counting of events is counting that misses no events).
⁶	The minimum signal levels required for stable pulse width or glitch triggering of an acquisition. Also, see the footnote for <i>Sensitivity, Edge-Type Trigger, DC Coupled</i> in this table. (Stable counting of events is counting that misses no events).
⁷	For Logic, time between channels refers to the length of time a logic state derived from more than one channel must exist to be recognized. For Events, the time is the minimum time between a main and delayed event that will be recognized if more than one channel is used.
⁸	For Slew Rate Triggering, this is the minimum transition time, defined to be the time the user's signal spends between the two trigger threshold settings.
⁹	Active pulse width is the width of the clock pulse from its active edge (as defined in the Clock Edge selection in the Clock Source menu) to its inactive edge. Inactive pulse width is the width of the pulse from its inactive edge to its active edge.
¹⁰	User Hold Time is the number selected by the user in the Hold Time Menu.

Installation

Supplying Operating Power

NOTE. Read all information and heed all warnings in this subsection before connecting the oscilloscope to a power source.



WARNING. AC POWER SOURCE AND CONNECTION. The oscilloscope operates from a single-phase power source. It has a three-wire power cord and two-pole, three-terminal grounding type plug. The voltage to ground (earth) from either pole of the power source must not exceed the maximum rated operating voltage, 250 volts.

Before making connection to the power source, be sure the digitizing oscilloscope has a suitable two-pole, three-terminal grounding-type plug.

GROUNDING. This instrument is safety Class 1 equipment (IEC designation). All accessible conductive parts are directly connected through the grounding conductor of the power cord to the grounded (earthing) contact of the power plug.



WARNING. The power input plug must be inserted only in a mating receptacle with a grounding contact where earth ground has been verified by a qualified service person. Do not defeat the grounding connection. Any interruption of the grounding connection can create an electric shock hazard.

For electric shock protection, the grounding connection must be made before making connection to the instrument's input or output terminals.







Power Cord Information

A power cord with the appropriate plug configuration is supplied with each oscilloscope. Table 2–1 gives the color-coding of the conductors in the power cord. If you require a power cord other than the one supplied, refer to Table 2–2, Power Cord Identification.

Table 2-1: Power cord conductor identification

Conductor	Color	Alternate Color
Ungrounded (Line)	Brown	Black
Grounded (Neutral)	Light Blue	White
Grounded (Earthing)	Green/Yellow	Green

Table 2-2: Power cord identification

Plug configuration	Normal usage	Option number
	North America 125 V	Standard
	Europe 230 V	A1
	United Kingdom 230 V	A2
	Australia 230 V	A3
	North America 230 V	A4
	Switzerland 230 V	A5

Operating Voltage

This oscilloscope operates with any line voltage from 90–250 VAC_{RMS} with any line frequency from 45–440 Hz. There are two fuses, either of which may be used throughout the line voltage and frequency ranges. (The two fuses are not totally interchangeable as each requires a different fuse cap.)

Memory Backup Power

Memory modules with on-board batteries allow the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes to retain some types of data upon loss of the AC power source. The stored adjustment constants, saved front-panel settings, current front-panel settings (instrument status), and waveforms saved in memory are retained.

The on-board batteries of the memory modules have a shelf life of about five years. Partial or total loss of stored settings upon power on may indicate that the memory modules need to be replaced.

Operating Environment

The following environmental requirements are provided to ensure proper operation and long instrument life.

Operating Temperature

Operate oscilloscopes where the ambient air temperature is from 4° C to +45° C (+40° C for TDS 694C, +50° C for the TDS 500D, 700D and TDS 714L) with no diskette in the floppy drive. Store the oscilloscopes in ambient temperatures from –22° C to +60° C with no diskette in the floppy drive. After storage at temperatures outside the operating limits, allow the chassis to stabilize at a safe operating temperature before applying power.

Ventilation Requirements

The oscilloscopes are cooled by air drawn in and exhausted through their cabinet side panels by an internal fan. To ensure proper cooling of the oscilloscope, allow at least two inches clearance on both sides and 3/4 inch on the bottom of the oscilloscope. (The feet on the bottom of the oscilloscope provide the required clearance when set on flat surfaces.) The top of the oscilloscope does not require ventilation clearance.



CAUTION. *If air flow is restricted, the digitizing oscilloscope's power supply may temporarily shut down.*

Applying and Interrupting Power

Consider the following information when you power on or power off the instrument, or when power is interrupted due to an external power failure.

Power On

Upon power on, the oscilloscope runs a power-on self check. If it passes, the oscilloscope displays a “passed” status message and a prompt to press CLEAR MENU to continue. If it fails, the oscilloscope displays a diagnostic log that identifies the area(s) that failed and a prompt to press CLEAR MENU to continue. See Section 6, *Maintenance*, for information on diagnostics and fault isolation.

Power Off



CAUTION. *DO NOT power off the oscilloscope when either running a signal path compensation or when doing any of the adjustments described in Section 5, Adjustment Procedures. To do so might result in the loss of internally stored adjustment constants.*

In general, do not power off the instrument when doing operations that affect the data types listed in Table 1–1. Wait for the instrument to finish the operation when doing adjustments, saving waveforms, or saving setups.

Improper power off or unexpected loss of power to the oscilloscope can result in the following corruptions of nonvolatile RAM (NVRAM). The following table describes the messages displayed when power is restored after an abnormal power off.

Table 2–3: Effects of corrupted data

Corrupted Data Type	Results
Adjustment Constants:	
Signal Path Compensation	A signal path compensation is required
Voltage Reference	A voltage reference adjustment is required (Section 5)
Frequency Response	A frequency response adjustment is required (Section 5)
Error Log	Errors logged are lost
Reference Waveforms	Waveform Lost
Saved Setups	Setup Lost

Repackaging Instructions

Use a corrugated cardboard shipping carton having a test strength of at least 275 pounds and with an inside dimension at least six inches greater than the instrument dimensions.

If the instrument is being shipped to a Tektronix Service Center, enclose the following information: the owner's address, name and phone number of a contact person, type and serial number of the instrument, reason for returning, and a complete description of the service required.

Seal the shipping carton with an industrial stapler or strapping tape.

Mark the address of the Tektronix Service Center and also your own return address on the shipping carton in two prominent locations.

Installed Options

Your instrument may be equipped with one or more instrument options. Except for the line-cord options described by Table 2-2 (on page 2-2 of this section), all options and optional accessories are listed and described in Section 7, *Options*. For further information and prices of instrument options, see your Tektronix Products catalog or contact your Tektronix Field Office.

Operating Instructions

Before doing service, read the following operating instructions. These instructions are at the level appropriate for servicing these oscilloscopes. The *User Manual* contains more complete operating instructions.

Additional instructions are integrated into the service procedures found in later sections of this manual. For instance, the procedures found in the section *Performance Verification* contain instructions for making the front-panel settings required to check each instrument characteristic included there. Also, the general instructions for operating these oscilloscopes' internal diagnostic routines are found in Section 6, *Maintenance*. You may also find the *Product Description* in Section 1 useful for understanding how the oscilloscope functions.

Screen Layout

Figure 2–1 on page 2–8 shows the screen layout. This figure illustrates a full graticule. You may also select a grid, crosshair, or frame graticule from the display menu.

Basic Procedures

How to Power On

Push the principal power switch found on the rear panel of the oscilloscope, then push the **ON/STBY** (standby) switch to toggle the oscilloscope into operation. The switch at the rear panel is the true power disconnect switch. The **ON/STBY**(standby) switch simply toggles operation on and off.



WARNING. The principal power switch at the rear panel is the true power disconnect switch. The **ON/STBY** (standby) switch simply toggles operation on and off. When connected to a power source and when the principal power switch is on, the internal power supplies and much of the other circuitry of these oscilloscopes are energized regardless of the setting of the **ON/STBY** switch.




Figure 2-1: Map of display functions

How to Use Help

Push the **HELP** front-panel button to enter help mode. Front-panel knobs and buttons now display information about their function when turned or pushed. Push **HELP** again to exit help mode.

To get help information on a menu item, display the menu desired (if you are in help mode, exit help first). Push **HELP**. Now the menu buttons display information about their function when pushed.


How to Use the Status Menu

Push the **SHIFT**, then the **STATUS** front-panel buttons to display the status menu. You will find messages reflecting the state of the acquisition system, whether it is running or stopped (and if it is stopped, why), as well as setup-related information.


How to Set Functions

Most functions can be set either by using one (or two) front-panel button(s) or knob(s), or by pushing a front-panel button to use a main menu, and then a side-menu button to set the function. The following steps illustrate both procedures.

1. Locate the block that contains the function to be set.




2. Select the waveform source(s). Position, scale, and set trigger level for waveform source(s) directly from the front panel. The steps that follow provide examples of possible control selections.



- a. Input waveforms into these channels (7). Example: **CH 1**.
- b. Push any channel's button (8) to display its waveform. The last channel turned on determines which waveform is positioned and scaled. The indicator above the channel last selected is lighted.
Example: Push **CH 1**; then **CH 2**.
- c. Vertically (1) and horizontally (2) scale and position the waveform(s) selected. Example: Set the scale to 100 mV/div and center the waveform on screen.
- d. Stop and start acquiring waveforms (3). Example: Push **RUN/STOP** if not acquiring.

- e. Adjust trigger level (6) to trigger the waveform(s) selected or use these buttons (5) to either set a trigger level at the mid-amplitude level of the selected waveform or to force a single trigger. Example: Push **SET LEVEL TO 50%**.
3. Set all other functions using menus.
 - a. Choose the waveform source (8) first if setting a vertical function; else skip to step b. Example: Push **CH 2**.
 - b. Push **SHIFT** (4) if the function to be set is highlighted in blue; else skip to step c.



- c. Push the front-panel button that corresponds to the menu containing the function. A main menu (14) for selecting among related functions appears. Example: Push **VERTICAL MENU**.

Note the two labels: the top label is a function to choose from; the bottom label tells you the current setting for that function. **Offset** is currently set to **0 V**.


- d. Select a function from the main menu using the main-menu buttons (12). A side menu for selecting among that the available settings for that function appears. Example: Push **Coupling** (13).

- e. Select the setting for the function from the side menu (9) using the side-menu buttons (11). Example: Push **AC** (10).

How to Set Complex Functions

A few functions require more than just two levels (main and side) of menus to completely specify their settings. In such cases, either the main menu, the side menu, or both are modified to supply additional choices. The procedures that follow show both schemes.

1. Set up a function using pop-up menus:




- a. For some selections, pushing a main-menu button pops up a menu (18) of subfunctions. Example: Push **Type** (17).

Note the pop-up menu for **Type** is set to **Edge**. All the main-menu buttons to the right of the pop-up menu are labeled with subfunctions of **Edge**.

- b. Pushing the button that popped up the menu (17) toggles through the pop-up menu choices. Example: Repeatedly push **Type** to move through the pop-up menu. Notice the other main-menu button labels change accordingly. Push **Type** to move back to **Edge**.
- c. Complete the setting of the desired mode by selecting from the main menu and the side menu that results. Example: Push **Mode & Holdoff** (16), and then push **Normal** (15).

2. Set up a function using the general purpose knob (20). (The examples of possible menu selections in the substeps that follow assume you have pushed **TRIGGER MENU**.)



- a. Pushing some main-menu buttons displays a side menu with labels containing readouts that can be varied. Example: Push **Level** (21).
- b. Pushing the side-menu button **Level** assigns the general purpose knob to control the readout appearing in the button label. It also copies the readout to the general purpose knob readout area in the right corner of the screen. Example: Push **Level** (19).
- c. Use the general purpose knob (20) to adjust the trigger level to the setting desired. Example: Turn the knob to **-20 mV**.

More About the General Purpose Knob. As you've just seen, the general purpose knob can be used to extend the number of choices available to a side menu button. The general purpose knob can also be assigned to control the following functions:

- Cursor positioning
- Display intensities
- Delay time

- Gated measurements
- Number of events
- Template generation
- Trigger position
- Holdoff
- Offset
- Variable persistence

In all cases, the menus are used to select the function to which the general purpose knob is assigned. The following attributes apply to this knob:

- Depending on the function it is assigned to control, the general purpose knob may vary numerical readouts, position objects (cursors) on screen, or select between icon-label settings that show up in side-menu labels.
- The general purpose knob has a readout area at the upper right corner of the screen. (See Figure 2–1.) This readout always reflects the name and value of the function that the general purpose knob is currently controlling.
- Whenever the general purpose knob assignment is changed, a knob icon appears immediately to the left of the general purpose knob readout to notify you of the assignment change. The icon is removed as soon as you use the general purpose knob to change the value of the function it is assigned to.
- To assign the general purpose knob to control a function, display the menu containing the function; then select the function. (Note that not all functions can be controlled by the general purpose knob.)
- Whenever the menu is removed, the general purpose knob is not assigned and doesn't control any function. (An exception is the cursor function. If cursors are turned on, removing the menu leaves the knob assigned to control the cursors until reassigned by selecting another menu and function that uses the knob.)
- When the **SHIFT** button is lighted, the general purpose knob becomes a coarse adjustment. When the **SHIFT** button is not lighted, the general purpose knob becomes a fine adjustment.
- The general purpose knob also has a **SELECT** button. This button is used to toggle the knob between the control of either of the two cursors displayed when H-bar or V-bar cursors are turned on in the cursor menu.

Display and Utility Menus. Using the techniques described for using menus, you can access and change functions in the display menu and utilities menu. In the Display menu, you can set the following functions:

- Color: waveforms, readouts, graticule
- Intensity: waveforms, readouts, graticule, etc.
- Style of waveform display(s): vectors or dots, intensified or nonintensified samples, and infinite or variable persistence
- Display format: XY or YT
- Graticule format: type
- Waveform interpolation filter and readout options

From the Utility menu, you can configure the GPIB port (talk/listen, address, etc.) and access internal routines for self diagnostics and self compensation. Instructions for setting up communication over the GPIB are found in Section 5, *Adjustment Procedures*.

Theory of Operation

This section describes the electrical operation of the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes using the major circuit blocks or modules.

This section has two main parts:

- *Logic Conventions* describes how logic functions are discussed and represented in this manual.
- *Module Overview* describes circuit operation from a functional-circuit block perspective.

Logic Conventions

The oscilloscopes contain many digital logic circuits. This manual refers to these circuits with standard logic symbols and terms. Unless otherwise stated, all logic functions are described using the positive-logic convention: the more positive of the two logic levels is the high (1) state, and the more negative level is the low (0) state. Signal states may also be described as “true” meaning their active state or “false” meaning their nonactive state. The specific voltages that constitute a high or low state vary among the electronic devices.

Active-low signals are indicated by a tilde prefixed to the signal name (~RESET). Signal names are considered to be either active-high, active-low, or to have both active-high and active-low states.

Module Overview

This module overview describes the basic operation of each functional circuit block as shown in Figure 9-2.

General

The TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes have four channels. Each channel provides a calibrated vertical scale factor.

Input Signal Path

A signal enters the oscilloscope through a probe connected to a BNC on the A10 Attenuator/Acquisition board.

Attenuators. Circuitry in the attenuator selects the input coupling, termination, and the attenuation factor. The processor system, by way of the acquisition system, controls the attenuators. For example, if 50 Ω input termination is

selected and the input is overloaded, the processor system switches the input to the 1 M Ω position (on TDS models with 1 M Ω termination).

Probe Coding Interface. Probe coding interface signals pass through the attenuator portion of the A10 Attenuator/Acquisition to the acquisition system, where they are sensed and controlled.

Acquisition System. The acquisition system amplifies the input signals, samples them, converts them to digital signals, and controls the acquisition process under direction of the processor system. The acquisition system includes the trigger, acquisition timing, and acquisition mode generation and control circuitry.

Voltage Controlled Oscillator (VCO). Master clocks for the acquisition system are generated by the circuitry on the A10 Acquisition board. The circuitry makes up a phase-locked loop. The master clock is divided down by the A10 Acquisition circuitry under control of the processor system.

D1 Bus. The acquisition system passes the digital values representing the acquired waveform through the A14 D1 Bus to the A11 DRAM Processor/Display board. This happens after a waveform acquisition is complete if the digital signal processor in the processor system requests the waveform.

Processor System. The processor system contains a microprocessor that controls the entire instrument. This system also includes the firmware and a GPIB interface. You can reprogram the firmware from a remote controller using the GPIB and an external software package.

The processor also includes a digital signal processor. This signal processor processes each waveform as directed by the system processor. Waveforms and any text to be displayed are passed on to the display system. The A11 DRAM Processor/Display board contains both the processor and display systems.

Display System. Text and waveforms are processed by different parts of the display circuitry. The display system sends the text and waveform information to the tube assembly as a video signal. The display system also generates and sends vertical (VSYNC) and horizontal (HSYNC) sync signals to the tube assembly. A VGA-compatible video output is at the rear of the TDS 500D, TDS 600C, TDS 700D and TDS 714L.

Tube Assembly

All information (waveforms, text, graticules, and pictographs) is displayed by the A30/31/32 Display system. The A30 generates the high voltages necessary to drive the display tube. It also contains the video amplifier, horizontal oscillator, and the vertical and horizontal yoke driver circuitry.

Front Panel

The processor system sends instructions to and receives information from the Front Panel Processor on the A12 Front Panel board. The Front Panel Processor reads the front-panel switches and potentiometers. Any changes in their settings are reported to the processor system. The Front Panel Processor also turns the LEDs on and off and generates the bell signal.

Front-panel menu switches are also read by the Front Panel Processor. The processor sends any changes in menu selections to the processor system. The **ON/STBY** switch is one of the menu switches. However, it is not read by the Front Panel Processor, but passes through the A12 Front Panel board and the A11 DRAM Processor/Display board to the low voltage power supply.

The front panel also generates the probe compensation signals **SIGNAL** and **GND**.

Rear Panel

The **GPIO** connector provides access to stored waveforms and allows external control of the oscilloscope.

You can make hardcopies on the GPIO, RS-232 and Centronics ports.

Low Voltage Power Supply

The low voltage power supply is a switching power converter with active power factor control. It supplies power to all of the circuitry in the oscilloscope.

The principal **POWER** switch, located on the rear panel, controls all power to the oscilloscope including the Low Voltage Power Supply. The **ON/STBY** switch, located on the front panel, also controls all of the power to the oscilloscope except for part of the circuitry in the Low Voltage Power Supply.

The power supply sends a power fail (~PF) warning to the processor system if the power is going down.

Fan

The fan provides forced air cooling for the oscilloscope. It connects to +25 V from the Low Voltage Power Supply by way of the A11 DRAM Processor/Display module.

Performance Verification Procedures

Two types of Performance Verification procedures can be performed on this product: *Brief Procedures* and *Performance Tests*. You may not need to perform all of these procedures, depending on what you want to accomplish.

- To rapidly confirm that the oscilloscope functions and was adjusted properly, just do the brief procedures under *Self Tests*, which begin on page 4–5.

Advantages: These procedures are quick to do, require no external equipment or signal sources, and perform extensive functional and accuracy testing to provide high confidence that the oscilloscope will perform properly. They can be used as a quick check before making a series of important measurements.

- To further check functionality, first do the *Self Tests* just mentioned; then do the brief procedures under *Functional Tests* that begin on page 4–7.

Advantages: These procedures require minimal additional time to perform, require no additional equipment other than a standard-accessory probe, and more completely test the internal hardware of the oscilloscope. They can be used to quickly determine if the oscilloscope is suitable for putting into service, such as when it is first received.

- If more extensive confirmation of performance is desired, do the *Performance Tests*, beginning on page 4–17, after doing the *Functional* and *Self Tests* just referenced.

Advantages: These procedures add direct checking of warranted specifications. They require more time to perform and suitable test equipment is required. (See *Equipment Required* beginning on page 4–18).

If you are not familiar with operating this oscilloscope, read the oscilloscope reference or user manuals. These contain instructions that will acquaint you with the use of the front-panel controls and the menu system.

Input Channels versus Model

When performing the procedures in this section, be aware that some TDS models refer to input channels Ch 3 and Ch 4 as Aux 1 and Aux 2 respectively. Where appropriate, both names will appear in the procedure, for example, Ch 3 (Aux 1). The channel names for the various TDS models are shown below.

TDS Model	Channel Names
TDS 540D, 580D, 654C, 684C, 694C, 714L, 754D, 784D, and 794D	Ch 1, Ch 2, Ch 3, and Ch 4
TDS 520D, 680C, and 724D	Ch 1, Ch 2, Aux 1, and Aux 2

Conventions

Throughout these procedures the following conventions apply:

- Each test procedure uses the following general format:

Title of Test

Equipment Required

Prerequisites

Procedure

- Each procedure consists of as many steps, substeps, and subparts as required to do the test. Steps, substeps, and subparts are sequenced as follows:

1. First Step

- a. First Substep

- First Subpart
- Second Subpart

- b. Second Substep

2. Second Step

- In steps and substeps, the lead-in statement in *italics* instructs you what to do, while the instructions that follow tell you how to do it, as in the example step below, “*Initialize the oscilloscope*” by doing “Press save/recall **SETUP**. Now, press the main-menu button...”.

Initialize the oscilloscope: Press save/recall **SETUP**. Now, press the main-menu button **Recall Factory Setup**; then the side-menu button **OK Confirm Factory Init**.

- Where instructed to use a front-panel button or knob, or select from a main or side menu, or verify a readout or status message, the name of the button or knob appears in boldface type: “press **SHIFT**; then **UTILITY**, press the main-menu button **System** until **Cal** is highlighted in the pop-up menu. Verify that the status message is **Pass** in the main menu under the **Voltage Reference** label.”

STOP. The **STOP** notation at the left is accompanied by information you must read to do the procedure properly.

- Refer to Figure 4–1: “Main menu” refers to the menu that labels the seven menu buttons under the display; “side menu” refers to the menu that labels the five buttons to the right of the display. “Pop-up menu” refers to a menu that pops up when a main-menu button is pressed.




Figure 4–1: Map of display functions

Brief Procedures

The *Self Tests* use internal routines to confirm basic functionality and proper adjustment. No test equipment is required to do these test procedures.

The *Functional Tests* utilize the probe-compensation output at the front panel as a test-signal source for further verifying that the oscilloscope functions properly. A probe is required to do these test procedures.

Self Tests

This procedure uses internal routines to verify that the oscilloscope functions and was adjusted properly. No test equipment or hookups are required.

Verify Internal Adjustment, Self Compensation, and Diagnostics

Equipment required	None
Prerequisites	Power on the oscilloscope and allow a 20 minute warm-up before doing this procedure.

1. *Verify that internal diagnostics pass:* Do the following substeps to verify passing of internal diagnostics.
 - a. *Display the System diagnostics menu:*
 - Press **SHIFT**; then press **UTILITY**.
 - Repeatedly press the main-menu button **System** until **Diag/Err** is highlighted in the pop-up menu.
 - b. *Run the System Diagnostics:*
 - First disconnect any input signals from all four channels.
 - Press the main-menu button **Execute**; then press the side-menu button **OK Confirm Run Test**.
 - c. *Wait:* The internal diagnostics do an exhaustive verification of proper oscilloscope function. This verification will take up to three and a half minutes on some models. When the verification is finished, the resulting status will appear on the screen.
 - d. *Verify that no failures are found and reported on-screen.* If any failures occur do step 1a, then press the main menu button **Error Log** for details.
 - e. *Confirm the three adjustment sections have passed status:*

- Press **SHIFT**; then press **UTILITY**.
 - Highlight **Cal** in the pop-up menu by repeatedly pressing the main-menu button **System**. See Figure 4–2.
 - Verify that the word **Pass** appears in the main menu under the following menu labels: **Voltage Reference**, **Frequency Response**, and **Pulse Trigger**. See Figure 4–2.
- f. *Run the signal-path compensation:* Press the main-menu button **Signal Path**; then press the side-menu button **OK Compensate Signal Paths**.
- g. *Wait:* Signal-path compensation may take five to fifteen minutes to run. While it progresses, a “clock” icon (shown at left) is displayed on-screen. When compensation completes, the status message will be updated to **Pass** or **Fail** in the main menu. See step h.
- h. *Confirm signal-path compensation returns passed status:* Verify that the word **Pass** appears under **Signal Path** in the main menu. See Figure 4–2.




Figure 4–2: Verifying adjustments and signal-path compensation

2. *Return to regular service:* Press **CLEAR MENU** to exit the system menus.

Functional Tests

The purpose of these procedures is to confirm that the oscilloscope functions properly. The only equipment required is one of the standard-accessory probes and, to check the file system, a 3.5 inch, 720 K or 1.44 Mbyte floppy disk.



CAUTION. The P6243, P6245, P6249 and probes that can be used with this oscilloscope provide an extremely low loading capacitance (<1 pF) to ensure the best possible signal reproduction. These probes should not be used to measure signals exceeding ± 8 volts, or errors in signal measurement will be observed. Above 40 volts, damage to the probe may result. To make measurements beyond ± 10 volts, use either the P6139A probe (good to 500 volts peak), the P6339A probe (for the TDS 694C & TDS 794D), or refer to the catalog for a recommended probe.

STOP. These procedures verify functions; that is, they verify that the oscilloscope features operate. They do not verify that they operate within limits.

Therefore, when the instructions in the functional tests that follow call for you to verify that a signal appears on-screen “that is about five divisions in amplitude” or “has a period of about six horizontal divisions,” etc., do NOT interpret the quantities given as limits. Operation within limits is checked in Performance Tests, which begin on page 4–17.

STOP. DO NOT make changes to the front-panel settings that are not called out in the procedures. Each verification procedure will require you to set the oscilloscope to certain default settings before verifying functions. If you make changes to these settings, other than those called out in the procedure, you may obtain invalid results. In this case, just redo the procedure from step 1.

When you are instructed to press a menu button, the button may already be selected (its label will be highlighted). If this is the case, it is not necessary to press the button.

Verify All Input Channels

Equipment required	One probe such as the P6243, P6245, P6249, P6139A ¹ , or P6339A
Prerequisites	None

¹ P6139A probe is not appropriate for the TDS694C/794D oscilloscopes.

1. Install the test hookup and preset the oscilloscope controls:

- a. Hook up the signal source:** Install the probe on **CH 1**. Connect the probe tip to **PROBE COMPENSATION SIGNAL** on the front panel; connect the probe ground (typically black) to **PROBE COMPENSATION GND**. If using a P6243, P6245 or P6249 probe, you may want to attach a Y-lead connector and two SMD KlipChips as shown in Figure 4–3.




Figure 4-3: Universal test hookup for functional tests – TDS 600C shown

b. Initialize the oscilloscope:

- Press save/recall **SETUP**.
- Press the main-menu button **Recall Factory Setup**.
- Press the side-menu button **OK Confirm Factory Init**.

2. *Verify that all channels operate:* Do the following substeps — test CH 1 first, *skipping substep a and b since CH 1 is already set up for verification and as the trigger source from step 1.*
 - a. *Select an unverified channel:*
 - Press **WAVEFORM OFF** to remove the channel just verified from display.
 - Press the front-panel button that corresponds to the channel you are to verify.
 - Move the probe to the channel you selected.
 - b. *Match the trigger source to the channel selected:*
 - Press **TRIGGER MENU**.
 - Press the main-menu button **Source**.
 - Press the side-menu button that corresponds to the channel selected, **Ch2**, **Ch3**, or **Ch4**. (Some TDS models use **Ax1** and **Ax2** instead of **Ch3** and **Ch4**).
 - c. *Set up the selected channel:*
 - Set the vertical **SCALE** to 200 mV.
 - Set the horizontal **SCALE** to 200 μ s. Press **CLEAR MENU** to remove any menu that may be on the screen.
 - Press **SET LEVEL TO 50%**.
 - d. *Verify that the channel is operational:* Confirm that the following statements are true.
 - The vertical scale readout for the channel under test shows a setting of 200 mV, and a square-wave probe-compensation signal about 2.5 divisions in amplitude is on-screen. See Figure 4–1 on page 4–3 to locate the readout.
 - The vertical **POSITION** knob moves the signal up and down the screen when rotated.
 - Turning the vertical **SCALE** knob counterclockwise decreases the amplitude of the waveform on-screen, turning the knob clockwise increases the amplitude, and returning the knob to 200 mV returns the amplitude to about 2.5 divisions.

- e. *Verify that the channel acquires in all acquisition modes:* Press **SHIFT**; then press **ACQUIRE MENU**. Use the side menu to select, in turn, each of the three hardware acquire modes and confirm that the following statements are true. Refer to the icons at the left of each statement as you confirm those statements.



- Sample mode displays an actively acquiring waveform on-screen. (Note that there is noise present on the peaks of the square wave).



- Peak Detect mode displays an actively acquiring waveform on-screen with the noise present in Sample mode “peak detected.”



- Hi Res mode (TDS 500D and 700D/L only) displays an actively acquiring waveform on-screen with the noise that was present in Sample mode reduced.



- Envelope mode displays an actively acquiring waveform on-screen with the noise displayed.



- Average mode displays an actively acquiring waveform on-screen with the noise reduced.

- f. *Test all channels:* Repeat substeps a through e until all four input channels are verified.

3. *Remove the test hookup:* Disconnect the probe from the channel input and the probe-compensation terminals.

Verify the Time Base

Equipment required	One probe such as the P6243, P6245, P6249, P6139A ¹ , or P6339A
Prerequisites	None

¹ P6139A probe is not appropriate for the TDS694C/794D oscilloscopes.

1. *Install the test hookup and preset the oscilloscope controls:*
 - a. *Hook up the signal source:* Install the probe on **CH 1**. Connect the probe tip to **PROBE COMPENSATION SIGNAL** on the front panel; connect the probe ground to **PROBE COMPENSATION GND**. See Figure 4–3 on page 4–8.
 - b. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**; then press the side-menu button **OK Confirm Factory Init**.
 - c. *Modify default settings:*

- Set the vertical **SCALE** to 200 mV.
 - Set the horizontal **SCALE** to 200 μ s.
 - Press **SET LEVEL TO 50%**.
 - Press **CLEAR MENU** to remove the menus from the screen.
2. *Verify that the time base operates:* Confirm the following statements.
 - a. One period of the square-wave probe-compensation signal is about five horizontal divisions on-screen for the 200 μ s horizontal scale setting (set in step 1c).
 - b. Rotating the horizontal **SCALE** knob clockwise expands the waveform on-screen (more horizontal divisions per waveform period), counter-clockwise rotation contracts it, and returning the horizontal scale to 200 μ s returns the period to about five divisions.
 - c. The horizontal **POSITION** knob positions the signal left and right on-screen when rotated.
 3. *Remove the test hookup:* Disconnect the probe from the channel input and the probe-compensation terminals.

Verify the Main and Delayed Trigger Systems

Equipment required	One probe such as the P6243, P6245, P6249, P6139A ¹ , or P6339A
Prerequisites	None

¹ P6139A probe is not appropriate for the TDS694C/794D oscilloscopes.

1. *Install the test hookup and preset the oscilloscope controls:*
 - a. *Hook up the signal source:* Install the probe on **CH 1**. Connect the probe tip to **PROBE COMPENSATION SIGNAL** on the front panel; connect the probe ground to **PROBE COMPENSATION GND**. See Figure 4–3 on page 4–8.
 - b. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**.
 - Press the side-menu button **OK Confirm Factory Init**.
 - c. *Modify default settings:*
 - Set the vertical **SCALE** to 200 mV.
 - Set the horizontal **SCALE** for the **M** (main) time base to 200 μ s.

- Press **SET LEVEL TO 50%**.
 - Press **TRIGGER MENU**.
 - Press the main-menu button **Mode & Holdoff**.
 - Press the side-menu button **Normal**.
 - Press **CLEAR MENU** to remove the menus from the screen.
2. *Verify that the main trigger system operates:* Confirm that the following statements are true.
- The trigger level readout for the main trigger system changes with the trigger-**LEVEL** knob.
 - The trigger-**LEVEL** knob can trigger and untrigger the square-wave signal as you rotate it. (Leave the signal *untriggered*, which is indicated by the display not updating).
 - Pressing **SET LEVEL TO 50%** triggers the signal that you just left untriggered. (Leave the signal triggered).
3. *Verify that the delayed trigger system operates:*
- a. *Select the delayed time base:*
 - Press **HORIZONTAL MENU**.
 - Press the main-menu button **Time Base**.
 - Press the side-menu button **Delayed Triggerable**; then press the side-menu button **Delayed Only**.
 - Set the horizontal **SCALE** for the **D** (delayed) time base to 200 μ s.
 - b. *Select the delayed trigger level menu:*
 - Press **SHIFT**; then press **DELAYED TRIG**.
 - Press the main-menu button **Level**; then press the side-menu button **Level**.
 - c. *Confirm that the following statements are true:*
 - The trigger-level readout for the delayed trigger system changes as you turn the general purpose knob.
 - As you rotate the general purpose knob, the square-wave probe-compensation signal can become triggered and untriggered. (Leave the signal *untriggered*, which is indicated by the display not updating).

- Pressing the side-menu button **Set to 50%** triggers the probe-compensation signal that you just left untriggered. (Leave the signal triggered).
- d. *Verify the delayed trigger counter:*
- Press the main-menu button **Delay by Time**.
 - Use the keypad to enter a delay time of 1 second. Press **1**, then press **ENTER**.
 - Verify that the trigger **READY** indicator on the front panel flashes about once every second as the waveform is updated on-screen.
4. *Remove the test hookup:* Disconnect the probe from the channel input and the probe-compensation terminals.

Verify the File System

Equipment required	One probe such as the P6243, P6245, P6249, P6139A ¹ , or P6339A One 720 K or 1.44 Mbyte, 3.5 inch DOS-compatible disk. You can use a disk of your own or you can use the TDS Family Programmer Disk included in your user manual.
Prerequisites	None

¹ P6139A probe is not appropriate for the TDS694C/794D oscilloscopes.

1. *Install the test hookup and preset the oscilloscope controls:*
- a. *Hook up the signal source:* Install the probe on **CH 1**. Connect the probe tip to **PROBE COMPENSATION SIGNAL** on the front panel; connect the probe ground to **PROBE COMPENSATION GND**. See Figure 4–3 on page 4–8.
 - b. *Insert the test disk:* Insert the floppy disk in the floppy disk drive to the left of the monitor.
 - Position the disk so the metal shutter faces the drive.
 - Position the disk so the stamped arrow is on the top right side. In other words, place the angled corner in the front bottom location.
 - Push the disk into the drive until it goes all the way in and clicks into place.
 - c. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**.
 - Press the side-menu button **OK Confirm Factory Init**.

d. *Modify default settings:*

- Set the vertical **SCALE** to 200 mV.
- Set the horizontal **SCALE** for the **M** (main) time base to 200 μ s. Notice the waveform on the display now shows two cycles instead of five.
- Press **SET LEVEL TO 50%**.
- Press **CLEAR MENU** to remove the menus from the screen.

e. *Save the settings:*

- Press **SETUP**.
- Press the main-menu button **Save Current Setup**; then press the side-menu button **To File**.
- Turn the general purpose knob to select the file to save. Choose TEK?????.SET (or **fd0:**, the floppy disk drive, **hd0:**, the optional hard disk drive, or **Zip:**, if an external Zip drive is connected). With this choice, you will save a file starting with TEK, then containing 5-numbers, and a .SET extension. For example, the first time you run this on a blank, formatted disk or on the Example Programs Disk, the oscilloscope will assign the name TEK00000.SET to your file. If you ran the procedure again, the oscilloscope would increment the name and call the file TEK00001.SET.

NOTE. *If testing an external Zip drive, it must first be connected to the oscilloscope, then be powered on simultaneously with the oscilloscope, or immediately after the oscilloscope is powered-on. This ensures proper communications are set up between the oscilloscope and the Zip drive.*

- f. To test the optional hard disk drive or external Zip drive, choose either the hard disk drive (**hd0:**), or the external Zip drive (**Zip:**). Then use the general purpose knob to select the file to save. Save the file as in step e.
- Press the side-menu button **Save To Selected File**.

2. *Verify the file system works:*

- Press the main-menu button **Recall Factory Setup** and the side-menu button **OK Confirm Factory Init** to restore the 500 μ s time base and the five cycle waveform.
- Press the main-menu button **Recall Saved Setup**; then press the side-menu button **From File**.

- Turn the general purpose knob to select the file to recall. For example, if you followed the instructions previously and saved the file to either the floppy disk drive (**fd0:**), or the optional hard disk drive (**hd0:**), you had the oscilloscope assign the name TEK00000.SET to your file.
 - Press the side-menu button **Recall From Selected File**.
 - Verify that the oscilloscope retrieved the saved setup from the disk. Do this by noticing the horizontal **SCALE** for the **M** (main) time base is again 200 μ s and the waveform shows only two cycles just as it was when you saved the setup.
3. *Remove the test hookup:*
- Disconnect the probe from the channel input and the probe-compensation terminals.
 - Remove the floppy disk from the floppy disk drive.

Performance Tests

This section contains a collection of procedures for checking that the TDS 500D, TDS 600C, TDS 700D, and TDS 714L Oscilloscopes perform as warranted.

The procedures are arranged in four logical groupings: *Signal Acquisition System Checks*, *Time Base System Checks*, *Triggering System Checks*, and *Output Ports Checks*. They check all the characteristics that are designated as checked in *Specifications*. (The characteristics that are checked appear in **boldface** type under *Warranted Characteristics in Specifications*).

STOP. *These procedures extend the confidence level provided by the basic procedures described on page 4–5. The basic procedures should be done first, then these procedures performed if desired.*

Prerequisites

The tests in this section comprise an extensive, valid confirmation of performance and functionality when the following requirements are met:

- The cabinet must be installed on the oscilloscope.
- You must have performed and passed the procedures under *Self Tests*, found on page 4–5, and those under *Functional Tests*, found on page 4–7.
- A signal-path compensation must have been done within the recommended calibration interval and at a temperature within $\pm 5^{\circ}$ C of the present operating temperature. (If at the time you did the prerequisite *Self Tests*, the temperature was within the limits just stated, consider this prerequisite met).
- The oscilloscope must have been last adjusted at an ambient temperature between $+20^{\circ}$ C and $+30^{\circ}$ C, must have been operating for a warm-up period of at least 20 minutes, and must be operating at an ambient temperatures as follows: $+4^{\circ}$ C to $+40^{\circ}$ C for the TDS 694C, $+4^{\circ}$ C to $+45^{\circ}$ C for other TDS 600C and 0° C to $+50^{\circ}$ C for the TDS 500D, TDS 700D, and TDS 714L. (The warm-up requirement is usually met in the course of meeting the Self Tests and Functional Tests prerequisites listed above).

Equipment Required

Procedures starting on page 4–35, use external, traceable signal sources to directly check warranted characteristics. Table 4–1 lists the required equipment.

Table 4–1: Test equipment

Item number and description	Minimum requirements	Example	Purpose
1. Attenuator, 10X (two required)	Ratio: 10X; impedance 50 Ω ; connectors: female BNC input, male BNC output	Tektronix part number 011-0059-02	Signal Attenuation
2. Attenuator, 5X	Ratio: 5X; impedance 50 Ω ; connectors: female BNC input, male BNC output	Tektronix part number 011-0060-02	Signal Attenuation
3. Adapter, BNC female-to-Clip Leads	BNC female-to-Clip Leads	Tektronix part number 013-0076-00	Signal Coupling for Probe Compensator Output Check
4. Terminator, 50 Ω	Impedance 50 Ω ; connectors: female BNC input, male BNC output	Tektronix part number 011-0049-01	Signal Termination for Channel Delay Test
5. Cable, Precision 50 Ω Coaxial (three required)	50 Ω , 36 in, male-to-male BNC connectors	Tektronix part number 012-0482-00	Signal Interconnection
6. Connector, Dual-Banana (two required)	Female BNC-to-dual banana	Tektronix part number 103-0090-00	Various Accuracy Tests
7. Connector, BNC “T”	Male BNC-to-dual female BNC	Tektronix part number 103-0030-00	Checking Trigger Sensitivity
8. Coupler, Dual-Input	Female BNC-to-dual male BNC	Tektronix part number 067-0525-02	Checking Delay Between Channels
9. Generator, DC Calibration	Variable amplitude to ± 104 V; accuracy to 0.1%	Data Precision 8200 ¹	Checking DC Offset, Gain, and Measurement Accuracy
10. Generator, Calibration	500 mV square wave calibrator amplitude; accuracy to 0.25%	Tegam/Tektronix PG 506A Calibration Generator ^{1,3}	To check accuracy of CH 3 Signal Out
11. Generator, Time Mark (optional)	Variable marker frequency from 10 ms to 10 ns; accuracy within 2 ppm	Tegam/Tektronix TG 501A Time Mark Generator ^{1,3}	Checking Sample-Rate and Delay-time Accuracy
12. Probe, 10X	A P6139A ² , P6243, P6249, P6245, or P6339A probe ⁴	Tektronix part number P6139A or P6245	Signal Interconnection
13. 3.5 inch, 720 K or 1.44 Mbyte, DOS-compatible floppy disk		TDS Family Programmer Disk (Tektronix part number 063–3120–00), included with User Manual (Tektronix part number 071–0130–XX)	Checking File System Basic Functionality
14. Generator, Sine Wave	250 kHz to at least 500 MHz (higher for higher-bandwidth scopes). Variable amplitude from 60 mV to 2 V _{p-p} into 50 Ω . Frequency error >2.0%	Rohde & Schwarz SMT or SMY ^{1,5}	Checking Analog Bandwidth, Trigger Sensitivity, Sample-rate, External Clock, and Delay-Time Accuracy

Table 4–1: Test equipment (cont.)

Item number and description	Minimum requirements	Example	Purpose
15. Meter, Level and Power Sensor	Frequency range: 10 MHz to the oscilloscope bandwidth. Amplitude range: 6 mV _{p-p} to 2 V _{p-p}	Rohde & Schwarz URV 35, with NRV-Z8 power sensor ^{1,5}	Checking Analog Bandwidth and Trigger Sensitivity
16. Splitter, Power	Frequency range: DC to 3 GHz. Tracking: >2.0%	Tektronix part number ^{1,5} 015-0565-00	Checking Analog Bandwidth
17. Adapter (four required)	Male N-to-female BNC	Tektronix part number 103-0045-00	Checking Analog Bandwidth
18. Adapter	Female N-to-male BNC	Tektronix part number 103-0058-00	Checking Analog Bandwidth
19. Adapter	3 SMA male-to-male	Tektronix part number 015-1012-00	Checking the delay between channels
20. Adapter	3 SMA female-to-male BNC	Tektronix part number 015-1018-00	Checking the delay between channels
21. Generator, Video Signal	Provides PAL compatible outputs	Tektronix TSG 121	Used to Test Video Option 05 Equipped Instruments Only
22. Oscillator, Leveled Sine wave Generator	60 Hz Sine wave	Tegam/Tektronix SG 502 (if available) ^{1,3}	Used to Test Video Option 05 Equipped Instruments Only
23. Pulse Generator		Tektronix CFG280 (or Tegam/Tektronix PG 502) ³	Used to Test Video Option 05 Equipped Instruments Only
24. Cable, Coaxial (two required)	75 Ω , 36 in, male-to-male BNC connectors	Tektronix part number 012-1338-00	Used to Test Video Option 05 Equipped Instruments Only
25. Terminator, 75 Ω (two required)	Impedance 75 Ω ; connectors: female BNC input, male BNC output	Tektronix part number 011-0102-01	Used to Test Video Option 05 Equipped Instruments Only
26. Generator, Optical Impulse	850 nm optical impulse	Tektronix OIG501 Optical Impulse Generator ³	Checking Option 3C
27. Generator, Optical Impulse	1300 nm optical impulse	Tektronix OIG502 Optical Impulse Generator ³	Checking Option 4C
28. Cable, Coaxial (two required)	50 Ω , 20 in, male-to-male SMA connectors	Tektronix part number 174-1427-00	Used to Test Delta Time Measurement Accuracy
29. Adapter	SMA "T", male to 2 SMA female	Tektronix part number 015-1016-00	Used to Test Delta Time Measurement Accuracy
30. Adapter	SMA female to BNC male	Tektronix part number 015-0572-00	Used to Test Delta Time Measurement Accuracy
31. Adapter	BNC male to female elbow	Tektronix part number 103-0031-00	Used to Test Delta Time Measurement Accuracy
32. Terminator	Short circuit, SMA connector	Tektronix part number 015-1021-00	Used to Test Delta Time Measurement Accuracy
33. Attenuator, 2X	Ratio: 2X; impedance 50 Ω ; connectors: female BNC input, male BNC output	Tektronix part number 011-0069-02	Used to Test Delta Time Measurement Accuracy

Table 4–1: Test equipment (cont.)

Item number and description	Minimum requirements	Example	Purpose
34. Attenuator, Optical	62.5 micron optical attenuator	Tektronix OA5022 Optical Attenuator ³	Checking Option 3C and 4C
35. Cable, Fiber Optic	FC-FC fiber cable	Tektronix part number 174-2322-00	Checking Option 3C and 4C
36. Optical-to-Electrical Converter	P6701B (used with Option 3C) or P6703B (used with Option 4C) optical-to-electrical converter	Tektronix part number P6701B or P6703B	Checking Option 3C and 4C

- ¹ You may replace items 9, 10, 11, 14, 15, 16, and 22 with a Wavetek 9100 (with options 100 and 600) for 500 MHz oscilloscopes, or a Wavetek 9500 (with option 100) and output head appropriate for the bandwidth of the oscilloscope(s) being tested. For 3 GHz oscilloscopes use a Wavetek 9530 head.
- ² P6139A probe is not appropriate for the TDS694C/794D oscilloscopes.
- ³ Requires a TM 500 or TM 5000 Series Power Module Mainframe. For Delta Time Measurement Accuracy use a Wavetek 9500 or a pulse generator with a rise time as shown in Table 4–6 on page 4–58.
- ⁴ Warning: The P6243 and P6245 probes that may be used with this oscilloscope provide an extremely low loading capacitance (<1 pF) to ensure the best possible signal reproduction. These probes should not be used to measure signals exceeding ± 8 V, or errors in signal measurement will be observed. Above 40 V, damage to the probe may result. To make measurements beyond ± 8 V, use either the P6139A probe (good to 500 V), or refer to the catalog for a recommended probe. P6139A is not an appropriate probe for the TDS 694C or TDS 794D oscilloscopes.
- ⁵ If available, you may replace items 14, 15, and 16 with the following set of equipment for bandwidths up to 1 GHz: a Tegam/Tektronix SG503 and SG504 with SG504 leveling head.

TDS 600C Test Record

Photocopy this and the next three pages and use them to record the performance test results for your TDS 600C. The TDS 694C Test Record begins on page 4–29.

TDS 600C Test Record

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		

TDS 600C Performance Test		Minimum	Incoming	Outgoing	Maximum
Offset Accuracy					
CH1 Offset	+1 mV +101 mV +1.01 V	– 2.1 mV – 75.6 mV – 756 mV	_____	_____	+ 2.1 mV + 75.6 mV + 756 mV
CH2 Offset	+1 mV +101 mV +1.01 V	– 2.1 mV – 75.6 mV – 756 mV	_____	_____	+ 2.1 mV + 75.6 mV + 756 mV
CH3 or AX1 Offset	+1 mV +101 mV +1.01 V	– 2.1 mV – 75.6 mV – 756 mV	_____	_____	+ 2.1 mV + 75.6 mV + 756 mV
CH4 or AX2 Offset	+1 mV +101 mV +1.01 V	– 2.1 mV – 75.6 mV – 756 mV	_____	_____	+ 2.1 mV + 75.6 mV + 756 mV
DC Voltage Measurement Accuracy (Averaged)					
CH1	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0329 V	_____	_____	+ 1.0471 V
CH1	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0471 V	_____	_____	– 1.0329 V
CH1	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.4165 V	_____	_____	+ 11.7835 V
CH1	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.7835 V	_____	_____	– 11.4165 V
CH1	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.102 V	_____	_____	+ 18.899 V
CH1	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.899 V	_____	_____	– 17.102 V
CH2	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0329 V	_____	_____	+ 1.0471 V
CH2	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0471 V	_____	_____	– 1.0329 V
CH2	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.4165 V	_____	_____	+ 11.7835 V

TDS 600C Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____			
Temperature: _____		RH %: _____			
Date of Calibration: _____		Technician: _____			
TDS 600C Performance Test		Minimum	Incoming	Outgoing	Maximum
CH2	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.7835 V	_____	_____	– 11.4165 V
CH2	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.102 V	_____	_____	+ 18.899 V
CH2	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.899 V	_____	_____	– 17.102 V
CH3 or AX1	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0329 V	_____	_____	+ 1.0471 V
CH3 or AX1	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0471 V	_____	_____	– 1.0329 V
CH3 or AX1	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.4165 V	_____	_____	+ 11.7835 V
CH3 or AX1	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.7835 V	_____	_____	– 11.4165 V
CH3 or AX1	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.102 V	_____	_____	+ 18.899 V
CH3 or AX1	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.899 V	_____	_____	– 17.102 V
CH4 or AX2	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0329 V	_____	_____	+ 1.0471 V
CH4 or AX2	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0471 V	_____	_____	– 1.0329 V
CH4 or AX2	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.4165 V	_____	_____	+ 11.7835 V
CH4 or AX2	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.7835 V	_____	_____	– 11.4165 V
CH4 or AX2	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.102 V	_____	_____	+ 18.899 V
CH4 or AX2	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.899 V	_____	_____	– 17.102 V
Analog Bandwidth					
CH1	100 mV	424 mV	_____	_____	N/A
CH2	100 mV	424 mV	_____	_____	N/A
CH3 or AX1	100 mV	424 mV	_____	_____	N/A
CH4 or AX2	100 mV	424 mV	_____	_____	N/A

TDS 600C Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		
TDS 600C Performance Test	Minimum	Incoming	Outgoing	Maximum
Delay Between Channels				
Delay Between Channels	N/A	_____	_____	100 ps
Time Base System				
Long Term Sample Rate/ Delay Time @ 500 ns/10 ms	-2.0 Div	_____	_____	+2.0 Div
Trigger System Accuracy				
Pulse-Glitch or Pulse-Width, Hor. scale $\leq 1 \mu\text{s}$				
Lower Limit	3.5 ns	_____	_____	6.5 ns
Upper Limit	3.5 ns	_____	_____	6.5 ns
Pulse-Glitch or Pulse-Width, Hor. scale $> 1 \mu\text{s}$				
Lower Limit	1.9 μs	_____	_____	2.1 μs
Upper Limit	1.9 μs	_____	_____	2.1 μs
CH1 Sensitivity, 50 MHz, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, 50 MHz, Delayed	Pass/Fail	_____	_____	Pass/Fail
CH1 AUX Trigger Input	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, 1 GHz, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, 1 GHz, Delayed	Pass/Fail	_____	_____	Pass/Fail
Output Signal Checks				
MAIN TRIGGER OUTPUT, 1 M Ω				
High	High $\geq 2.5 \text{ V}$	_____	_____	Low $\leq 0.7 \text{ V}$
Low		_____	_____	
MAIN TRIGGER OUTPUT, 50 Ω				
High	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
Low		_____	_____	
DELAYED TRIGGER OUTPUT, 50 Ω				
	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
		_____	_____	
DELAYED TRIGGER OUTPUT, 1 M Ω				
	High $\geq 2.5 \text{ V}$	_____	_____	Low $\leq 0.7 \text{ V}$
		_____	_____	

TDS 600C Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		
TDS 600C Performance Test	Minimum	Incoming	Outgoing	Maximum
CH 3 or AX1 SIGNAL OUTPUT, 1 M Ω	p-p $\geq$ 80 mV	_____	_____	p-p $\leq$ 120 mV
CH 3 or AX1 SIGNAL OUTPUT, 50 Ω	p-p $\geq$ 40 mV	_____	_____	p-p $\leq$ 60 mV
Probe Compensator Output Signal				
Frequency (CH1 Freq).	950 Hz	_____	_____	1.050 kHz
Voltage (difference)	495 mV	_____	_____	505 mV

TDS 500D/700D/714L Test Record

Photocopy this and the next three pages and use them to record the performance test results for your TDS 500D/700D/714L. The TDS 794D Test Record begins on page 4–32.

TDS 500D/700D/714L Test Record

Instrument Serial Number: _____		Certificate Number: _____			
Temperature: _____		RH %: _____			
Date of Calibration: _____		Technician: _____			
TDS 500D/700D/714L Performance Test		Minimum	Incoming	Outgoing	Maximum
Offset Accuracy					
CH1 Offset	+1 mV +101 mV +1.01 V	– 1.6 mV – 25.1 mV – 251 mV	_____	_____	+ 1.6 mV + 25.1 mV + 251 mV
CH2 Offset	+1 mV +101 mV +1.01 V	– 1.6 mV – 25.1 mV – 251 mV	_____	_____	+ 1.6 mV + 25.1 mV + 251 mV
CH3 or AX1 Offset	+1 mV +101 mV +1.01 V	– 1.6 mV – 25.1 mV – 251 mV	_____	_____	+ 1.6 mV + 25.1 mV + 251 mV
CH4 or AX2 Offset	+1 mV +101 mV +1.01 V	– 1.6 mV – 25.1 mV – 251 mV	_____	_____	+ 1.6 mV + 25.1 mV + 251 mV
DC Voltage Measurement Accuracy (Averaged)					
CH1	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0355 V	_____	_____	+ 1.0445 V
CH1	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0445 V	_____	_____	– 1.0355 V
CH1	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.5195 V	_____	_____	+ 11.6805 V
CH1	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.6805 V	_____	_____	– 11.5195 V
CH1	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.621 V	_____	_____	+ 18.379 V
CH1	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.379 V	_____	_____	– 17.621 V
CH2	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0355 V	_____	_____	+ 1.0445 V
CH2	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0445 V	_____	_____	– 1.0355 V
CH2	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.5195 V	_____	_____	+ 11.6805 V

TDS 500D/700D/714L Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		

TDS 500D/700D/714L Performance Test		Minimum	Incoming	Outgoing	Maximum
CH2	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.6805 V	_____	_____	– 11.5195 V
CH2	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.621 V	_____	_____	+ 18.379 V
CH2	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.379 V	_____	_____	– 17.621 V
CH3 or AX1	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0355 V	_____	_____	+ 1.0445 V
CH3 or AX1	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0445 V	_____	_____	– 1.0355 V
CH3 or AX1	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.5195 V	_____	_____	+ 11.6805 V
CH3 or AX1	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.6805 V	_____	_____	– 11.5195 V
CH3 or AX1	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.621 V	_____	_____	+ 18.379 V
CH3 or AX1	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.379 V	_____	_____	– 17.621 V
CH4 or AX2	5 mV Vert scale setting, –5 Div position setting, +1 V offset	+ 1.0355 V	_____	_____	+ 1.0445 V
CH4 or AX2	5 mV Vert scale setting, +5 Div position setting, –1 V offset	– 1.0445 V	_____	_____	– 1.0355 V
CH4 or AX2	200 mV Vert scale setting, –5 Div position setting, +10 V offset	+ 11.5195 V	_____	_____	+ 11.6805 V
CH4 or AX2	200 mV Vert scale setting, +5 Div position setting, –10 V offset	– 11.6805 V	_____	_____	– 11.5195 V
CH4 or AX2	1.01 V Vert scale setting, –5 Div position setting, +10 V offset	+ 17.621 V	_____	_____	+ 18.379 V
CH4 or AX2	1.01 V Vert scale setting, +5 Div position setting, –10 V offset	– 18.379 V	_____	_____	– 17.621 V

Analog Bandwidth					
CH1	100 mV	424 mV	_____	_____	N/A
CH2	100 mV	424 mV	_____	_____	N/A
CH3 or AX1	100 mV	424 mV	_____	_____	N/A
CH4 or AX2	100 mV	424 mV	_____	_____	N/A

TDS 500D/700D/714L Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		
TDS 500D/700D/714L Performance Test	Minimum	Incoming	Outgoing	Maximum
Delay Between Channels	N/A	_____	_____	50 ps
Time Base System				
Long Term Sample Rate/ Delay Time @ 100 ns/10.0 ms	-2.5 Div	_____	_____	+2.5 Div
Trigger System Accuracy				
Pulse-Glitch or Pulse-Width, Hor. scale $\leq 1 \mu\text{s}$				
Lower Limit	3.5 ns	_____	_____	6.5 ns
Upper Limit	3.5 ns	_____	_____	6.5 ns
Pulse-Glitch or Pulse-Width, Hor. scale $> 1 \mu\text{s}$				
Lower Limit	1.9 μs	_____	_____	2.1 μs
Upper Limit	1.9 μs	_____	_____	2.1 μs
CH1 Sensitivity, 50 MHz, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, 50 MHz, Delayed	Pass/Fail	_____	_____	Pass/Fail
CH1 AUX Trigger Input	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, full bandwidth, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, full bandwidth, Delayed	Pass/Fail	_____	_____	Pass/Fail
Output Signal Checks				
MAIN TRIGGER OUTPUT, 1 M Ω				
High	High $\geq 2.5 \text{ V}$	_____	_____	Low $\leq 0.7 \text{ V}$
Low		_____	_____	
MAIN TRIGGER OUTPUT, 50 Ω				
High	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
Low		_____	_____	
DELAYED TRIGGER OUTPUT, 50 Ω				
High	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
Low		_____	_____	
DELAYED TRIGGER OUTPUT, 1 M Ω				
High	High $\geq 2.5 \text{ V}$	_____	_____	Low $\leq 0.7 \text{ V}$
Low		_____	_____	

TDS 500D/700D/714L Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		
TDS 500D/700D/714L Performance Test	Minimum	Incoming	Outgoing	Maximum
CH 3 or AX 1 SIGNAL OUTPUT, 1 M Ω	p-p $\geq$ 88 mV	_____	_____	p-p $\leq$ 132 mV
CH 3 or AX 1 SIGNAL OUTPUT, 50 Ω	p-p $\geq$ 44 mV	_____	_____	p-p $\leq$ 66 mV
Probe Compensator Output Signal				
Frequency (CH1 Freq).	950 Hz	_____	_____	1.050 kHz
Voltage (difference)	495 mV	_____	_____	505 mV

TDS694C Test Record

Photocopy this and the next two pages and use them to record the performance test results for your TDS694C.

TDS694C Test Record

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		

TDS694C Performance Test		Minimum	Incoming	Outgoing	Maximum
Offset Accuracy					
CH1 Offset	+10 mV +101 mV	- 2.5 mV - 25.1 mV	_____ _____	_____ _____	+ 2.5 mV + 25.1 mV
CH2 Offset	+10 mV +101 mV	- 2.5 mV - 25.1 mV	_____ _____	_____ _____	+ 2.5 mV + 25.1 mV
CH3 Offset	+10 mV +101 mV	- 2.5 mV - 25.1 mV	_____ _____	_____ _____	+ 2.5 mV + 25.1 mV
CH4 Offset	+10 mV +101 mV	- 2.5 mV - 25.1 mV	_____ _____	_____ _____	+ 2.5 mV + 25.1 mV
DC Voltage Measurement Accuracy (Averaged)					
CH1	10 mV Vert scale setting, -5 Div position setting, +.5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH1	10 mV Vert scale setting, +5 Div position setting, -.5 V offset	-0.5845 V	_____	_____	-0.5755 V
CH1	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.828 V	_____	_____	+5.172 V
CH1	200 mV Vert scale setting, 0 Div position setting, -5 V offset	-5.172 V	_____	_____	-4.828 V
CH1	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.738 V	_____	_____	+5.263 V
CH1	1 V Vert scale setting, 0 Div position setting, -2.5 V offset	-5.263 V	_____	_____	-4.738 V
CH2	10 mV Vert scale setting, -5 Div position setting, +.5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH2	10 mV Vert scale setting, +5 Div position setting, -.5 V offset	-0.5845 V	_____	_____	-0.5755 V
CH2	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.828 V	_____	_____	+5.172 V

TDS694C Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		

TDS694C Performance Test		Minimum	Incoming	Outgoing	Maximum
CH2	200 mV Vert scale setting, 0 Div position setting, –5 V offset	–5.172 V	_____	_____	–4.828 V
CH2	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.738 V	_____	_____	+5.263 V
CH2	1 V Vert scale setting, 0 Div position setting, –2.5 V offset	–5.263 V	_____	_____	–4.738 V
CH3	10 mV Vert scale setting, –5 Div position setting, +5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH3	10 mV Vert scale setting, +5 Div position setting, –5 V offset	–0.5845 V	_____	_____	–0.5755 V
CH3	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.828 V	_____	_____	+5.172 V
CH3	200 mV Vert scale setting, 0 Div position setting, –5 V offset	–5.172 V	_____	_____	–4.828 V
CH3	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.738 V	_____	_____	+5.263 V
CH3	1 V Vert scale setting, 0 Div position setting, –2.5 V offset	–5.263 V	_____	_____	–4.738 V
CH4	10 mV Vert scale setting, –5 Div position setting, +5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH4	10 mV Vert scale setting, +5 Div position setting, –5 V offset	–0.5845 V	_____	_____	–0.5755 V
CH4	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.828 V	_____	_____	+5.172 V
CH4	200 mV Vert scale setting, 0 Div position setting, –5 V offset	–5.172 V	_____	_____	–4.828 V
CH4	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.738 V	_____	_____	+5.263 V
CH4	1 V Vert scale setting, 0 Div position setting, –2.5 V offset	–5.263 V	_____	_____	–4.738 V

Analog Bandwidth					
CH1	100 mV	424 mV	_____	_____	N/A
CH2	100 mV	424 mV	_____	_____	N/A
CH3	100 mV	424 mV	_____	_____	N/A
CH4	100 mV	424 mV	_____	_____	N/A
Delay Between Channels		N/A	_____	_____	50 ps

TDS694C Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		
TDS694C Performance Test	Minimum	Incoming	Outgoing	Maximum
Time Base System				
Long Term Sample Rate/ Delay Time @ 100 ns/10.0 ms	-1.0 Div	_____	_____	+1.0 Div
Trigger System Accuracy				
Pulse-Glitch or Pulse-Width, Hor. scale $\leq 1 \mu\text{s}$				
Lower Limit	3.5 ns	_____	_____	6.5 ns
Upper Limit	3.5 ns	_____	_____	6.5 ns
Pulse-Glitch or Pulse-Width, Hor. scale $> 1 \mu\text{s}$				
Lower Limit	1.9 μs	_____	_____	2.1 μs
Upper Limit	1.9 μs	_____	_____	2.1 μs
CH1 Sensitivity, 50 MHz, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, 50 MHz, Delayed	Pass/Fail	_____	_____	Pass/Fail
CH1 AUX Trigger Input	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, full bandwidth, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, full bandwidth, Delayed	Pass/Fail	_____	_____	Pass/Fail
Output Signal Checks				
MAIN TRIGGER OUTPUT, 50 Ω				
High	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
Low		_____	_____	
DELAYED TRIGGER OUTPUT, 50 Ω				
High	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
Low		_____	_____	
Probe Compensator Output Signal				
Frequency (CH1 Freq).	950 Hz	_____	_____	1.050 kHz
Voltage (difference)	495 mV	_____	_____	505 mV

TDS794D Test Record

Photocopy this and the next two pages and use them to record the performance test results for your TDS794D.

TDS794D Test Record

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		

TDS794D Performance Test		Minimum	Incoming	Outgoing	Maximum
Offset Accuracy					
CH1 Offset	+10 mV +101 mV	– 2.5 mV – 25.1 mV	_____	_____	+ 2.5 mV + 25.1 mV
CH2 Offset	+10 mV +101 mV	– 2.5 mV – 25.1 mV	_____	_____	+ 2.5 mV + 25.1 mV
CH3 Offset	+10 mV +101 mV	– 2.5 mV – 25.1 mV	_____	_____	+ 2.5 mV + 25.1 mV
CH4 Offset	+10 mV +101 mV	– 2.5 mV – 25.1 mV	_____	_____	+ 2.5 mV + 25.1 mV
DC Voltage Measurement Accuracy (Averaged)					
CH1	10 mV Vert scale setting, –5 Div position setting, +5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH1	10 mV Vert scale setting, +5 Div position setting, –5 V offset	–0.5845 V	_____	_____	–0.5755 V
CH1	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.9405 V	_____	_____	+5.0595 V
CH1	200 mV Vert scale setting, 0 Div position setting, –5 V offset	–5.0595 V	_____	_____	–4.9405 V
CH1	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.794 V	_____	_____	+5.206 V
CH1	1 V Vert scale setting, 0 Div position setting, –2.5 V offset	–5.206 V	_____	_____	–4.794 V
CH2	10 mV Vert scale setting, –5 Div position setting, +5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH2	10 mV Vert scale setting, +5 Div position setting, –5 V offset	–0.5845 V	_____	_____	–0.5755 V
CH2	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.9405 V	_____	_____	+5.0595 V

TDS794D Test Record (cont.)

Instrument Serial Number: _____ Certificate Number: _____
 Temperature: _____ RH %: _____
 Date of Calibration: _____ Technician: _____

TDS794D Performance Test		Minimum	Incoming	Outgoing	Maximum
CH2	200 mV Vert scale setting, 0 Div position setting, -5 V offset	-5.0595 V	_____	_____	-4.9405 V
CH2	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.794 V	_____	_____	+5.206 V
CH2	1 V Vert scale setting, 0 Div position setting, -2.5 V offset	-5.206 V	_____	_____	-4.794 V
CH3	10 mV Vert scale setting, -5 Div position setting, +5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH3	10 mV Vert scale setting, +5 Div position setting, -5 V offset	-0.5845 V	_____	_____	-0.5755 V
CH3	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.9405 V	_____	_____	+5.0595 V
CH3	200 mV Vert scale setting, 0 Div position setting, -5 V offset	-5.0595 V	_____	_____	-4.9405 V
CH3	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.794 V	_____	_____	+5.206 V
CH3	1 V Vert scale setting, 0 Div position setting, -2.5 V offset	-5.206 V	_____	_____	-4.794 V
CH4	10 mV Vert scale setting, -5 Div position setting, +5 V offset	+0.5755 V	_____	_____	+0.5845 V
CH4	10 mV Vert scale setting, +5 Div position setting, -5 V offset	-0.5845 V	_____	_____	-0.5755 V
CH4	200 mV Vert scale setting, 0 Div position setting, +5 V offset	+4.9405 V	_____	_____	+5.0595 V
CH4	200 mV Vert scale setting, 0 Div position setting, -5 V offset	-5.0595 V	_____	_____	-4.9405 V
CH4	1 V Vert scale setting, 0 Div position setting, +2.5 V offset	+4.794 V	_____	_____	+5.206 V
CH4	1 V Vert scale setting, 0 Div position setting, -2.5 V offset	-5.206 V	_____	_____	-4.794 V

Analog Bandwidth					
CH1	100 mV	424 mV	_____	_____	N/A
CH2	100 mV	424 mV	_____	_____	N/A
CH3	100 mV	424 mV	_____	_____	N/A
CH4	100 mV	424 mV	_____	_____	N/A
Delay Between Channels		N/A	_____	_____	50 ps

TDS794D Test Record (cont.)

Instrument Serial Number: _____		Certificate Number: _____		
Temperature: _____		RH %: _____		
Date of Calibration: _____		Technician: _____		
TDS794D Performance Test	Minimum	Incoming	Outgoing	Maximum
Time Base System				
Long Term Sample Rate/ Delay Time @ 100 ns/10.0 ms	-2.5 Div	_____	_____	+2.5 Div
Trigger System Accuracy				
Pulse-Glitch or Pulse-Width, Hor. scale $\leq 1 \mu\text{s}$				
Lower Limit	3.5 ns	_____	_____	6.5 ns
Upper Limit	3.5 ns	_____	_____	6.5 ns
Pulse-Glitch or Pulse-Width, Hor. scale $> 1 \mu\text{s}$				
Lower Limit	1.9 μs	_____	_____	2.1 μs
Upper Limit	1.9 μs	_____	_____	2.1 μs
CH1 Sensitivity, 50 MHz, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, 50 MHz, Delayed	Pass/Fail	_____	_____	Pass/Fail
CH1 AUX Trigger Input	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, full bandwidth, Main	Pass/Fail	_____	_____	Pass/Fail
CH1 Sensitivity, full bandwidth, Delayed	Pass/Fail	_____	_____	Pass/Fail
Output Signal Checks				
MAIN TRIGGER OUTPUT, 50 Ω				
High	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
Low		_____	_____	
DELAYED TRIGGER OUTPUT, 50 Ω				
High	High $\geq 1.0 \text{ V}$	_____	_____	Low $\leq 0.25 \text{ V}$
Low		_____	_____	
CH 3 SIGNAL OUTPUT, 50 Ω	p-p $\geq 44 \text{ mV}$	_____	_____	p-p $\leq 66 \text{ mV}$
Probe Compensator Output Signal				
Frequency (CH1 Freq).	950 Hz	_____	_____	1.050 kHz
Voltage (difference)	495 mV	_____	_____	505 mV

Signal Acquisition System Checks

These procedures check those characteristics that relate to the signal-acquisition system and are listed as checked under *Warranted Characteristics* in *Specifications*. Refer to Table 4–1 on page 4–18 for test equipment specifications.

Check Offset Accuracy (Zero Setting)

Equipment required	None
Prerequisites	The oscilloscope must meet the prerequisites listed on page 4–17. See <i>Input Channels versus Model</i> on page 4–2.

1. *Preset the instrument controls:*
 - a. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**.
 - Press the side-menu button **OK Confirm Factory Init**.
 - Press **CLEAR MENU** to remove the menus from the screen.
 - b. *Modify the default settings:*
 - Press **SHIFT**; then press **ACQUIRE MENU**.
 - On the TDS 600C, press the main-menu button **Mode**; then press the side-menu button **Average 16**.
 - On the TDS 500D, 700D and 714L, press the main-menu button **Mode**; then press the side-menu button **Hi Res**.
 - Press **CURSOR**.
 - Press the main-menu button **Function**; then press the side-menu button **H Bars**.
 - Press **CLEAR MENU**.
 - Be sure to disconnect any input signals from all four channels.
2. *Confirm input channels are within limits for offset accuracy at zero offset:*
Do the following substeps — test CH 1 first, *skipping substep a, since CH 1 is already set up to be checked from step 1*.
 - a. *Select an unchecked channel:* Press **WAVEFORM OFF** to remove the channel just confirmed from the display. Then, press the front-panel button that corresponds to the channel you are to confirm.

- b. *Set the vertical scale:* Set the vertical **SCALE** to one of the settings listed in Table 4–2 that is not yet checked. (Start with the first setting listed).
- Press **VERTICAL MENU**. Press the main-menu button **Fine Scale**.
 - Use the keypad to enter the vertical scale. For the 1 mV setting, press **1**, **SHIFT**, **m**, then **ENTER**. For the 101 mV setting, press **101**, **SHIFT**, **m**, then **ENTER**. For the 1.01 V setting, press **1.01**, then **ENTER**.
 - Press **CLEAR MENU**.

Table 4–2: DC offset accuracy (zero setting)

Vertical scale setting	Vertical position and offset setting ¹	TDS 600C offset accuracy limits	TDS 500D/700D/714L (except TDS 794D) offset accuracy limits
1 mV	0	±2.1 mV	±1.6 mV
101 mV	0	±75.6 mV	±25.1 mV
1.01 V	0	±756 mV	±251 mV
		TDS694C and TDS794D offset accuracy limits	
10 mV	0	±2.5 mV	
101 mV	0	±25.1 mV	

¹ Vertical position is set to 0 divisions and vertical offset to 0 V when the oscilloscope is initialized in step 1.

- c. *Display the test signal:* The waveform position and offset were initialized for all channels in step 1 and are displayed as you select each channel and its vertical scale.
- d. *Measure the test signal:* Align the active cursor over the waveform by rotating the general purpose knob. Ignore the other cursor. See Figure 4–4.
- e. Read the measurement results at the absolute (@:) cursor readout, not the delta (Δ:) readout on screen. That is, read the offset relative to the ground reference. See Figure 4–4.
- f. *Check against limits:* Do the following subparts in the order listed.
- CHECK that the measurement results are within the limits listed for the current vertical scale setting.
 - Enter voltage on test record.

- Repeat substeps b through f until all vertical scale settings listed in Table 4-2, are checked for the channel under test.




Figure 4-4: Measurement of DC offset accuracy at zero setting – TDS 684C shown

- g. *Test all channels:* Repeat substeps a through f for all input channels.

Check DC Voltage
Measurement Accuracy



WARNING. The generator is capable of outputting dangerous voltages. Be sure to set the DC calibration generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure. Also, check that the calibrator does not have shorting straps installed between the DC and sense outputs or grounds.

Equipment required	Two dual-banana connectors (Item 6) One BNC T connector (Item 7) One DC calibration generator (Item 9) Two precision 50 Ω coaxial cables (Item 5)
Prerequisites	The oscilloscope must meet the prerequisites listed on page 4–17 See <i>Input Channels versus Model</i> on page 4–2.

1. Install the test hookup and preset the instrument controls:

a. Hook up the test-signal source:

- Set the output of a DC calibration generator to off or 0 volts.
- Connect the output of a DC calibration generator through a dual-banana connector followed by a 50 Ω precision coaxial cable to one side of a BNC T connector. See Figure 4–5.
- Connect the Sense output of the generator through a second dual-banana connector followed by a 50 Ω precision coaxial cable to the other side of the BNC T connector. Now connect the BNC T connector to **CH 1**. See Figure 4–5.




Figure 4–5: Initial test hookup

- b. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**.
 - Press the side-menu button **OK Confirm Factory Init**.
 - c. *Modify the default settings:*
 - Press **SHIFT**; then press **ACQUIRE MENU**.
 - Press the main-menu button **Mode**; then press the side-menu button **Average 16**.
 2. *Confirm input channels are within limits for DC accuracy at maximum offset and position: Do the following substeps — test CH 1 first, skipping substep 2a since CH 1 is already selected from step 1.*
 - a. *Select an unchecked channel:*
 - Press **WAVEFORM OFF** to remove the channel just confirmed from the display.
 - Press the front-panel button that corresponds to the channel you are to confirm.
 - *Set the generator output to 0 V.*
 - Move the test hookup to the channel you selected.
 - b. *Turn on the measurement Mean for the channel:*
 - Press **MEASURE**, then press the main-menu button **Select Measrmnt for CHx**.
 - Press the side-menu button **more** until the menu label **Mean** appears in the side menu (its icon is shown at the left). Press the side-menu button **Mean**.
 - Press **CLEAR MENU**.
 - c. *Set the vertical scale:* Set the vertical **SCALE** to one of the settings listed in Table 4–3 that is not yet checked. (Start with the first setting listed).



Table 4–3: DC Voltage measurement accuracy

Scale setting	Position setting (Divs)	Offset setting	Generator setting	TDS 600C (except TDS694C) Accuracy limits	TDS 500D/700D/714L (except TDS794D) Accuracy limits
5 mV	–5	+1 V	+1.040 V	+1.0329 V to +1.0471 V	+1.0355 V to +1.0445 V
	+5	–1 V	–1.040 V	–1.0471 V to –1.0329 V	–1.0445 V to –1.0355 V
200 mV	–5	+10 V	+11.6 V	+11.4165 V to +11.7835 V	+11.5195 V to +11.6805 V
	+5	–10 V	–11.6 V	–11.7835 V to –11.4165 V	–11.6805 V to –11.5195 V
1.01 V	–5	+10 V	+18V	+17.102 V to +18.899 V	+17.621 V to +18.379 V
	+5	–10 V	–18 V	–18.899 V to –17.102 V	–18.379 V to –17.621 V
				TDS694C Accuracy limits	TDS794D Accuracy limits
10 mV	–5	+0.5 V	+0.58 V	+575.5 mV to +584.5 mV	+575.5 mV to +584.5 mV
	+5	–0.5 V	–0.58 V	–584.5 mV to –575.5 mV	–584.5 mV to –575.5 mV
200 mV	0	+5 V	+5.0 V	+4.828 V to +5.172 V	+4.9405 V to +5.0595 V
	0	–5 V	–5.0 V	–5.172 V to –4.828 V	–5.0595 V to –4.9405 V
1 V	0	+2.5 V	+5.0 V	+4.738 V to +5.263 V	+4.794 V to +5.206 V
	0	–2.5 V	–5.0 V	–5.263 V to –4.738 V	–5.206 V to –4.794 V

d. *Display the test signal:*

- Press **VERTICAL MENU**. Press the main-menu button **Position**.
- Use the keypad to set vertical position to –5 divisions (press –5, then **ENTER**, on the keypad). The baseline level will move off screen.
- Press the main-menu button **Offset**.
- Use the keypad to set vertical offset to the positive-polarity setting listed in the table for the current vertical scale setting. The baseline level will remain off screen.
- Set the generator to the level and polarity indicated in the table for the vertical scale, position, and offset settings you have made. The DC test level should appear on screen. (If it doesn't return, the DC accuracy check has failed for the current vertical scale setting of the current channel).

e. *Measure the test signal:* Press **CLEAR MENU**. Read the measurement results at the **Mean** measurement readout. See Figure 4–6.




Figure 4-6: Measurement of DC accuracy at maximum offset and position

f. *Check against limits:*

- CHECK that the readout for the measurement **Mean** readout on screen is within the limits listed for the current vertical scale and position/offset/generator settings. Enter value on test record.
- Repeat substep d, reversing the polarity of the position, offset, and generator settings as is listed in the table.
- CHECK that the **Mean** measurement readout on screen is within the limits listed for the current vertical scale setting and position/offset/generator settings. Enter value on test record.
- Repeat substeps c through f until all vertical scale settings, listed in Table 4-3, are checked for the channel under test.

g. *Test all channels:* Repeat substeps a through f for all four channels.

3. *Disconnect the hookup:*

- a. *Set the generator output to 0 V.*
- b. Disconnect the cable from the generator output at the input connector of the channel last tested.

Check Analog Bandwidth

Equipment required	One sine wave generator (Item 14) One level meter and power sensor (Item 15) One power divider (Item 16) One female N to male BNC adapter (Item 18) Four male N to female BNC adapters (Item 17) Two 50 Ω precision cables (Item 5) Attenuators (Items 1 and 2) Optional: One high-frequency leveled sine wave generator and its leveling head – replaces items 14, 15, 16, 17, and 18
Prerequisites	See page 4–17

1. Install the test hookup and preset the instrument controls:**a. Initialize the oscilloscope:**

- Press save/recall **SETUP**. Press the main-menu button **Recall Factory Setup**; then press the side-menu button **OK Confirm Factory Init**.

b. Modify the default settings:

- Turn the horizontal **SCALE** knob to 50 ns (TDS694C 40 ns). Press **SHIFT**; then press **ACQUIRE MENU**.
- Press the main-menu button **Mode**; then press the side-menu button **Average 16**.
- Press **MEASURE**. Press the main-menu button **Level Setup**; then press the side-menu button **Min-Max**.

NOTE. The sine wave generator output amplitude must be leveled to within 0.35 db of the reference frequency (10 MHz) through the bandwidth frequency listed in Table 4–4 on page 4–45. The 0.35 db requirement is necessary to ensure a bandwidth that meets Tektronix specifications.

You can perform bandwidth PV using an unleveled sine wave generator (with amplitude error > 0.35 db). Under these conditions, the bandwidth PV is subject to the flatness errors associated with the generator used.

Refer to the Sine Wave Generator Leveling Procedure on page 4–94 if your sine wave generator does not have automatic output amplitude leveling.

- c. Hook up the test-signal source:** Connect the sine wave output of a leveled sine wave generator to **CH 1**. Set the output of the generator to a

reference frequency of 10 MHz or less. See Figure 4–7.

For the optional setup using a leveled sine wave generator with a leveling head, see Figure 4–8 and, if using this optional setup with the example Tektronix SG 504, set the generator output to 6 MHz.




Figure 4–7: Initial test hookup




Figure 4–8: Optional initial test hookup

2. *Confirm the input channels are within limits for analog bandwidth:* Do the following substeps — test CH 1 first, *skipping substeps a and b since CH 1 is already set up for testing from step 1.*
 - a. *Select an unchecked channel:*
 - Press **WAVEFORM OFF** to remove the channel just confirmed from display.
 - Press the front-panel button that corresponds to the channel you are to confirm.
 - Move the leveling output of the sine wave generator to the channel you selected.

- b. *Match the trigger source to the channel selected:*
 - Press **TRIGGER MENU**. Press the main-menu button **Source**; then press the side-menu button that corresponds to the channel selected.
- c. *Set its input impedance: (This substep is not required on the TDS694C and TDS794D.)*
 - Press **VERTICAL MENU**. Press the main-menu button **Coupling**, then press the side-menu **Ω** button to toggle it to the **50 Ω** setting.
- d. *Set the vertical scale:* Set the vertical **SCALE** to one of the settings listed in Table 4–4 not yet checked. (Start with the 100 mV setting).
- e. *Set the triggering coupling:*
 - Press **TRIGGER MENU**.
 - Press the main-menu button **Coupling**.
 - For vertical settings of 1, 2, and 5 mV, press the side menu button **Noise Rej**. For all other settings, press side menu button **DC**.

Table 4–4: Analog bandwidth

Vertical scale	Reference amplitude (6 divisions)	Horizontal scale	Test frequency					–3 db Limits
			TDS694C	TDS794D	TDS580D TDS680C TDS684C TDS784D	TDS654C	TDS520D TDS540D TDS714L TDS724D TDS754D	
100 mV	600 mV	1 ns	3 GHz	2 GHz	1 GHz	500 MHz	500 MHz	≥424 mV
1 mV	6 mV	1 ns	NA	NA	500 MHz	250 MHz	450 MHz	≥4.24 mV
2 mV	12 mV	1 ns	NA	NA	600 MHz	300 MHz	500 MHz	≥8.48 mV
5 mV	30 mV	1 ns	NA	NA	750 MHz	450 MHz	500 MHz	≥21.2 mV
10 mV	60 mV	1 ns	3 GHz	2 GHz	1 GHz	500 MHz	500 MHz	≥42.4 mV
20 mV	120 mV	1 ns	3 GHz	2 GHz	1 GHz	500 MHz	500 MHz	≥84.8 mV
50 mV	300 mV	1 ns	3 GHz	2 GHz	1 GHz	500 MHz	500 MHz	≥212 mV
200 mV	1.2 V	1 ns	3 GHz	2 GHz	1 GHz	500 MHz	500 MHz	≥848 mV
500 mV	3 V ¹	1 ns	3 GHz	2 GHz	1 GHz	500 MHz	500 MHz	≥2.12 V ¹
1 V	6 V ¹	1 ns	3 GHz	2 GHz	1 GHz	500 MHz	500 MHz	≥4.24 V ¹

¹ If your generator cannot output 6 divisions of amplitude, determine its maximum output at the Test frequency, and use this for the reference amplitude. The –3 db limit can be calculated as: $0.707 \times \text{reference amplitude}$.

f. *Display the test signal:* Do the following subparts to first display the reference signal and then the test signal.

- Press **MEASURE**; then press the main-menu button **Select Measrmt for CHx**.
- Press the side-menu button **more**, if needed, until the menu label **Frequency** appears in the side menu (its icon is shown at the left). Press the side-menu button **Frequency**.
- Press the side-menu button **more** until the menu label **Pk-Pk** appears in the side menu (its icon is shown at the left). Press the side-menu button **Pk-Pk**.
- Press **CLEAR MENU**.
- Set the generator output so the CHx Pk-Pk readout equals the reference amplitude in Table 4–4 that corresponds to the vertical scale set in substep d.
- Press the front-panel button **SET LEVEL TO 50%** as necessary to trigger a stable display. At full bandwidth, you may also want to make small, manual adjustments to the trigger level. You can use the



TRIGGER LEVEL knob to do this. (Full bandwidth varies with TDS model as is shown in Table 4-4).

g. Measure the test signal:

- Set the frequency of the generator, as shown on screen, to the test frequency in Table 4-4 that corresponds to the vertical scale set in substep **d**. See Figure 4-9.
- Set the horizontal **SCALE** to the horizontal scale setting in Table 4-4 that corresponds to the vertical scale set in substep **d**. Press **SET LEVEL TO 50%** as necessary to trigger the signal.
- Read the results at the CHx Pk-Pk readout, which will automatically measure the amplitude of the test signal. See Figure 4-9.




Figure 4-9: Measurement of analog bandwidth

h. Check against limits:

- CHECK that the **Pk-Pk** readout on screen is within the limits listed in Table 4-4 for the current vertical scale setting.
- Enter voltage on test record.
- When finished checking, set the horizontal **SCALE** back to the 50 ns (TDS694C 40 ns) setting.

STOP. Checking each channel's bandwidth at all vertical scale settings is time consuming and unnecessary. You may skip checking the remaining vertical scale settings in Table 4–4 (that is, skip the following substep, i) if this oscilloscope has performed as follows:

- Passed the 100 mV vertical scale setting just checked in this procedure.
 - Passed the *Verify Internal Adjustment, Self Compensation, and Diagnostics* procedure found under *Self Tests*, on page 4–5.
-

NOTE. Passing the signal path compensation confirms the signal path for all vertical scale settings for all channels. Passing the internal diagnostics ensures that the factory-set adjustment constants that control the bandwidth for each vertical scale setting have not changed.

- i. *Check remaining vertical scale settings against limits (optional):*
 - If desired, finish checking the remaining vertical scale settings for the channel under test by repeating substeps d through h for each of the remaining scale settings listed in Table 4–4 for the channel under test.
 - When doing substep f, skip the subparts that turn on the CHx Pk-Pk measurement until you check a new channel.
 - Install/remove attenuators between the generator leveling head and the channel input as needed to obtain the six division reference signals listed in the table.
 - j. *Test all channels:* Repeat substeps a through h for all four channels.
3. *Disconnect the hookup:* Disconnect the test hook up from the input connector of the channel last tested.

Check Delay Between Channels

Equipment required	One sine wave generator (Item 14) Three precision 50 Ω coaxial cables (Item 5) One power divider (Item 16) or dual input coupler (item 8) 3 SMA male to male adapter connector (Item 19) 3 SMA female-to-male BNC adapter connector (Item 20)
Prerequisites	See page 4–17 See <i>Input Channels versus Model</i> on page 4–2.

STOP. *DO NOT use the vertical position knob to reposition any channel while doing this check. To do so invalidates the test.*

1. *Install the test hookup and preset the instrument controls:*
 - a. *Initialize the front panel:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**.
 - Press the side-menu button **OK Confirm Factory Init**.
 - b. *Modify the initialized front-panel control settings:*
 - Do not adjust the vertical position of any channel during this procedure.
 - Set the horizontal **SCALE** to 500 ps.
 - Press **SHIFT**; then press **ACQUIRE MENU**.
 - Press the main-menu button **Mode**, and then press the side-menu button **Average 16**.
 - c. *Hook up the test-signal source:*
 - Connect the sine wave output of a sine wave generator to a 50 Ω precision coaxial cable followed by a 50 Ω termination and a dual-input coupler. (If checking a TDS694C or TDS794C, substitute a 50 Ω power divider and two 50 Ω coaxial cables for the 50 Ω termination and dual-input coupler).
 - Connect the coupler to both **CH 1** and **CH 2**. See Figure 4–10.




Figure 4–10: Initial test hookup

2. *Confirm all four channels are within limits for channel delay:*

- a. *Set up the generator:* Set the generator frequency to 250 MHz and the amplitude for six to eight divisions in CH 1.

Hint: As you are adjusting the generator amplitude, push **SET LEVEL TO 50%** frequently to speed up the updating of the waveform amplitude on screen.

- b. The horizontal **SCALE** should already be set to 500 ps. On the TDS 580D, 784D, 794D, and all TDS 600C, now set it to 200 ps. On the TDS 520D, 540D, 714L, 724D, and 754D, push the front-panel **ZOOM** button, press the side-menu **On** button, set the horizontal **SCALE** to 250 ps, and be sure the vertical scale factor is kept at 1.0X and the horizontal scale factor is 2.0X for the remainder of this check.
- c. *Save a CH 2 waveform:* Press **CH 2**. Press save/recall **WAVEFORM**. Now, press the main-menu button **Save Wfm**; then press the side-menu button **To Ref 2**.
- d. *Save CH 3 (AX1 on some TDS models) waveform:*
 - Move the coupler from **CH 2** to **CH 3** (AUX1 on some TDS models), so that **CH 1** and **CH 3** are driven. Press **WAVEFORM OFF**. Press **CH 3**. Then press the side-menu button **To Ref 3**.
- e. *Display all test signals:*
 - Press **WAVEFORM OFF** to remove CH 3 (AX1 on some TDS models) from the display.

- Display the live waveform. Move the coupler from **CH 3** to **CH 4**, so that CH 1 and CH 4 are driven. (Use AUX1 and AUX2 instead of CH3 and CH4 if your TDS model is so equipped). Press **CH 4** to display. See Figure 4–11 on page 4–51.
 - Display the reference waveforms. To do this, press the front-panel button **MORE**. Press the main-menu buttons **Ref 2** and **Ref 3**. You may notice their overlapping ground reference indicators. See Figure 4–11 on page 4–51.
- f. Measure the test signal:**
- Locate the time reference points for these waveforms. Do this by first identifying the point where the rising edge of the left-most waveform crosses the center horizontal graticule line. Next, note the corresponding *time reference point* for the right-most waveform. See Figure 4–11 on page 4–51.
 - Press **CURSOR**.
 - Press the main-menu button **Function**; then press the side-menu button **V Bars**.
 - Press **CLEAR MENU**.
 - Align one V bar cursor to the *time reference point* of the left-most waveform edge and the other cursor to the *time reference point* of the right-most waveform edge by rotating the General Purpose knob. (Press **SELECT** to switch between the two cursors). See Figure 4–11 on page 4–51.
 - Read the measurement results at the Δ : cursor readout, not the @: readout on screen.




Figure 4-11: Measurement of channel delay – TDS 684C shown

- g. *Check against limits:* CHECK that the cursor readout on screen is ≤ 100 ps for the TDS600C or ≤ 50 ps for the TDS 500D, TDS694C, TDS700D, and TDS714L.
- h. If the channel skew is within the limits, enter time on the test record and proceed to step 3. Otherwise, proceed with steps **i** through **p**.
- i. Use the cursors to measure the skew from CH1 to CH2, CH1 to CH3, and CH1 to CH4 (use AX1 and AX2 instead of CH3 and CH4 if your TDS model is so equipped). Write down these three numbers in the first measurement column of Table 4-5. Note that these numbers may be either positive or negative.
- j. Repeat the procedure from step 1.c through 2.e.
- k. Again use the cursors to measure the skew from CH1 to CH2, CH1 to CH3, and CH1 to CH4. Write down these numbers in the second measurement column of Table 4-5. Note that these numbers may be either positive or negative.
- l. Add the first CH1 to CH2 skew measurement to the second CH1 to CH2 skew measurement and divide the result by 2. Use Table 4-5.

- m.** Add the first CH1 to CH3 (AX1 on some TDS models) skew measurement to the second CH1 to CH3 skew measurement and divide the result by 2. Use Table 4–5.
- n.** Add the first CH1 to CH4 (AX2 on some TDS models) skew measurement to the second CH1 to CH4 skew measurement and divide the result by 2. Use Table 4–5.
- o.** Check against limits: CHECK that the largest of the three results from steps l, m, and n is between –100 ps and + 100 ps for the TDS600C or between –50 ps and + 50 ps for the TDS500D, TDS694C, TDS700D, and TDS714L.
- p.** Enter time on the test record.

Table 4–5: Delay between channels worksheet

Coupling	First measurement	Second measurement	Add first and second measurements	Divide sum by 2
CH1 to CH2 skew				
CH1 to CH3 skew				
CH1 to CH4 skew				

- 3.** *Disconnect the hookup:* Disconnect the cable from the generator output at the input connectors of the channels.

Time Base System Checks

These procedures check those characteristics that relate to the Main and Delayed time base system and are listed as checked under *Warranted Characteristics in Specifications*.

Check Accuracy for Long-Term Sample Rate and Delay Time

Equipment required	One time-mark generator (Item 11), or Sine wave generator (Item 14) One 50 Ω , precision coaxial cable (Item 5)
Prerequisites	See page 4-17




Figure 4-12: Initial test hookup

1. *Install the test hookup and preset the instrument controls:*
 - a. *Hook up the test-signal source:* Connect, through a 50 Ω precision coaxial cable, the output of the generator to **CH 1** (see Figure 4-12).
 - If using a time-mark generator, set the output for 10 ms markers.
 - If using a sine wave generator, set the output for 1.2 V and 500 kHz.
 - b. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**. Press the main-menu button **Recall Factory Setup**. Press the side-menu button **OK Confirm Factory Init**.
 - c. *Modify the initialized front-panel control settings:*
 - Set the vertical **SCALE** to 200 mV (or 500 mV with the optional Tektronix TG 501A Time Mark Generator).
 - Set the horizontal **SCALE** of the Main time base to 2 μ s.

- Press **VERTICAL MENU**; then press the main-menu button **Coupling**. Press the side-menu button **Ω** to toggle it to the **50 Ω** setting. (This step is not required on the TDS694C or TDS794D.)
 - Press **SET LEVEL TO 50%**.
 - Use the vertical **POSITION** knob to center the test signal on screen.
 - Press **TRIGGER MENU**; then press the main-menu button **Mode & Holdoff**. Press the side-menu button **Normal**.
2. *Confirm Main and Delayed time bases are within limits for accuracies:*
- a. *Display the test signal:*
 - Press **HORIZONTAL MENU**.
 - Set horizontal modes. To do this, press the main-menu button **Time Base**. Press the side-menu buttons **Delayed Only** and **Delayed Runs After Main**. See Figure 4–13 on page 4–55.
 - b. *Measure the test signal:*
 - Set the horizontal **SCALE** of the **D** (delayed) time base to 500 ns for the TDS600C or to 100 ns for the TDS694C, TDS500D, TDS700D, or TDS714L.
 - If using a time-mark generator, align the trigger **T** to the center vertical graticule line by adjusting the horizontal **POSITION**. See Figure 4–13 on page 4–55.
 - If using a sine wave generator, align the rising edge of the sine wave on the center graticule crosshairs by adjusting the horizontal **POSITION**.
 - Set delayed time to 10.000016 ms. Do this on the keypad by pressing **10.000016**, then **SHIFT**, then **m** followed by **ENTER**).
 - c. *Check long-term sample rate and delay time accuracies against limits:*
 - CHECK that the rising edge of the marker (or sine wave) crosses the center horizontal graticule line at a point within either ± 1.0 divisions for the TDS694C, ± 2.0 divisions for the TDS600C, ± 2.5 divisions for the TDS500D, TDS700D, or TDS714L, of center graticule.
See Figure 4–13 on page 4–55.
 - Enter number of divisions on the test record.




Figure 4-13: Measurement of accuracy – long-term and delay time

3. *Disconnect the hookup:* Disconnect the cable from the generator output at the input connector of **CH 1**.

Check Accuracy for Delta Time Measurement (Skip for Option 1G and TDS 714L)

Equipment required	One 50 Ω , precision coaxial cable (Item 5) One Connector, BNC "T", male BNC-to-dual female BNC (Item 7) One Pulse Generator, Wavetek 9500 or equivalent (Item 23) Two 50 Ω , coaxial cable, male-to-male SMA connectors (Item 28) One SMA female to BNC male connector (Item 30) One BNC elbow connector (Item 31) One SMA "T", male to two SMA female connectors (Item 29) Two SMA terminator connectors, short circuit, (Item 32) One 2X attenuator, 50 Ω , female BNC-to- male BNC (Item 33)
Prerequisites	See page 4-17

This procedure checks the "sample rate" portion of the Delta Time Measurement Accuracy as listed under *Warranted Characteristics* in *Specifications*. The previous procedure, *Check Accuracy for Long-Term Sample Rate and Delay Time*, see page 4-53, verified the "PPM" portion of the delta time specification.




Figure 4-14: Delta time accuracy test hookup

1. *Install the test hookup and preset the instrument controls:*
 - a. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**. Press the main-menu button **Recall Factory Setup**. Press the side-menu button **OK Confirm Factory Init**.

b. *Hook up the pulse generator (see Figure 4–14 on page 4–56):*

- Connect the pulse generator output to a **50 Ω** precision coaxial cable followed by a 90° right-angle female to male BNC adapter, then a **50 Ω** 2X attenuator. The attenuator is connected to one side of the female BNC T connector. The other side of the BNC T is connected to BNC male to SMA adapter. The SMA side is connected to male side of the SMA T connector. (Keep the distance between the BNC T and SMA T as short as possible). Connect 20 inch **50 Ω** coaxial cables to each female side of the SMA T connector. Connect a female to female SMA adapter to both male coaxial connectors. Connect the SMA short, to the remaining female SMA adapter. Now connect the male BNC T connector to **CH 1**.
- Set the pulse generator output for a positive-going pulse with a rise-time as shown in Table 4–6 on page 4–58 for your oscilloscope, and for the fastest possible rep rate (at least 1 kHz).
- Set the pulse generator output for about 500 mV. (This amplitude can be adjusted later to get a 5-division pulse on screen.)

c. *Modify the initialized front-panel control settings:*

- *(This substep is not required on the TDS694C or TDS794D.)* Press **VERTICAL MENU**. Press the main-menu button **Coupling**, then press the side-menu **Ω** button to toggle it to the **50 Ω** setting.
- Press **AUTOSET**. You may see both positive and negative pulses. Adjust the trigger **MAIN LEVEL** knob so the trigger level is about 50% of the rising edge of the **positive** pulse.
- *(TDS 500D/700D/714L only.)* Press **SHIFT**; then press **ACQUIRE MENU**. Press the main-menu button **Repetitive Signal**, then press the side-menu **OFF (Real Time Only)**.
- Set the horizontal **SCALE** of the Main time base to 2 ns/division. The pulse width should be about **6 ns**.
- Adjust pulse amplitude and oscilloscope vertical scale and position as necessary to obtain about **5 divisions** of the **positive** pulse.

d. *Set up for statistics measurements:*

- Re-adjust the trigger **MAIN LEVEL** knob so the trigger level is about 50% of the rising edge of the **positive** pulse.
- Press **RUN/STOP** button to freeze the display.
- Press **MEASURE** to bring up the Measure menu.

- Press **MEASURE** → **Select Measurmnt for Ch1** (main menu) → **Positive Width** (side menu).
- Press **Statistics** → **Statistics OFF** (side menu) to reset the statistics, then press → **Statistics Mean/StdDev** (side menu).
- Press **Statistics Weights** (side menu). On the keypad press **1000**, then **ENTER**.
- Press **RUN/STOP** button to start the acquisitions.
- Wait about 30 seconds.
- Press **RUN/STOP** button to freeze the display.
- Record the mean, μ (value).
- Press **Statistics Min/Max** (side menu) to display those values.
- Calculate the difference of the Max minus the mean.
- Calculate the difference of the mean minus the Min.
- Both differences must be less than or equal to the Delta-time accuracy limit shown in Table 4–6 for your oscilloscope.

Table 4–6: Delta time measurement

Oscilloscope type	Pulse rise time range	Delta time accuracy limit
TDS520D, TDS540D, TDS724D, TDS754D	≤ 2 ns	≤ 0.075 ns
TDS580D, TDS784D	≤ 900 ps	≤ 0.038 ns
TDS794D	300 ps – 1 ns	≤ 0.038 ns
TDS654C	≤ 150 ps	≤ 0.040 ns
TDS680C, TDS684C	≤ 700 ps	≤ 0.040 ns
TDS694C	50 ps – 400 ps	≤ 0.015 ns

e. *Repeat for all other channels:*

- Note the vertical scale setting of the channel just confirmed.
- Press **WAVEFORM OFF** to remove the channel just confirmed from display.
- Press the front-panel button that corresponds to the channel you are to confirm.
- Set vertical **SCALE** to the setting noted in step **e**, first bullet.

- Press **TRIGGER MENU**. Press the main-menu button **Source**; then press the side-menu button that corresponds to the channel selected.
 - Move the test hookup to the channel you selected.
 - *(This substep is not required on the TDS694C or TDS794D.)* Press **VERTICAL MENU**. Press the main-menu button **Coupling**, then press the side-menu **Ω** button to toggle it to the **50 Ω** setting.
 - Press **RUN/STOP** button to start the display.
 - Repeat step **d**.
2. *Disconnect all test equipment from the oscilloscope:*

Trigger System Checks

These procedures check those characteristics that relate to the Main and Delayed trigger systems and are listed as checked in *Specifications*.

Check Accuracy (Time) for Pulse-Glitch or Pulse-Width Triggering

Equipment required	One sine wave generator (Item 14) One 10X attenuator (Item 1) One 50 Ω, precision coaxial cable (Item 5)
Prerequisites	See page 4-17

1. *Install the test hookup and preset the instrument controls:*
- a. *Initialize the instrument:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**.
 - Press the side-menu button **OK Confirm Factory Init**.
 - b. *Modify the default setup:*
 - Set the horizontal **SCALE** to 10 ns on the TDS 600C and 12.5 ns on the TDS 500D/700D/714L.
 - Press **VERTICAL MENU**; then press the main-menu button **Coupling**. Now press the side-menu button **Ω** to toggle it to the 50 Ω setting. (This step is not required on the TDS694C or TDS794D.)
 - c. *Hook up the test-signal source:* Connect the output of the sine wave generator (Item 14) to CH 1.

Do this through a 50 Ω precision coaxial cable, followed by a 10X attenuator. See Figure 4–15. The 10X attenuator is optional if the SG503 is used.




Figure 4–15: Initial test hookup

2. *Confirm the trigger system is within time-accuracy limits for pulse-glitch or pulse-width triggering (time range ≤ 500 ns):*
 - a. *Display the test signal:* Set the output of the sine wave generator for a 100 MHz, five-division sine wave on screen. Press **SET LEVEL TO 50%**.
 - b. *Set the trigger mode:* Press **TRIGGER MENU**. Now press the main-menu button **Mode & Holdoff**; then press the side-menu button **Normal**.
 - c. *Set upper and lower limits that ensure triggering:* See Figure 4–16.
 - Press the main-menu button **Type**; then repeatedly press the same button until **Pulse** is highlighted in the menu that pops up.
 - Press the main-menu button **Class**; then repeatedly press the same button until **Width** is highlighted in the menu that pops up.
 - Press the main-menu button **Trig When**; then press the side-menu button **Within Limits**.
 - Press the side-menu button **Upper Limit**. Use the keyboard to set the upper limit to 10 ns: press **10**, then **SHIFT**, then **n**, and **ENTER**.
 - Press the side-menu button **Lower Limit**. Use the keypad to set the lower limit to 2 ns.
 - d. *Change limits until triggering stops:*

- Press **SET LEVEL TO 50%**.
- While doing the following subparts, monitor the display (it will stop acquiring) and the front-panel light **TRIG** (it will extinguish) to determine when triggering is lost.
- Press the side-menu button **Lower Limit**.
- Use the general purpose knob to *increase* the **Lower Limit** readout until triggering is lost.
- CHECK that the **Lower Limit** readout, after the oscilloscope loses triggering, is within 3.5 ns to 6.5 ns, inclusive.
- Enter time on test record.
- Use the keypad to return the **Lower Limit** to 2 ns and reestablish triggering.
- Press the side-menu button **Upper Limit**; then use the general purpose knob to slowly *decrease* the **Upper Limit** readout until triggering is lost.
- CHECK that the **Upper Limit** readout, after the oscilloscope loses triggering, is within 3.5 ns to 6.5 ns, inclusive.
- Enter time on test record.




Figure 4-16: Measurement of time accuracy for pulse and glitch triggering

3. *Confirm the trigger system is within time-accuracy limits for pulse-glitch or pulse-width triggering (time range >520 ns):*
 - a. *Set upper and lower limits that ensure triggering at 250 kHz:*
 - Press the side-menu button **Upper Limit**. Use the keyboard to set the upper limit to 4 μ s.
 - Press the side-menu button **Lower Limit**. Use the keypad to set the lower limit to 500 ns.
 - b. *Display the test signal:*
 - Set the horizontal **SCALE** to 5 μ s.
 - Set the output of the sine wave generator for a 250 kHz, five-division sine wave on screen. Set the vertical **SCALE** to 20 mV (the waveform will overdrive the display).
 - Press **SET LEVEL TO 50%**.
 - c. *Check against limits:* Do the following subparts in the order listed.
 - Press the side-menu button **Lower Limit**.
 - Use the general purpose knob to *increase* **Lower Limit** readout until triggering is lost.
 - CHECK that the **Lower Limit** readout, after the oscilloscope stops triggering, is within 1.9 μ s to 2.1 μ s, inclusive.
 - Enter time on test record.
 - Use the keypad to return the **Lower Limit** to 500 ns and reestablish triggering.
 - Press the side-menu button **Upper Limit**; then use the general purpose knob to slowly *decrease* the **Upper Limit** readout until triggering stops.
 - CHECK that the **Upper Limit** readout, after the oscilloscope loses triggering, is within 1.9 μ s to 2.1 μ s, inclusive.
 - Enter time on test record.
4. *Disconnect the hookup:* Disconnect the cable from the generator output at the input connector of **CH 1**.

**Sensitivity, Edge Trigger,
DC Coupled**

Equipment required	One sine wave generator (Item 14) Two precision 50 Ω coaxial cables (Item 5) One 10X attenuator (Item 1) One BNC T connector (Item 7) One 5X attenuator (Item 2)
Prerequisites	See page 4–17.

1. Install the test hookup and preset the instrument controls:**a. Initialize the oscilloscope:**

- Press save/recall **SETUP**.
- Press the main-menu button **Recall Factory Setup**.
- Press the side-menu button **OK Confirm Factory Init**.

b. Modify the initialized front-panel control settings:

- Set the horizontal **SCALE** for the **M** (main) time base to 20 ns on the TDS 600C or 25 ns on the TDS 500D/700D/714L.
- Press **HORIZONTAL MENU**; then press the main-menu button **Time Base**.
- Press the side-menu button **Delayed Only**; then press the side-menu button **Delayed Triggerable**.
- Set the horizontal **SCALE** for the **D** (delayed) time base to 20 ns on the TDS 600C or 25 ns on the TDS 500D/700D/714L; then press the side-menu button **Main Only**.
- Press **TRIGGER MENU**; then press the main-menu button **Mode & Holdoff**. Press the side-menu button **Normal**.
- Press **VERTICAL MENU**; then press the main-menu button **Coupling**. Press the side-menu button Ω to select the 50 Ω setting. (This step is not required on the TDS694C TDS794D.)
- Press **SHIFT**; then press **ACQUIRE MENU**. Press the main-menu button **Mode**; then press the side-menu button **Average 16**.

c. Hook up the test-signal source:

- Connect the signal output of the generator to a BNC T connector. Connect one output of the T connector to **CH 1** through a 50 Ω precision coaxial cable. Connect the other output of the T connector to the **AUX TRIG INPUT** at the rear panel. See Figure 4–17.




Figure 4-17: Initial test hookup

2. Confirm Main and Delayed trigger systems are within sensitivity limits (50 MHz):

a. Display the test signal:

- Set the generator frequency to 50 MHz.
- Press **MEASURE**.
- Press the main-menu button **Level Setup**; then press the side-menu button **Min-Max**.
- Press the main-menu button **Select Measrmnt for Ch1**.
- Press the side-menu button **—more—** until **Amplitude** appears in the side menu (its icon is shown at the left). Press the side-menu button **Amplitude**.
- Press **SET LEVEL TO 50%**.
- Press **CLEAR MENU**.
- Set the test signal amplitude for about three and a half divisions on screen. Now fine adjust the generator output until the **CH 1 Amplitude** readout indicates the amplitude is 350 mV. Readout may fluctuate around 350 mV.
- Disconnect the 50 Ω precision coaxial cable at **CH 1** and reconnect it to **CH 1** through a 10X attenuator.



b. Check the Main trigger system for stable triggering at limits:

- Read the following definition: A stable trigger is one that is consistent; that is, one that results in a uniform, regular display triggered on the selected slope (positive or negative). This display should *not* have its trigger point switching between opposite slopes, nor should it roll across the screen. At horizontal scale settings of

2 ms/division and faster, **TRIG'D** will remain constantly lighted. It will flash for slower settings.

- Press **TRIGGER MENU**; then press the main-menu button **Slope**.
- Adjust the **TRIGGER LEVEL** knob so that there is a stable trigger. CHECK that the trigger is stable for the test waveform on the positive slope.
- Use the side menu to select the negative slope. Adjust the **TRIGGER LEVEL** knob so that there is a stable trigger. CHECK that the trigger is stable for the test waveform on the negative slope.
- Enter pass/fail result for main trigger on the test record.
- Leave the Main trigger system triggered on the positive slope of the waveform before continuing to the next step.




Figure 4-18: Measurement of trigger sensitivity – 50 MHz results shown on a TDS 684C screen

- c. *Check Delayed trigger system for stable triggering at limits:* Do the following subparts in the order listed.
 - Press **HORIZONTAL MENU**; then press the main-menu button **Time Base**. Press the side-menu button **Delayed Only**; then press **Delayed Triggerable** in the same menu.

- Press **SHIFT**; then press **DELAYED TRIG**. Press the main-menu button **Level**.
- Press the side-menu button **SET TO 50%**.

CHECK that a stable trigger is obtained for the test waveform for both the positive and negative slopes of the waveform. Use the **TRIGGER LEVEL** knob to stabilize the Main trigger. Use the general purpose knob to stabilize the Delayed trigger. Press the main-menu button **Slope**; then use the side menu to switch between trigger slopes. See Figure 4–18 on page 4–65.

- Enter pass/fail result for delayed trigger on the test record.
- Leave the Delayed trigger system triggered on the positive slope of the waveform before continuing to the next step. Also, return to the main time base: Press **HORIZONTAL MENU**; then press the main-menu button **Time Base**. Press the side-menu button **Main Only**.
- Press **CLEAR MENU**.

3. *Confirm the AUX Trigger input:*

a. *Display the test signal:*

- Remove the 10X attenuator and reconnect the cable to **CH 1**.
- Set the test signal amplitude for about 2.5 divisions on screen.
- Now fine adjust the generator output until the **CH 1 Amplitude** readout indicates the amplitude is 250 mV. (Readout may fluctuate around 250 mV).

b. *Check the AUX trigger source for stable triggering at limits: Do the following in the order listed.*

- Use the definition for stable trigger from step 2.
- Press **TRIGGER MENU**; then press the main-menu button **Source**.
- Press the side-menu button **–more–** until the side-menu label **DC Aux** appears; then press **DC Aux**.
- Press **SET LEVEL TO 50%**. CHECK that a stable trigger is obtained for the test waveform on both the positive and negative slopes. Press the main-menu button **Slope**; then use the side menu to switch between trigger slopes. Use the **TRIGGER LEVEL** knob to stabilize the trigger if required.
- Enter the pass/fail result on the test record.

- Leave the Main trigger system triggered on the positive slope of the waveform before proceeding to the next check.
 - Press the main-menu button **Source**; then press the side-menu button **—more—** until **CH 1** appears. Press **CH 1**.
4. *Confirm that the Main and Delayed trigger systems are within sensitivity limits (full bandwidth):*
- a. *Hook up the test-signal source:* Disconnect the hookup installed in step 1. Connect the signal output of a high-frequency sine wave generator to **CH 1**. Some TDS models need a high frequency (>500 MHz) generator; see footnotes 1 and 5 in Table 4–1 on page 4–18.
 - b. *Set the Main and Delayed Horizontal Scales:*
 - Set the horizontal **SCALE** to 500 ps for the **M** (Main) time base.
 - Press **HORIZONTAL MENU**. Now press the main-menu button **Time base**; then press the side-menu button **Delayed Triggerable**.
 - Press the side-menu button **Delayed Only**.
 - Set the horizontal **SCALE** to 500 ps for the **D** (Delayed) time base. Press the side-menu button **Main Only**.
 - c. *Display the test signal:*
 - Set the generator frequency to full bandwidth as follows:

TDS694C:	3 GHz
TDS794D:	2 GHz
TDS580D, TDS680C, TDS684C, & TDS784D:	1 GHz
TDS520D, TDS540D, TDS654C, TDS714L, TDS724D, & TDS754D:	500 MHz
 - Set the test signal amplitude for about five divisions on screen. Now fine adjust the generator output until the **CH 1 Amplitude** readout indicates the amplitude is 500 mV. (Readout may fluctuate around 500 mV). TDS694C only: Press the set level to 50% and check that a stable trigger is obtained.
 - Disconnect the leveling head at **CH 1** and reconnect it to **CH 1** through a 5X attenuator. Check that a stable trigger is obtained.
 - d. Repeat step 2, substeps **b** and **c** only, for the full bandwidth selected. TDS694C or TDS794D exception: Perform step 2, substep **c** (Delayed trigger) with the generator frequency set to **1.5 GHz**.

NOTE. You just checked the trigger sensitivity. If desired, you may repeat steps 1 through 4 for the other channels (CH2, CH3, and CH4).

5. *Disconnect the hookup:* Disconnect the cable from the channel last tested.

Output Signal Checks

The procedure that follows checks those characteristics of the output signals that are listed as checked under *Warranted Characteristics* in *Specifications*. The oscilloscope outputs these signals at its front and rear panels.

Check Outputs — CH 3 (AUX 1 on some models) Main and Delayed Trigger

Equipment required	Two precision 50 Ω coaxial cables (Item 5) One calibration generator (Item 10)
Prerequisites	See page 4–17. Also, the oscilloscope must have passed <i>Check DC Voltage Measurement Accuracy</i> on page 4–38. See <i>Input Channels versus Model</i> on page 4–2.

1. *Install the test hookup and preset the instrument controls:*




Figure 4–19: Initial test hookup

- a. *Hook up test-signal source 1 (See Figure 4–19):*
 - Connect the standard amplitude output of a calibration generator through a 50 Ω precision coaxial cable to **CH 3 (AUX1)** on some TDS models).
 - Set the output of the calibration generator to 0.500 V.
- b. *Hook up test-signal source 2:* Connect the **Main Trigger Out** at the rear panel to **CH 2** through a 50 Ω precision cable.

c. *Initialize the oscilloscope:*

- Press save/recall **SETUP**.
- Press the main-menu button **Recall Factory Setup**.
- Press the side-menu button **OK Confirm Factory Init**.

d. *Modify the initialized front-panel control settings:*

- Press **WAVEFORM OFF** to turn off CH 1.
- Press **CH 3 (AUX 1)** on some TDS models to display that channel.
- TDS694C only: Press trigger menu, select Ch 3 as trigger, set to 50%.
- If necessary, adjust the calibration generator output for 5 divisions of amplitude. (With the 50 Ω input of the TDS694C and TDS794D, you may need to double the output of the generator to get 5 divisions of amplitude.)
- Set the horizontal **SCALE** to 200 μ s.
- Press **SHIFT**; then press **ACQUIRE MENU**.
- Press the main-menu button **Mode**; then press the side-menu button **Average**.
- Select **64** averages. Do this with the keypad or the general purpose knob.

2. *Confirm Main and Delayed Trigger outputs are within limits for logic levels:*

a. *Display the test signal:*

- Press **WAVEFORM OFF** to turn off CH 3.
- Press **CH 2** to display that channel.
- Set the vertical **SCALE** to 1 V, 500 mV for TDS694C or TDS794D.
- Use the vertical **POSITION** knob to center the display on screen.

b. *Measure logic levels:*

- Press **MEASURE**; then press the main-menu button **Select Measurement for Ch2**.
- Select high and low measurements. To do this, repeatedly press the side-menu button **–more–** until **High** and **Low** appear in the side menu (their icons are shown at the left). Press both side-menu buttons **High** and **Low**.



c. Check Main Trigger output against limits: (Skip the first three subparts of this substep for the TDS694C and TDS794D only.)

- CHECK that the **Ch2 High** readout is ≥ 2.5 volts and that the **Ch2 Low** readout is ≤ 0.7 volts. See Figure 4–20.
- Enter high and low voltages on test record.
- Press **VERTICAL MENU**; then press the main-menu button **Coupling**. Now press the side-menu button Ω to toggle it to the 50 Ω setting.
- CHECK that the **Ch2 High** readout is ≥ 1.0 volt and that the **Ch2 Low** readout ≤ 0.25 volts.
- Enter high and low voltages on the test record.




Figure 4–20: Measurement of main trigger out limits

d. Check Delayed Trigger output against limits: See Figure 4–20.

- Move the precision 50 Ω cable from the rear-panel **Main Trigger Output** BNC to the rear-panel **Delayed Trigger Output** BNC.
- CHECK that the **Ch2 High** readout is ≥ 1.0 volt and that the **Ch2 Low** readout ≤ 0.25 volts.
- Enter high and low voltages on test record.

- Press the side-menu button **Ω** to select the 1 MΩ setting. (This step is not required on the TDS794D – proceed to step 3. TDS694C skip the following steps and proceed to step 4.)
 - Press **CLEAR MENU**.
 - CHECK that the **Ch2 High** readout is ≥ 2.5 volts and that the **Ch2 Low** readout is ≤ 0.7 volts.
 - Enter high and low voltages on test record.
3. *Confirm CH 3 (AUX 1 on some TDS models except TDS694C) output is within limits for gain:*
- a. *Measure gain:*
- Move the precision 50 Ω cable from the rear-panel **DELAYED TRIGGER OUTPUT** BNC to the rear-panel **CH 3/AUX 1** BNC (**SIGNAL OUT** on some models).
 - Push **TRIGGER MENU**.
 - Press the main-menu button **Source**.
 - Press the side-menu button **Ch3**. (**Ax1** on some TDS models)
 - Set vertical **SCALE** to 100 mV.
 - Press **SET LEVEL TO 50%**.
 - Press **MEASURE**; then press the main-menu button **Select Measrmnt for Ch2**.
 - Repeatedly press the side-menu button **–more–** until **Pk-Pk** appears in the side menu (its icon is shown at the left). Press the side-menu button **Pk-Pk**.
 - Press **CLEAR MENU**.
- b. *Check against limits: (Skip the first four subparts of this substep for the TDS 794D only.)*
- CHECK that the readout **Ch2 Pk-Pk** is between 80 mV and 120 mV, inclusive, for the TDS 600C or is between 88 mV and 132 mV, inclusive, for the TDS 500D/700D/714L.
 - Enter voltage on test record.
 - Press **VERTICAL MENU**; then press the side-menu button **Ω** to toggle to the 50 Ω setting.
 - Press **CLEAR MENU**.



- CHECK that the readout **Ch2 Pk-Pk** is between 40 mV and 60 mV, inclusive, for the TDS 600C or is between 44 mV and 66 mV, inclusive, for the TDS 500D/700D/714L.
 - Enter voltage on test record.
4. *Disconnect the hookup:* Disconnect the cables from the channel inputs and the rear panel outputs.

Check Probe Compensator Output

Equipment required	One female BNC to clip adapter (Item 3) Two dual-banana connectors (Item 6) One BNC T connector (Item 7) Two precision 50 Ω coaxial cables (Item 5) One DC calibration generator (Item 9)
Prerequisites	See page 4–17. Also, the oscilloscope must have passed <i>Check Accuracy For Long-Term Sample Rate, Delay Time, and Delta Time Measurement</i> on page 4–56.

1. *Install the test hookup and preset the instrument controls:*
- a. *Hook up test-signal:*
- Connect one of the 50 Ω cables to **CH 1**. See Figure 4–21.
 - Connect the other end of the cable just installed to the female BNC-to-clips adapter. See Figure 4–21.
 - Connect the red clip on the adapter just installed to the **PROBE COMPENSATION SIGNAL** on the front panel; connect the black clip to **PROBE COMPENSATION GND**. See Figure 4–21.




Figure 4–21: Initial test hookup

b. *Initialize the oscilloscope:*

- Press save/recall **SETUP**.
- Press the main-menu button **Recall Factory Setup**.
- Press the side-menu button **OK Confirm Factory Init**.

c. *Modify the initialized front-panel control settings:*

- Set the horizontal **SCALE** to 200 μ s.
- Press **SET LEVEL TO 50%**.
- Use the vertical **POSITION** knob to center the display on screen.
- Press **SHIFT**; then press **ACQUIRE MENU**.
- Press the main-menu button **Mode**; then press the side-menu button **Average**.
- Select **128** averages with the keypad or the general purpose knob.

2. *Confirm that the Probe Compensator signal is within limits for frequency:*a. *Measure the frequency of the probe compensation signal:*

- Press **MEASURE**; then press the main-menu button **Select Measrmnt for Ch1**.
- Repeatedly press the side-menu button **–more–** until **Frequency** appears in the side menu (its icon is shown at the left). Press the side-menu button **Frequency**.

b. *Check against limits:*

- CHECK that the **CH 1 Freq** readout is within 950 Hz to 1.050 kHz, inclusive. See Figure 4-22.
- Enter frequency on test record.
- Press **MEASURE**; then press the main-menu button **Remove Measrmnt**. Press the side-menu **Measurement 1**.




Figure 4-22: Measurement of probe compensator frequency

c. *Save the probe compensation signal in reference memory:*

- Press save/recall **WAVEFORM**; then press the main-menu button **Save Wfm Ch 1**.
- Press the side-menu button **To Ref 1** to save the probe compensation signal in reference 1.
- Disconnect the cable from **CH 1** and the clips from the probe compensation terminals.
- Press **MORE**; then press the main-menu button **Ref 1** to displayed the stored signal.
- Press **CH 1**.

d. *Hook up the DC standard source:*

- Set the output of a DC calibration generator to off or 0 volts.
- Connect the output of a DC calibration generator through a dual-banana connector followed by a 50 Ω precision coaxial cable to one side of a BNC T connector. See Figure 4–23.
- Connect the Sense output of the generator through a second dual-banana connector followed by a 50 Ω precision coaxial cable to the other side of the BNC T connector. Now connect the BNC T connector to **CH 1**. See Figure 4–23.




Figure 4–23: Subsequent test hookup

- e. *Measure amplitude of the probe compensation signal:*
 - Press **SHIFT**; then press **ACQUIRE MENU**. Press the side-menu button **AVERAGE** then enter 16 using the keypad or the general purpose knob.
 - Adjust the output of the DC calibration generator until it precisely overlaps the top (upper) level of the stored probe compensation signal. (This value will be near 500 mV).
 - Record the setting of the DC generator.
 - Adjust the output of the DC calibration generator until it precisely overlaps the base (lower) level of the stored probe compensation signal. (This value will be near zero volts).
 - Record the setting of the DC generator.
- f. Press **CLEAR MENU** to remove the menus from the display. See Figure 4–24.




Figure 4-24: Measurement of probe compensator amplitude

g. *Check against limits:*

- Subtract the value just obtained (base level) from that obtained previously (top level).
- CHECK that the difference obtained is within 495 mV to 505 mV, inclusive.
- Enter voltage difference on test record.

3. *Disconnect the hookup:* Disconnect the cable from **CH 1**.

Option 05 Video Trigger Checks (Not Available on TDS694C or TDS794D)

Check Video Trigger	Equipment required PAL signal source (Item 21) 60 Hz sine wave generator (Item 22) Pulse generator (Item 23) Two 75 Ω cables (Item 24) Two 75 Ω terminators (Item 25) One BNC T connector (Item 7) One precision 50 Ω coaxial cable (Item 5) 50 Ω terminator (Item 4)
	Prerequisites See page 4–17. These prerequisites include running the signal path compensation routine.

1. *Set up the oscilloscope to factory defaults by completing the following steps:*

- a. Press save/recall **SETUP**.
- b. Press the main-menu **Recall Factory Setup**.
- c. Press the side-menu **OK Confirm Factory Init**.
- d. Wait for the Clock Icon to leave the screen.
- e. CONFIRM the oscilloscope is setup as shown below.

Channel: CH1

Volt/div: 100 mV

Horizontal scale: 500 μ s/div

2. *Set up the oscilloscope for TV triggers by completing the following steps:*

- a. Press **TRIGGER MENU**.
- b. Press the main-menu **Type** pop-up until you select **Video**.
- c. Press the main-menu **Standard** pop-up until you select **625/PAL**.
- d. Press the main-menu **Line**.
- e. Use the keypad to set the line number to 7 (press 7, then **ENTER**).
- f. Press **VERTICAL MENU**.
- g. Press the main-menu **Bandwidth**.

- h.** Select **250 MHz** from the side menu.
 - i.** Press the main-menu **Fine Scale**.
 - j.** Press **HORIZONTAL MENU**.
 - k.** Press the main-menu **Horiz Scale**.
 - l.** Use the keypad to set the horizontal scale to 200 ns (press **200**, **SHIFT**, **n**, then **ENTER**).
 - m.** Use the Vertical Position knob to center the waveform on screen.
- 3. Check Jitter vs. Signal Amplitude**
- a.** Set up equipment for Jitter Test. See Figure 4–25.
 - Connect one of the rear panel composite outputs marked **COMPST** on the TSG121 through a 75 Ω cable and a 75 Ω terminator to the CH1 input of the oscilloscope.
 - Press the **100% FIELD** control (the fourth TSG121 front-panel button from the left) of the PAL signal source.




Figure 4-25: Jitter test hookup

- b.** CHECK that the oscilloscope lights up its front panel **TRIG'D** LED and it displays the waveform on screen. See Figure 4–26.




Figure 4-26: Jitter test displayed waveform – TDS 754D shown

- c. Press **SHIFT**; then press **ACQUIRE MENU**.
 - d. Press the main-menu **Mode**.
 - e. Press the side-menu **Envelope**.
 - f. Use the keypad to set envelope to use 100 acquisitions (press **100**, then **ENTER**).
 - g. Press the main-menu **Stop After** button.
 - h. Press the side-menu **Single Acquisition Sequence**.
 - i. Wait for the word **Run** in the top left corner of the display to change to **STOP**.
4. *Perform Check Trigger Jitter.*
- Set up Oscilloscope for the Trigger Jitter Test.
- a. Press **DISPLAY**.
 - b. Press the main-menu **Format/RO**.
 - c. Press the side-menu **Display 'T' @ Trigger Point** until you select **OFF**.
 - d. Press **CURSOR**.

- e. Press the side-menu **V-Bars**.
- f. Use the general purpose knob to move the left cursor to the right until the @ measurement reads -32 ns.
- g. Press **SELECT**.
- h. Use the General Purpose knob to adjust the right cursor until the delta measurement reads 60 ns.
- i. CONFIRM that the width of the falling edge of the trace (at the center crossings) falls between the cursors. See Figure 4–27.
- j. Press **DISPLAY**.
- k. Press the main-menu **Format/RO**.
- l. Press the side–menu **Display ‘T’ @ Trigger Point** until you select **ON**.




Figure 4-27: Jitter test when completed – TDS 754D shown

5. *Check Triggered Signal Range.*

Set up oscilloscope for Triggered Signal Test.

- a. Press **MORE**.
- b. Press **WAVEFORM OFF**.

- c. Press **HORIZONTAL MENU**.
- d. Use the keypad to set horizontal scale (/div) to 50 μ s (press **50**, **SHIFT**, **μ** , then **ENTER**).
- e. Press **SHIFT**; then press **ACQUIRE MENU**.
- f. Press the main-menu **Stop After**.
- g. Press the side-menu **RUN/STOP button only**.
- h. Press the main-menu **Mode**.
- i. Press the side-menu **Sample**.
- j. Press **RUN/STOP**.
- k. Press **VERTICAL MENU**.
- l. Use the keypad to set fine scale to 300 mV (press **300**, **SHIFT**, **m**, then **ENTER**).
- m. CONFIRM that the **TRIG'D** LED stays lighted and that the waveform on screen is stable. Also, CONFIRM that the waveform on the screen has one positive pulse and a number of negative pulses. See Figure 4–28.




Figure 4–28: Triggered signal range test – 300 mV

- n. Use the keypad to set the fine scale to 75 mV (press **75**, **SHIFT**, **m**, then **ENTER**).
- o. CONFIRM that the **TRIG'D** LED stays lighted and that the waveform on screen is stable. That is, it does not move horizontally or vertically. Also, CONFIRM that the waveform on the screen has one positive pulse and a number of negative pulses. See Figure 4-29.




Figure 4-29: Triggered signal range test – 75 mV

- p. Disconnect all test equipment (TSG121) from the oscilloscope.
6. Check 60 Hz Rejection.
- a. Set up oscilloscope for 60 Hz Rejection Test:
 - Use the keypad to set the Ch1 Fine Scale to 282 mV (press **282**, **SHIFT**, **m**, then **ENTER**).
 - Press **WAVEFORM OFF**.
 - Press **CH2**.
 - Press **VERTICAL MENU**.
 - Use the keypad set the fine scale to 2 V (press **2**, then **ENTER**).
 - Press **HORIZONTAL MENU**.

- Use the keypad to set the horizontal scale (/div) to 5 ms (press 5, **SHIFT**, **m**, then **ENTER**).
- b. *Set up 60 Hz signal generator:*
- Connect the output of the signal generator to the CH2 input through a 50 Ω cable. See Figure 4–30.




Figure 4–30: 60 Hz Rejection test hookup

- Adjust the signal generator for three vertical divisions of 60 Hz signal. See Figure 4–31. The signal will not be triggered. That is, it will run free.




Figure 4–31: 60 Hz Rejection test setup signal

c. Check 60 Hz rejection:

- Use the keypad to set the horizontal scale (/div) to 50 μ s (press **50**, **SHIFT**, **μ** , then **ENTER**).
- Reconnect the output of the signal generator. Connect the composite signal connector of the PAL signal source (labeled **COMPST** on the TSG 121) to a 75 Ω cable and a 75 Ω terminator. Connect both signals to the CH1 input through a BNC T. See Figure 4–32.
- Press **VERTICAL MENU**.
- If needed, press the main-menu **Fine Scale**.
- Use the keypad to set fine scale to 500 mV (press **500**, **SHIFT**, **m**, then **ENTER**).
- Connect another composite signal connector of the PAL signal source (labeled **COMPST** on the TSG 121) through a 75 Ω cable and a 75 Ω terminator to the CH2 input. See Figure 4–32.




Figure 4–32: Subsequent 60 Hz Rejection test hookup

- CONFIRM that the **TRIG'D** LED stays lighted and that the waveform on screen is stable. In other words, be sure the waveform does not move horizontally or vertically. Also, confirm that the waveform on the screen has one positive pulse and a number of negative pulses. See Figure 4–33.
- Disconnect all test equipment from the oscilloscope.




Figure 4-33: 60 Hz Rejection test result – TDS 684C shown

7. *Check Line Count Accuracy.*

a. *Set up oscilloscope for Line Count Accuracy Test:*

- Press **WAVEFORM OFF**.
- Press **CH1**.
- Press **HORIZONTAL MENU**.
- Press the main-menu **Record Length**.
- Press the side-menu **—more—** until you see the appropriate menu.
- Press the side-menu **5000 points in 100divs**.
- Press the main-menu **Horiz Scale (/div)**.
- Use the keypad to set the horizontal scale to 200 ns (press **200**, **SHIFT**, **n**, then **ENTER**).

b. *Check Line Count Accuracy:*

- Connect a composite output signal from the rear of the PAL signal source (labeled **COMPST** on the TSG 121) to the CH1 input through a 75 Ω cable and a 75 Ω terminator. See Figure 4-34.




Figure 4-34: Line count accuracy test hookup

- Press the main-menu **Trigger Position**.
- Press the side-menu to **Set to 50%**.
- Press the main-menu to **Horiz Pos**.
- Press the side-menu to **Set to 50%**.
- Use the **HORIZONTAL POSITION** knob to move the falling edge of the sync pulse to two divisions to the left of center screen. See Figure 4-35.




Figure 4-35: Line count accuracy test setup waveform – TDS 684C shown

- Press **CURSOR**.
- Press the main-menu **Function**.
- Press the side-menu **V Bars**.
- Using the General Purpose knob, place the left cursor directly over the trigger 'T' icon.
- Press **SELECT**.
- Turn the General Purpose knob to adjust the right cursor for a cursor delta reading of **6.780us**.
- Use the **HORIZONTAL POSITION** knob to position the right cursor to center screen.
- Verify that the cursor is positioned on a positive slope of the burst signal. See Figure 4-36.




Figure 4-36: Line count accuracy correct result waveform

- Disconnect all test equipment (TSG 121) from the oscilloscope.
- Turn off cursors by pressing **CURSOR**, then the main-menu **Function** button, and, finally, **Off** from the side menu.

8. *Check the Sync Duty Cycle.*

a. *Set up oscilloscope for Sync Duty Cycle Test:*

- Press **TRIGGER MENU**.
- Press the **Standard** pop-up to select **FlexFmt**. Trigger **Type** should already be set to **Video**.
- Press the main-menu **Setup**.
- Press the side-menu **Field Rate**.
- Use the keypad to set the field rate to 60.05 Hz (press **60.05**, then **ENTER**).
- Press the side-menu **Lines**.
- Use the keypad to set the field rate to 793 lines (press **793**, then **ENTER**).
- Press the side-menu **Fields**.

- Use the keypad to set the number of fields to 1 (press **1**, then **ENTER**).
 - Press the side-menu **Sync Width**.
 - Use the keypad to set the width to 400 ns (press **400**, **SHIFT**, **n**, then **ENTER**).
 - Press the side-menu **—more— 1 of 2**. Then press **V1 Start Time**.
 - Use the keypad to set V1 start time to 10.10 μ s (press **10.10**, **SHIFT**, **μ** , then **ENTER**).
 - Press the side-menu **V1 Stop Time**.
 - Use the keypad to set V1 stop time to 10.50 μ s (press **10.50**, **SHIFT**, **μ** , then **ENTER**).
 - Press the main-menu **Type** pop-up to select **Edge**.
 - Press **HORIZONTAL MENU**.
 - Press the main-menu **Record Length**.
 - Select the side-menu **1000 points in 20div**. If needed, first press the side-menu **—more—** until you see the appropriate side-menu item.
 - Turn the **HORIZONTAL POSITION** knob to position the trigger 'T' two divisions to the left of the center screen.
 - Press **MEASURE**.
 - If needed, press the main-menu **Select Measrmnt**.
 - Press the side-menu **Negative Width**.
 - Press the side-menu **Period**.
- b. *Set up the pulse generator for Sync Duty Cycle Test:*
- Set **PULSE DURATION** to 50 ns.
 - Set **PERIOD** to 10 μ s.
 - Set **OUTPUT (VOLTS)** to **–1** for **LOW LEVEL** and **+1** for **HIGH LEVEL**.
 - Depress the **COMPLEMENT** button.
 - Be sure **BACK TERM** is depressed (in).

c. *Check Sync Duty Cycle:*

- Connect the pulse generator through a 50 Ω cable and a 50 Ω terminator to the oscilloscope CH1 input. See Figure 4–37.




Figure 4–37: Setup for sync duty cycle test

- Turn the pulse generator **OUTPUT (VOLTS)** control until the signal on the oscilloscope shows a one division negative-going pulse. See Figure 4–38.

NOTE. *You may need to adjust the trigger level control to obtain a stable trigger.*




Figure 4-38: Sync duty cycle test: one-div neg pulse waveform

- Turn the pulse generator **PULSE DURATION** variable control to adjust the negative pulse so the oscilloscope's **CH1 - Width** measurement displays **400ns +/-10 ns**.
- Turn the **HORIZONTAL SCALE** knob to set the oscilloscope time base to **5 μ s/div**.
- Turn the pulse generator **PERIOD** variable control to adjust the period until the oscilloscope **CH1 Period** measurement reads **21.000 μ s -25/+50 ns**. See Figure 4-39. Read note shown below.

NOTE. The pulse duration and period adjustments are critical in making this measurement. If the pulse duration and/or the duty cycle are not stable, the **FLEXFMT** function may not function. You must take care when making these adjustments.




Figure 4-39: Sync duty cycle test: critically adjusted pulse

- Press **TRIGGER MENU**.
- Press the main-menu **Type** pop-up until you select **Video**.

If the **TRIG'D** LED is not lighted, check that the **CH1 – Width** and **CH1 Period** measurements are adjusted correctly. See note above. CONFIRM that the setup is correct and the oscilloscope will trigger.

- CONFIRM that the **TRIG'D** LED is lighted and the waveform is stable.
- Disconnect the signal source from CH1, wait a few seconds, then reconnect the signal.
- CONFIRM that the **TRIG'D** LED is lighted and the waveform is stable.
- Press **Sync Polarity**.
- Press **Pos Sync**.
- Push the pulse generator **COMPLEMENT** button out.
- CONFIRM that the **TRIG'D** LED is lighted and the waveform is stable.

- Disconnect the signal source from CH1, wait a few seconds, then reconnect the signal.
- CONFIRM that the **TRIG'D** LED is lighted and the waveform is stable.
- Disconnect all test equipment from the oscilloscope.
- Press save/recall **SETUP**, the main-menu button **Recall Factory Setup**, and the side-menu **OK Confirm Factory Init**.

Sine Wave Generator Leveling Procedure

Some procedures in this manual require a sine wave generator to produce the necessary test signals. If you do not have a leveled sine wave generator, use one of the following procedures to level the output amplitude of your sine wave generator.

Equipment required	Sine wave generator (Item 14)
	Level meter and power sensor (Item 15)
	Power divider (Item 16)
	Two male N to female BNC adapters (Item 17)
	One precision coaxial cable (Item 5)
Prerequisites	See page 4-17




Figure 4-40: Sine wave generator leveling equipment setup

1. *Install the test hookup:* Connect the equipment as shown in Figure 4-40.
2. *Set the Generator:*
 - Set the sine wave generator to a reference frequency of 10 MHz.

- Adjust the sine wave generator amplitude to the required number of divisions as measured by the oscilloscope.
3. *Record the reference level:* Note the reading on the level meter.
 4. *Set the generator to the new frequency and reference level:*
 - Change the sine wave generator to the desired new frequency.
 - Input the correction factor and/or the new frequency into the level meter.
 - Adjust the sine wave generator amplitude until the level meter again reads the value noted in step 3. The signal amplitude is now correctly set for the new frequency.

Equipment required	Sine wave generator (Item 14) Level meter and power sensor (Item 15) Two male N to female BNC adapters (Item 17) Two precision coaxial cables (Item 5)
Prerequisites	See page 4-17

1. *Install the test hookup:* Connect the equipment as shown in Figure 4-41 (start with the sine wave generator connected to the oscilloscope).




Figure 4-41: Equipment setup for maximum amplitude

2. Set the Generator:

- Set the sine wave generator to a reference frequency of 10 MHz.
- Adjust the sine wave generator amplitude to the required number of divisions as measured by the oscilloscope.

3. Record the reference level:

- Disconnect the sine wave generator from the oscilloscope.
- Connect the sine wave generator to the power sensor.
- Note the level meter reading.

4. Set the generator to the new frequency and reference level:

- Change the sine wave generator to the desired new frequency.
- Input the correction factor and/or the new frequency into the level meter.
- Adjust the sine wave generator amplitude until the level meter again reads the value noted in step 3. The signal amplitude is now correctly set for the new frequency.
- Disconnect the sine wave generator from the power sensor.
- Connect the sine wave generator to the oscilloscope.

Optical Filter Checks (Options 2C, 3C & 4C Only)

The procedure that follows verifies that the frequency response of the combined P670xB and TDS500D/700D oscilloscope system is a Fourth Order Bessel Thompson Filter which is within limits.

Filter Availability

Nominal Filters are available with Option 2C. Reference Receiver Filters are available with Options 3C and 4C. Options 3C and 4C are not available without 2C, and 3C and 4C are not available on the TDS 794D.

You can verify Option 2C is enabled on the TDS 794D by pressing **MEASURE**, then selecting **Masks** from the Measure pop-up menu. Table 4–7 lists the available vertical scale factors for each option. Tables 4–8, 4–9, and 4–10 list the available filters and their specifications.

Table 4–7: Available filters

Nominal Filters (Option 2C)	Reference Receivers Filters (Options 3C, 4C)
1 μ W per division	
2 μ W per division	
5 μ W per division	
10 μ W per division	10 μ W per division
20 μ W per division	20 μ W per division
50 μ W per division	50 μ W per division
100 μ W per division	
200 μ W per division	
500 μ W per division	
1 mW per division	

Table 4–8: Reference receiver filter options

Option 4C – SONET (P6703B 1300nm)	Option 3C – Fibre Channel (P6701B 850nm)
52Mbit OC1	FC133Mbit
	FC266Mbit
	FC531Mbit
155Mbit OC3	155Mbit OC3
622Mbit OC12	622Mbit OC12
FC1063 (TDS 784D Only)	FC1063 (TDS 784D Only)

Table 4–9: Option 3C and 4C specifications

Name	Description
Calibration Range, Reference Receiver	10 μ W per division 20 μ W per division 50 μ W per division
Temperature Range, Warranted Filter	23° C, $\pm$ 5° C
Calibration Range, Controlled	Up to 2X the data rate for all filters except FC1063 filter Up to 1.5X the data rate for FC1063 filter

Table 4–10: Available receivers

	Option 4C ¹				Option 3C ²					
	OC1 ⁴	OC3	OC12	FC1063 ³	FC133	FC266	FC531	FC1063 ³	OC3	OC12
TDS 520D	✓	✓			✓				✓	
TDS 540D	✓	✓	✓		✓	✓	✓		✓	✓
TDS 580D	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
TDS 724D	✓	✓			✓				✓	
TDS 754D	✓	✓	✓		✓	✓	✓		✓	✓
TDS 784D	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

¹ Requires Tektronix P6703B, 1300 nm Optical to Electrical Converter.


² Requires Tektronix P6701B, 850 nm Optical to Electrical Converter.

³ Reference receivers are warranted to 2.0 times the bit rate except for FC1063 which is warranted to 1.5 times the bit rate.

⁴ OC1 is type tested

**Reference Receiver
Verification**

Equipment required	OIG501 (use with P6701B) (Item 26) OIG502 (use with P6703B) (Item 27) Optical Attenuator OA5022 (Item 34) Fiber Optic Cable (Item 35) Optical-to-Electrical Converter (item 36)
Prerequisites	See page 4–17. Also, the probe and the oscilloscope channel it is attached to must have been calibrated as a reference receiver.

1. Install the test hookup and preset the instrument controls:**Figure 4–42: Reference-receiver performance-verification set up****a. Initialize the oscilloscope:**

- Press **SAVE/RECALL SETUP**.
- Press the main-menu button **Recall Factory Setup**.
- Press the side-menu button **OK Confirm Factory Init**.

b. Connect the probe, oscilloscope, optical impulse generator (OIG), and the optical attenuator:

- Connect the optical probe to CH 1 of the oscilloscope under test (see Figure 4–42).
- See Table 4–10. If using a P6701B probe, connect the OIG501 (Item 26) OPTICAL OUTPUT to the optical attenuator (Item 34) OPTICAL INPUT using a fiber-optic cable (Item 35). If using a P6703B probe, connect the OIG502 (Item 27) OPTICAL OUTPUT to the optical attenuator (Item 34) OPTICAL INPUT using a fiber-optic cable (Item 35).

- Connect the optical probe on CH 1 of the oscilloscope to the OPTICAL OUTPUT of the optical attenuator using the fiber-optic cable of the probe. Set an optical impulse level that does not clip the vertical channel of the oscilloscope.
- c. Set up the OIG to run with LOW impulse energy.
 - Keep the impulse below 100 μ W peak level because high-energy impulses into the P670x probe will cause major changes in the frequency response of the probe.
 - Set the OIG for 1 MHz internal trigger.
 - Set the OIG for the wavelength shown in Table 4–10 that is required for the standard and option you are verifying.
- d. Enable the laser.
- e. Set the VERTICAL SCALE of the oscilloscope to either 10 μ W, 20 μ W or 50 μ W/division.

NOTE. These are the only scale settings for which the reference receivers have calibrated filters.

- f. *Set the trigger type to edge:*
 - Press **TRIGGER MENU**; then select **Edge** from the Type pop-up menu.
 - Press **SET LEVEL TO 50%**.
- g. Set the HORIZONTAL SCALE to 500 ps.
- h. Set the Optical Attenuator for several divisions of display on the oscilloscope.
- i. *Set the horizontal controls:*
 - Press **HORIZONTAL MENU**; then press the main-menu button **Record Length**. If Fit To Screen is not OFF, press **Fit to Screen** to toggle it to the **OFF** setting. Fit to Screen needs to be OFF so that the FFT waveform horizontal scale can be adjusted to obtain the desired display of the frequency response.
 - To obtain a 10000 point FFT in step 3, press **HORIZONTAL MENU**; then press the main-menu button **Record Length**. Then repeatedly press the side-menu button **–more–** until **15000** appears in the side menu. Press the side-menu button **15000**.

- Press **HORIZONTAL MENU**; then press the main-menu button **Trigger Position**. Set the Trigger Position to **20%** using the general purpose knob or keypad.

NOTE. Press **SHIFT** to change the horizontal position speed. The position moves faster when **SHIFT** is lighted.

- Adjust the **HORIZONTAL POSITION** to move the 20% trigger point onto the display (see Figure 4–43).




Figure 4–43: Optical impulse of Ch1 input from OA5022 Optical Attenuator (OIG501 / OIG502 fed into optical attenuator in Step 1)

j. *Select linear interpolation:*

- If **SHIFT** is lighted, press **SHIFT**.
- Press **DISPLAY**; then press the main-menu button **Filter**.
- Press the side-menu button **Linear Interpolation**.

2. *Select the desired Mask standard and turn it on:*

- Press **MEASURE**; then select **Masks** from the Measure pop-up menu.

NOTE. <xxx> is the standard that you are verifying (such as OC1, OC3, OC12, FC1063; see Table 4–11 on page 4–106).

- From the Mask Type pop-up menu, select the mask type (<xxx>) of your reference receiver.
- Press the **Standard Mask** main menu; then select your reference receiver mask (<xxx>) from the side menu.

NOTE. For the Bessel Thompson (BT) filter to be active, the VERTICAL MENU deskew must be set to zero on all four channels. Also, the ACQUIRE MENU Acquisition Mode must be Sample. If you did the Factory Setup specified in Step 1a, you selected these modes.

- If checking a reference receiver, verify that RR is displayed to the right of the vertical scale factor (see Figure 4–44 on page 4–104).
 - Press **TRIGGER MENU**; then select **Edge** from the Type pop-up menu.
3. Turn on an FFT of the optical impulse [the Impulse Response (or Frequency Response) of the P670xB and oscilloscope system] (Refer to Figure 4–45 on page 4–105):
- a. Press the front panel **MORE** button; then press the main-menu button **Math2**. This turns on a math waveform.
 - b. If the math waveform is not set to FFT, create an FFT waveform:
 - Press **Change Math waveform definition**; then press the main-menu button **FFT**.
 - Press the side-menu button **Set FFT source to Ch1**.

NOTE. Verify the FFT window is set to Rectangular. Also verify the FFT Vert Scale is set to dBV RMS. If you did the Factory Setup in Step 1a, you selected these modes.

- Press the side-menu button **OK Create Math Waveform**.
- Press the side menu button **Average**, then set the number of averages to **16** using the general purpose knob or keypad.

4. Move the beginning of the FFT data record onto the screen:

NOTE. Press **SHIFT** to change the horizontal position speed. The position moves faster when **SHIFT** is lighted.

- Adjust the **HORIZONTAL POSITION** control to move the beginning of the FFT data record onto the display.

NOTE. Expanding the horizontal scale of the FFT waveform gives greater resolution when making cursor measurements. Expand the FFT to display DC to the highest frequency listed in Table 4–11 for the standard being verified.

- Adjust the **HORIZONTAL SCALE** and **VERTICAL SCALE** to view the frequency response of the BT filter. The large spike around DC is due to DC offset in the signal and should be ignored.
5. Observe the desired response characteristics using the vertical paired cursors (see figures 4–44 and 4–45):
- a. Press **CURSOR**.
 - b. Press the main-menu button **Function**; then press the side-menu button **Paired**.
 - c. Press **CLEAR MENU**.

NOTE. Pressing **SHIFT** will change cursor speed. Use the select key to alternate between cursors.

- d. Position one cursor at the beginning of the FFT record.
- e. Position the other cursor at the bit rate (the frequency closest to the bit rate) of the mask that is turned on (see Table 4–11 and Figure 4–44).




Figure 4-44: Optical impulse response for OC-12 SONET Reference Receiver

NOTE. In Figure 4-44, the left cursor is at the DC frequency. The right cursor is at the OC-12 data rate of 622 MHz $\pm$ 4 MHz. Also, note that the reference receiver, RR, designation is beside the 20 μ W vertical scale factor.

- f. Next, move the cursor currently positioned at the beginning of the record until the cursor is just right of the DC spike in the response (see Figure 4-45 on page 4-105). The unsigned Δ dB readout should be at or between the upper and lower limits shown in Table 4-11 on page 4-106 (note that the entries in the table are signed numbers, but the Δ dB readout is not) for the mask that is turned on.




Figure 4-45: Optical impulse response for OC-12 SONET Reference Receiver

NOTE. In Figure 4-45 the left cursor has been moved to the zero dB level. The right cursor remains at the OC-12 data rate of 622 MHz $\pm$ 4 MHz (the delta frequency is 584 MHz because the right cursor is no longer referenced to DC). The delta attenuation from the zero dB level to the 622 MHz Cursor is 5.6 dB.

6. Repeat steps 5d through 5f, starting on page 4-103, moving the second cursor to twice the bit rate (1.5 times the bit rate for the FC1063 standard).
7. For an exhaustive test of the reference receiver, repeat steps 5d through 5f for each frequency shown in Table 4-11 on page 4-106 for the standard.
8. If verifying additional standards, repeat this procedure for each standard.

Table 4–11: Bessel Thompson frequency response and reference receiver limits

Standard	Frequency (MHz)	Lower Limit (dB)	Nominal (dB)	Upper Limit (dB)	Measured (delta dB)
OC–12 SONET or STM–4 SDH, Data Rate: 622.08 Mb/s					
	0.0	–0.3	0.0	0.3	
	93.31	–0.41	–0.11	0.19	
	186.6	–0.75	–0.45	–0.15	
	279.9	–1.32	–1.02	–0.72	
	373.2	–2.16	–1.86	–1.56	
	466.7	–3.31	–3.00	–2.71	
	5.60.0	–5.15	–4.51	–3.87	
	622.08	–6.58	–5.71	–4.84	
	653.2	–7.35	–6.37	–5.39	
	746.5	–9.86	–8.54	–7.22	
	839.8	–12.59	–10.93	–9.27	
	933.1	–15.41	–13.41	–11.41	
	1244.2	–24.58	–21.44	–18.31	
OC–3 SONET or STM–1 SDH, Data Rate: 155.52 Mb/s					
	0.0	–0.3	–0.0	0.3	
	23.327	–0.41	–0.11	0.19	
	46.65	–0.75	–0.45	–0.15	
	69.975	–1.32	–1.02	–0.72	
	93.3	–2.16	–1.86	–1.56	
	116.88	–3.31	–3.00	–2.71	
	139.97	–5.15	–4.51	–3.87	
	155.52	–6.58	–5.71	–4.84	
	163.3	–7.35	–6.37	–5.39	
	209.95	–9.86	–8.54	–7.22	
	209.95	–12.59	–10.93	–9.27	
	233.27	–15.41	–13.41	–11.41	
	311.04	–24.58	–21.44	–18.31	

Table 4–11: Bessel Thompson frequency response and reference receiver limits (cont.)

Standard	Frequency (MHz)	Lower Limit (dB)	Nominal (dB)	Upper Limit (dB)	Measured (delta dB)
FC133 Fibre Channel, Data Rate: 132.8125 Mb/s					
	0.00	–0.5	0.0	0.5	
	19.922	–0.6	–0.1	0.4	
	38.440	–0.9	–0.4	–0.1	
	59.765	–1.5	–1.0	–0.5	
	79.690	–2.4	–1.9	–1.4	
	99.610	–3.5	–3.0	–2.5	
	119.53	–5.5	–4.5	–3.5	
	132.81	–7.03	–5.7	–4.37	
	139.45	–7.9	–6.4	–4.9	
	159.37	–10.5	–8.5	–6.5	
	179.29	–13.4	–10.9	–8.4	
	199.22	–16.4	–13.4	–10.4	
	265.62	–26.17	–21.5	–16.5	
FC266 Fibre Channel, Data Rate: 265.625 Mb/s					
	0.0	–0.5	0.0	0.5	
	39.844	–0.6	–0.1	0.4	
	79.688	–0.9	–0.4	–0.1	
	119.53	–1.5	–1.0	–0.5	
	159.38	–2.4	–1.9	–1.4	
	199.22	–3.5	–3.0	–2.5	
	239.06	–5.5	–4.5	–3.5	
	265.62	–7.03	–5.7	–4.37	
	278.91	–7.9	–6.4	–4.9	
	318.75	–10.5	–8.5	–6.5	
	358.59	–13.4	–10.9	–8.4	
	398.44	–16.4	–13.4	–10.4	
	531.25	–26.17	–21.5	–16.5	

Table 4–11: Bessel Thompson frequency response and reference receiver limits (cont.)

Standard	Frequency (MHz)	Lower Limit (dB)	Nominal (dB)	Upper Limit (dB)	Measured (delta dB)
FC531 Fibre Channel, Data Rate: 531.25 Mb/s					
	0.0	–0.5	–0.0	0.5	
	79.688	–0.6	–0.1	0.4	
	159.38	–0.9	–0.4	–0.1	
	239.06	–1.5	–1.0	–0.5	
	318.76	–2.4	–1.9	–1.4	
	398.44	–3.5	–3.0	–2.5	
	478.12	–5.5	–4.5	–3.5	
	531.24	–7.03	–5.7	–4.37	
	557.82	–7.9	–6.4	–4.9	
	637.50	–10.5	–8.5	–6.5	
	717.18	–13.4	–10.9	–8.4	
	796.88	–16.4	–13.4	–10.4	
	1062.5	–26.17	–21.5	–16.3	
FC1063 Fibre Channel (Controlled to 1.5X Data Rate), Data Rate: 1062.5 Mb/s					
	0.0	–0.5	0.0	0.5	
	159.38	–0.6	–0.1	0.4	
	318.75	–0.9	–0.4	0.1	
	478.12	–1.5	–1.0	–0.5	
	637.50	–2.4	–1.9	–1.4	
	796.87	–3.5	–3.0	–2.5	
	956.25	–5.5	–4.5	–3.5	
	1062.5	–7.03	–5.7	–4.37	
	1115.63	–7.9	–6.4	–4.9	
	1275.0	–10.5	–8.5	–6.5	
	1434.37	–13.4	–10.9	–8.4	
	1593.75	–16.4	–13.4	–10.4	

Adjustment Procedures

This section contains information needed to adjust the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes.

Description	The <i>Adjustment Procedures</i> are divided into six subsections: ■ General information about adjusting the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. ■ A list of equipment required to perform the adjustments. ■ The written procedures for installing and using both the <i>TDS 600C Adjustment Software</i> and the <i>TDS 700D Adjustment Software</i>. The <i>TDS 700D Adjustment Software</i> works with both the TDS 500D, TDS 700D and TDS 714L oscilloscopes. ■ The TDS 600C and the <i>TDS 700D Adjustment Software</i> included with this manual. The material found in the subsections listed above should be read before using the adjustment software. ■ A written procedure for manually adjusting the optional P6139A probe. ■ A written procedure for manually adjusting the display assembly.
Purpose	This procedure is used to return the oscilloscope to conformance with its <i>Warranted Characteristics</i> as listed in Section 1, <i>Specifications</i>. It can also be used to optimize the performance of the oscilloscope.
Adjustment Interval	As a general rule, these adjustments should be done every 2000 hours of operation or once a year if the oscilloscope is used infrequently.

Requirements for Performance

Before you do this procedure, you need to address the following requirements.

Personnel	This procedure is only to be performed by trained service technicians.
Warm-Up Period	This oscilloscope requires a 20 minute warm-up time in a 20° C to 30° C environment before it is adjusted. Adjustments done before the operating temperature has stabilized may cause errors in performance.

Access Except when adjusting the display assembly, the cabinet is not removed. Instead, you enable the internal adjustment constants of the oscilloscope to be written. Two small holes in the chassis allow service personnel to insert a tool and push a switch to enable or disable the writing of new adjustment constants to nonvolatile RAM.

The procedure that follows will tell you how and when to enable and disable the writing of adjustment constants. Be sure to disable the switch when you have finished adjusting the oscilloscope.

System Adjustment of this oscilloscope requires a computer with hard drive, 3.5 inch 1.44 MByte floppy drive, and the following items:

For DOS software:

- An IBM[®] PC[™] compatible computer running DOS 3.2 or higher. A math coprocessor is strongly recommended.
- 640K resident RAM with 580 K available RAM.
- A GPIB board — National Instruments[®] GPIB-PCII, GPIB-PCIIA or GPIB-PCII/IIA. (A PC-GPIB Package that includes the PCII/IIA is available — Tektronix part number S3FG210)

For Windows NT software:

- An Intel compatible computer running Windows NT.
- A GPIB board and software — National Instruments[®] AT-GPIB/TNT, Windows NT (INTEL).

Test Equipment The equipment list, starting on page 5–5, lists all test equipment required to adjust this oscilloscope.

Usage

The following topics cover what is required of you when adjusting the oscilloscope and what is done by the software. Also, the performance of individual adjustments is discussed.

Performing the Adjustments

When using the adjustment software, you will not be required to manually adjust any circuits. As you run the calibration tests, the software adjusts the circuits using external standards you provide in response to prompts on the computer screen. Your role, then, is to provide those test signals and to prompt the computer to continue.

Since the display-assembly and P6139A probe adjustment require manual adjustment of circuit components, they are not part of the adjustment software. Written procedures for these adjustments start on page 5–6.

If you are using the optional P6139A probe, do the manual adjustment procedures found at the end of this section.

Complete Adjustment

A complete adjustment is the performance of all adjustments on the *TDS 600C Adjustment Software* and the *TDS 700D Adjustment Software*, in sequence, plus the P6139A probe adjustment (if you are using the P6139A probe).

Throughout this section, “complete adjustment” is used as just defined.

Individual Adjustments

The adjustment software contains three classes of adjustments as shown in Table 5–1. Each class contains one or more individual calibration tests and an internal compensation routine (SPC). The *Adjustment Software* and the release notes (on disk), provide you with instructions for running each of the tests.

All these software-based adjustments are made internally by the adjustment software, and all adjustments can be done without removal of the oscilloscope cabinet.

Signal Path Compensation (SPC). This internal routine is not an adjustment. It is a temperature compensation routine that compensates for the current operating temperature to optimize oscilloscope performance.

Table 5–1: Calibration tests

Class of Adjustment	TDS 600 Tests	TDS 500/700 Tests
Voltage Reference	CVR_CAL SPC PROBE_COMP_CAL	COLD_START SPC CVR_CAL POWER_CYCLE SPC PROBE_COMP_CAL
Frequency Response	HF_CAL	SPC HF_CAL INTERLEAVE SPC
Pulse Trigger	GLITCH_TRIG_CAL PNP_LATENCY_CAL SKEW_CALS	GLITCH_TRIG_CAL PNP_LATENCY_CAL TRIG_POS_CAL

Adjustment Dependencies

Some adjustments depend on successful prior completion of other adjustments. For example, all the tests associated with the Voltage Reference Adjustment class must be passed before any other adjustments can be successfully completed. Table 5–2 lists the adjustments and their dependencies.

Table 5–2: Adjustments and dependencies

Class of Adjustment	Prior Completion Requirements
Voltage Reference Adjustment	None
Frequency Response Adjustment	Voltage Reference (SPC and all tests)
Pulse Trigger Adjustment	Voltage Reference (SPC and all tests)
P6139A Probe Adjustment	Voltage Reference and Frequency Response (SPC and all tests)
Display Adjustment	None

Partial Adjustment

The adjustment software will allow you to make individual adjustments. However, usually all adjustments are made unless you are adjusting circuits in the course of troubleshooting the oscilloscope. Read the information under *Complete Adjustment*, *Adjustment After Repair*, and *Adjustment Dependencies* before doing an individual adjustment.

Adjustment After Repair

After the removal and replacement of a module due to electrical failure, you must either do a complete adjustment or no adjustment at all, depending on the module replaced. See Table 5–3.

Table 5–3: Adjustments required for module replaced

Module Replaced	Adjustment Required
Acquisition Board	Complete Adjustment
Front Panel Assembly	None Required
Low Voltage Power Supply	Complete Adjustment ¹
Processor Board	Complete Adjustment
Display Assembly	Display Adjustment Only

¹ Optionally, you may first do the complete performance verification (all procedures in Chapter 4). If all procedures are passed, you can skip the complete adjustment; if any procedures fail, you must do a complete adjustment.

Equipment Required

Table 5–4 lists the test equipment required to adjust the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes.

Table 5–4: Test equipment, fixtures, and supplies

Item Number and Description	Minimum Requirements	Example	Purpose
1. Adapter, BNC-Female-to-BNC-Female	Tektronix part number 013-0028-00	Tektronix part number 013-0028-00	Probe Adjustment
2. Adapter, Probe Tip-to-BNC, 50 Ω termination	Tektronix part number 013-0227-00	Tektronix part number 013-0227-00	Probe Adjustment
3. Adapter, BNC female-to-Clip Leads	BNC female-to-Clip Leads	Tektronix part number 013-0076-00	Signal Coupling for Probe Compensator Output Check
4. Adjustment Tool	Less than 1/8 inch diameter and over 2 inches long	Tektronix part number 003-0675-00	Software-based Adjustments (used as a probe) and Manual Adjustments
5. Attenuator, 10X (Two required)	Ratio: 10X; impedance 50 Ω ; connectors: female BNC input, male BNC output	Tektronix part number 011-0059-02	Software-based Adjustments
6. Attenuator, 2X	Ratio: 2X; impedance 50 Ω ; connectors: female BNC input, male BNC output	Tektronix part number 011-0069-02	Software-based Adjustments
7. Cable GPIB	IEEE Std 488.1–1987/ IEEE Std 488.2–1987	Tektronix part number 002-0991-01	Software-based Adjustments
8. Coupler, Dual-Input	Female BNC to dual male BNC	Tektronix part number 067-0525-02	Software-based Adjustments
9. Cable, Precision Coaxial	50 Ω , 36 in, male to male BNC connectors	Tektronix part number 012-0482-00	Software-based Adjustments
10. Connector, Dual-Banana	Female BNC to dual banana	Tektronix part number 103-0090-00	Software-based Adjustments
11. Generator, Calibration	High Amplitude pulse with variable amplitude of at least 60 V.	Tegam/Tektronix PG 506A Calibration Generator ^{1,2}	Probe Adjustment
12. Generator, DC Calibration	Variable amplitude to ± 104 V; accuracy to 0.1%	Data Precision 8200 ¹	Software-based Adjustments
13. Generator, Sine Wave	250 kHz to 1 GHz; Variable amplitude from 60 mV to 2 V _{p-p} into 50 Ω ; 6 MHz reference	Rohde & Schwarz SMT or SMY ^{1,3}	Software-based Adjustments
14. Meter, Level and Power Sensor	Frequency range: 10 MHz to 1 GHz. Amplitude range: 6 mV _{p-p} to 2 V _{p-p}	Rohde & Schwarz URV 35, with NRV-Z8 power sensor ^{1,3}	Sinewave leveling during software-based adjustments
15. Splitter, Power	Frequency range: DC to 1 GHz. Tracking: >2.0%	Rohde & Schwarz RVZ ^{1,3}	Sinewave leveling during software-based adjustments

Table 5–4: Test equipment, fixtures, and supplies (Cont.)

Item Number and Description	Minimum Requirements	Example	Purpose
16. Magnifier, 6X	Standard Tool		Brightness and Focus Adjustment
17. Photometer	0.1 to 200 Footlamberts	Tektronix J17 Photometer with J1803 Luminance Probe	Contrast Adjustment
18. Probe, 10X, optional accessory	A P6139A Probe	Tektronix P6139A	Probe Adjustment
19. Pulser, Tunnel Diode	Tektronix part number 067-0681-01	Tektronix part number 067-0681-01	Probe Adjustment
20. Generator, Optical Impulse	850 nm optical impulse	Tektronix OIG501 Optical Impulse Generator ²	Option 3C Software-based Adjustments
21. Generator, Optical Impulse	1300 nm optical impulse	Tektronix OIG502 Optical Impulse Generator ²	Option 4C Software-based Adjustments
22. Attenuator, Optical	62.5 micron optical attenuator	Tektronix OA5022 Optical Attenuator ²	Option 3C and 4C Software-based Adjustments
23. Cable, Fibre Optic	FC-FC fiber cable	Tektronix part number 174-2322-00	Option 3C and 4C Software-based Adjustments
24. Optical-to-Electrical Converter	P6701B (used with Option 3C) or P6703B (used with Option 4C) optical-to-electrical converter	Tektronix P6701B or P6703B	Option 3C and 4C Software-based Adjustments

¹ You may replace items 11, 12, 13, 14, and 15 with a Wavetek 9100 (with options 100 and 600) for 500 MHz oscilloscopes, or a Wavetek 9500 (with option 100) and output head appropriate for the bandwidth of the oscilloscope(s) being tested.

² Requires a TM 500 or TM 5000 Series Power Module Mainframe.

³ If available, you may replace items 13, 14, and 15 with a Tegam/Tektronix SG5030 and its leveling head for bandwidths up to 500MHz, or a Tegam/Tektronix SG503 and SG504 with SG504 leveling head for bandwidths up to 1 GHz.

Adjustment Instructions

The following instructions describe installing the software on your system, setting up the oscilloscope for adjustment, and starting the adjustment of the oscilloscope by the software.

Hardware Installation

1. *Install the proper GPIB card (see System on page 5–2):* Use the manual accompanying your GPIB card to install and configure that card.
2. *Configure the GPIB card:*
 - a. The adjustment software is compatible with cards configured for PCII and PCIIA operation (DOS) or AT-GPIB/TNT (Windows NT). The following table lists the default card settings.

- b. If these settings conflict with your hardware setup, see your GPIB card manual for alternate settings.
- c. If you have more than one GPIB card installed, this adjustment software assumes the first card (referenced 0). See your GPIB card manual for information on how to determine which card is your “0” card.

Table 5-5: GPIB board configuration¹

Board Settings	GPIB-PCII	GPIB-PCIIA	AT-GPIB/TNT
Base I/O Address (hex)	2B8	2E1	2C0
DMA Channel	1	1	5
Interrupt Line	7	7	11

¹ Systems using the combination card (GPIB-PCII/IIA) can be configured as either a GPIB-PCII or a GPIB-PCIIA (preferred).

Software Installation

STOP. ALWAYS use this installation procedure when installing this software on a new computer. This installation program uses parameters you supply (see step 2, substep b) to create a custom start-up file on your hard disk directory. After installation, the software will instruct you to run this start-up batch file whenever you do software-based adjustments, so it can configure your computer properly before it runs the adjustment program. Do not simply copy the software files from one computer to another, since the start-up batch file you copy may not match the computer you copy it to.

1. *Create a working disk:* Copy the Adjustment Software disk to a working disk.
2. *Install the software to the hard disk:*
 - a. Read the README and RELEASE.NTS files.
 - b. Insert your working disk in a floppy drive, change to that drive, and run *install*. The software will ask you to specify the hard disk on which to install the adjustment software. It will also prompt you to specify several GPIB-card configuration parameters.
 - c. The adjustment software will be installed in a directory called *TDS600C.ADJ* or *TDS700D.ADJ* on your hard drive.
3. *Store your installation disks:* Remove your working disk and store it and the master disk in a secure place.

**Software-Based
Adjustments**

Equipment required	All items that are listed for "Software-based Adjustments" under the "Purpose" column in Table 5–4 starting on page 5–5. If you intend to perform the adjustments for Options 3C and 4C, you also need the equipment listed for Option 3C and 4C software-based adjustments.
---------------------------	---

1. *Hook up the oscilloscope:*
 - a. Connect the GPIB cable (Item 7) to the GPIB port at the computer rear panel. (When multiple GPIB cards are installed, connect to the GPIB0 card.)
 - b. Connect the GPIB cable (Item 7) to the GPIB port at the oscilloscope rear panel.
 - c. Power on the oscilloscope.
2. *Set up the oscilloscope:*
 - a. Press **SHIFT**; then press **UTILITY**.
 - b. Repeatedly press the main-menu button **System** until **I/O** is highlighted in the pop-up menu.
 - c. Press the side-menu button **TALK/LISTEN**.
 - d. Use the keypad to set the address to 1.
3. *Let the oscilloscope warm up:* Allow a 20 minute warm-up period before you begin step 4.
4. *Start the adjustment software:*
 - a. Change drives to your hard drive (typically C:).
 - b. Change directories to TDS600C.ADJ for any TDS 600C oscilloscope or TDS700D.ADJ for any TDS 500D, 700D or 714L oscilloscope.
 - c. Type *ADJ600C* for any TDS 600C oscilloscope or type *ADJ700D* for any TDS 500D, 700D or TDS 714L oscilloscope.

NOTE. *If you are adjusting an Option 3C or 4C equipped oscilloscope, read the RELEASE.NTS file and refer to Figure 4–42 on 4–99 to set up the equipment.*

- d. Follow the instructions as prompted on your computer screen. This will include the actions listed in step 5 shown below.
5. *Enable the adjustment constants to be written –when prompted on your computer screen in step 4 above:*

- a. Locate the two small access holes on the right side of the oscilloscope cabinet near the front.
- b. Insert the adjustment tool (Item 2) in the hole nearest the front of the oscilloscope about 1/2 inch to engage the rocker switch.
- c. Push to rock the switch to its unprotected (enabled) position. See Figure 5–1.




Figure 5–1: Accessing the protection switch

6. *When adjustment has been completed:*



CAUTION. Be sure to disable the NVRAM Protection switch as instructed below to protect the adjustment constants against alteration.

- a. Locate the two small access holes on the right side of the oscilloscope cabinet near the front. (See Figure 5–1.)
- b. Insert the adjustment tool (Item 2) in the hole nearest the *rear* of the oscilloscope about 1/2 inch to engage the rocker switch.

- c. Push to rock the switch to its protected (disabled) position.
- d. To do a complete adjustment as defined on page 5–3, you must also do the procedure *Compensate the Probe* on page 5–10 if you are using the optional P6139A probe.

Probe Adjustment for the P6139A Probe

STOP. *It is not necessary to do this procedure to perform a complete adjustment unless you are using the optional P6139A probe.*

This probe adjustment is divided into three parts: *Compensate the Probe*, *Measure the Probe Bandwidth*, and *Adjust the Probe — High Frequency Response*. If probe bandwidth is within required limits, you will be instructed to *not* do the high frequency response adjustment.

Compensate the Probe

Equipment required	One P6139A probe (Item 18).
--------------------	-----------------------------

1. *Install the test hookup and preset the oscilloscope controls:*
 - a. *Hook up test-signal source:* Install the optional-accessory probe to **CH 1**. Connect the probe tip to **PROBE COMPENSATION SIGNAL** on the front panel; connect the probe ground to **PROBE COMPENSATION GND** (See Figure 5–2).




Figure 5–2: Hookup for probe compensation

- b. *Initialize the oscilloscope:*
 - Press save/recall **SETUP**.
 - Press the main-menu button **Recall Factory Setup**.
 - Press the side-menu button **OK Confirm Factory Init**.
 - c. *Modify the initialized front-panel control settings:*
 - Press **AUTOSET**. Set the horizontal **SCALE** to 250 μ s.
 - Press **SET LEVEL TO 50%** as required to trigger the signal.
 - Press **SHIFT**; then press **ACQUIRE MENU**.
 - Press the main-menu button **Mode**. Then press the side-menu button **Average 16**.
2. *Compensate the Probe:*
 - a. Locate the probe compensation hole in the side of the probe body.
 - b. Using the probe compensation tool, adjust the probe for best square wave compensation (flat as possible across its top) (See Figures 5–3 and 5–4).




Figure 5-3: Performing probe compensation




Figure 5-4: Proper and improper probe compensation

3. *Disconnect the hookup:* Disconnect the probe from the probe compensator terminals; leave probe installed on CH 1 and leave the oscilloscope control setup as is for doing the next part of probe adjustment.

Measure Probe Bandwidth

Equipment required	One high-frequency sine wave generator with its leveling head (Item 13)
	One BNC-female-to-female BNC adapter (Item 1)
	One BNC-to-probe tip adapter (Item 2)
	One P6139A 10X probe (Item 18)

1. Install the test hookup and preset the oscilloscope controls:

- a. Expose the Inner Probe Tip:** Follow the instructions in Figure 5–5.




Figure 5–5: Exposing the inner probe tip

b. Hook up test-signal source:

- Connect the output of a high-frequency sine wave generator, through its leveling head, to a female-to-female adapter. See Figure 5–6.
- Connect the female-to-female adapter to a BNC-to-probe tip adapter.
- Plug the probe tip from the probe on CH 1 into the BNC-to-probe tip adapter.




Figure 5-6: Initial test hookup

c. *Initialize the oscilloscope:*

- Press save/recall **SETUP**.
- Press the main-menu button **Recall Factory Setup**.
- Press the side-menu button **OK Confirm Factory Init**.

d. *Modify the initialized front-panel control settings:*

- Set the vertical **SCALE** to 500 mV.
- Set the horizontal **SCALE** to 100 ns.
- Push **SET LEVEL TO 50%** as required to trigger the signal.
- Press **SHIFT**. Then press **ACQUIRE MENU**.
- Press the main-menu button **Mode**. Then press the side-menu button **Average 16**.
- Press **MEASURE**.
- Press the main-menu button **Hi-Low Setup**. Then press the side-menu button **Min-Max**.
- Press the main-menu button **Select Measrmnt for Ch1**.
- Repeatedly press the side-menu button **–more–** until **Pk-Pk** appears in the side menu. Press the side-menu button **Pk-Pk**.
- Press **CLEAR MENU**.

2. *Confirm that the Probe Compensator signal is within limits for bandwidth:*
 - a. *Display and measure the test signal:*
 - Monitor the **CH 1 Pk-Pk** readout while you set the output of the generator for a 3.0 V (6 division), 6 MHz reference signal.
 - Set the horizontal **SCALE** to 1 ns and set the frequency of the generator to 500 MHz.
 - Read the measurement results at the CH 1 Pk-Pk readout on screen.
 - b. *Check against limits:* CHECK that the **CH 1 Pk-Pk** readout is greater than or equal to 2.1 V.
3. *Disconnect the hookup:*
 - a. Unplug the probe from BNC-to-probe tip adapter.
 - b. If substep 2b was passed, the probe adjustment is finished. Reverse the instructions in Figure 5–5, page 5–13, to reinstall the retractable hook probe tip.
 - c. If substep 2b was *not* passed, leave the probe tip exposed. Remove the probe from CH 1 and go on to the next procedure *Adjust the Probe — High Frequency Response*.

Adjust the Probe — High Frequency Response

Do not perform this procedure until you have first completed the procedures *Compensate the Probe* and *Measure Probe Bandwidth* on pages 5–10 and 5–13, respectively.

Do not perform this procedure if you have successfully completed *Measure Probe Bandwidth*. Probe adjustment is complete.

Equipment required	One calibration generator (Item 11) One 50 Ω precision cable (Item 9) One tunnel diode pulser (Item 19) One BNC female-to-female adapter (Item 1) One BNC to probe adapter (Item 2) One 10X attenuator (Item 5) One P6139A 10X probe (Item 18)
---------------------------	---

1. Install the test hookup and preset the oscilloscope controls:

a. Access Inner Probe Tip and Adjustment Ports:

- The probe tip should be exposed from the procedure *Measure Probe Bandwidth*. If not, follow the instructions in Figure 5–5 to expose the probe tip.
- Follow the instructions in Figure 5–7 to remove the probe body covers.




Figure 5–7: Exposing the probe body

b. Hook up test-signal source:

- Connect the high-amplitude output of a calibration generator, through a 50 Ω precision cable, to the input of a tunnel diode pulser. See Figure 5–8.
- Connect the output of the tunnel diode pulser through a 10X attenuator to CH 1.
- Set the triggering level of the tunnel diode pulser to minimum.




Figure 5–8: Initial test hookup

c. *Initialize the oscilloscope:*

- Press save/recall **SETUP**.
- Press the main-menu button **Recall Factory Setup**.
- Press the side-menu button **OK Confirm Factory Init**.

d. *Modify the initialized front-panel control settings:*

- Set vertical **SCALE** to 5 mV.
- Push **SET LEVEL TO 50%** as required to trigger the signal.
- Press **VERTICAL MENU**. Then press the main-menu button **Coupling**. Press the side-menu button **Ω** to toggle to 50 Ω coupling.
- Press **CLEAR MENU**.

2. *Adjust the Probe:*

a. *Display and store the reference signal:*

- Set the high-amplitude output of the generator to ≥ 60 V at the input to the tunnel diode pulser.
- Set the **Period** (repetition rate) to 10 kHz.
- Advance the triggering level of the tunnel diode pulser until a five to six division square wave appears on screen. Do not advance the knob any further than required to achieve stable amplitude.
- Use the vertical **POSITION** to center the displayed waveform on screen.

- Press **SHIFT**; then press **ACQUIRE MENU**.
 - Press the main-menu button **Mode**. Then press the side-menu button **Average 16**.
 - Push **SET LEVEL TO 50%** as required to trigger the signal.
 - Advance the horizontal **SCALE** to 5 ns.
 - Press **HORIZONTAL MENU**.
 - Press the main-menu button **Trigger Position**; press the side-menu button **Set to 20%**.
 - Press **SAVE WAVEFORM**.
 - Press the main-menu button **Save Waveform**. Then press the side-menu button **To Ref 1**.
 - Press **MORE**. Then push the main-menu button **Ref 1**.
- b. *Display the test signal:*
- Disconnect the tunnel diode pulser at CH 1 and remove the 10X attenuator.
 - Connect the output of the tunnel diode pulser through a BNC-female-to-BNC-female adapter to a BNC-to-probe tip adapter.
 - Install the probe on CH 1.
 - Plug the probe tip from the probe into the BNC-to-probe tip adapter.
 - Press **VERTICAL MENU**; then press **CH 1**.
 - Press the main-menu button **Coupling**. Then press the side-menu button **Ω** to toggle to 1 M Ω coupling.
 - Push **SET LEVEL TO 50%** as required to trigger the signal.
 - Adjust the triggering level of the tunnel diode pulser until a five to six division square wave appears on screen. Do not advance the knob any further than required to achieve stable amplitude.
- c. *Make the adjustments:*
- Locate the various adjustments in Figure 5–9.
 - Manually adjust the front-corner response of the probe to best match the response of the Ref 1 waveform. It is more important to match the response during the first 5 ns than during the entire first 20 ns the adjustments affect.




Figure 5–9: Locations of P6139A probe adjustments

- See Figure 5–10 to see the areas on the front corner that the various adjustments affect.
- d. Recheck Probe Bandwidth:**
- Redo the procedure *Adjust Probe — High Frequency Response* to check if probe now meets its bandwidth requirement.
 - If the bandwidth requirement is met, adjustment is complete. Skip to step 3.
 - If the bandwidth requirement is *not* met, redo this procedure, increasing front corner overshoot slightly relative to the stored waveform.
 - Repeat this step (d) until the bandwidth requirement is met.




Figure 5-10: Adjustments versus front-corner response

3. *Disconnect the hookup:* Unplug the probe from the BNC-to-probe tip adapter. Reverse the instructions in Figure 5-5, page 5-13, to reinstall the retractable probe tip.

Display Assembly Adjustment

STOP. It is not necessary to do this procedure to perform a complete adjustment. Only use this procedure to adjust the display assembly if it has been repaired or if brightness and contrast have become unsatisfactory.

Brightness, and Contrast Adjustment (TDS 500D and 680C – Monochrome Only)

Equipment required	One 6X magnifier (Item 16)
	One J17 Photometer with a J1803 Luminance Probe (Item 17)

1. Access the inside of the oscilloscope: See Removal and Installation Procedures in Section 6 to remove the cabinet.
2. Adjust the display brightness:
 - a. Display the Composite test pattern:
 - Leave the oscilloscope powered off.
 - Set the DIP switch, located near the front of the A11 DRAM Processor/Display, as follows:

Switch No.	1	2	3	4	5	6	7	8
Open						X	X	
Closed	X	X	X	X	X			X

- Power on the oscilloscope.
- Press **SHIFT**; then press **UTILITY**.
- Repeatedly press the main-menu button **System** until **Diag/Err** is highlighted in the pop-up menu.
- Repeatedly press the main-menu button **Area** until **Display** is highlighted in the pop-up menu.
- Repeatedly press the side-menu button **–more–** until **Composite** appears in the side menu. Push **Composite**.
- Press the main-menu button **EXECUTE**; then press the side-menu button **Ok Confirm Run Test**.

b. Make the brightness adjustment:

- Locate R569 (BRIGHTNESS). It is one of the two adjustments on the left side of the instrument located just ahead of the fan. It is the adjustment nearest the fan.
- Observe the luminance patches using a 6X magnifier.
- Adjust R569 (BRIGHTNESS) until the background raster lines in the 5% luminance patch (see Figure 5–11) just disappear, while the lines in the 10% luminance patch are just visible, when both are viewed through the magnifier.




Figure 5–11: Five and ten percent luminance patches

3. Adjust the display contrast:

a. Display the White Field test pattern:

- Press the center main-menu button to display the main menu.
- Press the main-menu button **Tests**.
- Repeatedly press the side-menu button **–more–** until **White Field** appears in the side menu. Push **White Field**.
- Press the main-menu button **EXECUTE**; then press the side-menu button **Ok Confirm Run Test**.

b. Make the contrast adjustment:

- Locate R572. It is one of two adjustments on the left side of the instrument located just ahead of the fan. It is the adjustment nearest the front of the oscilloscope.
- Monitor the luminance at center screen using a J17 photometer and a luminance probe.
- Adjust R572 (CONTRAST) for a reading of 50 foot lamberts if the gray display shield is installed; adjust for 110 foot lamberts if the shield is missing.

4. Restore the oscilloscope to normal operation:**a. Restore the dip switch to the settings that follow:**

Switch No.	1	2	3	4	5	6	7	8
Open								
Closed	X	X	X	X	X	X	X	X

b. Power off the oscilloscope.**c. See *Removal and Installation Procedures* in Section 6 to reinstall the cabinet and other modules removed in step 1.**
**Rotation, Brightness, and
Contrast Adjustment
(TDS 654C, 684C, 700D,
714L – Color Only)**

Equipment required	One 6X magnifier (Item 16)
	One J17 Photometer with a J1803 Luminance Probe (Item 17)

- 1. Access the inside of the oscilloscope:** See *Removal and Installation Procedures* in Section 6 to remove the cabinet.
- 2. Adjust the display rotation:**
 - a. Display the Composite test pattern:**
 - Leave the oscilloscope powered off.

- Set the DIP switch, located near the front of the A11 DRAM Processor/Display, as follows:

Switch No.	1	2	3	4	5	6	7	8
Open			X			X	X	
Closed	X	X		X	X			X

- Power on the oscilloscope.
 - Press **SHIFT**; then press **UTILITY**.
 - Repeatedly press the main-menu button **System** until **Diag/Err** is highlighted in the pop-up menu.
 - Repeatedly press the main-menu button **Area** until **Display** is highlighted in the pop-up menu.
 - Repeatedly press the side-menu button **—more—** until **Composite** appears in the side menu. Push **Composite**.
 - Press the main-menu button **EXECUTE**; then press the side-menu button **Ok Confirm Run Test**.
- b. Adjust R401 (TRACE ROTATION) to minimize the display's tilt. Use the frame around the display as a reference. R401 is the second adjustment from the fan.
3. *Adjust the display brightness:*
- Locate R403 (BRIGHTNESS). It is one of the adjustments on the left side of the instrument located just ahead of the fan. It is the fourth adjustment from the fan.
 - Observe the luminance patches using a 6X magnifier.
 - Adjust R403 (BRIGHTNESS) until the background raster lines in the 5% luminance patch (see Figure 5–11) just disappear, while the lines in the 10% luminance patch are just visible, when both are viewed through the magnifier.
4. *Adjust the display contrast:*
- a. *Display the White Field test pattern:*
- Press the center main-menu button to display the main menu.
 - Press the main-menu button **Tests**.

- Repeatedly press the side-menu button **more** until **White Field** appears in the side menu. Push **White Field**.
 - Press the main-menu button **EXECUTE**; then press the side-menu button **Ok Confirm Run Test**.
- b. Make the contrast adjustment:**
- Locate R404. It is one of the adjustments on the left side of the instrument located just ahead of the fan. It is the fifth adjustment from the fan.
 - Monitor the luminance at center screen using a J17 photometer and a luminance probe.
 - Adjust R404 (CONTRAST) for a reading of 36 foot lamberts for 640-0077-XX display assemblies where -XX equals -06 or above. Use a reading of 40 foot lamberts for 640-0077-XX assemblies where -XX equals -05 or below.

NOTE. *The adjustments for contrast and brightness interact with each other.*

5. Restore the oscilloscope to normal operation:

- a. Restore the dip switch to the settings that follow:**

Switch No.	1	2	3	4	5	6	7	8
Open			X					
Closed	X	X		X	X	X	X	X

- b. Power off the oscilloscope.**
- c. See *Removal and Installation Procedures* in Section 6 to reinstall the cabinet and other modules removed in step 1.**

Maintenance

This section contains the information needed to do periodic and corrective maintenance on the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. The following subsections are included:

- *Preparation* — Introduction plus general information on preventing damage to internal modules when doing maintenance.
- *Inspection and Cleaning* — Information and procedures for inspecting the oscilloscope and cleaning its external and internal modules.
- *Removal and Installation Procedures* — Procedures for the removal of defective modules and replacement of new or repaired modules. Also included is a procedure for disassembly of the oscilloscope for cleaning.
- *Troubleshooting* — Information for isolating failed modules. Included are instructions for operating the oscilloscope's internal diagnostic routines and troubleshooting trees. Most of the trees make use of these internal diagnostic routines to speed fault isolation to a module.

Related Maintenance Procedures

The following sections contain information and procedures related to maintenance.

- Section 2, *Operating Information*, covers instructions useful when operating the oscilloscope in order to troubleshoot it. It also details the service strategy and lists options for obtaining maintenance service and for replacing failed modules.
- Section 3, *Theory of Operation*, contains a circuit description at the module, or block, level.
- Section 4, *Performance Verification*, contains procedures that may be useful in isolating problems to modules by testing oscilloscope performance.
- Section 5, *Adjustment Procedures*, addresses after repair adjustment and the interval between periodic adjustments. It contains a procedure for adjusting the internal circuits of the oscilloscope.
- Section 9, *Diagrams*, contains a block diagram using individual modules as blocks and an interconnection diagram showing connections between the modules.
- Section 10, *Mechanical Parts List*, lists all field replaceable modules by part number.

Preparation

Before servicing this product, read the *Safety Summary* and *Introduction* at the front of the manual and the ESD information below.



CAUTION. *Static discharge can damage any semiconductor component in this oscilloscope.*

Preventing ESD

When performing any service which requires internal access to the oscilloscope, adhere to the following precautions to avoid damaging internal modules and their components due to electrostatic discharge (ESD).

1. Minimize handling of static-sensitive modules.
2. Transport and store static-sensitive modules in their static protected containers or on a metal rail. Label any package that contains static-sensitive modules.
3. Discharge the static voltage from your body by wearing a grounded antistatic wrist strap while handling these modules. Do service of static-sensitive modules only at a static-free work station.
4. Nothing capable of generating or holding a static charge should be allowed on the work station surface.
5. Handle circuit boards by the edges when possible.
6. Do not slide the modules over any surface.
7. Avoid handling modules in areas that have a floor or work-surface covering capable of generating a static charge.

Susceptibility to ESD

Table 6–1 lists the relative susceptibility of various classes of semiconductors. Static voltages of 1 kV to 30 kV are common in unprotected environments.

Table 6–1: Relative susceptibility to static-discharge damage

Semiconductor classes	Relative susceptibility levels¹
MOS or CMOS microcircuits or discrete circuits, or linear microcircuits with MOS inputs (most sensitive)	1
ECL	2
Schottky signal diodes	3
Schottky TTL	4
High-frequency bipolar transistors	5
JFET	6
Linear microcircuits	7
Low-power Schottky TTL	8
TTL (least sensitive)	9

¹ **Voltage equivalent for levels (voltage discharged from a 100 pF capacitor through resistance of 100 ohms):**

1 = 100 to 500 V

2 = 200 to 500 V

3 = 250 V

4 = 500 V

5 = 400 to 600 V

6 = 600 to 800 V

7 = 400 to 1000 V (est.)

8 = 900 V

9 = 1200 V

Inspection and Cleaning

Inspection and Cleaning describes how to inspect for dirt and damage. It also describes how to clean the exterior and interior of the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes. Inspection and cleaning are done as preventive maintenance. Preventive maintenance, when done regularly, may prevent oscilloscope malfunction and enhance its reliability.

Preventive maintenance consists of visually inspecting and cleaning the oscilloscope and using general care when operating it.

How often to do maintenance depends on the severity of the environment in which the oscilloscope is used. A proper time to perform preventive maintenance is just before oscilloscope adjustment.

General Care

The cabinet helps keep dust out of the oscilloscope and should normally be in place when operating the oscilloscope. The oscilloscope's front cover protects the front panel and display from dust and damage. Install it when storing or transporting the oscilloscope.

Inspection and Cleaning Procedures

Inspect and clean the oscilloscope as often as operating conditions require. The collection of dirt on components inside can cause them to overheat and break-down. (Dirt acts as an insulating blanket, preventing efficient heat dissipation.) Dirt also provides an electrical conduction path that could cause an oscilloscope failure, especially under high-humidity conditions.



CAUTION. *Avoid the use of chemical cleaning agents which might damage the plastics used in this oscilloscope. Use only deionized water when cleaning the menu buttons or front-panel buttons. Use a 75% isopropyl alcohol solution as a cleaner and rinse with deionized water. Before using any other type of cleaner, consult your Tektronix Service Center or representative.*

Inspection — Exterior. Inspect the outside of the oscilloscope for damage, wear, and missing parts, using Table 6–2 as a guide. Oscilloscopes that appear to have been dropped or otherwise abused should be checked thoroughly to verify correct operation and performance. Immediately repair defects that could cause personal injury or lead to further damage to the oscilloscope.

Table 6–2: External inspection check list

Item	Inspect For	Repair Action
Cabinet, front panel, and cover	Cracks, scratches, deformations, damaged hardware or gaskets.	Repair or replace defective module.
Front-panel knobs	Missing, damaged, or loose knobs.	Repair or replace missing or defective knobs.
Connectors	Broken shells, cracked insulation, and deformed contacts. Dirt in connectors.	Repair or replace defective modules. Clear or wash out dirt.
Carrying handle, bail, cabinet feet.	Correct operation.	Repair or replace defective module.
Accessories	Missing items or parts of items, bent pins, broken or frayed cables, and damaged connectors.	Repair or replace damaged or missing items, frayed cables, and defective modules.

Cleaning Procedure — Exterior. To clean the oscilloscope exterior, do the following steps:

1. Remove loose dust on the outside of the oscilloscope with a lint free cloth.
2. Remove remaining dirt with a lint free cloth dampened in a general purpose detergent-and-water solution. Do not use abrasive cleaners.
3. Clean the light filter protecting the monitor screen with a lint-free cloth dampened with either isopropyl alcohol or, preferably, a gentle, general purpose detergent-and-water solution.



CAUTION. To prevent getting moisture inside the oscilloscope during external cleaning, use only enough liquid to dampen the cloth or applicator.

Inspection — Interior. To access the inside of the oscilloscope for inspection and cleaning, refer to the *Removal and Installation Procedures* in this section.

Inspect the internal portions of the oscilloscope for damage and wear, using Table 6–3 as a guide. Defects found should be repaired immediately.

If any electrical module is replaced, check Table 5–3 in Section 5 to see if it is necessary to adjust the oscilloscope.



CAUTION. To prevent damage from electrical arcing, ensure that circuit boards and components are dry before applying power to the oscilloscope.

Table 6–3: Internal inspection check list

Item	Inspect For	Repair Action
Circuit boards	Loose, broken, or corroded solder connections. Burned circuit boards. Burned, broken, or cracked circuit-run plating.	Remove failed module and replace with a fresh module.
Resistors	Burned, cracked, broken, blistered condition.	Remove failed module and replace with a fresh module.
Solder connections	Cold solder or rosin joints.	Resolder joint and clean with isopropyl alcohol.
Capacitors	Damaged or leaking cases. Corroded solder on leads or terminals.	Remove damaged module and replace with a fresh module from the factory.
Semiconductors	Loosely inserted in sockets. Distorted pins.	Firmly seat loose semiconductors. Remove devices that have distorted pins. Carefully straighten pins (as required to fit the socket), using long-nose pliers, and reinsert firmly. Ensure that straightening action does not crack pins, causing them to break off.
Wiring and cables	Loose plugs or connectors. Burned, broken, or frayed wiring.	Firmly seat connectors. Repair or replace modules with defective wires or cables.
Chassis	Dents, deformations, and damaged hardware.	Straighten, repair, or replace defective hardware.

Cleaning Procedure — Interior. To clean the oscilloscope interior, do the following steps:

1. Blow off dust with dry, low-pressure, deionized air (approximately 9 psi).
2. Remove any remaining dust with a lint-free cloth dampened in isopropyl alcohol (75% solution) and rinse with warm deionized water. (A cotton-tipped applicator is useful for cleaning in narrow spaces and on circuit boards.)

STOP. If, after doing steps 1 and 2, a module is clean upon inspection, skip the remaining steps.

3. If steps 1 and 2 do not remove all the dust or dirt, the oscilloscope may be spray washed using a solution of 75% isopropyl alcohol by doing steps 4 through 8.

4. Gain access to the parts to be cleaned by removing easily accessible shields and panels (see *Removal and Installation Procedures*).
5. Spray wash dirty parts with the isopropyl alcohol and wait 60 seconds for the majority of the alcohol to evaporate.
6. Use hot (120° F to 140° F) deionized water to thoroughly rinse them.
7. Dry all parts with low-pressure, deionized air.
8. Dry all components and assemblies in an oven or drying compartment using low-temperature (125° F to 150° F) circulating air.

Lubrication. There is no periodic lubrication required for this oscilloscope.

Removal and Installation Procedures

This subsection contains procedures for removal and installation of all mechanical and electrical modules. Any electrical or mechanical module, assembly, or part listed in Section 10 of this manual is a module.

Preparation — Please Read



WARNING. Before doing this or any other procedure in this manual, read the Safety Summary found at the beginning of this manual. Also, to prevent possible injury to service personnel or damage to this oscilloscope's components, read Installation in Section 2, and Preventing ESD in this section.

This subsection contains the following items:

- This preparatory information that you need to properly do the procedures that follow.
- List of tools required to remove all modules.
- Three module locator diagrams for finding the External Modules (see Figure 6–1), Outer-Chassis Modules (see Figure 6–2), and Inner-Chassis Modules (see Figure 6–3) in this oscilloscope.
- Procedures for removal and reinstallation of the electrical and mechanical modules.
- A disassembly procedure for removal of all the major modules from the oscilloscope at one time and for reassembly of those modules into the oscilloscope. Such a complete disassembly is normally only done when completely cleaning the oscilloscope. (Instructions for doing the actual cleaning are found under *Inspection and Cleaning* at the beginning of this section.)



WARNING. Before doing any procedure in this subsection, disconnect the power cord from the line voltage source. Failure to do so could cause serious injury or death.

List of Modules Section 10 lists all modules.

General Instructions

STOP. READ THESE GENERAL INSTRUCTIONS BEFORE REMOVING A MODULE.

First read over the Summary of Procedures that follows to understand how the procedures are grouped. Then read Equipment Required for a list of the tools needed to remove and install modules in this oscilloscope.

If you are disassembling this oscilloscope for cleaning, go to the procedure Disassembly for Cleaning on page 6–55.

If you are removing a module for service, begin by doing the procedure Access Procedure (page 6–15). By following the instructions in that procedure, you remove the module to be serviced while removing the minimum number of additional modules.

Summary of Procedures

The procedures are described in the order in which they appear in this section. In addition, you can look up any procedure for removal and reinstallation of any module in the *Table of Contents* of this manual.

- The *Access Procedure* on page 6–15 first directs you to the procedure(s) (if any) that are required to access the module to be serviced, then it directs you to the procedure to remove that module.
- *Procedures for External Modules* on page 6–16 are procedures for removing modules the removal of which do not require internal access to the oscilloscope.
- *Procedures for Outer-Chassis Modules* on page 6–28 are procedures for removing modules the removal of which require access internal to the instrument but external to the chassis.
- *Procedures for Inner-Chassis Modules* on page 6–48 are procedures for removing modules the removal of which require access internal to the instrument and internal to the chassis.
- *Disassembly for Cleaning* on page 6–55 is a procedure, based on the removal procedures just described, that removes all modules for cleaning. Instructions for cleaning are found in *Inspection and Cleaning*, which begins this section.

NOTE. *Read the cleaning procedure before disassembling the oscilloscope for cleaning.*

Equipment Required, see Table 6–4. Most modules in this oscilloscope can be removed with a screwdriver handle mounted with a size T-15, Torx® screwdriver tip. *Use this tool whenever a procedure step instructs you to remove or install a screw unless a different size screwdriver is specified in that step.* All equipment required to remove and reinstall each module is listed in the first step of its procedure.

Table 6–4: Tools required for module removal

Item No.	Name	Description	Tektronix Part Number
1	Screwdriver handle	Accepts Torx®-driver bits	003-0301-00
2	T-15 Torx tip	Torx®-driver bit for T-15 size screw heads	003-0966-00
3	T-20 Torx tip	Torx®-driver bit for T-20 size screw heads	003-0866-00
4	T-20 Torx tip	Special Tool: Narrow Torx®-driver bit for T-20 size screw heads (fan removal only)	003-1457-01
5	Flat-bladed screwdriver	Screwdriver for removing standard-headed screws	
6	Needle-Nose Pliers	Standard tool	
7	Nutdriver, ¼ inch	Standard tool	
8	Retaining Ring Pliers	Standard tool; 1⅛ inch minimum throw	
9	Angle-Tip Tweezers	Standard tool	
10	Soldering Iron	Standard tool	
11	Pliers	Standard tool	
12	Solder Wick	Standard tool	
13	⅝ hex tip	Bit for ⅝ hex set screw	
14	Adhesive	TRA-CON: Tra-Bond #BA-2114	




Figure 6-1: External modules




Figure 6-2: Outer-chassis modules




Figure 6-3: Inner-chassis modules

Access Procedure

Begin with this procedure when you have identified a module to be removed for service and have read *General Instructions* found earlier in this section.

1. *Locate module to be removed:*
 - a. Find the module to be removed in the module locator diagrams, Figures 6–1 through 6–3.
 - b. Once the module is found, note from the title of the figure whether the module is an external, outer-chassis mounted, or inner-chassis mounted part.
2. *If the module is externally mounted, no internal access is required; remove the module:* Find and do the procedure whose title matches the name of the module to be removed under *Procedures for External Modules* (page 6–16).
3. *If the module is an outer- or inner-chassis module, access the inside of the instrument:*
 - a. First do the procedure *Line Fuse and Line Cord*; then do the procedure *Rear Cover and Cabinet*. Both are found under *Procedures for External Modules* immediately following this procedure.
 - b. After completing those procedures, return to this procedure and continue with step 4.
4. *If the module is an outer-chassis module, remove it:*
 - a. If removing the attenuator or display-frame assembly, first do the procedure *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel*, found under *Procedures for External Modules* (page 6–16).
 - b. Find and do the procedure whose title matches the name of the module to be removed under *Procedures for Outer-Chassis Modules*, on page 6–28.
5. *If the module is an inner-chassis module, access the inner-chassis:*
 - a. If removing the display tube, display-driver board, or the front subpanel, first do the procedure *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel*, found under *Procedures for External Modules*. Also remove the display-frame assembly found under *Procedures for External Modules*, on page 6–16.
 - b. Also, if removing the front subpanel, do *A12 Front-Panel Assembly* also found under *Procedures for External Modules*.
 - c. Do, in the order listed, the three procedures *A14 D1 Bus and Analog-Power and Digital-Power Cables*, *A11 Processor/Display Board* and *Top Cover* found under *Procedures for Outer-Chassis Modules*, page 6–28.

- d. Find and do the procedure whose title matches the name of the module to be removed under *Procedures for Inner-Chassis Modules*, page 6–48.
6. *Reinstall all modules removed:* Read the instructions found at the end of the procedure that removes the module to be serviced — they will guide you in reinstalling all modules removed.

Procedures for External Modules


Do the *Access Procedure* (page 6–15) before doing any procedure in this collection.

The following procedures are found here and are listed in order presented.

- Front-Panel Knobs
- Line Fuse and Line Cord
- EMI Gaskets
- Rear Cover and Cabinet
- Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel
- A12 Front-Panel Assembly
- Display Frame Assembly
- Cabinet Modules

Front-Panel Knobs

1. *Assemble equipment and locate modules to be removed:* Have an angled-tip tweezers (Item 9) handy. Find the knob(s) to be removed on the front panel.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its front is facing you.
3. *Remove the knob(s):* Grasp any knob you want to remove and pull it straight out from the front panel slightly to create some clearance between the base of the knob and the front panel. Insert the tweezers between the knob and front panel and use them to remove the knob. See Figure 6–4.
4. *Reinstallation:* To reinstall, align knob to shaft and push it in until it snaps.

**Figure 6–4: Knob removal****Line Fuse and Line Cord**

1. *Assemble equipment and locate modules to be removed:* Have a flat-bladed screwdriver (Item 5) handy. Locate the line fuse and line cord in the locator diagram *External modules*, Figure 6–1.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its rear is facing you. If you are servicing the line fuse, do the next step; if you are servicing the line cord, skip to step 4.
3. *Remove line fuse:* Find the fuse cap on the rear panel. (See Figure 6–5.) Now, remove the fuse cap by turning it counterclockwise using a flat-bladed screwdriver, and remove the line fuse. Reverse procedure to reinstall.
4. *Remove line cord:* Find the line cord on the rear cover. (See Figure 6–5.) Now, remove the line-cord retaining clamp by first unplugging the line cord from its receptacle. Next, grasp both the line cord and the retaining clamp and rotate it 90 degrees counterclockwise. Pull the line cord and clamp away to complete the removal. Reverse procedure to reinstall.

5. *Reinstallation:* Do in reverse steps 3 and 4 to reinstall the line cord and then the line fuse.




Figure 6-5: Line fuse and line cord removal

EMI Gaskets

See *Rear Cover and Cabinet* procedure on page 6-18.

Rear Cover and Cabinet

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a size T-20 Torx® tip (Items 1 and 3).
 - b. Make sure the oscilloscope's front cover is installed; if it's not, install it by snapping its edges over the trim ring.
 - c. Locate the rear cover and cabinet in the locator diagram *External modules*, Figure 6-1 on page 6-12.
2. *Orient the oscilloscope:* Set the oscilloscope so its face is down with its front cover on the work surface and its bottom facing you.

3. *Disconnect the line cord:* Unplug the line cord from its receptacle at the rear cover.
4. *Remove rear cover:* Remove the four screws securing the rear cover to the oscilloscope. Lift off the rear cover.
5. *Remove the cabinet:*
 - a. At the rear of the cabinet, grasp its left and right edges.
 - b. Pull upward to slide the cabinet off the oscilloscope. Take care not to bind or snag the cabinet on the oscilloscope's internal cabling as you remove it.

STOP. DO NOT do steps 6 through 8 to remove the EMI gasket(s) unless they must be replaced due to damage. If you are not replacing those gaskets, skip to step 9.

When reinstalling EMI gaskets and/or the oscilloscope cabinet, carefully follow the instructions given. Unless they are performed properly, the oscilloscope may not meet its emissions requirements (EMI).

6. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a pair of needle-nose pliers (Item 6).
 - b. Locate the modules to be removed in the locator diagram *External modules*, Figure 6-1 on page 6-12.
7. *Remove the EMI gaskets:*
 - a. Look for the point where the ends of the gasket touch in the channel at the rear edge of the cabinet.
 - b. Use a pair of needle-nose pliers to pry up one of the ends.
 - c. Grasp the EMI gasket, and gently pull it out of the its channel.
 - d. Repeat substeps a through c to remove the gasket from its channel on the front casting.
8. *Reinstallation of EMI gaskets:* Press each EMI gasket back into its groove at the rear edge of the cabinet or front casting. Make sure the ends of the gasket touch, but do not overlap, when installing. (Cut off excess length if required to prevent overlap.)

9. Reinstallation of cabinet and rear cover:



CAUTION. To avoid excessive heat retention and circuit damage in instruments with serial number B040100 and above, use the proper cabinet. If you have several instruments apart for servicing, the proper cabinet for instruments with serial number B040100 and above can be identified by the larger ventilation areas, as shown in Figure 6–6.




Figure 6–6: Cabinet identification

- a. Do in reverse order steps 3 and 4 to reinstall the cabinet.
- b. Take care not to bind or snag the cabinet on internal cabling; redress cables as necessary.
- c. When sliding the cabinet, be sure that the front edge of the cabinet aligns with the groove containing the EMI shield on the front casting.
- d. Be sure that the ridge around the rear chassis slides into the groove containing a second EMI cable on the rear of the cabinet.
- e. When reinstalling the four screws at the rear panel, tighten them to 16 foot-lbs torque.
- f. See the procedure *Line Fuse and Line Cord* to reinstall the line cord, which completes the oscilloscope reassembly.




Figure 6-7: Rear cover and cabinet removal

Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel

1. *Assemble equipment and locate modules to be removed:* No tools are needed. Locate the modules to be removed in the locator diagram *External modules*, Figure 6-1 on page 6-12.
2. *Orient the oscilloscope:* Set the oscilloscope so its rear is down on the work surface and its bottom is facing you.
3. *Remove the front cover:* Grasp the front cover by its left and right edges and snap it off of the front subpanel. When reinstalling, align and snap back on.
4. *Remove the trim ring:* Grasp the trim ring by its top edge and pry it up and lift it forward to snap it off of the front subpanel. If servicing the menu buttons, lift them out of the trim ring. (When reinstalling, reinsert the menu buttons, align the trim ring to the front subpanel and press it back on.) See Figure 6-8.




Figure 6-8: Front cover, trim ring, menu buttons, and attenuator panel removal (front cover not shown)

STOP. *DO NOT touch the carbon contact points on the menu buttons installed in the trim ring. Also, do not touch the contacts on the flex circuit exposed when you remove the trim ring.*

5. *Remove the attenuator panel:* Gently pry, using your fingers, the snap-off/snap-on attenuator panel away from the front subpanel to remove it. (When reinstalling, use your hands to press it back on.)
6. *Reinstallation:* Do in reverse steps 3–5 to reinstall the attenuator panel, menu buttons, trim ring, and the front cover, following the reinstallation instructions found in each step.

A12 Front-Panel Assembly

NOTE. *This procedure includes removal and reinstallation instructions for the front panel and front panel buttons. Unless either of those modules are being serviced, do not do step 4, “Further disassembly of front-panel assembly.”*

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2).
 - b. Locate the modules to be removed in the locator diagram *External modules*, Figure 6–1 on page 6–12.
 - c. Do the procedure *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel*, steps 1–5, immediately preceding this procedure.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its front is facing you.
3. *Remove the front-panel assembly:*
 - a. Lift the front-panel assembly out of the front subpanel until you can reach the interconnect cable connecting it to the processor/display board.
 - b. Disconnect that cable at J2 of the processor/display board. Disconnect the flex-board connector at P3 of the front-panel assembly. (The flex board is part of the display-frame assembly.) Disconnect cable W76. See Figure 6–9 on page 6–24.
 - c. Finally, lift the front-panel assembly out of the front subpanel to complete the removal.




Figure 6-9: A12 Front-panel assembly removal

Display-Frame Assembly

1. *Assemble equipment and locate modules to be removed:* Have handy a screwdriver with a size T-15 Torx® (Items 1 and 2). Locate the modules to be removed in the locator diagram *Outer-chassis modules*, Figure 6-2, page 6-13.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its front is facing you.

3. *Remove the display-frame assembly:*
 - a. Do the procedure *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel* (page 6–22) to remove the front cover and trim ring.
 - b. Lift the front-panel assembly out of the front subpanel until you can reach J2 on the front-panel assembly. Disconnect the flex cable coming from the display-frame assembly at J39 of the front-panel assembly.
 - c. Do the procedure *Floppy Disk Drive* (page 6–44) to remove the floppy disk drive.
 - d. Remove the three screws securing the display-frame assembly to the front subpanel and remove that assembly.
4. *Reinstallation:*
 - a. Do, in reverse order, substeps 3b–3d, reversing each step to reinstall the display-frame assembly. Then see the procedure *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel* (page 6–22) to complete reassembly of the oscilloscope.

Cabinet Modules

1. *Assemble equipment and locate modules to be removed:* Have handy a pair of needle-nose pliers (Item 6). Locate the modules to be removed in the locator diagram *External modules* (see Figure 6–1 on page 6–12).
2. *Orient the oscilloscope:* Set the oscilloscope so the left side is down on the work surface and its handle is facing upwards.
3. *Remove the handle (see Figure 6–10 on page 6–27) :*
 - a. Insert the tips of a pair of needle-nose pliers (Item 6) into the hole of either handle cap. Push and hold to depress the handle release.
 - b. While holding the handle released, pull it out of the slot in the handle cap. Repeat procedure to remove the handle from the other handle cap.
 - c. Reverse procedure to reinstall.
4. *Remove the handle caps:*
 - a. Insert the retaining ring pliers (Item 8) into the opening created in the handle cap when you removed the handle.
 - b. While using the pliers to expand the handle cap outward, grasp it and snap it off.
 - c. Repeat procedure to remove the remaining cap as needed; push the cap(s) back on to reinstall.

5. *Remove the flip stand:* Grasp the flip stand by both sides near where it joins each flip stand foot. Now compress the flip stand until the flip stand ends clear the flip stand feet to complete the removal.
6. *Remove the flip stand foot (or feet):*
 - a. Do *Rear Cover and Cabinet* procedure (page 6–18) to gain access to inside of the cabinet.
 - b. Working from inside the cabinet, push the two retainers to release the flip stand foot you wish to remove and lift it away from the outside of the cabinet.
 - c. Repeat procedure to remove as many of the remaining feet as needed; insert the two retainers back in their slots in the cabinet and snap into place any flip stand foot removed.
7. *Reinstallation:* If any flip stand feet were removed, reinstall as directed in step 6c; then see *Rear Cover and Cabinet* procedure (page 6–18) to reinstall the rear cover and cabinet. Do in reverse order steps 3 and 5, reversing each step, to reinstall the flip stand, then the handle caps (if removed), then the handle.




Figure 6-10: Cabinet modules removal

Procedures for Outer-Chassis Modules

You should have completed the *Access Procedure* (page 6–15), before doing any procedure in this collection. The procedures found here, listed in order presented, follow.

- Fan
- A14 D1 Bus and Analog-Power and Digital-Power Cables
- A23 SerPar Board
- A29 Video Trigger Board
- A11 Processor/Display Board
- Hard Disk Drive
- Top Cover and Board Brackets
- Rear-Panel Cables
- A10 Acquisition Board
- Floppy Disk Drive
- Rear Chassis

- Fan**
1. *Assemble equipment and locate module to be removed:* Have handy a screwdriver with a size T-20 Torx® tip (Items 1 and 3). Locate the fan in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13.
 2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its left side is facing you.
 3. *Disconnect the fan from processor/display board:* Unplug the fan's power cable from J20.
 4. *Remove the fan:* Remove the two screws securing the fan to the main chassis, and lift the fan away from the chassis.
 5. *Reinstallation:* Do in reverse order substeps 3 and 4, reversing the removal instructions in each substep to reinstall the assembly. See the procedure *Rear Cover and Cabinet* (page 6–18) to complete reassembly of the oscilloscope.

**A14 D1 Bus and
Analog-Power and
Digital-Power Cables**

1. *Assemble equipment and locate modules to be removed:* Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2). Find the modules to be removed in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13.

2. *Orient the oscilloscope:* Set the oscilloscope so its left side is down on the work surface and its front is facing you.
3. *Remove the D1 bus:* Grasp the D1 bus and pull it up from the oscilloscope to unplug it from its two plug-in connectors. (J28 is the connector on the processor/display board; J100 is on the acquisition board.) Reverse these removal instructions to reinstall.
4. *Remove the analog-power and digital-power interconnect cables:*
 - a. Unplug the analog-power cable at J26 on the display processor board, at J5 on the low-voltage power supply, and at J700 on the acquisition board.
 - b. Unplug the digital-power cable at J27 on the display processor board, at J6 on the low-voltage power supply, and at J101 on the acquisition board.




Figure 6–11: A14 D1 bus and analog-power and digital-power cables removal

5. *Reinstallation:*
 - a. Do in reverse order steps 3 and 4, reversing the procedure outlined in each step to reinstall the assembly.
 - b. When installing the D1 bus be sure to orient it so the single connector at the bottom of the bus plugs into the acquisition board.

- c. See the procedure *Rear Cover and Cabinet* (page 6–18) to complete reassembly of the oscilloscope.

**A23 SerPar Board —
RS232/Centronics
Hardcopy Interface
(Optional on Some
Models)**

1. *Remove circuit board assembly:*
 - a. Using a screwdriver with size T-15 Torx® tip, remove the two screws (number 4 in Figure 6–12) securing the rear plate of the circuit board assembly.
 - b. Disconnect the cable connector (number 2) from the processor-display circuit board connector (number 1).
 - c. Pull out the A23 SerPar Board assembly (number 3).




Figure 6–12: Remove circuit board assembly from oscilloscope

2. *Remove circuit board from assembly:*

- a. Using a $\frac{3}{16}$ inch nutdriver, remove the four lock connectors (number 3 in Figure 6–13) securing the circuit board to the rear plate.
- b. Separate the circuit board with attached cable (number 1), from the rear plate with attached brackets (number 2).




Figure 6–13: Remove circuit board from assembly

3. *Replace circuit board:*

Equipment Required: One $\frac{3}{16}$ inch nutdriver.

- a. Replace the failed circuit board with a replacement A23 SerPar Board ordered from the factory (see *Replaceable Parts List* for detailed ordering information). Do in reverse order steps a and b of the *Circuit Board Removal From Assembly* procedure on the previous page.
- b. Reinstall the A23 SerPar Board assembly in the oscilloscope. Do in reverse order steps a and b of the *Remove circuit board from assembly* procedure shown above.
- c. Then see the following procedure to complete reassembly of the oscilloscope:
 - *Rear Cover and Cabinet* (page 6–18).
- d. To ensure the A23 SerPar Board is working correctly, perform the power-up short diagnostics procedure described on page 6–59.

A29 Video Trigger Board

Additional modules Removed: D1 bus and analog-and digital-power cables.

1. *Assemble equipment and locate modules to be removed*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2).
 - b. Locate the modules to be removed in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13. See also the A29 Video Trigger Board on Figure 6–15, page 6–34.
 - c. Do the procedures *A14 D1 Bus and Analog-Power and Digital-Power Cables* and *A23 SerPar Board* that precede this procedure to remove those items. It is **not** necessary to pull the A23 board assembly out entirely nor is it necessary to remove the cable connector from the A23 SerPar board to the A11 Processor/Display board
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its front is facing you.
3. *Remove the A29 Video Trigger board:* Figure 6–14 shows the A29 Video Trigger board (option 05) installed.
 - a. Remove (or pull loose) the A27 Connector board (see number 3 on Figure 6–15).
 - b. Slide back and lift up the Video Trigger circuit board (see Figure 6–15).




Figure 6-14: Circuit board installed




Figure 6–15: Circuit board removal

4. Reinstallation:

- a.** Do, in reverse order, steps a through e. Reverse the removal instructions of each step to reinstall the A29 Video Trigger Board.

NOTE. For the TDS 600C, be sure to arrange the coax cable as shown in figures 6–14 and 6–15. Failure to do this may impair performance.

Also, when plugging in the digital bus boards, 1 and 3 in Figure 6–15, make sure that they remain plugged in on both ends.

- b. See the procedures *A14 D1 Bus and Analog-Power and Digital-Power Cables* (page 6–28), *A23 SerPar Board* (page 6–30) and *Rear Cover and Cabinet* (page 6–18) to complete reassembly of the oscilloscope.
- c. To ensure the Video Trigger is working correctly, perform the *Diagnostics* procedure on page 6–59.

A11 Processor/Display Board

Additional Modules Removed: D1 bus and analog-and digital-power cables, A23 SerPar Board, and, if option 05 is installed, A29 Video Trigger Board.

1. *Assemble equipment and locate modules to be removed*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2).
 - b. Locate the modules to be removed in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13.
 - c. Do the procedure *A14 D1 Bus and Analog-Power and Digital-Power Cables* that precedes this procedure to remove those interconnect cables.
 - d. Do the procedure *A23 SerPar Board* and, if option 05 is installed, do the procedure *A29 Video Trigger Board*.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its rear is facing you.
3. *Disconnect the fan from processor/display board:* Unplug the fan's power cable from J20.
4. *Remove the processor/display board:* Use Figure 6–16 as a guide while doing the following substeps:
 - a. Unplug the interconnect cable from the GPIB connector on the rear cover at J35 of the processor/display board. Disconnect the monitor cable at J5. Unplug J62 video signal connector, J51 RS-232 connector, and J38 floppy driver connector.
 - b. Grasp the board by its right and left sides and pull it towards the rear of the oscilloscope. This will disconnect the processor/display board from the eight board mounts securing the board above the top cover.
 - c. Lift the board up away from the oscilloscope chassis to complete the removal.
5. *Reinstallation:*
 - a. Do, in reverse order, steps 3 through 4 reversing the removal instructions of each step to reinstall the processor/display board.
 - b. See the procedures *A14 D1 Bus and Analog-Power and Digital-Power Cables* (page 6–28), *A23 SerPar Board* (page 6–30), if option 05 is

installed, *A29 Video Trigger Board*, and *Rear Cover and Cabinet* (page 6–18) to complete reassembly of the oscilloscope.




Figure 6–16: A11 Processor/display removal

Hard Disk Drive (Optional)

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2).
 - b. Locate the modules to be removed in the locator diagram *Outer-Chassis Modules*, Figure 6-2, page 6-13.
 - c. Do the procedures *A14 D1 Bus and Analog-Power and Digital-Power Cables* (page 6-28), *A23 SerPar Board* (page 6-30), if option 05 is installed *A29 Video Trigger Board* (page 6-32) and *A11 Processor/Display Board* (page 6-35) to remove those modules.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its rear is facing you.
3. *Remove the hard disk drive:* Use Figure 6-17 as a guide.
 - a. Slide the retainer bracket toward the rear of the oscilloscope. Lift the bracket up and away from the oscilloscope to complete the removal.
 - b. Grasp the board by its right and left sides and pull it towards the rear of the oscilloscope. This will disconnect the hard disk board from the board mounts securing the board above the top cover.
 - c. Lift the board up away from the oscilloscope chassis to complete the removal.
4. *Reinstallation:*
 - a. Do, in reverse order, steps 3a through 3c. Reverse the removal instructions of each step to reinstall the hard disk drive.
 - b. See the procedures *A11 Processor/Display Board* (page 6-35), if option 05 is installed *A29 Video Trigger Board* (page 6-32), *A23 SerPar Board* (page 6-30), *A14 D1 Bus and Analog-Power and Digital-Power Cables* (page 6-28), and *Rear Cover and Cabinet* (page 6-18) to complete reassembly of the oscilloscope.




Figure 6-17: Hard disk removal

Top Cover and Board Brackets

1. Assemble equipment and locate modules to be removed:

- a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2) and, if removing any *board mount*, a flat-bladed screwdriver (Item 5).
 - b. Locate the modules to be removed in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13.
 - c. Do the procedures *A14 D1 Bus and Analog-Power and Digital-Power Cables* (page 6–28), *A23 SerPar Board* (page 6–30), if option 05 is installed *A29 Video Trigger Board* (page 6–32) and *A11 Processor/Display Board* (page 6–35) to remove those modules.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its front is facing you.
3. *Remove the top cover:* Remove the 12 screws securing the top cover to the main chassis, then slide it back until its front edge clears the retainers in the front subpanel. Lift the top cover away to complete removal.
4. *Remove the board mount(s):* From the top side of the top cover, use the flat-bladed screwdriver to pry up the retainer lug until it clears the slot in the front cover. While holding the lug clear of the slot, push the mount towards the rear until it releases. (When reinstalling, be sure to align the lug properly and be sure it snaps into its slot.)




Figure 6–18: Board bracket removal

5. *Reinstallation:*

- a. Do in reverse order steps 3 and 4, reversing the procedure outlined in each step to reinstall the assembly. Then see the following procedures, in the order listed, to complete reassembly of the oscilloscope.
 - A11 Processor/Display Board (page 6–35)
 - If option 05 is installed, A29 Video Trigger Board (page 6–32)
 - A14 D1 Bus and Analog-Power and Digital-Power Cables (page 6–28)
 - A23 SerPar Board (page 6–30)
 - Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel (page 6–22)
 - Rear Cover and Cabinet (page 6–18)

Rear-Panel Cables

1. *Assemble equipment and locate modules to be removed:* Have available a pair of needle-nose pliers (Item 6) and a $\frac{1}{4}$ inch nut driver (Item 7).
2. *If removing the GPIB cable, do the following substeps:*
 - a. Unplug the GPIB cable from its jack (J35) on the processor/display board.
 - b. Working from the rear panel and using the $\frac{1}{4}$ inch nut driver, unscrew the two hex-headed mounting posts that secure the cable to the rear chassis.
 - c. Working from inside the oscilloscope, lift the cable out of the rear chassis.
3. *If removing any cable connected to the rear panel BNC connectors, do the following substeps:*
 - a. Do the procedure A10 Acquisition Board, on page 6–40.
 - b. Pull out the cables for SIGNAL OUTPUT, AUX TRIGGER INPUT, MAIN TRIGGER OUTPUT, and DELAYED TRIGGER OUTPUT from J1201, J1001, J1000, and J1550 on A10.
4. *Reinstallation:* Reverse substeps in step 2 and 3 to reinstall any cables removed.

A10 Acquisition Board

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2).
 - b. Locate the modules to be removed, including those listed under *Additional Modules Removed* in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13.

- c. Do the procedure *A14 D1 Bus and Analog-Power and Digital-Power Cables* (page 6–28) to remove the D1 bus and the interconnect cables.
 - d. Do the procedure *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel* (page 6–22)
 2. *Orient the oscilloscope:* Set the oscilloscope so its top is down on the work surface and its front is facing you.
 3. *Remove the Acquisition Board:* Use Figure 6–19 or 6–20 as a guide.
 - a. Disconnect the cables from (CH 3) SIGNAL OUT (except TDS 694C, at J1201), AUX TRIG INPUT (at J1550), MAIN TRIG OUTPUT (at J1000), DELAYED TRIG OUTPUT (at J1001), TDS 694C (J124).
 - b. If the option 05 video board is installed, disconnect the coax cable attached to J1500.
 - c. Remove the six screws (seven screws for TDS 694C) that mount the acquisition board to the main chassis.



CAUTION. Use care not to damage SMT components when removing or installing the screws that mount the acquisition board to the main chassis.

- d. Remove the four or five front-panel screws that attach the frame to the attenuator portion of the A10 Acquisition board. Lift the board away from the main chassis to complete removal.
 4. *Reinstallation:* Do, in reverse order, substeps 3a to 3d, reversing each step to reinstall the *acquisition board*. Then see the following procedures, in the order listed, to complete reassembly of the oscilloscope:
 - *A14 D1 Bus and Analog-Power and Digital-Power Cables* (page 6–28).
 - *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel* (page 6–22).
 - *Rear Cover and Cabinet* (page 6–18).




Figure 6-19: A10 Acquisition board removal




Figure 6-20: TDS 694C, A10 Acquisition board removal

Floppy Disk Drive

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a small Phillips head.
 - b. Locate the modules to be removed, including those listed under *Additional Modules Removed* in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13.
2. Do the procedure *Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel* (page 6–22)
3. *Orient the oscilloscope:* Set the oscilloscope so its top is down on the work surface and its front is facing you.
4. *Remove the floppy disk drive:* Use Figure 6–21 as a guide.
 - a. Unplug the J38 connector (ribbon interconnect cable) that connects the disk drive to the A11 Processor/Display board.
 - b. Remove the disk drive by unscrewing the two retaining Phillips screws on the sides of the disk drive. Then pull out the drive.

NOTE. Due to vendor differences in floppy disk drive dimensions, your instrument may include an adapter bracket on the bottom of the drive. If this is the case, use the inset in Figure 6–21 as a guide for installation.




Figure 6-21: Floppy disk drive removal

5. *Reinstallation:* Do, in reverse order, substeps 4b then 4a to reinstall the *floppy disk drive*. Then see the following procedures, in the order listed, to complete reassembly of the oscilloscope:
 - Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel (page 6-22).
 - Rear Cover and Cabinet (page 6-18).

Rear Chassis

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2).
 - b. Locate the modules to be removed, including those listed under *Additional Modules Removed* in the locator diagram *Outer-Chassis Modules*, Figure 6–2, page 6–13.
 - c. Install the front cover if it is not already installed.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its rear is facing you.
3. *Remove the rear chassis:* Use Figure 6–22 as a guide when doing the following substeps:
 - a. Unplug the GPIB interconnect cable at J35 of the processor/display board.
 - b. Unplug the video cable at J51 of the processor/display board.
 - c. Remove the 6 screws securing the rear chassis to the main chassis and the two screws securing it to the low-voltage power-supply shield.
 - d. Lift the rear chassis up slightly to access the cables connected to it. Disconnect those cables from (CH 3) SIGNAL OUT (at J1201), AUX TRIG IN (at J1550), MAIN TRIG OUT (at J1000), DELAYED TRIG OUT (at J1001), all found on the acquisition board.
4. *Reinstallation:* Do, in reverse order, substeps 3a–3c, reversing each step to reinstall the rear chassis. Then see the following procedures, in the order listed, to complete reassembly of the oscilloscope.
 - A14 D1 Bus and Analog-Power and Digital-Power Cables (page 6–28)
 - Rear Cover and Cabinet (page 6–18)




Figure 6-22: Rear chassis removal

Procedures for Inner-Chassis Modules,

You should have completed the *Access Procedure* (page 6–15) before doing any of the procedures for the Inner-Chassis modules. The procedures are presented in the following order:

A16 Low Voltage Power Supply

A30 Display Assembly and Supply Fuse

Front Subpanel

Main Chassis

A16 Low Voltage Power Supply

1. *Assemble equipment and locate modules to be removed:* Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2). Locate the modules to be removed in the locator diagram *Inner-Chassis Modules*, Figure 6–2, page 6–13.
2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its rear is facing you.
3. *Remove the low-voltage power supply:*
 - a. Working from the rear of the oscilloscope, remove the two screws securing the low-voltage power supply to the rear chassis. See Figure 6–23.
 - b. Now, working from the top of the oscilloscope, remove the seven screws, indicated in Figure 6–23, that mount the supply to the main chassis.
 - c. Grasp the supply at the points indicated in Figure 6–23 and lift the board up out of the oscilloscope to complete removal.
4. *Reinstallation:* Do, in reverse order, substeps **3a** through **3c** reversing each step to reinstall the low-voltage power supply. Then see the following procedures to complete the reassembly:
 - Top Cover and Board Brackets (page 6–38)
 - A11 Processor/Display Board (page 6–35)
 - If option 05 is installed, *A29 Video Trigger Board* (page 6–32)
 - A14 D1 Bus and Analog-Power and Digital-Power Cables (page 6–28)
 - Rear Cover and Cabinet (page 6–18)




Figure 6–23: A16 Low voltage power supply removal

A30 Display Assembly and Supply Fuse

NOTE. The display and the display-driver board are a single module and must be removed and replaced as such. They are listed as a single module in the Replaceable Parts List.

1. *Assemble equipment and locate modules to be removed:* Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2). Locate the modules to be removed in the locator diagram *Inner-Chassis Modules*, Figure 6–2, page 6–13.

2. *Orient the oscilloscope:* Set the oscilloscope so its bottom is down on the work surface and its rear is facing you.
3. *Remove the high-voltage fuse:* If you are servicing this fuse, remove the fuse from its fuse holder. Reverse the procedure to reinstall.



WARNING. Display tube handling: Use care when handling a display tube. If you break a display tube it may implode, scattering glass fragments with high velocity and possibly injuring you. Wear protective clothing, including safety glasses (preferably a full-face shield). Avoiding striking the display tube with or against any object.

Display tube storage: Store the display tube face down in a protected location, placing it on a soft, nonabrasive surface to prevent scratching the face plate.

4. *Remove the display tube:*
 - a. Take the precautions outlined in the warning above. Reference Figure 6–24 while doing the following substeps.
 - b. Unplug the display tube connector from the back of the display tube and the display tube yoke connector from the display circuit board (J170, J305 and J570). Loosen the screw on the video board that holds the CRT sockets. Then pull back on the video board slightly. This separates the board from the socket.
 - c. Remove the two screws that secure the band circling the front of display tube to the front subpanel. Carefully guide display tube forward to partially remove it from the front subpanel and to access the anode lead connected to the display tube.



WARNING. High-voltage is present on the anode lead. Before unplugging the anode in the following substep, you must discharge it: ground a flat-bladed screwdriver (Item 5) with an insulated handle to the chassis through a suitable grounding strap. Next, probe under the insulating cap of the anode lead and touch the lead's metal conductor to discharge. Repeat. After unplugging the anode in substep d, touch its metal conductor to the chassis for a few minutes to further ensure discharge.

- d. Discharge the anode lead as described in the immediately proceeding **WARNING**, unplug it from the display tube, and discharge that lead (again, see **WARNING**).
- e. Be sure you have read the **WARNING** on display tube handling and storage found at the start of this display tube removal procedure. Then pull the display tube out through the front subpanel to complete removal. Store as directed in the previous **WARNING** message.




Figure 6–24: Display assembly removal

5. *Remove the display supply board:* Use Figure 6–25 as a guide.
 - a. Remove the six screws that mount the display-driver board to the main chassis.
 - b. Grasp the display driver board. Work from the front and top to tilt the board so its right edge is up and its left side is down and lift it out of the top of the oscilloscope's main chassis.




Figure 6-25: Display driver board removal

6. Reinstallation:

- a. Do, in reverse order, substeps 5a–5b, reversing each step to reinstall Display-Driver board.
- b. Do, in reverse order, substeps 4a–4e, reversing each step to reinstall the display tube if removed.
- c. See step 3 to reinstall the supply fuse if it was removed.
- d. See the following procedures, in order, to complete reassembly of the oscilloscope:
 - Top Cover and Board Brackets (top cover only) on page 6–38
 - A11 Processor/Display Board (page 6–35)
 - If option 05 is installed, A29 Video Trigger Board (page 6–32)
 - A14 D1 Bus and Analog-Power and Digital-Power Cables (page 6–28)

- Display-Frame Assembly
- Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel (page 6–22)
- Rear Cover and Cabinet (page 6–18) (completes reassembly)

Front Subpanel

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2).
 - b. Do the procedure *A30 Display Assembly and Supply Fuse* (page 6–49). Do not remove the display-driver board.
 - c. Locate the modules to be removed in the locator diagram *Inner-Chassis Modules*, Figure 6–2, page 6–13.
2. *Orient the oscilloscope:* Set the oscilloscope so its rear is down on the work surface and its bottom is facing you.
3. *Remove the front subpanel:* Remove the six screws securing the front subpanel to the main chassis. (See Figure 6–26 for screw locations.) Lift the front subpanel up away from the main chassis to complete the removal.
4. *Reinstallation:* Do the following substeps to reinstall the front subpanel and reassemble the remainder of the oscilloscope:
 - a. Align the front subpanel to the main chassis, taking care to ensure that the main chassis slips into its alignment slot on the front subpanel (see magnified view, Figure 6–26.) Then reinstall the six screws removed in step 3.
 - b. See the procedure *A30 Display Assembly and Supply Fuse* (page 6–49) to reinstall the display-frame assembly and display tube.
 - c. See the following procedures, in the order listed, for instructions for reinstalling the remaining modules.
 - Top Cover and Board Brackets (page 6–38)
 - A11 Processor/Display Board (page 6–35)
 - If option 05 is installed, A29 Video Trigger Board (page 6–32)
 - A14 D1 Bus and Analog-Power and Digital-Power Cables (page 6–28)
 - Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel (page 6–22)
 - *Rear Cover and Cabinet* (page 6–18)




Figure 6-26: Front subpanel removal

Main Chassis *Additional Modules Removed: All.*

1. *Remove the main chassis:* Since the removal of the main chassis requires the removal of virtually all modules, do the procedure *Disassembly for Cleaning* that follows. While doing *Disassembly for Cleaning*, you will remove the front-panel assembly. Ignore the instructions to disassemble that assembly.
2. *Reinstallation:* See reinstallation instructions in *Disassembly for Cleaning*.

Disassembly for Cleaning

This procedure is for disassembly of the digitizing oscilloscope into its individual modules so they can be cleaned. For the cleaning instructions, see *Inspection and Cleaning*, which begins this section.

1. *Assemble equipment and locate modules to be removed:*
 - a. Have handy a screwdriver with a size T-15 Torx® tip (Items 1 and 2), a T-20 Torx® tip (Item 3), a flat-bladed screwdriver (Item 6–11), and a pair of angle-tip tweezers (Item 6–11).
 - b. Familiarize yourself with the modules illustrated in figures 6–1 through 6–3.
2. *Remove external modules:* Do in order the following procedures. They are found under *Procedures for External Modules* which starts on page 6–16.
 - a. Line Fuse and Line Cord (page 6–17)
 - b. Rear Cover and Cabinet (page 6–18)
 - c. Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel (page 6–22)
 - d. A12 Front-Panel Assembly (page 6–23)
 - e. Front Subpanel (page 6–53) and Display-Frame Assembly
3. *Remove the outer-chassis modules:* Do in order the following procedures. They are found under *Procedures for Outer-Chassis Modules* which start on page 6–28.
 - a. Fan (page 6–28)
 - b. A14 D1 Bus and Analog-Power and Digital-Power Cables (page 6–28)
 - c. A23 SerPar Board (page 6–30)
 - d. A29 Video Trigger Board – with option 05 (page 6–32)
 - e. A11 Processor/Display Board (page 6–35)
 - f. Hard Disk Drive (page 6–37)
 - g. Top Cover and Board Brackets (page 6–38)
 - h. A10 Acquisition Board (page 6–40)
 - i. Floppy Disk Drive (page 6–44)

4. *Remove the inner-chassis modules:* Do in order the following procedures. They are found under *Procedures for Inner-Chassis Modules*, which start on page 6–48.
 - a. A16 Low Voltage Power Supply (page 6–48)
 - b. A30 Display Assembly and Supply Fuse (page 6–49)
5. *Disassemble the chassis:*
 - a. Set the assembly so its bottom is down on the work surface and its front is facing you.
 - b. Remove the six screws securing the front subpanel to the main chassis. (See Figure 6–26 for screw location.)
 - c. Lift the front subpanel up away from the main chassis.
 - d. Now remove the five screws securing the rear chassis to the main chassis and separate the two chassis. (See Figure 6–22 on page 6–47 for screw location.)
6. *Reassembly:* Do the following substeps:
 - a. *Reassemble the chassis:* Align the rear chassis to the main chassis and reinstall the five screws removed in step 5; align the front subpanel to the main chassis and reinstall the six screws removed in step 5.

NOTE. *The following substeps refer you to procedures for installing each module removed. When reinstalling the modules, ignore any instructions that require connecting a cable or bus to an module that you have not yet installed. The necessary connections will be made when you install the missing module later.*

- b. *Reinstall the inner-chassis modules:* Do in the order listed below. When reinstalling, do the removal steps in reverse order. These procedures are found under *Procedures for Inner-Chassis Modules*, which start on page 6–48.
 - A30 Display Assembly and Supply Fuse (page 6–49)
 - A16 Low Voltage Power Supply (page 6–48)
- c. *Reinstall the outer-chassis modules:* Do in the order listed in the following procedures. When doing these procedures, do their steps in reverse order. These procedures are found under *Procedures for Outer-Chassis Modules* which start on page 6–28.
 - Top Cover and Board Brackets (page 6–38)
 - Hard Disk Drive (page 6–37)

- A11 Processor/Display Board (page 6–35)
 - A23 SerPar Board (page 6–30)
 - A29 Video Trigger Board – with option 05 (page 6–32)
 - A14 D1 Bus and Analog-Power and Digital-Power Cables (page 6–28)
 - Fan (page 6–28)
 - Floppy Disk Drive (page 6–44)
 - A10 Acquisition Board (page 6–40)
- d. *Reinstall external modules:* Do in the order listed in the following procedures. When doing these procedures, do the steps in reverse order. These procedures are found under *Procedures for External Modules* which starts on page 6–16.
- Front Subpanel (page 6–53)
 - Display-Frame Assembly (page 6–49)
 - A12 Front-Panel Assembly (page 6–23)
 - Front Cover, Trim Ring, Menu Buttons, and Attenuator Panel (page 6–22)
 - Rear Cover and Cabinet (page 6–18)
 - Line Fuse and Line Cord (page 6–17)

Troubleshooting

This subsection contains information and procedures designed to help you isolate faulty modules in the oscilloscope. If a module needs to be replaced, follow the *Removal and Installation Procedures* located in this section.

Diagnostics

The oscilloscope has two levels of internal diagnostics that focus on verifying, adjusting, and if need be, isolating faulty modules.

Both levels of internal diagnostics report any bad modules and/or interfaces. If a bad module and/or interface is found, use the troubleshooting procedures in this section to determine which module needs to be replaced.

The two levels of diagnostics are the short confidence set and the extended set that tests the oscilloscope circuitry in depth and takes more time. At power on, the oscilloscope automatically executes the short set. The extended set is optional and is executed by using the following procedure:

Prerequisites: Power on the oscilloscope and allow a 20 minute warm-up before doing this procedure.

1. *Display the System diagnostics menu:*
 - a. Press **SHIFT**; then press **UTILITY**.
 - b. Repeatedly press the main-menu button **System** until **Diag/Err** is highlighted in the pop-up menu.
2. *Run the System Diagnostics:* Press the main-menu button **Execute**; then press the side-menu button **OK Confirm Run Test**.
3. *Wait:* The internal diagnostics do an exhaustive verification of proper oscilloscope function. This verification will take about two minutes. When finished, the oscilloscope will display a report of any bad modules and/or interfaces.



Firmware Updates

Oscilloscope firmware updates are easy to do. Simply install the firmware disks on your PC and follow the instructions in the README file located on the first disk.

NOTE. You must set the Protection switch to the unprotected position before updating the Firmware. Figure 6–27 shows how to set the switch. After loading the Firmware, be sure you set the switch back to the protected position and cycle power.

If you want to order a firmware update, contact your Tektronix service center.




Figure 6–27: Accessing the protection switch

Hard Disk Drive Maintenance

Use the same procedures to maintain the oscilloscope hard disk drive that you use to maintain a hard disk drive in a personal computer.

The easiest procedure is to format the disk using the File Utilities Format command. Format will destroy all data currently on the disk.

Using ScanDisk on a personal computer will attempt to fix the disk without destroying data on the disk. If ScanDisk does not repair the disk, replace the disk drive. To use ScanDisk, perform the following steps:

1. Remove the hard disk drive from the oscilloscope.
2. Install the hard disk drive into a Type III PCMCIA card slot.
3. Power up the computer and run ScanDisk. Set Scandisk to perform a thorough surface scan and to automatically fix errors.
 - Using Microsoft Windows 95: select Start\Programs\Accessories\System Tools\ScanDisk
 - Using Microsoft Windows 3.1: exit Windows and use the MSDOS procedure
 - Using Microsoft MSDOS: enter `SCANDISK drive: /SURFACE /AUTOFIX`
4. If ScanDisk will not repair the disk, install a new hard disk drive.




Figure 6-28: Primary troubleshooting procedure




Figure 6-28: Primary troubleshooting procedure (cont.)




Figure 6–29: Module isolation troubleshooting procedure




Figure 6-30: A16 Low voltage power supply module isolation troubleshooting procedure

Table 6–5: Normal supply voltages (measured on J26 and J27 on the A11 DRAM Processor/Display module)

Supply	Lower Limit	Upper Limit
Ground (J26 or J27 pin 15)		
+5.1 VA (J27 pin 5)	+5.0 V	+5.2 V
+5.1 VB (J27 pin 17)	+5.0 V	+5.2 V
+25 V (J27 pin 1)	+23.5 V	+27.5 V
+5 V (J26 pin 39)	+4.9 V	+5.1 V
–5.1 V (J26 pin 17)	–4.9 V	–5.2 V
+15 V (J26 pin 11)	+14.7 V	+15.3 V
–15 V (J26 pin 7)	–14.7 V	–15.3 V

Table 6–6: No-load supply voltages (measured on J5 and J6 on the A17 Main LV Power Supply module)

Supply	Lower Limit	Upper Limit
Ground (J5 or J6 pin 15)		
+5.1 VA (J6 pin 5)	+4.95 V	+5.25 V
+5.1 VB (J6 pin 17)	+4.95 V	+5.25 V
+25 V (J6 pin 1)	+23.5 V	+27.5 V
+5 V (J5 pin 39)	+0.59 V	+0.81 V
–5.1 V (J5 pin 17)	–0.39 V	–0.61 V
+15 V (J5 pin 11)	+1.05 V	+1.75 V
–15 V (J5 pin 7)	–1.05 V	–1.75 V




Figure 6–31: Power supply voltage measurement locations




Figure 6-32: Color display troubleshooting procedure




Figure 6-33: Horizontal and vertical sync signals – color display




Figure 6-34: A video signal with white, black, and blanking levels – color display




Figure 6-35: Processor/acquisition troubleshooting procedure




Figure 6-36: Processor/front panel troubleshooting procedure




Figure 6–37: Attenuator/acquisition troubleshooting procedure



CAUTION. Only probe points specified in the procedures. You can cause catastrophic damage if you attempt to probe other points.




Figure 6-38: A11 DRAM Processor/Display module




Figure 6–39: A10 Acquisition module (test points)

Options and Accessories

This section describes the various options as well as the standard and optional accessories that are available for the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscope.

Options

Tektronix will ship the options shown in Table 7–1:

Table 7–1: Options

Option #	Label	Description
A1	Universal European power cord	220 V, 50 Hz power cord
A2	UK power cord	240 V, 50 Hz power cord
A3	Australian power cord	240 V, 50 Hz power cord
A4	North American power cord	240 V, 60 Hz power cord
A5	Switzerland power cord	220 V, 50 Hz power cord
HD	Hard disk drive	Add a hard disk.
05	Video trigger	Oscilloscope comes with tools for investigating events that occur when a video signal generates a horizontal or vertical sync pulse. These tools allow investigation of a range of NTSC, PAL, SECAM, and high definition TV signals. (Option is not available on the TDS 794D.)
13	RS-232/Centronics Hard-copy Interface Ports	Add RS-232-C and Centronics interface ports. (Option applies to TDS 500D only.)
1G	1 GS/s maximum	Limit sample rate to 1 GS/s maximum. (Option applies to TDS 520D, TDS 540D, TDS 724D and TDS 754D only.)
1K	Scope cart	K420 scope cart. This cart can help transport the oscilloscope around many lab environments.
1M	130,000 record length	Extend record length from 50,000 samples standard as follows: TDS 520D and TDS 724D: To 250,000 samples on one channel and 130,000 on two channels TDS 540D, TDS 580D, TDS 754D, TDS 784D, and TDS 794D: To 500,000 samples on one channel, 250,000 on two channels, and 130,000 samples on three or four channels (Option is only available for the models listed above.)
1M	120,000 samples record length	Extend record length from 30,000 samples standard (Option applies only to TDS 694C.)

Table 7–1: Options (cont.)

Option #	Label	Description
2M	8 M acquisition length	Extend standard acquisition length as follows: TDS 520D and TDS 724D: To 2 M samples on two channels and 4 M on one channel TDS 540D, TDS 580D, TDS 714L, TDS 754D, TDS 784D, & TDS 794D: To 2 M samples on three or four channels, 4 M on two channels, and 8 M samples on one channel (Option includes a hard disk and is only available for the models listed above.)
1R	Rackmount	Oscilloscope comes configured for installation in a 19 inch wide instrument rack. For later field conversions, order kit # 016-1236-00.
2C	Communication Signal Analyzer	Oscilloscope comes configured for communications signal triggering and mask testing. (Option applies to TDS 500D & TDS 700D only.)
3C	P6701B with system calibration	Oscilloscope comes with a P6701B and calibrated short-wavelength optical reference receiver on channel 1. (Option applies to TDS 500D & TDS 700D only, except TDS 794D.)
4C	P6703B with system calibration	Oscilloscope comes with a P6703B and calibrated long-wavelength optical reference receiver on channel 1. (Option applies to TDS 500D & TDS 700D only, except TDS 794D.)
31	Buffered passive probe	Add a 500 MHz P6339A 10x, buffered passive probe (Option applies only to TDS 794D.)
32	Active probe	Add a 4 GHz P6217 active probe (Option applies only to TDS 794D.)
33	Low capacitance probe	Add a 3.0 GHz (probe only) P6158 20x, 1 k Ω , low capacitance probe (Option applies only to TDS 580D, TDS 680C, TDS 684C, TDS 784D, and TDS 794D.)
34	Differential probe	Add a 1 GHz (probe only) P6247 differential probe
35	Active probe	Add a 1 GHz (probe only) P6243 active probe (Option applies only to TDS 754D, TDS 724D, TDS 714L, TDS 540D, and TDS 520D.)
36	Passive probe	Add a 500 MHz P6139A 10X passive probe (Option applies only to TDS 784D, TDS 714L, TDS 600C, and TDS 580D.)
37	Active probe	Add a 1.5 GHz P6245 active probe (Option applies only to TDS 794D, TDS 784D, TDS 680C, TDS 684C, and TDS 580D.)
38	Active probe	Add a 4 GHz (probe only) P6249 5X, small geometry active probe (Option applies only to TDS 694C and TDS 794D.)
39	Differential probe	Add a 1.5 GHz (probe only) P6248 small geometry active differential probe (Option applies only to TDS 694C and TDS 794D.)
2F	Advanced DSP math	Add advanced DSP math features such as FFT, integration, and differentiation. (Option applies only to TDS 500D models.)

Table 7–1: Options (cont.)

Option #	Label	Description
C3	Three years calibration	Provides three years of calibration
D1	Calibration data report	Oscilloscope comes with a calibration data report.
D3	Calibration data for C3	Provides calibration data for option C3
L1	Manuals in French	Provides Language versions of User Manual, according to option number chosen.
L3	Manuals in German	
L5	Manuals in Japanese	
L9	Manuals in Korean	

Standard Accessories

The oscilloscope comes standard with the accessories listed in Table 7–2.

Table 7–2: Standard accessories

Accessory	Part number
User Manual with Programmers Manual Help Disk	071-0130-XX
User Manual (with programmer disk 063-3060-XX) TDS 694C	071-0473-XX
TDS 714L Supplement (TDS 714L only)	071-0628-XX
TDS 600C Supplement (TDS 600C only)	071-0273-XX
Reference Manuals	020-2313-XX
Technical Reference: Performance Verification and Specifications	071-0630-XX
Probes: TDS 714L, TDS 754D and TDS 540D: Four P6139A 10X, 500 MHz Passive probes TDS 654C: Four P6243 1 GHz Active probes TDS 724D and TDS 520D: Two P6139A 10X, 500 MHz Passive probes TDS 794D, TDS 784D, TDS 684C, TDS 680C, TDS 580D, TDS 694C: No probes standard	P6139A P6243 P6139A
Front Cover	200-3696-01
Accessory Pouch (TDS 654C, TDS 684C, TDS 700D, TDS 714L without Option 1R)	016-1268-00
U.S. Power Cord	161-0230-01

Optional Accessories

You can also order the optional accessories listed in Table 7–3.

Table 7–3: Optional accessories

Accessory	Part number
Service Manual	071-0627-XX
Oscilloscope Cart	K420
Rack Mount Kit (for field conversion)	016-1236-00
Accessory Pouch (TDS 500D and TDS 680C)	016-1268-00
Soft-Sided Carrying Case	016-0909-01
Transit Case	016-1135-00
GPIB Cable (1 meter)	012-0991-01
GPIB Cable (2 meter)	012-0991-00
Centronics Cable	012-1214-00
RS-232 Cable	012-1298-00

Accessory Probes

Table 7–4 lists the recommended probes for each oscilloscope. Descriptions of each probe follow the table.

Table 7–4: Recommended probe cross reference

Probe	520D 540D	580D	654C	680C 684C	714L 724D 754D	784D	794D
Passive 1X	P6101B	P6101B	P6101B	P6101B	P6101B	P6101B	
10X	P6139A	P6139A	P6139A	P6139A	P6139A	P6139A	P6339A
100X	P5100	P5100	P5100	P5100	P5100	P5100	
1000X	P6015A	P6015A	P6015A	P6015A	P6015A	P6015A	
SMD	P6563A	P6563A	P6563A	P6563A	P6563A	P6563A	
Low Capacitance		P6158		P6158		P6158	P6158
Active CMOS/TTL	P6243	P6245	P6243	P6245	P6243	P6245	P6245
Active, High Bandwidth		P6245 P6217		P6245 P6217		P6245 P6217	P6245 P6217
Logic	P6408	P6408	P6408	P6408	P6408	P6408	
Differential Digital/ Telecom	P6246, P6247	P6247	P6246, P6247	P6247	P6246, P6247	P6247	P6247
Micro Volt	ADA400A	ADA400A	ADA400A	ADA400A	ADA400A	ADA400A	
High Voltage	P5205 P5210	P5205 P5210	P5205 P5210	P5205 P5210	P5205 P5210	P5205 P5210	
Current AC Only	P6021 P6022 CT-1 CT-2	P6021 P6022 CT-1 CT-2	P6021 P6022 CT-1 CT-2	P6021 P6022 CT-1 CT-2	P6021 P6022 CT-1 CT-2	P6021 P6022 CT-1 CT-2	CT-1 CT-2
Current AC/DC	TCP202 AM503S	TCP202 AM503S	TCP202 AM503S	TCP202 AM503S	TCP202 AM503S	TCP202 AM503S	TCP202 AM503S
Electro-Optical Converter	P6701B P6703B	P6701B P6703B	P6701B P6703B	P6701B P6703B	P6701B P6703B	P6701B P6703B	P6701B P6703B

- P6701B Optical-to-Electrical Analog Converter: 500 to 950 nm (DC to 1 GHz, 1 V/mW)
- P6703B Optical-to-Electrical Analog Converter: 1100 to 1700 nm (DC to 1.2 GHz, 1 V/mW)
- P6723 Optical Logic Probe: 1310 to 1550 nm (20 to 650 Mb/s, -8 to -28 dBm)
- AFTDS Differential Signal Adapter
- AMT75 75 Ω to 50 Ω Adapter
- P6243 Active, high speed digital voltage probe. FET. DC to 1.0 GHz
- P6245 Active, high speed digital voltage probe. FET. DC to 1.5 GHz
- P6246 Active, high bandwidth differential probe. FET. DC to 400 MHz
- P6247 Active, high bandwidth differential probe. FET. DC to 1 GHz
- P6248 Active, high bandwidth differential probe. FET. DC to 1.5 GHz
- P6249 Active, small geometry active probe, 5X, 4 GHz
- P6101B 1X, 15 MHz, Passive probe
- P6158 3.0 GHz, 20x, 1 K Ω , low capacitance probe
- P6139A 10X, 500 MHz Passive probe
- P6339A 500 MHz buffered passive, AC/DC coupling, 20/150 MHz bandwidth limit probe (for TDS 794D)
- P6217 Active, high speed digital voltage probe. FET. DC to 4 GHz. DC offset
- P6204 Active, high speed digital voltage probe. FET. DC to 1 GHz. DC offset
- P6563A Passive, SMD probe, 20X, 500 MHz

- P5100 High Voltage Passive probe, 2.5 kV, DC to 250 MHz
- P6015A High Voltage probe, 40 kV peak, 75 MHz
- P5205 High Voltage differential probe, 1.3 kV (differential), DC to 100 MHz
- P5210 Differential, high voltage probe, 5.6 kV (DC + peak AC) 50 MHz
- ADA 400A differential preamp, switchable gain
- AM 503S — DC/AC 50 MHz Current measurement system, AC/DC.
Supplied with A6302 Current Probe
- AM 503S Option 03: DC/AC 100 A Current measurement system, AC/DC.
Supplied with A6303 Current Probe
- AM 503S Option 05: DC/AC 100 MHz Current measurement system.
Supplied with A6312 Current Probe
- TCP 202 Current Probe, DC to 50 Mhz, 15 A DC
- P6021 AC Current probe. 120 Hz to 60 MHz
- P6022 AC Current probe. 935 kHz to 120 MHz
- CT-1 Current probe — designed for permanent or semi-permanent in-circuit installation. 25 kHz to 1 GHz, 50 Ω input
- CT-2 Current probe — designed for permanent or semi-permanent in-circuit installation. 1.2 kHz to 200 MHz, 50 Ω input
- CT-4 Current Transformer — for use with the AM 503S (A6302, A6312) and P6021. Peak pulse 20 kA. 0.5 Hz to 20 MHz with AM 503S (A6302)
- P6408 Logic probe, 17-bit, TTL

Accessory Software

The optional accessories listed in Table 7–5 are Tektronix software products recommended for use with your oscilloscope.

Table 7–5: Accessory software

Software	Part number
Wavewriter: AWG and waveform creation	S3FT400
WaveStar [™] : Waveform capture and documentation	WSTR31
WaveStar [™] : Waveform capture and documentation, Windows 95/NT version	WSTR0
Telecommunication Package and i–Pattern Software	TTiP

Warranty Information

Check for the full warranty statements for this product and the products listed above on the first page after the title page of each product manual.

Electrical Parts List

The modules that make up this instrument are often a combination of mechanical and electrical subparts. Therefore, all replaceable modules are listed in Section 10, *Mechanical Parts List*. Refer to that section for part numbers when using this manual.

Diagrams

This contains the interconnection diagram, see Figure 9–1 on page 9–2 and block diagram, see Figure 9–2 on page 9–4 for the TDS 500D, TDS 600C, TDS 700D and TDS 714L Oscilloscopes.

Symbols

Graphic symbols and class designation letters are based on ANSI Standard Y32.2–1975. Abbreviations are based on ANSI Y1.1–1972.

Logic symbology is based on ANSI/IEEE Std 91-1984 in terms of positive logic. Logic symbols depict the logic function performed and can differ from the manufacturer's data.

The tilde (~) preceding a signal name indicates that the signal performs its intended function when in the low state.

Other standards used in the preparation of diagrams by Tektronix, Inc. are:

- Tektronix Standard 062–2476 Symbols and Practices for Schematic Drafting
- ANSI Y14.159–1971 Interconnection Diagrams
- ANSI Y32.16–1975 Reference Designations for Electronic Equipment
- MIL–HDBK–63038–1A Military Standard Technical Manual Writing Handbook




Figure 9-1: Interconnections




Figure 9-1: Interconnections (Cont.)




Figure 9-2: Block diagram




Figure 9-2: Block diagram (Cont.)

Mechanical Parts List

This section contains a list of the replaceable modules for the oscilloscope. Use this list to identify and order replacement parts.

Parts Ordering Information

Replacement parts are available through your local Tektronix field office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available and to give you the benefit of the latest circuit improvements. Therefore, when ordering parts, it is important to include the following information in your order.

- Part number
- Instrument type or model number
- Instrument serial number
- Instrument modification number, if applicable

If you order a part that has been replaced with a different or improved part, your local Tektronix field office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

Module Servicing

Modules can be serviced by selecting one of the following three options. Contact your local Tektronix service center or representative for repair assistance.

Module Exchange. In some cases you may exchange your module for a remanufactured module. These modules cost significantly less than new modules and meet the same factory specifications. For more information about the module exchange program, call 1-800-TEK-WIDE, extension 6630.

Module Repair and Return. You may ship your module to us for repair, after which we will return it to you.

New Modules. You may purchase replacement modules in the same way as other replacement parts.

Using the Replaceable Parts List

This section contains a list of the mechanical and/or electrical components that are replaceable for the oscilloscope. Use this list to identify and order replacement parts. The following table describes each column in the parts list.

Parts list column descriptions

Column	Column name	Description
1	Figure & Index Number	Items in this section are referenced by component number.
2	Tektronix Part Number	Use this part number when ordering replacement parts from Tektronix.
3 and 4	Serial Number	Column three indicates the serial number at which the part was first effective. Column four indicates the serial number at which the part was discontinued. No entries indicates the part is good for all serial numbers.
5	Qty	This indicates the quantity of parts used.
6	Name & Description	An item name is separated from the description by a colon (:). Because of space limitations, an item name may sometimes appear as incomplete. Use the U.S. Federal Catalog handbook H6-1 for further item name identification.
7	Mfr. Code	This indicates the code of the actual manufacturer of the part. (Code to name and address cross reference is located after this page.)
8	Mfr. Part Number	This indicates the actual manufacturer's or vendor's part number.

Abbreviations Abbreviations conform to American National Standard ANSI Y1.1–1972.

Mfr. Code to Manufacturer Cross Index The following table cross indexes codes, names, and addresses of manufacturers or vendors of components listed in the parts list.

Manufacturers Cross Index

Mfr. code	Manufacturer	Address	City, state, zip code
S3109	FELLER	72 VERONICA AVE UNIT 4	SUMMERSET NJ 08873
TK0IK	MODERN METALS	UNIT A/K, 5/F GOLD KING IND. BLDG NO. 35-41 TAI LIN ROAD	KWAI-CHUNG N.T. HONG KONG
TK0488	CURRAN COIL SPRING INC	9265 SW 5TH	WILSONVILLE, OR 97070
TK0588	UNIVERSAL PRECISION PRODUCTS	1775 NW 216TH	HILLSBORO OR 97123
TK1163	POLYCAST INC	9898 SW TIGARD ST	TIGARD OR 97223
TK1465	BEAVERTON PARTS MFG CO	1800 NW 216TH AVE	HILLSBORO OR 97124-6629
TK2162	DERBY MFG	24350 STATE ROAD 23 SOUTH	SOUTH BEND IN 46614-9696
TK2248	WESTERN MICRO TECHNOLOGY	1800 NW 169TH PL SUITE B-300	BEAVERTON OR 97006
TK2338	ACC MATERIALS	ED SNYDER BLDG 38-302	BEAVERTON OR 97077
TK2376	CONDUCTIVE RUBBER TECH	22125 17TH AVE SE, SUITE 117	BOTHELL, WA 98021
TK2432	UNION ELECTRIC	15/F #1, FU-SHING N. ROAD	TAIPEI, TAIWAN ROC
TK2500	SOLECTEK ACCESSORIES CORP	6370 NANCY RIDGE DR SUITE 109	SAN DIEGO CA 92121
TK2539	ROYAL CASE CO INC	315 SOUTH MONTGOMERY PO BOX 2231	SHERMAN TX 75091-2231
TK2548	XEROX BUSINESS SERVICES DIV OF XEROX CORPORATION	14181 SW MILLIKAN WAY	BEAVERTON OR 97077
TK2597	MERIX CORPORATION	1521 POPLAR LANE	FOREST GROVE, OR 97116
03LB0	SANDISK CORP	140 CASPIAN COURT	SUNNYVALE, CA 94089
0JR05	TRIQUEST CORP	3000 LEWIS AND CLARK HWY	VANCOUVER WA 98661-2999
0J9P9	GEROME MFG CO INC	PO BOX 737 403 NORTH MAIN	NEWBERG OR 97132
0KB01	STAUFFER SUPPLY	810 SE SHERMAN	PORTLAND OR 97214-4657
0KB05	NORTH STAR NAMEPLATE	5750 NE MOORE COURT	HILLSBORO OR 97124-6474
00779	AMP INC	2800 FULLING MILL PO BOX 3608	HARRISBURG PA 17105
060D9	UNITREK CORPORATION	3000 COLUMBIA HOUSE BLVD, SUITE 1 20	VANCOUVER, WA 98661
07416	NELSON NAME PLATE CO	3191 CASITAS	LOS ANGELES CA 90039-2410
1DM20	PARLEX CORPORATION LAMINATED CABLE DIV	7 INDUSTRIAL WAY	SALEM, NH 03079
1GM54	ARTESYN TECHNOLOGIES	7575 MARKET PLACE DR	EDEN PRAIRIE, MN 55344
1JJ96	KAM ELECTRIC CO	11866 SLATER AVE NE	KIRKLAND WA 98034
11536	OPTICAL COATING LABORATORY INC	2789 NORTHPOINT PARKWAY	SANTA ROSA, CA 95407
2W733	COOPER INDUSTRIES INC BELDEN DIVISION	2200 US HIGHWAY 27 SOUTH PO BOX 1980	RICHMOND IN 47375-0010
22526	BERG ELECTRONICS INC (DUPONT)	857 OLD TRAIL RD	ETTERS PA 17319

Manufacturers Cross Index (Cont.)

Mfr. code	Manufacturer	Address	City, state, zip code
24931	BERG ELECTRONICS INC	RF/COAXIAL DIV 2100 EARLYWOOD DR PO BOX 547	FRANKLIN, IN 46131
30817	INSTRUMENT SPECIALTIES CO INC	EXIT 53 RT 80 BOX A	DELAWARE WATER GAP PA 18327
34416	PARSONS MFG CORP	1055 OBRIAN DR	MENLO PARK CA 94025-1408
5Y400	TRIAX METAL PRODUCTS INC DIV OF BEAVERTON PARTS MFG CO	1800 NW 216TH AVE	HILLSBORO OR 97124-6629
50356	TEAC AMERICA INC	7733 TELEGRAPH RD, PO BOX 750	MONTEBELLO, CA 90640-6537
52152	3M COMPANY	INDUSTRIAL TAPE DIVISION 3M CENTER	ST PAUL, MN 55144-1000
53387	3M COMPANY ELECTRONIC PRODUCTS DIV	3M AUSTIN CENTER	AUSTIN TX 78769-2963
6D224	HARBOR ELECTRONICS COMPANY	14500 S BROADWAY	GARDENA, CA 90248
61857	SAN-0 INDUSTRIAL CORP	91-3 COLIN DRIVE	HOLBROOK NY 11741
61935	SCHURTER INC	1016 CLEGG COURT	PETALUMA CA 94952-1152
75915	LITTELFUSE TRACOR INC SUB OF TRACOR INC	800 E NORTHWEST HWY	DES PLAINES IL 60016-3049
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON OR 97077-0001
97918	LINEMASTER SWITCH CORP.	29 PLAINE HILL ROAD PO BOX 238	WOODSTOCK, CT 06281-0238

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discount'd	Qty	Name & description	Mfr. code	Mfr. part number
10-1							
-1	212-0189-00			4	SCR,ASSEM WSHR:8-32 X 0.500,PNH,STL,CDPL,T-20	0KB01	ORDER BY DESC
-2	200-3695-02			1	COVER,REAR:REAR COSMETIC COVER	TK1163	200-3695-02
	334-9709-00	B010100	B039999	1	MARKER,IDENT:REAR LABEL, SAFETY UL CSA CE	0KB05	334-9709-00
	334-9918-00	B040100		1	MARKER,IDENT:REAR LABEL, SAFETY UL CSA CE	0KB05	334-9918-00
	334-9918-00			1	MARKER,IDENT:REAR LABEL, SAFETY UL CSA CE,TDS694C	0KB05	334-9918-00
-3	161-0230-01			1	CABLE ASSY,PWR,:3.18 AWG,92 L,SVT,TAN (STANDARD ACCESSORY)	TK2432	ORDER BY DESC
-4	343-1213-00			1	CLAMP,PWR CORD:POLYIMIDE (STANDARD ACCESSORY)	TK1163	ORDER BY DESC
-5	200-2264-00			1	CAP,FUSEHOLDER:3AG FUSES (AMERICAN)	61935	FEK 031 1666
	200-2265-00			1	CAP,FUSEHOLDER:5 X 20MM FUSES (EUROPEAN)	61935	FEK 031.1663
-6	159-0013-00			1	FUSE,CARTRIDGE:3AG,6A,250V,FAST BLOW (AMERICAN)	75915	312006
	159-0210-00			1	FUSE,CART:DIN 5 X 20MM,5AMP,250VSLOW (EUROPEAN)	61857	ET 5 AMP
-7	650-3595-01	B010100	B039999	1	CABINET ASSY:TDS500D,TDS724D, 754D, 784D	QJ9P9	650-3595-01
		B010100	B019999	1	CABINET ASSY:TDS714L	QJ9P9	650-3595-01
				1	CABINET ASSY:TDS600C (EXCEPT 694C), TDS794D, TLS216, TDS820	QJ9P9	650-3595-01
	437-0485-00	B040100		1	CABINET ASSY:TDS500D,TDS724D, 754D, 784D	QJ9P9	437-0485-00
		B020100		1	CABINET ASSY:TDS714L	QJ9P9	437-0485-00
				1	CABINET ASSY:TDS694C	QJ9P9	437-0485-00
-8	367-0247-01			1	HANDLE,CARRYING:11.54 L,W/CLIP	80009	367-0247-01
-9	200-2191-00			2	CAP,RETAINER:PLASTIC	QJR05	ORDER BY DESC
-10	437-0465-00	B010100	B039999	1	CABINET,SCOPE:TDS500D,TDS724D, 754D, 784D (Opt. 1R)	80009	437-0465-00
		B010100	B019999	1	CABINET,SCOPE:TDS714L (Opt. 1R)	80009	437-0465-00
				1	CABINET,SCOPE:TDS600C (EXCEPT 694C), TDS794D, TLS216, TDS820 (Opt. 1R)	80009	437-0465-00
	390-1197-00	B040100		1	CABINET,SCOPE:TDS500D,TDS724D, 754D, 784D (Opt. 1R)	80009	390-1197-00
		B020100		1	CABINET,SCOPE:TDS714L (Opt. 1R)	80009	390-1197-00
				1	CABINET,SCOPE:TDS694C (Opt. 1R)	80009	390-1197-00
-11	348-1110-04			4	FOOT,CABINET:	80009	348-1110-04
-12	348-1254-01			4	PAD,FOOT:TEK BLACK,SANTOPRENE	80009	348-1254-01
-13	348-0875-00			1	FLIPSTAND,CAB.:	TK0488	ORDER BY DESC
-14	348-1109-01			2	GASKET,SHIELD:348-1109-00 CUT 45.0 L	80009	348-1109-01
-15	200-3696-01			1	COVER,FRONT:PLASTIC (STANDARD ACCESSORY)	80009	200-3696-01
-16	101-0142-00			1	TRIM,DECORATIVE:FRONT	TK1163	ORDER BY DESC
	101-0142-01			1	TRIM,DECORATIVE:FRONT (for use in Opt. 1R, rackmount instruments)	TK1163	ORDER BY DESC
-17	334-9659-00			1	MARKER,IDENT:FRONT PANEL,500MHZ,2GS/S,TDS520D	0KB05	334-9659-00

Replaceable Parts List (Cont.)

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discont'd	Qty	Name & description	Mfr. code	Mfr. part number
2118	334-9660-00			1	MARKER,IDENT:FRONT PANEL,500MHZ,2GS/S,TDS540D	OKB05	334-9660-00
	334-9661-00			1	MARKER,IDENT:FRONT PANEL,500MHZ,1GS/S,TDS540D OPT.1G	OKB05	334-9661-00
	334-9832-00			1	MARKER, IDENT:FRONT LABEL, TDS654C	80009	334-9832-00
	334-9833-00			1	MARKER, IDENT:FRONT LABEL, TDS680C	80009	334-9833-00
	334-9834-00			1	MARKER, IDENT:FRONT LABEL, TDS684C	80009	334-9834-00
	334-9916-00			1	MARKER, IDENT:FRONT LABEL, TDS694C	OKB05	334-9916-00
	335-0099-00			1	MARKER,IDENT:FRONT PANEL,500MHZ,500MS/S,TDS714L	OKB05	335-0099-00
	334-9708-00			1	MARKER,IDENT:FRONT PANEL,500MHZ,2GS/S,TDS724D	OKB05	334-9708-00
	334-9663-00			1	MARKER,IDENT:FRONT PANEL,500MHZ,2GS/S,TDS754D	OKB05	334-9663-00
	334-9664-00			1	MARKER,IDENT:FRONT PANEL,500MHZ,1GS/S,TDS754D OPT.1G	OKB05	334-9664-00
	334-9665-00			1	MARKER,IDENT:FRONT PANEL,1GHZ,4GS/S,TDS784D	OKB05	334-9665-00
	334-9666-00			1	MARKER,IDENT:MKD,FRONT PANEL,2GHZ,4GS/S,TDS794D	OKB05	334-9666-00
	214-4287-01	B010100	B032299	1	ACTUATOR:ELASTOMER MAT,FRONT PANEL,RBR (TDS 500D)	TK0IK	ORDER BY DESC
			B020399		(TDS 654C, 680C, 684C)		
-18			B031509		(TDS 694C)		
			B010409		(TDS 714L, 724D)		
			B033620		(TDS 754D, 784D)		
			B031620		(TDS 794D)		
	260-2715-00	B032300			ACTUATOR:ELASTOMER MAT,FRONT PANEL,RBR (TDS 500D)	TK2376	260-2715-00
			B020400		(TDS 654C, 680C, 684C)		
			B031510		(TDS 694C)		
			B010410		(TDS 714L, 724D)		
			B033621		(TDS 754D, 784D)		
			B031621		(TDS 794D)		
	366-2114-00			2	KNOB:LARGE,DETENTED	TK1163	ORDER BY DESC
	366-2111-00			3	KNOB:SMALL,FLUTED	TK1163	ORDER BY DESC
	650-2927-00			1	REPLACEABLE AS:DISPLAY FRAME WITH FLEX	80009	650-2927-00
	386-5954-00			1	PANEL,INPUT:PLASTIC,ATTENUATOR	80009	386-5954-00
-22	386-7099-00			1	PANEL,INPUT:PLASTIC,ATTENUATOR, TDS794D ONLY	80009	386-7099-00
	386-5954-00			1	PANEL,INPUT:PLASTIC,ATTENUATOR, TDS694C ONLY	80009	386-5954-00
	174-2288-00			1	CA ASSY,PWR:18 AWG,3.5 L,RTANG,0.25 XRING TONGUE	060D9	174-2288-00
	131-1688-00			1	TERM,QIK DISC.:0.250 SPADE,STUD MT	00779	42822-4
-24	614-0935-02	B010100	B020376	1	FNT PANEL ASSY:TDS654C, TDS684C, TDS714L	80009	614-0935-02
		B010100	B010144				
	614-0971-00	B020376		1	FNT PANEL ASSY:TDS654C, TDS684C, TDS714L	80009	614-0971-00
		B010144					
	614-0936-02	B010100	B020203	1	FNT PANEL ASSY:TDS680C	80009	614-0936-00
	614-0972-00	B020204				80009	614-0972-00
	614-0967-01	B010100	B031503	1	FNT PANEL ASSY:TDS694C	80009	614-0967-00
	614-0995-00	B031504					

Replaceable Parts List (Cont.)

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discontinued	Qty	Name & description	Mfr. code	Mfr. part number
	614-0952-02	B010100	B032117	1	FNT PANEL ASSY:TDS520D,	80009	614-0952-00
		B010100	B010409		TDS724D		
	614-0974-00	B032118			FNT PANEL ASSY:TDS520D,	80009	614-0974-00
		B010410			TDS724D		
	614-0953-02	B010100	B032276	1	FNT PANEL ASSY:TDS540D, TDS580D,	80009	614-0953-00
		B010100	B033620		TDS754D, TDS784D		
	614-0975-00	B032277			FNT PANEL ASSY:TDS540D, TDS580D,	80009	614-0975-00
		B033621			TDS754D, TDS784D		
	614-0954-02	B010100	B031620	1	FNT PANEL ASSY:TDS794D	80009	614-0954-00
	614-0976-00	B031621				80009	614-0976-00
-25	366-2170-00			1	KNOB:DIMPLED GPK,1.7 DIA	TK1163	ORDER BY DESC




Figure 10-1: External modules

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discount'd	Qty	Name & description	Mfr. code	Mfr. part number
10-2							
-1	212-0189-00			6	SCR,ASSEM WSHR:8-32 X 0.500,PNH,STL,T-20	0KB01	ORDER BY DESC
-2	119-5044-00			1	FAN,DC:TUBEAXIAL;ASSY,24V,5W,1600 RPM	5Y921	JQ24F4V/031349
	174-2349-00			1	CA ASSY:DISCRETE,LDI,2,22AWG,7.0L,1X2,	060D9	174-2349-00
-3	671-4172-00			1	CIRCUIT BD ASSY:COLOR PROCESSOR DISPLAY A11 (TDS 654C, 684C, 714L, 724D, 754D, 784D, 794D)	80009	671-4172-00
	671-4171-00			1	CIRCUIT BD ASSY:MONO PROCESSOR DISPLAY A11 (TDS 520D, 540D, 580D, 680C)	80009	671-4171-00
-4	441-1902-01			1	CHASSIS,SCOPE:REAR	0J9P9	ORDER BY DESC
	650-4021-00			1	CHASSIS,SCOPE:REAR:TDS694C	0J9P9	650-4021-00
-5	334-7966-02			1	MARKER,IDENT:MKD W/CONN IDENT,REARBNC	07416	334-7966-02
	334-9919-00			1	MARKER,IDENT:MKD W/CONN IDENT,REARBNC, TDS694C	0KB05	334-9919-00
-6	131-1315-01			4	CONN,RF JACK:BNC/PNL, 50 OHM, FEMALE	24931	28JR306-1
-7	679-2437-00			1	CIRCUIT BD ASSY:RS232/CENTRONIC; (OPTION 13 ON TDS 520D, 540D, & 680C)	80009	679-2437-00
-8	407-3825-00			2	BRACKET,CKT BD:PLASTIC,REAR	TK1163	ORDER BY DESC
-9	386-6182-00			1	PLATE,REAR:ALUMINUM,RS232/CENTRONIC (OPTION 13)	0J9P9	386-6182-00
	386-5872-00				PLATE,REAR:STANDARD (WITHOUT OPTION 13)		
-10	131-0890-01			2	CONN,HARDWARE:DSUB,JACK SCREW (OPTION 13 ON TDS 520D, 540D, & 680C)	00779	205818-2
-11	348-1300-00			2	SHLD,GSKT,ELEK:3.165 L,CLIP ON	30817	0098-0564-09-03
-12	211-0730-00			6	SCR,ASSEM WSHR:6-32 X 0.375,PNH,STL,T-15	0KB01	ORDER BY DESC
-13	344-0575-00	B032300		1	PULL TAB:POLYESTER,DOUBLE SIDED ADHESIVE TAPE WITH LINER,34 POS (TDS 500D)	53387	3490-3
		B020400			(TDS 654C, 680C, 684C)		
		B031510			(TDS 694C)		
		B010410			(TDS 714L, 724D)		
		B033621			(TDS 754D, 784D)		
		B031621			(TDS 794D)		
-14	650-3972-03	B020100		1	HARD DRIVE,119-5949-00 FORMATTED (OPTIONAL)	80009	650-3972-00
-15	407-4697-00	B032300		1	BRACKET,SUPPORT:HARD DRIVE BASE FIXTURE,3.725L X 2.815W X 0.375H.0.025 AL (TDS 500D)	0J9P9	407-4697-00
		B020400			(TDS 654C, 680C, 684C)		
		B031510			(TDS 694C)		
		B010410			(TDS 714L, 724D)		
		B033621			(TDS 754D, 784D)		
		B031621			(TDS 794D)		
-16	119-5901-00	B010100	B020099	1	DISK DRIVE:PCMCIA (OPTIONAL)	03LB0	SDP-3B175-101
-17	407-4486-00	B010100	B020099	1	RETAINER BRACKET,PCMCIA BD (OPTIONAL)	80009	407-4486-00
	407-4486-01	B020100					
-18	210-0457-00	B020100		4	NUT,PL,ASSEM WA6 32X0.312,STL CD PL,W/LOCKWASHER (OPTIONAL)	0KB01	ORDER BY DESC

Replaceable Parts List (Cont.)

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discount'd	Qty	Name & description	Mfr. code	Mfr. part number
-19	610-0825-00	B020100	B032299	1	CHASSIS ASSY:HD DRIVE:2BKTS,SPR,COVER (OPTIONAL) (TDS 500D)	80009	610-0825-00
			B020399		(TDS 654C, 680C, 684C)		
			B031509		(TDS 694C)		
			B010409		(TDS 714L, 724D)		
			B033620		(TDS 754D, 784D)		
			B031620		(TDS 794D)		
-20	211-0461-00	B020100	B032299	4	SCR,MACHINE M3X0.5X6MM,PNH,STL CD PL,T10 (OPTIONAL) (TDS 500D)	0KB01	211-0461-00
			B020399		(TDS 654C, 680C, 684C)		
			B031509		(TDS 694C)		
			B010409		(TDS 714L, 724D)		
			B033620		(TDS 754D, 784D)		
			B031620		(TDS 794D)		
-21	671-2848-00			1	CIRCUIT BD ASSY:D1 BUS A14	80009	671-2848-00
-22	211-0730-00			7	SCR,ASSEM WSHR:6-32 X 0.375,PNH,STL,T-15	0KB01	ORDER BY DESC
-23	671-4165-01	B010100	B029999	1	CIRCUIT BD ASSY:ACQUISITION SHORT (TDS 540D & 754D)	80009	671-4165-00
	671-4166-02	B010100	B039999	1	CIRCUIT BD ASSY:ACQUISITION LONG (TDS 540D & 754D)	80009	671-4166-02
	671-4771-01	B040100		1	CIRCUIT BD ASSY:ACQUISITION LONG (TDS 540D & 754D)	80009	671-4771-01
	671-4493-01	B010100	B029999	1	CIRCUIT BD ASSY:ACQ. SHORT (TDS 540D & 754D) OPT.1G	80009	671-4493-01
	671-4492-02	B010100	B039999	1	CIRCUIT BD ASSY:ACQ. LONG (TDS 540D & 754D) OPT.1G	80009	671-4492-02
	671-4786-00	B040100		1	CIRCUIT BD ASSY:ACQ. LONG (TDS 540D & 754D) OPT.1G	80009	671-4786-00
	671-4167-00	B010100	B029999	1	CIRCUIT BD ASSY:ACQUISITION SHORT (TDS 520D & 724D)	80009	671-4167-00
	671-4168-02	B010100	B039999	1	CIRCUIT BD ASSY:ACQUISITION LONG (TDS 520D & 724D)	80009	671-4168-02
	671-4774-01	B040100		1	CIRCUIT BD ASSY:ACQUISITION LONG (TDS 520D & 724D)	80009	671-4774-01
	671-4709-01	B010100	B029999	1	CIRCUIT BD:ACQUISITION (TDS 520D & 724D OPT.1G)	80009	671-4709-01
	671-4779-02	B010100	B039999	1	CIRCUIT BD:ACQUISITION (TDS 520D & 724D OPT.1G)	80009	671-4779-02
	671-4788-00	B040100		1	CIRCUIT BD:ACQUISITION (TDS 520D & 724D OPT.1G)	80009	671-4788-00
	671-4515-00	B010100	B010108	1	CIRCUIT BD:ACQUISITION (TDS 654C)	80009	671-4515-00
	671-3314-04	B010109	B020295	1	CIRCUIT BD:ACQUISITION (TDS 654C)	80009	671-3314-04
	671-4515-01	B020296	B020328	1	CIRCUIT BD:ACQUISITION (TDS 654C)	80009	671-4515-01
	671-3314-04	B020329		1	CIRCUIT BD:ACQUISITION (TDS 654C)	80009	671-3314-04
	671-4534-00	B010100	B010108	1	CIRCUIT BD:ACQUISITION (TDS 680C, 684C) A10	80009	671-4534-00
	671-3462-06	B010109	B020219	1	CIRCUIT BD:ACQUISITION (TDS 680C) A10	80009	671-3462-06
	671-3462-06	B010109	B020405	1	CIRCUIT BD:ACQUISITION (TDS 684C) A10	80009	671-3462-06
	671-4534-01	B020220	B020264	1	CIRCUIT BD:ACQUISITION (TDS 680C) A10	80009	671-4534-01
	671-4534-01	B020406	B020443	1	CIRCUIT BD:ACQUISITION (TDS 684C) A10	80009	671-4534-01
	671-3462-06	B020265		1	CIRCUIT BD:ACQUISITION (TDS 680C) A10	80009	671-3462-06
	671-3462-06	B020444		1	CIRCUIT BD:ACQUISITION (TDS 684C) A10	80009	671-3462-06
	671-4724-01			1	CIRCUIT BD:ACQUISITION (TDS 694C) A10	80009	671-4724-01
	671-4163-02	B010100	B029999	1	CIRCUIT BD ASSY:ACQUISITION SHORT (TDS 580D & 784D)	80009	671-4163-02
	671-4164-02	B010100	B039999	1	CIRCUIT BD ASSY:ACQUISITION LONG (TDS 580D & 784D)	80009	671-4164-02
	671-4770-01	B040100		1	CIRCUIT BD ASSY:ACQUISITION LONG (TDS 580D & 784D)	80009	671-4770-01
	671-5087-00	B010100	B019999	1	CIRCUIT BD ASSY:ACQUISITION (TDS 714L)	80009	671-5087-00
	671-4772-01	B020100		1	CIRCUIT BD ASSY:ACQUISITION (TDS 714L)	80009	671-4772-01
	671-4161-00	B010100	B029999	1	CIRCUIT BD ASSY:ACQUISITION SHORT (TDS 794D)	80009	671-4161-00
	671-4162-01	B010100		1	CIRCUIT BD ASSY:ACQUISITION LONG (TDS 794D)	80009	671-4162-01
-24	407-4666-00			1	BRACKET,CRT:BNC MOUNTING,0.040 BRASS	5Y400	407-4666-00
-25	259-0101-02			1	FLEX CIRCUIT:TEK PROBE INTERFACE	TK2597	259-0101-02
-26	348-1422-00			1	GASKET, RF, SHIELDING	0J9P9	348-1422-00
-27	131-1315-00			4	CONN,RCPT,ELEC:BNC,FEMALE	24931	28JR235-1
-28	407-3878-00			6	BRACKET,CKT BD:PLASTIC	TK1163	ORDER BY DESC

Replaceable Parts List (Cont.)

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discontinued	Qty	Name & description	Mfr. code	Mfr. part number
-29	407-3877-00			2	BRACKET,CKT BD:PLASTIC	TK1163	ORDER BY DESC
-30	441-1901-03			1	CHASSIS,SCOPE:TOP	0J9P9	ORDER BY DESC
					ATTACHED PARTS		
	407-3877-00			1	BRACKET,CKT BD:PLASTIC	TK1163	ORDER BY DESC
	407-3878-00			1	BRACKET,CKT BD:PLASTIC	TK1163	ORDER BY DESC
-31	671-4050-00	B010100	B020099	1	CIRCUIT BD ASSY:PCMCIA (OPTION HD)	80009	671-4050-00
	671-4050-01	B020100	B032299	1	CIRCUIT BD ASSY:(OPTION HD) (TDS 500D)	80009	671-4050-01
			B020399		(TDS 654C, 680C, 684C)		
			B031509		(TDS 694C)		
			B010409		(TDS 714L, 724D)		
			B033620		(TDS 754D, 784D)		
			B031620		(TDS 794D)		
					ATTACHED PART		
	174-4179-00	B020100	B032299	1	CA ASSY:44,28 AWG,7.0 L,Flat (TDS 500D)	52152	174-4179-00
			B020399		(TDS 654C, 680C, 684C)		
			B031509		(TDS 694C)		
			B010409		(TDS 714L, 724D)		
			B033620		(TDS 754D, 784D)		
			B031620		(TDS 794D)		
	671-4850-00	B032300		1	CIRCUIT BD ASSY:HARD DRIVE OPTION, TESTED,389-2347-02 WIRED,TDS SERIES (TDS 500D)	80009	671-4850-00
		B020400			(TDS 654C, 680C, 684C)		
		B031510			(TDS 694C)		
		B010410			(TDS 714L, 724D)		
		B033621			(TDS 754D, 784D)		
		B031621			(TDS 794D)		
-32	671-4095-00			1	CIRCUIT BD ASSY:OPTION CONNECTOR BD	80009	671-4095-00




Figure 10-2: Outer-chassis modules

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discontinued	Qty	Name & description	Mfr. code	Mfr. part number
10-3							
-1	640-0077-11			1	DISPLAY MODULE:TDS FAMILY FULL COLOR A30 (TDS 654C, 684C, 700D, & 714L ONLY)	80009	640-0077-11
	640-0071-06			1	DISPLAY,MONO:7 INCH A20 (TDS 520B, 540B, & 680C ONLY)	80009	640-0071-06
	378-0366-01			1	FILTER,LT,CRT:6.525 X 5.225, ESP, EMC (TDS 520B, 540B, & 680C ONLY)	11536	378-0366-01
	386-6211-02			1	RETAINER,FILTER:DUST SEAL ASSY,LEXAN (TDS 520B, 540B, & 680C ONLY)	TK1163	386-6211-02
-2	348-1300-00			2	SHLD,GSKT,ELEK:3.165 L,CLIP ON	30817	0098-0564-09-03
-3	620-0063-05	B010100	B039999	1	POWER SUPPLY:400W;5V 12A,5.1V 22A,15V 1,5A A16	1GM54	620-0063-05
	119-6040-00	B040100		1	POWER SUPPLY: TDS500, 600, 724/754/784	1GM54	119-6040-00
	119-6040-00	B020100		1	POWER SUPPLY: TDS714L	1GM54	119-6040-00
	119-6040-00			1	POWER SUPPLY: TDS694C	1GM54	119-6040-00
-4	441-2043-01	B010100	B039999	1	CHASSIS,SCOPE:MAIN,0.05 ALUMINUM	0J9P9	441-2043-01
	441-2169-00	B040100		1	CHASSIS,SCOPE:MAIN,AL,TDS500, 724/754/784	0J9P9	441-2169-00
	441-2169-00	B020100		1	CHASSIS,SCOPE:MAIN,AL, TDS714L	0J9P9	441-2169-00
	441-2169-00			1	CHASSIS,SCOPE:MAIN,AL, TDS694C	0J9P9	441-2169-00
-5	386-5871-01			1	SUBPANEL,FRONT:FINISHED,ALUMINUM	5Y400	386-5871-01




Figure 10-3: Inner-chassis modules

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discont'd	Qty	Name & description	Mfr. code	Mfr. part number
10-4							
-1	174-2031-00			4	CABLE ASSY, RF:50 OHM COAX, 6.5 L, W/BUE JKT (A10J1000 MAIN TO TRIGGER OUTPUT) (A10J1001 TO DELAYED TRIGGER OUTPUT)	TK2338	174-2031-00
-2	174-4175-00			1	CA ASSY, PWR:TW PAIR, 20 AWG, 26 L, (1 X 2, STR,) TDS 694C	060D9	174-4175-00




Figure 10-4: Cables, bottom view

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discount'd	Qty	Name & description	Mfr. code	Mfr. part number
10-5							
-1	174-1525-00			1	CA ASSY,SP,ELEC:2 X 8-13,28 AWG	060D9	ORDER BY DESC
-2	174-1524-01			1	CA ASSY SP:RIBBON,GPIB;IDC,24,28 AWG,4.0L	060D9	ORDER BY DESC
	129-1439-00			2	SPACER,POST:0.17 L,4-40 BRS,0.25 RND (USE WITH 174-1524-XX ONLY)	TK0588	ORDER BY DESC
-3	174-2975-00			1	CA ASSY,SP:RIBBON,;CPR,16,28 AWG,4.0 L	060D9	ORDER BY DESC
	131-0890-01			2	CONN,HARDWARE:DSUB,JACK SCREW	00779	205818-2
-4	346-0266-00			1	STRAP,CABLE:PLASTIC	0KB05	346-0266-00
-5	174-3736-00			1	CA ASSY,SP,ELEC:50,28 AWG,5.85 L,FLAT	53387	174-3736-00
-6	174-3735-00			2	CA ASSY,SP,ELEC:50,28 AWG,5.85 L,FLAT	53387	174-3735-00
-7	174-1728-00			1	CA ASSY,SP:RIBBON, IDC,26,28 AWG,6.0 L	53387	ORDER BY DESC
OPTION 05 CABLES							
	174-0655-00			1	CABLE ASSY:COAX,RFP,50 OHM,9-2,22.4 L	80009	174-0655-00
	174-3728-00			1	CA ASSY,SP:RIBBON,OPTION 05 AND PCMCIA,IDC, 28 AWG,2X25,5.15L	060D9	174-3728-00
	174-3729-00			1	CA ASSY,SP:RIBBON, OPTION 05 AND PCMCIA, IDC,28AWG,2X20,5.15L	060D9	174-3729-00




Figure 10-5: Cables, top view

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discount'd	Qty	Name & description	Mfr. code	Mfr. part number
10-6							
-1	407-4460-01			1	FDD NOISE SHIELD,DISK DRIVE TOP,0.014,80%NICKEL	OJ9P9	ORDER BY DESC
-2	211-0840-00	not present in all models		2	SCREW,MACHINE:M2.6 X 0.45MM PITCH X 4.0 L	0KB01	.26C4MXPHY
	211-0840-00	not present in all models		1	SCREW,MACHINE:M2.6 X 0.45MM PITCH X 4.0 L	0KB01	.26C4MXPHY
-3	211-0730-00			2	SCR,ASSEM WSHR:6-32 X 0.375,PNH,STL	0KB01	ORDER BY DESC
-4	174-2964-00			1	WIRE,ELECTRICAL:FLAT FLEX,JUMPER	1DM20	1.00MM-26-7-B
-5	276-0849-00			1	CORE,EM:EMI SUPPRESS,RBN CA	1JJ96	BFS 33.5 X 8 X
-6	407-4230-01			1	BRKT,DISK DRIVE:ALUMINUM	OJ9P9	407-4230-01
-7	337-3935-01			1	SHLD,DISK DRIVE	OJR05	337-3935-01
-8	119-5677-01	not present in all models		1	DISK DRIVE:FLOPPY,3.5 INCH;2MB,0.5 INH DSDD	50356	FD-04HF-2300
	119-6106-01	not present in all models		1	DISK DRIVE:FLOPPY,3.5INCH,1.44 MB, 0.5 IN HIGH,GRAY BEZEL,DDDS,96 X 126 X 12.7MM,FD-05HF563	TK2250	FD-05HF-5630
	950-4827-00			1	SCREW PHIL M 2.5 X 8 CSK	OKB01	950-4827-00
-9	105-1081-00	not present in all models		1	ADAPTER:FLOPPY DISK DRIVE BRACKET ADAPTER	TK1163	105-1081-00
-10	211-0866-00	not present in all models		1	92451-25010,SCREW PHIL M2.5X10 PHIL PNH BRZN	0KB01	211-0866-00




Figure 10-6: Floppy disk drive

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discontinued	Qty	Name & description	Mfr. code	Mfr. part number
10-7					STANDARD ACCESSORIES		
-1	161-0104-05			1	CA ASSY,PWR:3,1.0MM SQ,250V/10A,2.5 M (OPTION A3 – AUSTRALIAN)	S3109	198-010
-2	161-0104-06			1	CA ASSY,PWR:3,1.0MM SQ,250V/10A,2.5 M (OPTION A1 – EUROPEAN)	S3109	198-010
-3	161-0104-07			1	CA ASSY,PWR:3,1.0MM SQ,240V/10A,2.5 M (OPTION A2 – UNITED KINGDOM)	S3109	209010
-4	161-0104-08			1	CA ASSY,PWR:3,18 AWG,250/10A,98 INCH L (OPTION A4 – NORTH AMERICAN)	2W733	ORDER BY DESC
-5	161-0167-00			1	CA ASSY,PWR:3,0.75MM SQ,250V/10A,2.5 M (OPTION A5 – SWITZERLAND)	S3109	ORDER BY DESC
	_____			1	CABLE ASSY,PWR:3,18 AWG,92 L (STANDARD CABLE – SEE FIG 10-1-3)		
	343-0170-00			1	RTNR,CA TO CA:U/W 0.25 OD CABLES (OPTIONS A1,A2,A3,A4,A5)	0JR05	ORDER BY DESC
	_____			1	CLAMP,PWR CORD:POLYIMIDE (SEE FIGURE 10-1-4)		
	006-3415-04			1	STRAP,WRIST:3M TYPE 2214,ADJ.,6 FT COILED CORD (TDS794D ONLY)	TK0623	400 1829
	200-0678-00			1	COVER,ELEC CONN:BNC,COVER,MALE,STR,W/O INSERT,NON-SHORTING (TDS794D ONLY)	91836	KC89-58,TR-5
	063-3060-xx			1	MANUAL,TECH:PROGRAMMER HELP DISK TDS694C	80009	063-3060-xx
	063-3120-xx			1	MANUAL,TECH:PROGRAMMER HELP DISK	80009	063-3120-xx
	071-0473-xx			1	MANUAL,TECH:USERS TDS694C	80009	071-0473-xx
	071-0130-xx			1	MANUAL,TECH:USERS	80009	071-0130-xx
	071-0134-xx			1	MANUAL,TECH:USERS, (OPT. L5,JAPANESE)	80009	071-0134-xx
	071-0131-xx			1	MANUAL,TECH:USERS, (OPT. L1,FRENCH)	80009	071-0131-xx
	071-0132-xx			1	MANUAL,TECH:USERS, (OPT. L3,GERMAN)	80009	071-0132-xx
	071-0133-xx			1	MANUAL,TECH:USERS(OPT. L9,KOREAN)	80009	071-0133-xx
	071-0630-xx			1	MANUAL,TECH:PERF VERIF	80009	071-0630-xx
	020-2235-xx			1	MANUAL,TECH:REFERENCE SET	80009	020-2235-xx
	071-0273-xx			1	MANUAL,TECH:SUPPLEMENT (TDS 600C)	TK2548	020-0273-xx
	071-0628-xx			1	MANUAL,TECH:SUPPLEMENT (TDS 714L)	TK2548	020-0628-xx
	_____			1	COVER,FRONT:PLASTIC (SEE FIG 10-1-14)		
	016-1268-00			1	POUCH, ACCESSORY	TK2539	2122
	063-2028-00			1	DATA SHEET:INSTALLING THE ACCESSORY POUCH INSTRUCTION,TDS/TLS FAMILIES,DP	TK2548	PER TEK P/N




Figure 10-7: Accessories

Replaceable Parts List

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discont'd	Qty	Name & description	Mfr. code	Mfr. part number
OPTIONAL ACCESSORIES							
	003-1457-01			1	BIT,TORX DRIVER:MODIFY THE T-20	TK1465	003-1457-01
	012-0991-00			1	CABLE,INTCON:SHLD CMPST,GPIB	22526	81190-020
	012-0991-01			1	CABLE,GPIB:LOW EMI,1 METER	00779	553577-2
	012-1214-00			1	CABLE,INTCON:SHLD CMPST,IBM TO PRINTER	6D224	2206
	012-1298-00			1	CABLE,INTCON:RS232C DB25M-DB9F SERIAL	TK2500	C294-9
	012-1388-00			1	CABLE ASSEMBLY:OSCILLOSCOPE SECURITY	80009	012-1388-00
	016-0909-01			1	CASE,CARRYING:SOFTSIDED FOR 3002C	TK2162	0587
	016-1135-00			1	CASE,CARRYING:26 X 22 X 15,HARD TRANSFER	34416	2622RW-7T-7B
	016-1145-00			1	HOOD ASSEMBLY:TDS SERIES	80009	016-1145-00
	016-0099-00			1	HDW KIT,ELEK EQ:RACKMOUNTING HDW	80009	016-0099-00
	071-0627-xx			1	MANUAL,TECH:SERVICE	80009	071-0627-xx
	070-8432-xx			1	MANUAL,TECH:INSTR,TDS FAMILY RACKMOUNT	TK2548	070-8432-xx