

BRECOflex CO., L.L.C.

High Precision Drive Components

The World Leader In Polyurethane Timing Belts

SM5 Universal Belt Tension Meter



SM5 Tension Meter

Overview

The SM5 Tension Meter is designed to measure the static tension of all belt types and materials and offers the following benefits:

- Simple one-button operation
- Accurate measurement results for optimal belt performance and life
- Save production and downtime with quick readings
- Satisfy quality system requirements with traceable certification
- Integrates with our online calculation program - www.brecoflex.com/engineering-support/
- Download the SM5 Pretension Calculator Phone App free for iOS and Android

The purpose of pre-tensioning a belt is to maintain tension at all times during operation. The amount of pre-tension depends on the belt drive type and peak loading. Minimizing pretension reduces bearing and shaft loading and preserves belt tensile safety factors. Minimum pretension is achieved when the belt does not sag or flap under peak running load. Maximum pretension is limited by the belt strength and machine design (shafts, bearings and frame).

Characteristics:

- Measuring range: from 7 to 450 Hz
- Measurement tolerance: ± 5 Hz
- Weight: 148g
- Dimensions (LxWxH): 117 x 78 x 24mm
- Battery: 9Volts
- Conforms to EC standard



SM5 Tension Meter

Operation Instructions



1. **PRESS** button (1) one second to activate meter
2. **AIM** light beam at belt back with a sensor distance of 0.4 to 1.2 inches
3. **TAP** belt to generate a vibration and SM5 will display a frequency
4. **WAIT** for "Ready" display and repeat measurement to confirm reading
5. **PRESS** button (1) one second to turn off meter or meter will auto power off after one minute

Tips and Notes:

- Turn off the machine as well as nearby machinery that could cause vibration interference while measuring.
- For best results take readings on the belt back rather than tooth side or edge.
- Take a few readings to confirm consistency.
- For long belt spans better reading and resolution can be achieved by temporarily shortening the vibrating free span **L** to around 1 meter.
- Frequency recommendations from calculations or our belt sizing program are initial theoretical settings and should be confirmed as optimal by observation for no signs of sag or flapping during operation. Once optimal tension is found then a new reading should be taken and recorded for future use.
- New belts conform to the geometry of a system and lose up to 10% pre-tension within the first few hours of run-in. Machine manufacturers often recommend different frequency settings for new and used belts for this reason.
- We offer a certification service for traceability. Calibration interval depends on use/environment and is up to the customer. Please contact customer service for pricing, turn around time and a return authorization number.

Types of Belt Drives:

Select the type of belt drive below to determine required pretension (**Fv**) as a function of peripheral force. These values are a starting point and tension should be increased as necessary to eliminate sag or flapping during peak peripheral belt loading.

Two Pulley Drive	
# of belt teeth	Pre-tension Fv
< 60 teeth	$F_v = 1/3$ peripheral force
60 to 150 teeth	$F_v = 1/2$ peripheral force
> 150 teeth	$F_v = 2/3$ peripheral force



Linear Drive	
Belt Span	Pre-tension Fv
Any	$F_v =$ peripheral force



Multiple Pulley Drive	
Belt Span	Pre-tension Fv
Taut Length < slack length	$F_v =$ peripheral force
Taut Length > slack length	$F_v >$ peripheral force



SM5 Tension Meter

Check and Set Pre-tension

Use the SM5 to check belt pre-tension

Calculate the pre-tension **Fv** using the frequency **f** read from the meter

$$F_v = f^2 \cdot L^2 \cdot 4 \cdot m \cdot b$$

Fv [N]	current pre-tension in Newtons (1lbf = 4.45N)
f [Hz]	frequency read from the meter
L [m]	free vibrating span length in meters
m [Kg/m/cm]	belt mass in kilograms per meter of length per centimeter belt width
b [cm]	belt width in cm (1" = 2.54cm) (1cm = 10mm)

Use the SM5 to set belt pre-tension

Calculate the frequency **f** required to achieve a target frequency **Fv**. Alternately use our online calculation program recommendation.

$$f = \sqrt{\frac{F_v}{L^2 \cdot 4 \cdot m \cdot b}}$$

Fv [N]	target pre-tension in Newtons (1lbf = 4.45N)
f [Hz]	frequency reading
L [m]	free vibrating span length in meters
m [Kg/m/cm]	belt mass in kilograms per meter of length per centimeter belt width
b [cm]	belt width in cm (1" = 2.54cm) (1cm = 10mm)

Belt Mass - Steel Cord [kilograms per meter of belt length per centimeter of belt width]

Belt Pitch	Single Sided	Double Sided	Belt Pitch	Single Sided	Double Sided
AT3	0.022	-	T2	0.012	-
AT5	0.033	0.041	T2.5	0.017	-
ATL5	0.037	-	T5	0.021	0.028
ATK5K6	0.034	-	TK5K6	0.024	-
AT10	0.058	0.076	T10	0.045	0.058
ATL10	0.068	-	TK10K6	0.046	-
ATK10K6	0.059	0.077	TK10K13	0.057	-
ATK10K13	0.066	-	T20	0.074	0.100
BAT10/BATK10	0.059	-	MXL	0.012	-
ATP10	0.060	0.064	T1/5" = XL	0.024	-
SFAT10	0.058	-	T3/8" = L	0.035	-
ATS15	0.100	0.118	T1/2" = H	0.043	0.052
BAT15/BATK15	0.084	-	T7/8" = XH	0.104	-
ATP15	0.080	0.088	HTD 3M HP	0.031	-
SFAT15	0.088	-	HTD 5M HP	0.041	-
AT20	0.096	0.125	HTD 5M HF	0.034	-
ATL20	0.110	-	HTD 8M HP	0.063	-
ATK20K13	0.995	-	HTD 8M HF	0.054	-
SFAT20	0.096	-	HTD 14M HP	0.113	-

Note: These values are built in to the BRECOflex SM5 Pretension Calculator App. Download the App for free for iOS on The App Store or Android on Google Play.

For videos on how to use the SM5 Tension Meter, calculate pre-tension, use the SM5 Pretension Calculator App and more, visit our YouTube channel at www.youtube.com/brecoflexcollc.

SM5 Tension Meter

SM5 Pretension Calculator App

BRECOflex CO., L.L.C. offers the free “SM5 Pretension Calculator” which is a companion App to the SM5 Tension Meter. The two work together to make setting and calculating belt pretension simple and right at your fingertips. Scan the QR codes below with your smart phone to download it free directly from The App Store or Google Play.

Advantages:

- Our app doesn't require math and yields an instant, accurate result making it simple to use
- The user can translate it into English, Spanish, French or German with the touch of a button
- It eliminates the need to reference external charts to find the proper belt mass because they are built into the functionality
- BRECOflex keeps the App updated with the most recent belt pitch and belt mass data to ensure the most accurate pre-tension calculations for your belt



Available on the
App Store



GET IT ON
Google play





BRECOflex CO., L.L.C.

High Precision Drive Components

Contact Us

222 Industrial Way West, Eatontown, NJ 07724

Tel: 732-460-9500 • Fax: 732-542-6725

www.brecoflex.com • email: info@brecoflex.com

Regional Sales Offices:

Atlanta	(770)317-8745	Dallas	(214)476-5650	Miami	(770)317-8745	Richmond	(804)387-5760
Bay Area	(661)713-0121	Denver	(303)470-7226	Milwaukee	(908)461-6995	Seattle	(503)781-3631
Baltimore	(804)387-5760	Detroit	(908)433-0036	Minneapolis	(908)461-6973	Salt lake City	(303)470-7226
Boston	(603)496-5833	Ft. Wayne	(908)461-1168	Nashville	(732)757-6647	San Antonio	(214)476-5650
Buffalo	(412)600-5632	Grand Rapids	(908)461-1168	New York	(732)829-7773	Toledo	(908)433-0036
Charlotte	(908)461-3937	Houston	(214)476-5650	Philadelphia	(732)829-7773	Toronto	(416)476-7107
Chicago	(908)461-6995	Indianapolis	(908)461-2344	Phoenix	(480)961-3846	Mexico City	+52 1 55 45335835
Cincinnati	(908)461-2344	Las Vegas	(480)961-3846	Portland	(503)781-3631	Monterrey	+52 1 55 40840778
Cleveland	(412)600-5632	Los Angeles	(661)713-0121	Pittsburgh	(412)600-5632	Guadalajara	+52 1 55 40949053

Copyright 2019 BRECOflex CO., L.L.C. • BRECO®, BRECOFLEX® & ATN® are registered trademarks of BRECO Antriebstechnik GmbH • ARC-POWER® is a registered trademark of BRECOflex CO., L.L.C. • Kevlar® is a registered trademark of DuPont Patents Pending • ESBAND® is a registered trademark of Max Schlatterer GmbH & Co. KG Patents Pending. Specifications are subject to change without prior notice.

All recommendations for the use of the products described herein and all other data or information set forth in this publication, whether concerning such products or otherwise, are furnished without any guarantee, warranty representations or inducement of any kind whether expressed or implied, including but not limited to warranties of merchantability and fitness for a particular purpose. BRECOflex CO., L.L.C. expressly disclaims liability under any theory, including without limitation, contract negligence, misrepresentation or breach of any obligation relating to the recommendation, data or information set forth herein. Readers and customers are encouraged to conduct their own test before using any product. Read its label and all related instructions. BRECOflex CO., L.L.C. reserves the right to make changes in the technical and dimensional specifications of its products without prior notice. Responsibility for expenses incurred as a result of product changes or discontinuance of a product lies solely with the purchaser.