



TR-220 MULTIFUNCTION TEST SET



Transponder, TCAS, DME, TIS, and ADS-B Test Set Operating and Maintenance Manual Software Revision 3.40 and Later

REVISION

A	B	C	D	E	F	G	H	J	K	L	M	N
P	R	S	T	U	V	W	X	Y	Z			

01 July 2005

Tel-Instrument Electronics Corp
728 Garden Street
Carlstadt, NJ 07072
(201) 933-1600
www.telinstrument.com

Leading the AVIONICS TEST industry into the 21st Century!

NOTICE:

The information contained in this manual is subject to change without notice.

Tel-Instrument Electronics Corp. makes no warranty of any kind to this material, nor shall be liable including but not limited to, errors contained herein or for incidental or consequential damages in connection with the furnishings, performance, or use of this material.

PART NUMBER	VOLUMES INCLUDED	CHAPTERS INCLUDED
90008088-1	VOLUME 1	CHAPTERS I & II
90008088-2	VOLUMES 1 & 2	CHAPTERS I - VI

Chapter I – Introduction

Chapter II – Preparation for Use and Operation

Chapter III – Theory of Operation

Chapter IV – General Maintenance and Servicing Procedures

Chapter V – Schematics

Chapter VI – Illustrated Parts Catalog

COPYRIGHT NOTICE

© 2005 Tel-Instrument Electronics Corp

Reproduction of this publication or any portion thereof by any means without the express written permission of Tel-Instrument Electronics Corp. is prohibited. For further information, contact the Customer Support Manager, 728 Garden Street, Carlstadt, NJ 07072. (201) 933-1600

Safety Precautions


The following are general safety precautions that are not related to a particular test or procedure. These are recommended procedures that all personnel must apply during many phases of operation and maintenance. It is assumed that the operator has general knowledge of electrical theory and the dangers associated with it.

1. When performing any of the preceding; thoroughly read and understand all procedures before actually performing them.
2. The various front panel connectors, switches, and controls specified can be located by referring to Figure 2-1 on page 2-3.
3. Take the time to learn the proper operation and function of the Test Set as outlined in Chapters 1, 2, and 3. Through knowledge of the Test Set and its capabilities greatly improves the time it takes to complete the tests.
4. Pay particular attention to **NOTES** and **WARNINGS** that may accompany some test and operational procedures.



WARNINGS

Alerts the operator to potential dangers associated with a particular test. Thoroughly understand the warning before proceeding to prevent a potentially dangerous situation or damage to the Test Set.



NOTES

Provides supplemental information that enhances the procedure or further explains in detail additional information to ensure understanding or proper operation.

5. Observe all standard safety procedures when working with live voltages. The potential for electric shock exists any time the Test Set is removed from its case.
6. DO-NOT service the unit or make adjustments alone. Always be in the presence of another person when working with live voltages.
7. Thoroughly inspect the equipment and the local area for potential hazards. Loose clothing and jewelry should be removed anytime the test set is being utilized or being serviced.
8. Be familiar with general first aid procedures and CPR (Cardiopulmonary Resuscitation). Contact your local Red Cross for more information.
9. Ensure the test equipment and the tools you utilize are in good operational condition and not damaged in any way.
10. Use only specified replacement parts as listed in the IPB. Failure to utilize factory approved parts may cause damage to personnel; the test set's, and possibly void the warranty.

ESD Safety and Protection

Many parts contained in the Test Set are sensitive to ESD (Electro-Static Discharge) damage. ESD can damage integrated circuits or semiconductors located within the Test Set. Only qualified personnel should service the Test Set to prevent damage. The following are guidelines to avoid ESD damage while still performing tests and or maintenance. These guidelines are meant only as a reminder, consult local directives and follow standard operating procedures before servicing, or repairing the Test Set.

- Wear a properly grounded wrist strap and remain in contact with an approved grounding point.
- Do not touch the connector pins or backplanes of ESD Sensitive circuits or parts.
- Ensure soldering irons are grounded before use.
- Do not remove any components or disconnect any connectors located in the Test Set with the power “ON”.
- Properly ground all test equipment being utilized. Refer to the test equipment operating manual for information.
- Place all removed components or parts in or on an approved conductive package.

Most ESD devices or circuits and common points are readily identified utilizing several different methods. Below are some examples.



CE (IEC) Marking


The Following Symbols may be utilized in different locations throughout the Manual and are also located on and in the Test Set. Observe these warnings and markings and follow standard electrical safety anytime you utilize live circuits.




Caution



Alternating Current



Protective Conductor
Terminal



Caution, risk of
electrical shock

VOLUME 1

OPERATIONAL PROCEDURES

TR-220 TABLE OF CHANGES¹

Date	REV	ECO	Page	Description
07 Sep 03	Prelim. A			Initial Release Initial Release
15 July 04	B			Updated procedure explanations
16 Mar 05	C		2-5 & 6, 13, 17, 22, 43-46	Provided Detailed EHS and ADS setup and display info
01 Jul 05	D		Chapter 3-6	Added CHAPTERS 3, 4, 5, &6

¹ Changes are also denoted with a solid bar in the Left margin of each affected page.

Table of Contents

Chapter	Page
Table of Changes.....	i
List of Illustrations.....	vii
List of Tables.....	viii
I INTRODUCTION	
Section A- <u>General Information</u>	
1.1 Scope of Manual.....	1-1
1.2 Purpose and Function of Equipment.....	1-1
1.3 Regulatory Responsibilities.....	1-2
1.4 Warranty.....	1-3
1.4.1 Obtaining Warranty Service.....	1-3
1.4.1 Shipping and Packing the Test Set.....	1-4
Section B- <u>Equipment Description</u>	
1.5 Specifications.....	1-5
1.6 Abbreviations, Acronyms, and Glossary of Terms.....	1-7
II <u>PREPARATION FOR USE AND OPERATION</u>	
Section A- <u>General Information</u>	
2.1 General.....	2-1
2.2 Unpacking.....	2-1
2.3 Installation.....	2-1
2.4 Accessories.....	2-1

Table of Contents (continued)

Chapter	Page
Section B- <u>Operating Controls, Indicators, and Connectors</u>	
2.5 General.....	2-3
2.6 Controls, Indicators, and Connectors.....	2-3
Section C- <u>Operating Instructions</u>	
2.7 General.....	2-5
2.8 Battery Operation.....	2-5
2.8.1 Auto-Shutdown.....	2-6
2.9 TR-220 Supplied Antenna.....	2-6
2.9.1 Directional Antenna.....	2-6
2.9.2 Direct Connect.....	2-9
2.9.3 TAP-200 Antenna Coupler.....	2-9
2.10 Initial Startup and Self-Test.....	2-12
2.11 Transponder Test Sequence.....	2-13
2.12 Transponder Manual Sequence of Tests.....	2-14
2.12.1 ATCRBS, Mode A/C Manual Testing.....	2-14
2.12.2 Mode S Manual Testing.....	2-17
2.13 Transponder Automatic Sequence of Tests.....	2-24
2.13.1 ATCRBS, Mode A/C Automatic Testing.....	2-24
2.13.2 Mode S Automatic Testing.....	2-26
2.14 Testing a Transponders "IDENT" Function.....	2-28
2.15 TCAS Tests.....	2-29
2.15.1 Typical TCAS Concepts.....	2-29
2.15.2 TCAS Scenario Selection and Setup	2-29
2.15.3 Erasing the TCAS Scenario Memory.....	2-35
2.15.4 Testing a TCAS Equipped Aircraft.....	2-36
2.16 DME Tests.....	2-41
2.16.1 DME Setup.....	2-41
2.17 Mode S Enhanced Surveillance.....	2-43

Table of Contents (continued)

Chapter	Page
2.18 ADS-B and TIS Testing.....	2-47
2.18.1 ADS-B TX.....	2-47
2.18.2 ADS-B RX.....	2-50
2.19 RS-232 Download Procedures.....	2-52
2.19.1 Setting Up your Computer for RS-232 Download.....	2-53
2.19.2 Downloading the Data.....	2-54
2.19.3 Loading the Data to a Microsoft Excel File.....	2-55

III THEORY OF OPERATION

3.1 General.....	3-1
3.2 Subassemblies.....	3-1
3.3 Panel and Display Assembly.....	3-1
3.4 RF PCB Assembly and Attenuator Assembly.....	3-3
3.4.1 Transmitter.....	3-3
3.4.2 Modulator.....	3-3
3.4.3 Gain Control.....	3-5
3.4.4 Antennas, RF Switching, and Attenuator.....	3-5
3.4.5 Receiver.....	3-5
3.4.6 Power, Sensitivity, and Frequency Measurement.....	3-6
3.4.7 DPSK Demodulator.....	3-7
3.5 Digital PCB Assembly.....	3-7
3.5.1 Microprocessor Control Logic.....	3-7
3.5.2 Clock Frequencies and Range Counter.....	3-9
3.5.3 First-In/First-Out (FIFO).....	3-9
3.5.4 Operator Interface.....	3-9
3.5.5 Digital/Analog Converter.....	3-9
3.6 Power Supply PCB Assembly.....	3-10
3.6.1 Power Distribution.....	3-10
3.6.2 Power Functions.....	3-12
3.6.3 Power Control.....	3-12
3.6.4 Elapsed Time Indicator.....	3-12
3.7 Case Assembly.....	3-12
3.8 Case Assembly.....	3-12

Table of Contents (continued)

Chapter	Page
3.8 Directional Antenna Assembly.....	3-13
 IV GENERAL MAINTENANCE AND SERVICING INSTRUCTIONS	
4.1 General.....	4-1
4.1.1 Safety Precautions.....	4-2
4.1.2 Preliminary Consideration.....	4-3
 Section A- <u>Routine Maintenance</u>	
4.2 General.....	4-4
4.2.1 Cleaning Procedure.....	4-4
4.2.2 Inspection of all Connectors, Cables, and Assemblies.....	4-4
4.2.3 Battery Check and Charging.....	4-5
 Section B- <u>Test Set Verification and Acceptance Checks</u>	
4.3 General.....	4-6
4.3.1 Test Equipment Required.....	4-6
4.3.2 Test Set Initial Settings.....	4-7
4.4 Display Operation, Self Test and Initial Start Verification.....	4-8
4.4.1 Transponder, Transmitter/Frequency Verification Tests.....	4-9
4.4.2 TCAS Verification.....	4-12
4.4.3 DME Verification.....	4-14
4.4.4 Final Checks.....	4-17
 Section C- <u>Calibration and Alignment</u>	
4.5 General/ Frequency of Calibration	4-18
4.6 Test Equipment Required/ Initial Settings	4-19
4.7 Disassembly Procedures.....	4-20
4.8 Calibration and Alignment.....	4-21
4.8.1 Sub-Assembly Adjustments.....	4-21
4.8.2 DAC Table Adjustment.....	4-26

Table of Contents (continued)

Chapter	Page
4.8.3 RX Gain Calibration.....	4-29
4.8.4 Power Supply Test.....	4-35
4.8.5 Final Test.....	4-35

V SCHEMATICS

Sense Line Filter PCB, 80 169 003.....	5-2
Attenuator Board, 80 173 003.....	5-3
Antenna Attenuator, 80 208 003.....	5-4
Directional Antenna PCB, 80 201 003.....	5-5
IF Filter, 80 212 003.....	5-6
Power Supply PCB, 80 180 003.....	5-7
Regulator PCB, 80 191 003.....	5-9
Anti-Radiation Hat, 80 198 003.....	5-10
TR-220 Internal Interconnect Diagram, 89 003 135.....	5-11
Multi-Mode Digital Board, 80 210 003.....	5-12
Multi-Mode RF Board, 80 211 003.....	5-17

VI ILLUSTRATED PARTS AND PARTS LIST

TR-220 Test Set, 90 000 088.....	6-2
Front Panel Assembly, 89 000 135.....	6-3
Termination Cap, 88 001 014.....	6-7
RF Digital Chassis, 88 000 017.....	6-8
Multimode Digital Board, 80 210 001.....	6-9
Multimode RF Board, 80 211 001.....	6-14
Attenuator Assembly, 89 001 077.....	6-24
Attenuator PCB, 80 173 001.....	6-25
Cable Assembly, Dig/Panel Display, 75 010 165.....	6-26
Cable Assembly, Dig/FP Switch PCB, 75 010 166.....	6-27
Cable Assembly, RF/Antenna DIFF. 75 010 081.....	6-28
Cable Assembly, RF/Antenna SUM, 75 010 075.....	6-29
RF Direct Connect Cable, 75 010 079.....	6-30
Attenuator/RF Cable Assembly, 75 010 082.....	6-31
Sense Line Filter Cable, 75 010 142.....	6-32
Sense Line Filter, 80 169 001.....	6-33
Cable Assembly/Power Supply, 75 010 163.....	6-34
Power Supply Cable, 18 Pin, 75 010 193.....	6-35
Battery Cover Assembly, 75 010 029.....	6-36
Direct Connect Cable Assembly, 75 010 186.....	6-37
Directional Antenna Assembly, 89 001 158 07.....	6-38
Directional Antenna PCB, 80 201 001 04.....	6-40
Antenna Attenuator PCB, 80 208 001-03.....	6-42
Cable Assembly RF, 75 010 207.....	6-43
Directional Antenna Cable Assembly, 75 010 208 02.....	6-44
Directional Antenna Extension Cable Assembly, 75 010 078.....	6-45

Table of Contents (continued)

Chapter	Page
TAP-200 Assembly, 89 000 166.....	6-46
PCB Assembly/Power Supply, 80 180 001.....	6-48
Panel Switch Assembly, 80 189 001.....	6-51
PCB Assembly, Regulator, 80 191 001.....	6-54

Appendix's

A	Test Set Verification and Acceptance Check.....	A-1
B	Data Sheet Annual Calibration and Alignment.....	B-1
C	TAP-200 Calibration Procedures.....	C-1

List of Illustrations (Figures)

Figure	Title	Page
1-1	TR-220 Multifunction Test Set.....	1-1
2-1	TR-220 Accessories.....	2-2
2-2	Controls, Indicators, and Connector Locations.....	2-3
2-3	Directional Antenna Gain.....	2-7
2-4	Directional Antenna Setup.....	2-8
2-5	TAP-200.....	2-10
2-6	TAP-200 Placement.....	2-11
2-7	TAP-200 Adjustment.....	2-11
2-8	Sequence of Tests.....	2-13
2-9	Caution, Warning, and Collision Areas.....	2-29
2-10	Typical TCAS I Display.....	2-30
3-1	Test Set System Basic Functional Diagram.....	3-2
3-2	RF Functional Diagram.....	3-4
3-3	Digital PCB Functional Diagram.....	3-8
3-4	Power Distribution.....	3-11
4-1	Initial Settings.....	4-7
4-2	Transponder Output Frequency.....	4-11
4-3	TCAS Output Frequency.....	4-13
4-4	DME Test Setup.....	4-14
4-5	DME Interrogation/Reply pulses.....	4-15
4-6	DME Frequency.....	4-16
4-7	Directional Antenna.....	4-17
4-8	Initial Settings.....	4-20
4-9	Captive Screw Location.....	4-21
4-10	U-17.....	4-21
4-11	DPSK Ripple Check.....	4-23
4-12	DIFF Power Measurements.....	4-25
4-13	SUM/DIFF Setup.....	4-32
4-14	Test Point Locations.....	4-36

List of Tables

Table	Title	Page
2-1	TR-220 Accessories.....	2-2
2-2	Controls, Indicators, and Connectors.....	2-4
2-3	Preprogrammed TCAS Scenarios.....	2-30
2-4	TCAS Intruder Parameters.....	2-33
2-5	Additional TCAS Intruder Scenarios.....	2-34
2-6	TIS Intruders.....	2-51
4-1	Support Equipment.....	4-6
4-2	Initial settings.....	4-7
4-3	DME Range Verification.....	4-16
4-4	DME Frequency Verification.....	4-17
4-5	Test Set Annual Calibration List.....	4-19
4-6	Initial Settings.....	4-19
4-7	Initial Setup.....	4-22

CHAPTER I

INTRODUCTION

SECTION A

1.1 Scope of Manual

This manual is intended to familiarize the operator with the operating and maintenance procedures necessary to utilize the TR-220 Multifunction Test Set. Here-in after known as the T/S, Test Set, or TR-220.




Figure 1-1

TR-220 Multifunction Test Set

1.2 Purpose and Function of the Equipment

The TR-220 Test Set tests airborne ATCRBS, MODE A/C, and MODE S transponders, TCAS I/II systems, DME equipment, and ADS-B and TIS Transponders. It is self-contained and battery operated that requires no direct hardware connection to the Unit Under Test (UUT).

For transponder testing, the Test Set simulates secondary radar to receive and radiate signals to the UUT from antennas supplied with the Test Set. For accurate power and frequency measurements, the Test Set can be directly connected to the UUT without the use of additional hardware.

For TIS testing, the Test Set transmits simulated Intruder Flight Data, which is then shown on the TIS display to verify results.

The Test Set will receive and Decode 1090 MHz ADS-B data including squitter type, airborne position, surface position, aircraft IDENT category, Airborne velocity, Latitude/Longitude, North/South velocity, and East/West Velocity. The **ADS-B TX** function allows the operator to receive, decode, and display ADS-B squitters. The **ADS-B RX** function permits the operator to simulate a 1090MHz squitter. The TR-220 can be configured to transmit an airborne or surface position squitter containing position, altitude, velocity, heading, aircraft category, flight ID, and Mode S address.

The simulation of an intruder aircraft converging on the Aircraft Under Test (AUT) accomplishes TCAS testing. The simulated target will be displayed on the TCAS display so the operator can ensure proper advisories.

DME tests simulate an aircraft at a simulated speed converging to or from a selected distance. By comparing the Test Set displayed distance to the DME under test display, the operator can confirm proper DME operation.

1.3 Regulatory Responsibilities

Effective April 6, 1987, The Federal Aviation Administration (FAA) has required certain tests be performed on transponders, both conventional ATCRBS and MODE S. In preparation for the installation of new air traffic control radar facilities, the FAA required new measurements to be performed on existing transponders and instituted required tests for MODE S transponders. FAR (Federal Aviation Regulation) Part 43, Maintenance, Preventive Maintenance, Rebuilding and Alteration section has been modified to reflect current technologies and improvements. Tel-Instruments has met all FAA requirements and recommends that the user of this type of equipment review the appropriate FAR or contact the manufacturer of their particular model of transponder to ensure that the current procedures and limitations are being correctly adhered to.

Eurocontrol has also incorporated new regulations for Mode S Elementary and Enhanced Surveillance. These requirements include Selective Identifiers for high-density traffic areas and will become mandatory beginning in May of 2003 for Elementary Surveillance and March 2005 for Enhanced Surveillance. The TR-220 Test Set has the capability to thoroughly test these new functions to comply with upcoming requirements. If you would like further information regarding these requirements, visit www.eurocontrol.int/.

1.4 Warranty

The Tel-Instrument Electronics Corporation warrants that each product it manufactures is free from defective material and workmanship for a period of two (2) years subject to the following terms and conditions. Tel-Instrument Electronics Corp. will remedy any such warranted defect subject to the following:

This warranty requires the unit to be delivered by the owner to Tel-Instrument intact for examination, with all transportation charges prepaid to the factory, within two (2) years from the date of sale to original purchaser. Tel-Instrument will solely determine when such defect exists.

This warranty does not extend to any of Tel products which have been subject to misuse, neglect, accident, improper installation, or used in violation of operating instructions. This warranty does not extend to units which have been repaired, calibrated, or altered in any way by a facility that is not approved, in writing, by Tel-Instrument Electronics Corp. to perform such work. This warranty does not apply to any product where the seals or serial number thereof has been removed, defaced or changed, nor to accessories not of our own manufacture.

Repair parts will be made available for a minimum period of five (5) years after the manufacture of this equipment has been discontinued.

This warranty is in lieu of all other warranties expressed or implied and all such other warranties are hereby expressly excluded. No representative or person is authorized to assume for us any other liability or warranty in connection with the sale of Tel's products.

This warranty does not cover or include batteries (batteries have a separate 90 day warranty).

Additional information with regard to the applications and maintenance of this equipment will be available from time to time.

1.4.1 Obtaining Warranty Service

In the event the Test Set may require service or repair that is included under the warranty provided with the Test Set; the following is necessary to ensure proper handling:

1. Contact Tel-Instrument Customer Support before shipping any Test Set back under a warranty condition.

Tel-Instrument Electronics Corp. Customer Support can be reached by calling:

- (201) 933-1600 (telephone)
- (201) 933-7340 (fax)

2. The Customer Support Department will discuss the matter and if validated, issue an RMA (Return Material Authorization) number and form. Do not return any product without first receiving this authorization.
3. The Test Set must be returned with the completed RMA form. This will ensure prompt handling and expedited service.
4. Products must be returned in the Original Shipping Container (see Paragraph 1.4.1). If the original container is no longer available, please contact Tel-Instrument for guidance. Include in or on the shipping container the following information:

- RMA Form on top of the product
 - The assigned RMA number written in bold letters on the outside of the shipping container
 - Model, Serial Number, and specific details regarding the problem
 - POC name, return address, telephone number, and email address
5. Freight Charges to the factory are the responsibility of the owner/operator. Tel-Instrument will provide return shipping if the problem is determined to be warranty covered.

1.4.2 Shipping and Packing the Test Set

1. Repackage the Test Set in the Original container utilizing the provided packing material. Do Not Ship the Test Set with out using a shipping container, this will prevent damage to the case and or finish during transit.
2. Wrap the Test set within plastic sheeting and firmly seat the Test Set in the original corner molds. Place all necessary documentation (RMA Form, POC, etc...), on top of the Test Set.
3. Utilize Package Tape and seal all seams. If the use of an industrial box stapler is used, be sure that they do not protrude through the box to prevent injury to personnel handling the package.
4. Firmly affix a shipping label and mail the Test Set to the following:

**Tel-Instrument Electronics Corp.
728 Garden Street
Carlstadt, NJ 07072
Attn: Repair Department**

SECTION B

EQUIPMENT DESCRIPTION

1.5 Specifications

Transponder Transmitter

Frequency	1030 MHz $\pm$ 10 kHz
Output Power	$\geq$ 4dBm
Modes	A, C, S, ADS B TX/RX, and TIS

Transponder Receiver

Frequency	Frequency Accuracy	1086.5 to 1093.5 MHz $\pm$ 200 kHz
Power	Range Accuracy	47 to 64 dBm $\pm$ 2 dB (direct connect) $\pm$ 3 dB (radiated)
Sensitivity	Range Accuracy	-50 to -87 dBm $\pm$ 2 dB (direct connect) $\pm$ 3 dB (radiated)
Reply Percent	Range Accuracy	0 to 100% $\pm$ 1%

DME

DME Receiver

Frequency	Frequency Accuracy	Channel Freq +3.5 MHz $\pm$ 200 kHz
Sensitivity	Range	< -35 dB

DME Transmitter

Frequency	Frequency Accuracy Power	962 to 1213 MHz $\pm$ 100 kHz $\geq$ 4 dB
-----------	-----------------------------	---

TCAS

TCAS Transmitter

Frequency	1090 MHz $\pm$ 10 kHz
Output Power	$\geq$ 4dB
Modes	C & S
Antenna Beamwidth....	15° Sum & Diff Ports 30° Sum only

TCAS Receiver

Frequency

1026.5 to 1033.5 MHz

Power

47 to 64 dBm

Physical Characteristics

Packaging

MIL-PRF-28800 Style C

Size

14.5 x 9.4 x 6.5 inches

Weight.

20 pounds

Operating Temperature

-28° to +55° C

Battery Operation.

8 hours at a 20%

Duty Cycle

AC Operation/Charging

100 – 240 VAC

47 – 440 Hz

1.6 Abbreviations, Acronyms and Glossary of Term¹

A/A	Air to Air
A/A B	Air to Air Beacon
ac or AC	Alternating Current
A/D	Analog to Digital
ADS-B	Automatic Dependent Surveillance - Broadcast
Address	The unique code to which a MODE S transponder replies. This is not to be confused with the 4096 code used for identifying ATCRBS transponders. The address of a MODE S transponder is not alterable by the pilot or crew.
Altitude	The pressure altitude of the aircraft as transmitted by an ATCRBS or MODE S transponder. This information is obtained from an external sensor and transmitted to the transponder.
AM	Amplitude Modulation
ATCRBS	Air Traffic Control Radar Beacon System
ATCRBS/MODE S All Call	Interrogation that causes all ATCRBS/MODE S transponders to reply.
ATC	Air Traffic Control
AUT	Aircraft Under Test
BIT	Built in Test
Comm	Refers to the communications and data-link capability of a MODE S transponder. There are four (4) capabilities: No Comm, Comm A/B, Comm A/B/C and Comm A/B/C/D. The Comm. capability is displayed when the transponder is determined to be a MODE S.
CW	Continuous Wave
D/A	Digital to Analog
DAP	Downlinked Aircraft Parameter
dB	Decibel
dBm	Decibels above 1 milliwatt
dc or DC	Direct Current
DME	Distance Measuring Equipment
DPSK	Differential Phase Shift Keying. The method of modulation used for the selective MODE S uplink interrogations.
DF	Downlink Format. The format included in a MODE S transponder reply to an interrogation or squitter message that indicates the type of message.
ELM	Extended Length Messages
FAA	Federal Aviation Administration
FAR	Federal Aviation Regulation
FIFO	First In First Out
FREQ	Frequency
ft.	Feet
G/A	Ground to Air
Hz	Hertz
IF	Intermediate Frequency
IFF	Identify Friend or Foe
KHz	Kilohertz
kts.	Knots
LCD	Liquid Crystal Display
LED	Light Emitting Diode

¹ Further definitions may be found in the following reference books and documents: Helfrick, A.D. Principles of Avionics. Leesburg: Quality Books, 2000. RTCA/DO-181B. Minimum Operational Performance Standards for Air Traffic Control RADAR Beacon System/Mode Select (ATCRBS/Mode S) Airborne Equipment. Washington D.C.: 1999. United States. Federal Aviation Administration. Federal Register Fed 3, 1987 FAA rules Part 91.

MODE S	A secondary radar system where transponders can be individually interrogated or selected (the “S” in MODE S) so that in a crowded air traffic area, the amount of interference or garble can be reduced to a minimum.
MHz	Megahertz
nmi.	Nautical mile
ns	Nanosecond
PAM	Pulse Amplitude Modulation
PDME	Precision Distance Measuring Equipment
PMCS	Preventative Maintenance Checks and Services
PPM	Pulses per Minute
PRF	Pulse Repetition Frequency
PW	Pulse Width
PWR	Power
RA	Resolution Advisories
Receiver Efficiency	The Test Set’s Measurement of valid replies received. Displayed as a Percentage.
Reply Codes	A transmitted response, from the airborne transponder, to an interrogation. Commercial transponders responses are designated as either ATCRBS/A where the reply includes the pilot selected 4096 ID code, or ATCRBS/C, where the reply includes the aircraft pressure altitude. These same responses for military transponders are designated as MODE 3A and MODE 3C. See Mode S for further information.
RF	Radio Frequency
RMS	Root Mean Square
R/T	Receiver Transmitter
SIF	Selective Identification Feature
SLS	Side Lobe Suppression. A pulse transmitted from an omni-directional antenna used as a reference level to prevent replies to interrogations received from the secondary radar antenna side lobes.
Squitter	The self-generated transmissions made by a MODE S transponder, not in reply to an interrogation, for the use of the collision avoidance system. And ADS-B Receivers and Transmitters.
SSR	Secondary Surveillance Radar
Surveillance Altitude	An interrogation that causes only the addressed MODE S transponder to reply.
Surveillance ID	An interrogation that causes only the addressed MODE S transponder to reply to its “4096” code.
TA	Traffic Advisories
TACAN	Tactical Air Navigation
TCAS	Traffic Alert and Collision Avoidance System
TIS	Traffic Information System
TX	Transmitter
UF	Uplink Format. The format in a MODE S interrogation that indicates the type of reply expected.
VORTAC	VOR and TACAN (co-located)
VOR	VHF Omni-Directional Range
VSWR	Voltage Standing Wave Ratio
WOW	Weight On Wheels
UUT	Unit Under Test
XPDR	Transponder
XPDR UT	Transponder Under Test
4096 Code	This refers to the octal number dialed into either an ATCRBS MODE A or MODE S transponder by the pilot. This is to be distinguished from the address of the MODE S transponder, which cannot be changed.

CHAPTER II

PREPARATION FOR USE AND OPERATION

SECTION A

GENERAL INFORMATION

2.1 General

This Chapter contains all necessary information on the initial unpacking, inspection, and set-up of the TR-220 Multifunction Test Set (Hereinafter called the TR-220, Test Set, or T/S).

2.2 Unpacking

When receiving the TR-220 for the first time, ensure that there is no damage to the shipping container. Carefully unpack the unit and save the shipping container in a safe location for shipping or extended storage.

Examine the unit for obvious signs of damage. Check all displays, switches, and connectors before utilizing the Test Set.

If any damage is found, DO NOT use the Test Set until a determination of the Test Sets functions can be assessed. Contact Tel-Instrument as soon as possible for further instructions.

The TR-220 Test Set batteries were installed and fully charged when shipped from the factory.

2.3 Installation

The Test Set is fully functional and ready to use from the factory. There are no installation procedures applicable.


2.4 Accessories

Once opening the Test Set Cover, ensure all the accessories that were purchased with the Test Set are accounted for. The TR-220 comes standard with the following (See next page):

#	NOMENCLATURE	P/N	QTY
1	Test Set	90000088	1
2	Cable Assembly, AC Power Cord	75010025	1
3	Cable Assembly, Direct Connect	75010186	1
4	Extender Cable Assembly, Directional Antenna	75010078	1
5	Directional Antenna Cable Assembly	75010208-02	1
6	Directional Antenna Assembly	89001158-07	1
7	Directional Antenna Handle Assembly	88001002	1
X	TAP-200 Antenna Coupler		Optional
XX	TR-220 Manual (Not Shown)	90008088-1	1

TR-220 Accessories

Table 2-1



TR-220 Accessories

Figure 2-1

SECTION B


OPERATING CONTROLS, INDICATORS, AND CONNECTORS

2.5 General

This section covers location and function of the operating controls, indicators, and connectors. All controls, indicators, and connectors are located on the front panel of the Test Set.

2.6 Controls, Indicators, and Connectors

Figure 2-2 and Table 2-2 indicates the location and the function of each item on the front panel of the Test Set.



Controls, Indicators, and Connectors

Figure 2-2

FIG #	Control, Indicator, or Connector	(Table 2-2) FUNCTION
1	SUM Antenna Port	Provides Connection to the Directional Antenna Sum Connector and the optional TAP-135 Antenna Coupler.
2	DIFF Antenna Port	Provides Connection to the Directional Antenna Diff Connector
3	Data Display Window	Alpha/Numeric display (2 lines/20 characters) providing operational instructions, error messages, scenario progress, and test results.
4	UUT FUNCTION Switch	Provides access to Test Set Menus and Modes. SETUP - Set Antenna Gain, T/S Distance, TCAS Scenario Selection, Altitude, Velocity, and Vertical Speed and Distance, Power display (watts or dBm), Cable Loss, Mode S address, and Latitude and Longitude for ADS-B Functions. XPDR - Access ATCRBS and MODE S Transponder test menus. TCAS - Access TCAS intruder menus. ADS-B TX - Select ADS-B Transmitter Results. ADS-B RX - Select ADS-B, and TIS Functions. DME - Access DME Test menus.
5	CHN/ALT, DIST, VERT SPEED Switch	DME- Allows selection of DME Channels. Selectable from 108.0 MHZ in 50 KHz steps. Used in conjunction with UP/FWD – DOWN/REV switch. TCAS- Set Intruder altitude offset from 99,900' to 50,200' in 100' inc/ 50,175' to -9000' in 25' increments. Default is 0'. Used in conjunction with UP/FWD – DOWN/REV switch. TCAS- Intruder vertical speed in "feet per minute" (fpm) adjustable in 100' increments from +7500' to -7500'. Used in conjunction with UP/FWD – DOWN/REV switch.
6	UP/FWD, DOWN/REV Switch	Used in conjunction with CHN/ALT, DIST, VERT SPEED switch to vary parameters. Also used to set antenna gain and Test Set distance in SETUP mode.
7	TO/START – FROM/STOP Switch	Start and Stop TCAS Intruder scenarios and change DME To/From parameters.
8	IDENT Switch	Initiates a SPI Pulse for verification of transponder IDENT function.
9	ATCRBS/AIR, MODE S /GND INTRUDER Switch	Selects TCAS Intruder Type (MODE S or ATCRBS), and Air or Ground position.
10	INCREASE/DECREASE VELOCITY	Sets TCAS Intruder and DME speed velocities. Also utilized for ADS-B TX/RX Functions.
11	Direct Connect Port	For direct connection to a Transponder. Provides accurate RF Power, frequency and sensitivity measurements.
12	MOM/BACK LIGHT/ON Switch	Activates display backlighting either "ON" or momentarily.
13	AUTO/TEST/MANUAL Switch	Allows the operator to select an Automatic Sequence of Transponder tests or a Manual sequence. Initiates TCAS and DME scenarios. Hold AUTO key when Test Set power is turned "ON" to select CW operation. Use AUTO and MANUAL to advance through EHS and ADS-B tests.
14	STORE connector	RS-232 port for download of stored data to a PC.
15	Test Set charging indicator	Indicates to operator that the Test Set Batteries are charging
16	AC Power Panel	1. Provides connection to a 115 or 220 VAC power source. 2. AC "ON" / "OFF" switch for battery charging. 3. Fuse Cartridge.
17	TEST SET ON/OFF Switch	Turns Test Set "ON" and "OFF".
18	Power ON "LED"	Indicates to the operator that the Test Set is "ON".

SECTION C

OPERATING INSTRUCTIONS

2.7 General

The TR-220 is a self-contained instrument comprised of a Test Set mounted in a rugged case with a removable cover. The Test Set front panel contains all the switches necessary to test Transponders (ATCRBS and MODE S), ADS-B and TIS, DME and TCAS equipment. By the use of toggle switches and an easy to read display, the operator may quickly test, make accurate measurements and perform preprogrammed or manually selected TCAS scenarios. The directional antenna with an active LED display and optical sight are utilized for Transponder, DME, and TCAS tests. All accessories are stored in the Test Set case for easy storage and protection.

2.8 Battery Operation

The TR-220 Test Set is equipped with a rechargeable *Lead Acid* battery, capable of operating the Test Set using a 20% duty cycle for 8 hours at 77 degrees F (25 Degrees C). This represents a full day of typical testing on a single charge. When operating the Test Set in lower temperatures, the battery life will decrease slightly.

The operator will be able to utilize the Test Set until the batteries are nearly depleted. The unit may then be plugged into a standard 115 or 220 VAC / 47 to 440 HZ power source to continue testing. By observing a Duty Cycle (DC) of 20%, the Test Set batteries will begin regaining their charge while testing is in progress.

The TR-220 provides a low battery warning system to alert the operator when battery strength has been depleted to a point where testing may be interrupted. Several warning are displayed to warn the operator of this condition and to give them a warning that the batteries will require charging or supplemental AC power applied to complete extended testing.

As the battery capacity decreases, the Test Set will display the following:

Low Battery
Press AUTO to cont.

Toggle the **AUTO** switch to bypass the display and continue testing. Approximately 15 minutes of battery capacity is available. As the battery strength decreases, the display will indicate:

Low Battery
Recharge Required!

This indicates only several minutes of testing time is available. It is recommended that AC power be supplied to continue testing or testing halted at this point and the Test Set charged. Toggle the **AUTO** switch to bypass this warning. Further testing will result in the final warning:

**Low Battery
SHUTTING DOWN**

This warning cannot be bypassed, and AC power must be utilized or charging the battery is necessary.

It is strongly recommended that the batteries be charged for a short time each week, regardless if the Test Set has been utilized or not. A completely discharged battery will require approximately 16 hours to fully charge. Occasional charges of 16 hours on partially depleted batteries will have no adverse effects.

The current battery status display is available in the SETUP function.

**Battery: E■■■■■F
Cont: AUTO**

2.8.1 Auto Shutdown

To preserve battery strength, the TR-220 will automatically shut down after 20 minutes of inactivity. By toggling any switch during the 20 minutes will reset the timer allowing extended testing.

Shutdown will not occur when AC power is utilized as the source.

2.9 TR-220 Supplied Antenna


Standard equipment with the TR-220 is a Directional Antenna. The antenna, stored in the case cover, can either be hand held, tripod mounted, or directly mounted on the Test Set case. The Test Set also contains a direct connect cable for accurate power and frequency measurements (± 2 dB) when connected directly to the UUT. The Test Set has a built in 50 dB attenuator to prevent damage to the Test Set due to the High Power RF associated with Transponders.

2.9.1 Directional Antenna

The Directional Antenna is a printed circuit sandwiched between two opaque Lexan sheets.

1. Open and remove the TR-220 Test Set case cover. Release the two (2) push button holders
2. The Directional Antenna can be mounted on the case or be hand-held utilizing the supplied handle.
 - 2a. To mount the antenna to the case, simply slide the mounting Tabs (located on the back) into the slots located on the front of the Test Set Case.
 - 2b. To utilize the hand held method, attach the supplied handle to the bottom of the antenna and hand tighten only.

- 2c. You may also attach the antenna to a tripod, which will increase the stability due to high winds or hand movement thus increasing the lock on rate.
3. The operator must first set the proper Antenna Gain value into the Test Set memory. Turn the Test Set "ON" with the **UUT FUNCTION** switch in the **SETUP** position. Locate the **ANT GAIN** menu by toggling the **AUTO/MANUAL** switch. Enter the correct values that are affixed to the Directional Antenna (Figure 2-3) by using the **UP/FWD, DOWN/REV** switch. Ensure you enter both values, 1030 MHz and 1090 MHz. Once completed, turn "OFF" the Test Set. The values will remain in the Test Set memory. You will only need to reenter the values if the antenna is replaced or repaired.



Directional Antenna Gain

Figure 2-3

4. When using the handheld or tripod method, connect the extender cable supplied with the Test Set, ensuring to match the appropriate color-coded cables. Connect the opposite ends of the **ANTENNA SUM & DIFF** connectors on the Test Set front panel. If reversed, the Test Set will display a fault prompting the operator to check their antenna connections.

ANTENNA Connections
Missing or Reversed


5. Maintain a 10 to 170 ft. (3 to 50 meters) unobstructed path to the Aircraft Under Test (AUT), and point the Directional antenna to the appropriate antenna on the AUT.
6. Turn the Test Set "ON" with the **UUT FUNCTION** switch in **SETUP**. Locate the **T/S Distance** menu by toggling the **AUTO** switch and insert the approximate distance measured from the Test Set to the AUT antenna by toggling the **UP/FWD, DOWN/REV** switch. With out turning the Test Set OFF, turn the **UUT FUNCTION** switch to the desired sequence of tests.

T/S Distance: 170 ft
Chg: Up/Dn Cont:Auto

7. The optical sight will have a blinking LED indicating the operator must turn the antenna slightly to gain a strong RF signal. A steady red LED signifies a good RF signal and the Test Set will commence testing. The operator may also observe the *TURN* indicator located on the display. By slowly turning the antenna, the *TURN* indicator will spin slower until a lock is obtained. At that point, the Test Set will display the appropriate display.

NOTE: The TR-220 uses a software technique to narrow the beam width. When testing inside of a hanger, multi-path reflections can cause erroneous *TURN* indications. If unable to eliminate *TURN* message, remove antenna cable connection to DIFF port. This will not affect any test results.

8. Position the antenna with an unobstructed line to the UUT antenna. Ensure that the transmitter or receiver (RX/TX) that you are testing is significantly closer to the Test Set than another operating RX/TX; else, an undesired reply or erroneous and inaccurate results may occur.



Directional Antenna Setup

Figure 2-4

Measurements utilizing the Directional Antenna have an accuracy of ± 3 dB.

2.9.2 Direct Connect

The Direct Connect Cable, supplied with the Test Set, allows the operator to conduct transponder tests directly from the transponder under test. Utilizing the direct connect method eliminates possible antenna and cable losses and ensures the operator the transponder is operating at its full potential. The TR-220 has a built in 50 dB attenuator, thus eliminating the need to connect an external attenuator for power and frequency measurements. Simply connect the supplied cable from the test set to the transponder to be tested. Ensure that if your transponder has multiple antennas (diversity equipped), to terminate the second antenna to prevent damage to the transponder.

If you are not using the Direct Connect method, but the directional antenna method, you must install the supplied termination cap on the **DIRECT CONNECT** port. If it is not properly installed, the Test Set display will prompt the operator to remove the antenna.



Before testing utilizing the supplied Direct Connect cable, the operator must enter the appropriate cable loss to ensure accurate measurements.


1. Access the ANT GAIN menu by turning the Test Set "ON" with the **UUT FUNCTION** switch in the **SETUP** position. Locate the *Cable Loss* menu by toggling the **AUTO/MANUAL** switch. Enter the correct values that are affixed to the supplied cable by using the **UP/FWD, DOWN/REV** switch. If you are using a different cable, it is important to know the cable loss value or inaccurate results will occur. Once completed, turn "OFF" the Test Set or toggle to **AUTO** switch. The value will remain in the Test Set memory. You will only need to reenter the value if another cable is utilized or it is repaired.



Measurements utilizing the direct connect method have an accuracy of ± 2 dB.

2.9.3 TAP-200 Antenna Coupler (Optional)

The TR-220 can be used with the (optional) TAP-200 Anti Radiation Antenna Coupler for testing transponders (fig 2-5). The Antenna couplers provide a limited amount of attenuation, approximately 20 dB, to prevent the transmission of the transponder signal into the airspace above the aircraft under test. The Antenna Couplers may only be utilized on blade type antennas.



TAP-200 Coupler


Figure 2-5

1. Connect the TAP-200 Cable to the TR-220 antenna **SUM** port.
2. Turn the test set **ON** by toggling the **ON/OFF** switch *Up* and turn the **UUT FUNCTION** switch to the **SETUP** position. Scroll to the Antenna Selection screen using the **AUTO/MANUAL** switch.

Antenna: TAP
Chg:Up/Dn Cont:AUTO


3. Use the UP/FWD-DOWN/REV switch to select *TAP*.
4. To install the coupler, pull the ring, which separates the spring-loaded clamp, and slide the coupler over the blade antenna. Ensure that the EMI gasket of the coupler is flush with the aircraft skin and that the coupler is centered over the antenna. Release the ring (fig 2-6).
5. Ensure that the coupler is centered over the antenna to be tested.
6. Due to the availability of numerous styles of antennas, slight adjust of the Coupler may be necessary to receive accurate measurements. If incorrect readings occur, re-position and ensure a snug fit on the antenna. Move the TAP-200 forward or back and double check a firm and snug seal on the aircraft surface (fig 2-7).
7. An accurate adjust of the couplers can be accomplished by advancing to the Manual Mode of tests *POWER*, *RECEIVER*, *FREQ* test page and adjusting the coupler for the maximum power out. Once adjusted, the operator can then restart the appropriate series of tests ensuring accurate results.

Center the TAP-200 as close to center as possible for the style of antenna being tested. If inaccurate results occur, reposition the coupler slightly forward or back and check for a snug flush fit until accurate measurements are displayed. Due to the many styles of antennas available, adjustments may be necessary.



TAP-200 Placement

Figure 2-6



TAP-200 Antenna Adjustment

Figure 2-7

8. Proceed with Transponder testing as outlined in paragraph 2.12 or 2.13

2.10 Initial Startup and Self-Test

When using the Test Set, it is advisable to have a fully charged battery. This will ensure all tests can be completed with no interruptions or loss of data.

1. Turn on the TR-220 by toggling the **ON/OFF** switch “UP”. The green LED located above the switch will illuminate. Briefly, the Test Set display will indicate: Model number, current software version installed and total hours of operation.

Tel-Instrument TR-220 REV X.XX 00001 hrs

2. The Test Set will immediately commence a SELF TEST.

Self Test Testing . . .

The Self Test function is automatic, and will test the following components:

- a. Digital Board
- b. RF Maximum Power
- c. RF Minimum Power
- d. RF Board

If a failure is detected, a message indicating the failed component or test will be displayed. If no failures are detected, the result will be briefly displayed before moving to the initial start page of the selected tests.

Self Test PASS

3. Toggle the **BACKLIGHT** switch to the **MOM** position and verify the Test Set display backlighting illuminates. Release the switch and the backlighting will extinguish.
4. Turn the Test Set “OFF” by toggling the **ON/OFF** switch down. The display will be blank and the green LED will extinguish.

2.11 Transponder Test Sequence

The TR-220 T/S is capable of testing ATCRBS Mode A, Mode C and Mode S transponders. The operator may select between an *Automatic* series of tests and a *Manual* series of tests. Figure 2-8 outlines the sequence, in order, of tests conducted. The Test Set will determine the correct set of tests, either Mode A/C or Mode S upon receiving the transponder RF signal.





Figure 2-8

2.12 Transponder Manual Sequence of Tests



All illustrations shown are for demonstration purposes. Though the test results may be typical, they are not meant to replace FAA guidelines and manufacturer recommendations.

When conducting tests in the *MANUAL* sequence, the operator initializes the sequence by toggling the **AUTO/TEST/MANUAL** switch to the **MANUAL** position. The Test Set then commences a series of tests and displays the individual results of each test (see figure 2-8) ending in the POWER, RECEIVER EFFICIENCY and FREQUENCY page. After each test is completed, the operator must toggle the **MANUAL** switch to advance to the next test in the series.

The “*IDENT*” feature of a transponder can only be tested during the *MANUAL* sequence of tests. See paragraph 2-14 for detailed instructions.

2.12.1 ATCRBS, Mode A/C Manual Testing

1. Utilize the procedures as outlined in paragraph 2.9 to select the preferred antenna method for the following tests.
2. Turn the Test Set “ON” by toggling the **ON/OFF** switch to the **ON** position. Ensure the green LED illuminates.
3. The Test Set commences the Self Test. “PASS” is displayed briefly if no failures are detected.

Self Test
PASS

4. Turn the **UUT FUNCTION** switch to the **XPDR** position. The Test Set will automatically determine the transponder capability as being Mode A and/or C capable and display the appropriate start page.

Capab Mode A/C
Press A/M

5. Toggle the **AUTO/TEST/MANUAL** switch to the **MANUAL** position to begin the sequence.

M A /
Testing . . .

Mode A Test initialized.

M A 1234	100%
0.45–20.35– 0.45	PASS

Test Complete. Display indicates the UUT 4096 Octal Code (1234), Receiver Efficiency as a percentage (100%), Transponder Framing Pulse widths (0.45) and separation measured in .05 μ s increments (20.35 μ s).

6. To advance, toggle the **AUTO/TEST/MANUAL** switch to **MANUAL**. The next test in sequence will commence.

M C	/
Testing . . .	

Mode C Test initialized.

M C 6520 10000'	100%
0.45 – 20.35 – 0.45	PASS

Test Complete. Display indicates the UUT Altitude Gray Code (6520=1000'), Rcvr. Efficiency as a percentage (100%), Transponder Framing Pulse widths (0.45) and separation measured in .05 μ s increments (20.35 μ s).

7. To advance, toggle the **AUTO/TEST/MANUAL** switch to **MANUAL**. The next test in sequence will commence.

Mode A SLS	T
Testing . . .	

Mode A SLS tests are initiated. The test set makes alternating interrogations with and without the SLS pulse.

SLS P1>P2 100% PASS
P1=P2 0% PASS

When P1>P2 (SLS pulse at P1 - 9dB) the transponder reply efficiency should be greater than 99%. For P1=P3 (SLS) The transponder reply efficiency should be less than 1%

8. To advance, toggle the **AUTO/TEST/MANUAL** switch to **MANUAL**. The next test in sequence will commence.

Sensitivity
Testing . . .

UUT Receiver sensitivity tests (MTL) for modes A and C are initiated.

A: -73.9dB	C: -73.9dB
Sens. A&C:	PASS

Test Completed. Display indicates the UUT receiver sensitivity for mode A (-73.9db) and Mode C (-73.9dB) PASS is displayed when Mode A/C sensitivities are within 1dB.


9. To advance, toggle the **AUTO/TEST/MANUAL** switch to **MANUAL**. The next test in sequence will commence.

Power, Frequency /
Testing . . .

UUT Power and Frequency Test is initialized.

Power, Frequency
54 dB 1090.0 MHz

Test Completed. Display indicates the UUT power (54 dB) and Frequency (1090.0) in MHz.



Power measurements are measured in Watts or **dBm**. The Test Set only displays **dB** due to display restrictions. To change the display to indicate Watts, access the **SETUP** menu and toggle to the *Power in Watts* menu. Use the **UP/DOWN** toggle to make a selection.

END OF MODE A/C MANUAL TESTS

2.12.2 **Mode S Manual Testing**

1. Turn the Test Set "ON" by toggling the **ON/OFF** switch to the **ON** position. Ensure the green LED illuminates. Utilize the procedures as outlined in 2.9 to select the preferred antenna method for the following tests.
2. The Test Set commences the Self Test. "PASS" is displayed briefly if no failures are detected.

Self Test PASS

3. Turn the **UUT FUNCTION** switch to the **XPDR** position. The Test Set will automatically determine the transponder capability as being Mode S capable and display the appropriate start page with the COMM A, B, C, & D capabilities also listed. The Test Set will display if the transponder reports it is capable of Enhanced Surveillance (EHS). The Test Set will display the Vertical Status (Air/Ground) and display the results of an Interrogation Identifier (14) test.

Capab Comm AB	EHS
AIR Press A/M	II:14

4. Toggle the **AUTO/TEST/MANUAL** switch to the **MANUAL** position to begin the sequence:

M A	/
Testing . . .	

Mode A Test initialized.

M A 1234	100%
0.45–20.35– 0.45	PASS

Test Complete. Display indicates the UUT 4096 Octal Code (1234), Receiver Efficiency as a percentage (100%), Transponder Framing Pulse widths (0.45) and separation measured in .05 μ s increments (20.35 μ s).

5. To advance, toggle the **AUTO/TEST/MANUAL** switch to **MANUAL**. The next test in sequence will commence:

M C	/
Testing . . .	

Mode C Test initialized.

M C 6520 10000' 100% 0.45-20.35-0.45 PASS
--

Test Complete. Display indicates the UUT Altitude Gray Code (6520=1000'), Rcvr. Efficiency as a percentage (100%), Transponder Framing Pulse widths (0.45) and separation measured in .05 μ s increments (20.35 μ s).

6. To advance, toggle the **AUTO/TEST/MANUAL** switch to **MANUAL**. The next test in sequence will commence:

Mode A SLS / Testing . . .

Mode A SLS tests are initiated. The test set makes alternating interrogations with and without the SLS pulse.

SLS P1>P2 100% PASS P1=P2 0% PASS

When P1>P2 (SLS pulse at P1 - 9dB) the transponder reply efficiency should be greater than 99%. For P1=P3 (SLS) The transponder reply efficiency should be less than 1%

7. To advance, toggle the **AUTO/TEST/MANUAL** switch to **MANUAL**. The next test in sequence will commence:

M A All Call / Testing . . .

Mode A All Call Test initialized. Transmits an M A All Call.

M A All Call / A02008 100%

Test Complete. Successful DF=11 reply will display the decoded aircraft address in Hexadecimal (A02008) and Receiver Efficiency as a percentage (100%).

8. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

M C All Call / Testing . . .

Mode 3C All Call Test initialized. Transmits a Mode 3C All Call.

M C All Call / A02008 100%

Test Complete. Successful DF=11 reply will display the decoded aircraft address in Hexadecimal (A02008) and Receiver Efficiency as a percentage (100%).

9. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

M A Only / Testing . . .

Mode A ONLY Test initialized. Test Set transmits an ATCRBS ONLY All-Call.

M A Only / PASS

A Mode S transponder will not reply to an ATCRBS Only All-Call. A "PASS" signifies the Mode S transponder did not respond.

10. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

M C Only / Testing . . .

Mode 3C ONLY Test initialized. Test Set transmits an ATCRBS ONLY All-Call.

M C Only / PASS

A Mode S transponder will not reply to an ATCRBS Only All-Call. A "PASS" signifies the Mode S transponder did not respond.

11. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

SI Lockout / Testing . . .

SI Lockout PASS 18 sec

The Test Set issues a SI Lockout command (37) and verifies that UUT will not respond for minimum of 3 seconds and maximum of 18 seconds.


12. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

M S Surv ID / Testing . . .

Mode S Surveillance Identity Test initialized. Test Set will transmit an UF=5 interrogation.

M S Surv ID / 1234 FS: AIR 100%

Test complete. A successful DF=5 Reply will display the aircraft 4096 Octal code (1234), Flight Status (Air), and Receiver Efficiency as a percentage.



Possible Flight Status Codes are AIR (Airborne), GND (Ground), AL/AR (Alert/Airborne), AL/GND (Alert/Ground), AL/SP (Alert/SPI), and SPI .
--

13. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

M S Surv Alt	/
Testing . . .	

Mode S Surveillance Altitude Test. Test Set will transmit an UF=4 interrogation.

M S Surv Alt	/
10000'	100%

Test complete. A successful DF=4 Reply will display reported altitude (10000') and Receiver Efficiency as a percentage (100%).

14. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:


M S Surv Srt	/
Testing. . .	

Mode S Short Air to Air Surveillance Test. Test Set transmits a special short UF=0 interrogation.

USA: N107PP	/
A02008 VS:AIR 100%	

USA: N107PP	/
50020010 VS:AIR 100%	

Test complete. A Mode S transponder will reply in a DF=0 format. Alternating display will indicate the Country code (USA) and tail number, aircraft address in Hexadecimal (A02008) and Octal (50020010).



Appendix A list available country codes. If the Test Set can not locate the country algorithm, "?????" will be displayed.

15. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

M S Comm Id	/
Testing . . .	

Mode S Communication Identity Test. Test Set will transmit a COMM A/B transmission utilizing the UF=5/RR:18 field. This tests the transponders communication and data-link capabilities.

M S Comm Id	/
1234 yyyyyyyy 100%	

Test complete. A successful DF=21 Reply will display 4096 code (1234), Flight ID (yyyyyyyy) and Receiver efficiency as a percentage (100%).

16. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

M S Comm Alt /
Testing . . .

Mode S Communication Altitude Test. Test Set will transmit a COMM A/B transmission utilizing the UF=4/RR:18 format. This tests the transponders communication and data-link capabilities.

M S Comm Alt /
10000' 100%

Test complete. A successful DF=20 Reply will display UUT Altitude (10000') and Receiver Efficiency as a percentage

17. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

Undesrd Rply /
Testing . . .

Undesired Replies Test initialized. The Test Set will make randomly addressed interrogations.

Undesrd Rply /
PASS

Test complete. If the UUT replies to any of the random interrogations, "FAIL" will be displayed. A "PASS" indicates the UUT did not reply as required. The test set uses a minimum of 3 random addresses to comply with FAR 43 App F.

18. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

Squitter /
Testing . . .

The Test Set will not transmit interrogations but receive and process DF=11 and DF=17 extended replies.

ACQ: PASS 900 ms
ADD: A02008 II:0

EXT: NOT DETECTED

Test complete. Upon detection of the replies, the Test Set will display the interval time of the messages (if received) in milliseconds (900 ms). If either a DF=11 or DF=17 extended message is not acquired, *NOT DETECTED* will be displayed.

EXT: PASS 500 ms
ADD: A02008 II:0

If and Extended Squitter "IS" detected, the following display indicating the interval time and address.

19. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

Max True Spd /
Testing . . .

Test Set verifies the UUT airspeed code by transmitting an UF=0 interrogation.

Max True Spd /
GT 300 & LE 600 kts

Test complete. The DF=0 will report the aircraft maximum cruising airspeed in the RI field of the DF=0 format.

NOTE

Eight possible RI field codes are available.
1) *NO Max airspeed data*, 2) *LE 75 knots*, 3) *GT 75 & LE 150 kts.*, 4) *GT 150 & LE 300 kts*, 5) *GT 300 & LE 600 kts*, 6) *GT 600 & LE 1200 kts*, 7) *GT 1200 kts*, 8) *Not Assigned*.

GT denote "Greater Than", LE denotes "Less than or Equal too"

20. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

Diversity /
Testing . . .

Diversity Test initialized.

Diversity A02008 /
PASS 26 dB Attn

Test complete. A *PASS* indicates that isolation relative to the active antenna is greater than 20 dB. and the actual isolation figure is displayed.

21. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

Sensitivity /
Testing . . .

UUT Receiver sensitivity tests (MTL) for modes A and C are initiated.

A: -73.9dB C: -73.9dB
Mode S: -74.4 dB PASS

Test Completed. Display indicates the UUT receiver sensitivity for mode A (-73.9db), Mode C (-73.9dB) and Mode S (-74.4dB). *PASS* is displayed when Mode A/C/S sensitivities are within 1dB.

22. Toggle the **AUTO/TEST/MANUAL** switch to **MANUAL** to advance to the next sequence:

Power, Frequency / Testing

UUT Power and Frequency tests for modes A and C are initiated.


Power, Frequency / 54 dBm 1090.0Mhz
--

Test completed. UUT transmitter power (54dBm) (shown in dBm or WATTS as selected in Set-up Menu) and UUT transmitter frequency in MHz.

END OF MODE S MANUAL TESTS

2.13 Transponder Automatic Sequence of Tests

When conducting tests in the *AUTO* sequence, the operator initializes the sequence by toggling the **AUTO/TEST/MANUAL** switch to the **AUTO** position. The Test Set then commences a series of tests without interruption (see figure 2-8) ending in the POWER, RECEIVER EFFICIENCY and FREQUENCY page. Test results will not be displayed unless a failure occurs. The operator can then override the failure and continue testing by toggling the **TEST** switch to the **AUTO** position.



All illustrations shown are for demonstration purposes. Though the test results may be typical, they are not meant to replace FAA guidelines and manufacturer recommendations.

Before testing begins, ensure that you have read and fully understand the procedures preceding this section. By reviewing these sections, the operator can avoid erroneous and inaccurate results.

2.13.1 ATCRBS, Mode A/C Automatic Testing

1. Turn the Test Set “ON” by toggling the **ON/OFF** switch to the **ON** position. Ensure the green LED illuminates.
2. The Test Set commences the Self Test. “PASS” is displayed briefly if no failures are detected.

Self Test
PASS



3. Utilize the procedures as outlined in 2.9 to select the preferred antenna method for the following tests.
4. Turn the **UUT FUNCTION** switch to the **XPDR** position. The Test Set will automatically determine the transponder capability as being Mode A/C capable and display the appropriate start page.

Capab Mode A/C
Press A/M

5. Toggle the **AUTO/TEST/MANUAL** switch to the **AUTO** position. The Test Set will begin testing the transponder, without interruption, IAW figure 2-4. Each test will be displayed as “Testing . . .” but no results will be shown, until the Test Set as completed all tests.


M A /
Testing . . .

6. If no failures are detected, the Test Set will cease testing and display the following alternating display:



Power measurements are measured in Watts or **dBm**. The Test Set only displays **dB** due to display restrictions. To change the display to indicate Watts, access the **SETUP** menu and toggle to the *Power in Watts* menu. Use the **UP/DOWN** toggle to make a selection.

7. If a failure is detected during any test in the *Automatic* sequence, the Test Set will “STOP” at that test and display the failure along with the Framing Pulses, Pulse Width, and separation in μ s.



8. The operator may override and advance to the next test in sequence by toggling the **AUTO/TEST/MANUAL** switch to the **AUTO** position. It is recommended that the operator determine the cause of the failure before advancing. Subsequent tests may be inaccurate or misleading.
9. The operator may also elect to repeat the failed test by toggling the **AUTO/TEST/MANUAL** switch to the **MANUAL** position.

END OF MODE A/C AUTOMATIC TESTS

2.13.2 Mode S Automatic Testing

1. Turn the Test Set “ON” by toggling the **ON/OFF** switch to the **ON** position. Ensure the green LED illuminates.
2. The Test Set commences the Self Test. “PASS” is displayed briefly if no failures are detected.

Self Test PASS

3. Utilize the procedures as outlined in 2.9 to select the preferred antenna method for the following tests.
4. Turn the **UUT FUNCTION** switch to the **XPDR** position. The Test Set will automatically determine the transponder capability as being Mode S capable and display the appropriate start page with the Communication capability of the Transponder (COMM NO, COMM AB, COMM ABCD).

Capab Comm AB	EHS
AIR Press A/M	II:14

5. Toggle the **AUTO/TEST/MANUAL** switch to the **AUTO** position. The Test Set will begin testing the transponder, without interruption, IAW figure 2-7. Each test will be displayed as “TESTING . . .” but no results will be shown until the Test Set as completed all tests.

M A	/
Testing . . .	

6. If no failures are detected, the Test Set will cease testing and display the following alternating display:

FID: yyyyyy	10000'
54dB	1090.0MHz


H: A02008	O:50020010
1234	USA:N107PP

The final alternating display will indicate the transponder decoded *Flight ID Code* (FID: YYYYYYYY), Aircraft altitude (10000'), UUT Power (54dB), Freq. (1090.0), aircraft address in both Hexadecimal and Octal (A02008, 50020010), and the Country code and tail number (USA:N107PP) if available.

NOTE

Appendix A lists available country codes. If the Test Set can not locate the country algorithm, “??????” will be displayed.

7. If a failure is detected during any test in the *Automatic* sequence, the Test Set will “STOP” at that test and display the failure along with the Framing Pulses-Pulse Width and separation in μ s.




Illustrate a Squitter failure

8. The operator may override and advance to the next test in sequence by toggling the **AUTO/TEST/MANUAL** switch to the **AUTO** position. It is recommended that the operator determine the cause of the failure before advancing. Subsequent tests may be inaccurate or misleading.
9. The operator may also elect to repeat the failed test by toggling the **AUTO/TEST/MANUAL** switch to the **MANUAL** position.

END OF MODE S AUTOMATIC TESTS

2.14 Testing a Transponders “IDENT” Function



The “*IDENT*” function can only be tested in the **Manual** mode of Tests in both Mode A/C and Mode S.

1. To test the “*IDENT*” feature of a transponder the operator may select the **Mode A** or the **M C Test** for the appropriate transponder (Mode A/C or Mode S).

M A	/
Testing . . .	

2. Allow the Test Set to complete the test.

M A 1234	100%
0.45–20.35– 0.45	PASS

3. Press the **IDENT** button or switch located on the transponder control panel or cockpit interface.
4. **IDENT** will be displayed for approximately 20 seconds to verify the receipt of the *SPI* pulse from the transponder.

M A 1234 IDENT	100%
0.45 — 20.35 — 0.45	

5. The operator may now continue testing the transponder through the remainder of the tests.


END OF TRANSPONDER TESTS

2.15 TCAS Tests

The TR-220 Multifunction Test Set is capable of fully testing ATCRBS and Mode S, ACAS, TCAS I, and II systems (Traffic Alert and Collision Avoidance System). The operator is able to manually select a scenario or utilize the default scenario already preprogrammed in the Test Set Memory. When properly used, the Test Set will simulate an Intruder Aircraft converging on the position of the UUT. The operator may then observe the TCAS display to ensure the correct TA's (Traffic Advisory) and RA's (Resolution Advisory) occur on their display.

The Simulation is used with the Directional Antenna. This gives the operator the ability to move the Test Set to different locations and headings from the UUT.


2.15.1 Typical TCAS Concepts



All illustrations shown are for demonstration purposes. Though the test results may be typical, they are not meant to replace FAA guidelines and manufacturer recommendations.


TCAS is a system, which provides situational awareness of the surrounding airspace of an aircraft to the pilot and crew. A TCAS establishes a volume of airspace around the aircraft. The size of the airspace is based on range, speed and altitude. By working in-conjunction with the aircraft Transponder system, the TCAS can determine the relative threat of an aircraft, issue visual and audible advisories to assist the crew in locating and/or take action to prevent a collision.

The perimeter of the **CAUTION AREA** is approximately 20 to 48 seconds to the time the intruder would enter the **WARNING AREA**. Refer to Figure 2-9.



Caution, Warning, and Collision Areas for a TCAS I System

Figure 2-9



Typical TCAS I Display

Figure 2-10

The perimeter of the **WARNING AREA** is approximately 15-35 seconds from entering the **COLLISION AREA** (not depicted).

When an aircraft enters the **CAUTION AREA**, a "TA" (Traffic Advisory) is issued. This would consist of an audible and visual warning in the cockpit.

When an intruder enters the **COLLISION AREA**, the TCAS will issue a "RA" (Resolution Advisory). "RA's" consist of audible and visual warnings and possible instructions to avoid a collision.

A TCAS display will vary dependent on the manufacturer. Typically, a TCAS I system, as shown in figure 2-10, will display Traffic Advisories. A TCAS II System will be incorporated with a Vertical Speed Indicator (VSI), which will issue a RA, the pilots VSI will display a course of action to avoid a collision with an aircraft located in the **COLLISION AREA**.

2.15.2 TCAS Scenario Selection and Setup

1. To TR-220 must have the correct values entered to properly program an intruder to converge with the UUT aircraft. If the intruder scenario is incorrectly programmed, the operator may not receive the anticipated results.
2. Turn the Test Set "ON" and turn the **UUT FUNCTION** switch to **SETUP**.
3. Access the *TCAS Scenario* menu. The TR-220 has 10 preprogrammed intruder scenarios in its memory (see table 2-3). All TCAS Scenarios can be modified

and stored in the Test Set Memory. By toggling the **UP/FWD-DOWN/REV** switch, the operator can select the appropriate intruder scenario.

TCAS Scenario: 1
Chg:Up/Dn Cont: AUTO

4. After selecting a suitable scenario, the operator needs only to turn the **UUT FUNCTION** switch to the **TCAS** position to begin an intruder simulation. Proceed to paragraph 2.15.5 to continue with TCAS Tests. If the operator desires different parameters, continue with Step 5.

Scenario #	TCAS Start Distance	Start Altitude (Intruder)	Vertical Speed	Velocity
1	5 nmi.	2500 ft	0 fpm.	250 Kts.
2	5 nmi.	2500 ft	0 fpm.	250 Kts.
3	5 nmi.	2500 ft	0 fpm.	250 Kts.
4	5 nmi.	2500 ft	0 fpm.	250 Kts.
5	5 nmi.	2500 ft	0 fpm.	250 Kts.
6	5 nmi.	2500 ft	0 fpm.	250 Kts.
7	5 nmi.	2500 ft	0 fpm.	250 Kts.
8	5 nmi.	2500 ft	0 fpm.	250 Kts.
9	5 nmi.	2500 ft	0 fpm.	250 Kts.
10	5 nmi.	2500 ft	0 fpm.	250 Kts.

Preprogrammed (default) TCAS scenarios

Table 2-3

5. If the operator desires different parameters, Leave the **UUT FUNCTION** switch in the **SETUP** position and toggle the **AUTO** switch. The *Start Alt* menu will be displayed.

Start Alt: 2500'
Chg:Up/Dn Cont: AUTO

6. Toggle the **UP/FWD-DOWN/REV** switch to change the intruder's start altitude. The Altitude can be changed from -1000 ft. to +99,900 ft. The altitude is adjustable in 25 ft. increments between -1000 ft. and 50,175 ft. and in 100 ft. increments above 52,000 ft. Hold the toggle switch either *UP* or *Down* for more than 5 seconds and the adjust speed will increase.

Start Alt: 10000'
Chg:Up/Dn Cont: AUTO

7. Toggle the **AUTO/TEST/MANUAL** switch to the **AUTO** position to advance to the *Velocity* menu. Utilize the **UP/FWD-DOWN/REV** switch to set the velocity to the desired setting. The *Velocity* is adjustable from 120Kts to 1200Kts.

Velocity: 180 nmi/h Chg:Up/Dn Cont: AUTO

8. Toggle the **AUTO/TEST/MANUAL** switch to the **AUTO** position to advance to the *Vert Speed* menu. Utilize the **UP/FWD-DOWN/REV** switch to set the vertical speed to the desired setting. The *Vert Speed* is adjustable from +7,500 fpm. to -7,500 fpm.

Vert Speed: +000 fpm Chg:Up/Dn Cont: AUTO
--

9. Toggle the **AUTO/TEST/MANUAL** switch to the **AUTO** position to advance to the *TCAS dist* menu. Set the distance of the intruder to the UUT by toggling the **UP/FWD-DOWN/REV** switch to the desired range. The range is adjustable from 1 nmi. to 50 nmi.


TCAS dist: 5 nmi Chg:Up/Dn Cont: AUTO
--

10. Toggle the **AUTO/TEST/MANUAL** switch to the *Mode S Addr* menu. The operator may change the Mode S address of the intruder aircraft. Switching the **switch** to **ALT** and then using the **UP/FWD-DOWN/REV** switch will enable the first two digits of the address to be changed. Switching to DIST and then to SPEED will enable the second two digits and final two digits to be changed with the UP-DOWN switch respectively.

Mode S Addr: 3D8DFF Chg: Al/Ds/Sp-Up/Dn
--

By toggling the IDENT switch, the Mode S address will be decoded into the corresponding aircraft tail number where possible, or just show the country code for those countries that do not have an appropriate algorithm.

Mode S Addr: 3D8DFF DEU: D-GAAH

**WARNING**

Some Mode S Addresses may not be used. Ensure that the code you use is authorized in the country where the Test Set is being utilized. Tel-Instrument Corp. initially inserts **A00001** for the Mode S Address before shipping the Test Set.

When changing the Mode S address, utilize both the **CHN/ALT-DIST-VERT SPEED** and the **UP/FWD-DOWN/REV** switches.

11. Once all parameters have been set, turn the **UUT FUNCTION** switch to the **TCAS** position. The scenario is now held in the Test Set memory.
12. As a convenience, the following describes intruder scenarios and the correct parameters necessary to ensure a simulated convergence will occur.

The operator is able to select an infinite number of simulated Intruder scenarios. The TR-220 allows the user to select *Intruder Starting Altitude*, *Vertical Speed*, and *Distance* from target, and three preset *Velocities*. Table 2-4 describes each parameter and limitations.

PARAMETER	MIN AND MAX	NOTES
Intruder Velocity	120 – 1200 Kts.	10 KT. increments
Intruder Altitude	99,900 to -1000 ft.	50,200 to 99,900 in 100 ft increments -9000 to 51,175 ft in 25 ft increments
Vertical Speed	-7,500 to 7,500 fpm.	100 ft. increments
Intruder Distance	0 – 50 nmi.	1 nmi. increments

TCAS Intruder Parameters

Table 2-4

To select a scenario that will properly converge and intercept the UUT, the Aircraft altitude must be known. If any parameter is incorrectly entered, the intruder simulation may not intersect the UUT resulting in the operator not observing the intended display. The operator may utilize a Pitot Static Test Set to “Pump-Up” the aircraft altitude. It is recommended that this be accomplished before actual TCAS testing begins.

To correctly enter intruder parameters, utilize the following formula for reliable test results.

$$VS = \frac{(\text{UUT} - \text{Intruder Altitude}) \times \text{Velocity}}{\text{Intruder Distance} \times 60}$$

Assume the UUT Altitude is Pumped-up to 10,000 ft, Intruder Altitude set for 20,000 ft, Intruder Velocity is 600 kts and Intruder Distance is 20 nmi.

$$VS = \frac{(10,000 - 20,000) \times 600}{20 \times 60}$$

Complete the equation to find the correct Vertical Speed (VS) value to be entered.

$$VS = \frac{-6,000,000}{12000}$$

$$VS = -5000$$

The correct Vertical Speed variable is -5000 fpm.

Table 2-5 lists random TCAS Scenarios that will result in proper intruder convergence resulting in an RA and/or TA on the TCAS display.

Scenario #	UUT ALTITUDE (Pumped Up)	STARTING ALTITUDE	VELOCITY	TCAS DISTANCE	VERTICAL SPEED
1	-1000 ft.	2000 ft.	180 kts	10 nmi	-900 fpm
2	-500 ft.	1000 ft.	300 kts	15 nmi	-500 fpm
3	0 ft.	0 ft.	600 kts	20 nmi	0 fpm
4	500 ft.	1000 ft.	300 kts	25 nmi	-100 fpm
5	1000 ft.	3500 ft.	180 kts	25 nmi	-300 fpm
6	5000 ft.	4000 ft.	300 kts	25 nmi	200 fpm
7	7500 ft.	9500 ft.	600 kts	40nmi	-500 fpm
8	10,000 ft.	15,000 ft.	180 kts	50 nmi	-300 fpm
9	12,500 ft.	7500 ft.	300 kts	25 nmi	1000 fpm
10	15,000 ft.	30,000 ft.	600 kts	30 nmi	-5000 fpm
11	17,500 ft.	34,000 ft.	180 kts	15 nmi	-3300 fpm
12	20,000 ft.	10,000 ft.	300 kts	50 nmi	1000 fpm
13	25,000 ft.	41,500 ft.	600 kts	30 nmi	-5500 fpm
14	33,000 ft.	50,000 ft.	180 kts	30 nmi	-1700 fpm
15	42,000 ft.	15,000 ft.	300 kts	25 nmi	5400 fpm
16	49,000 ft.	31000 ft.	600 kts	45 nmi	4000 fpm
17	3000 ft.	5000 ft.	300 kts	25 nmi	-400 fpm
18	3500 ft.	2000 ft.	180 kts	45 nmi	-100 fpm
19	4500 ft.	2500 ft.	300 kts	50 nmi	200 fpm
20	7500 ft.	3000 ft.	600 kts	45 nmi	1000 fpm
21	8500 ft.	10,000 ft.	180 kts	15 nmi	-300 fpm
22	9000 ft.	15,000 ft.	300 kts	30 nmi	1000 fpm

Additional TCAS Intruder Scenarios

Table 2-5

2.15.3 Erasing the TCAS Scenario Memory

The TCAS memory can be restored to factory settings by the following procedures:

1. Place the **UUT FUNCTION** switch in the **SETUP** position.
2. Access the *TCAS Scenario* menu by toggling the **AUTO/TEST/MANUAL** switch.

TCAS Scenario: 1
Chg:Up/Dn Cont: AUTO

3. Toggle the **IDENT** switch "*UP*". The display shall revert to the *Reset Scenario* menu.

Reset Scenarios: MAN
Cont Press AUTO

4. Toggle the **AUTO/TEST/MANUAL** switch to the **MANUAL** position. This will reset the operator-inserted scenarios and revert to the factory settings.

Default Scenarios
Reset

2.15.4 Testing a TCAS Equipped Aircraft

1. Connect the Directional Antenna to the Test Set IAW Paragraph 2.9.1. The Directional Antenna is the only antenna that may be utilized for TCAS testing.
2. Turn the Test Set "ON" by toggling the **ON/OFF** switch to the **ON** position. Ensure the *GREEN* LED is illuminated.
3. Place the **UUT FUNCTION** switch in the **TCAS** position. The test set will first measure the TCAS transmitter power and frequency and the display will indicate the following

Power	Frequency /
Listening . . .	

4. After a few seconds, the display will indicate the following:

Power	Frequency /
150W	1030.01Mhz

Power and Frequency measurements are approximate values and should be used for reference purposes only.

5. Press the **AUTO/TEST/MANUAL** switch to continue. The test set will next display the AUT Mode S address, transmitted via the TCAS system in a UF16 interrogation. The display will indicate the following

TCAS UF16 Md S Add:
3D8DFF

6. Press the **AUTO/TEST/MANUAL** switch to access the TCAS scenario selection screen and select the appropriate intruder scenario by using the **UP/FWD-DOWN/REV** switch. Paragraph 2.15.2 describes in detail correct procedures for initially programming and storing the TCAS scenarios.

NOTE


The following text utilizes Scenario 1, which is the default TCAS scenario. The parameters are as programmed in the example in para 2.15.2.

TCAS Test	Mode S
Scen: 1,	Press AUTO

7. Simulate the UUT aircraft altitude to 10,000 ft by "Pumping Up" the aircraft with a Pitot Static test set
8. Select the Intruder velocity by toggling the **INCREASE-DECREASE VELOCITY** switch to the desired speed.


9. Select the intruder type, Mode S or ATRBS using the ATRBS/AIR-MODE S/GND switch. For TCAS I select ATRBS and for TCAS II select Mode S.
10. Toggle the **AUTO/TEST/MANUAL** switch to the **AUTO** position. The Test Set is now simulating an intruder aircraft at the selected position. **STP** indicates that the intruder is stopped at the initial position. Verify a display is annunciated on the UUT TCAS display. The display will indicate **ACQ** for a ATRBS TCAS system. A Mode S TCAS system will initially show **ACQ** then change to indicate **TRK** once the correct *BIT* is received.

TRK 180 Kts 10000' / 5.0nm 000fpm STP
--




11. Toggle the **TO/START-FROM/STOP** switch to the **TO** position to commence the intruder convergence on the UUT. The Test Set display will indicate the altitude, range, velocity and climb rate (fpm) of the intruder simulation.

TRK 180Kts 10000' / 3.5 nm +000fpm TO
--



12. The operator may now observe the AUT TCAS display to ensure correct operation. Once the simulated intruder's range has reached 0 nmi, the Test Set will reverse the heading and return back to the start point. This will continue, back and forth, until the operator stops the simulation.




13. At any point during the simulation, the operator may STOP the intruder at any range. Toggle the **TO/START-FROM/STOP** switch twice to the **STOP** position. The intruder will stop and hold at that range. The operator now may move the Test Set to a different location around the AUT to check that correct azimuth information is being displayed on the TCAS display.
14. By selecting a starting altitude above or below the “Pumped UP” UUT altitude, the operator can simulate an intruder converging on the UUT from above or below the UUT. Table 2-5 lists several scenarios, which can be utilized for this purpose.

14a. For Example: Select Scenario #10.


Scenario #	UUT Altitude	Starting Altitude	Velocity	TCAS Distance	Vertical Speed
10	15000 ft.	30,000 ft.	600 kts	30 nmi	-5000 fpm

14b. Enter the values above in the *TCAS Scenario* Setup menus (Paragraph 2.15.2) and “Pump Up” the UUT aircraft to 15000 ft.

14c. Start the Intruder simulation as described in Paragraph 2.15.5.(11)




- 14d. As the simulated intruder approaches, the altitude will decrease to ensure a proper intersect of the targets.



- 14e. Once the intruder has converged with the UUT, the simulation will reverse course and return to the original starting point.

TRK 600Kts 16150' / 2.1 nm -5000fpm FRM
--



15. It is possible to adjust the scenario parameters without changing the stored parameters within the *Setup Menu*. With the **UUT FUNCTION** switch in the TCAS position and with the TCAS scenario window displayed, proceed as follows:

TRK 600Kts 16150' / 2.1 nm -5000fpm STP
--

- 15a. Ensure that pressing the TO/STAR-FROM/STOP switch up twice and the display stop the scenario shows STP. (This is the only position, which allows temporary modification of the scenario parameters)
- 15b. By switching the **CHN/ALT-DIST-SPEED** switch to the relative positions, the altitude, distance and speed of the intruder can be adjusted with the UP-DOWN switch. Intruder velocity can be changed with the **INCREASE-DECREASE VELOCITY** switch. The scenario can now be run again with the modified parameters.

NOTE

Pressing AUTO to measure TCAS power and frequency or restarting the TCAS testing by moving the UUT Function switch will revert to the selected scenario parameters

END OF TCAS TESTS

2.16 DME Tests

The TR-220 is capable of selecting any of the DME frequencies of 108.0 – 117.95 MHz channels. The Test Set simulates a ground station at an operator selected range and velocity. When the operator initiates the test, the Test Set range, TO or FROM, will decrease to 0 nmi., and return back to the pre-selected range. The operator may also freeze the simulation at any point during the simulation.

The following paragraph will describe the procedure to properly conduct a test of a DME Receiver. The Directional Antenna is utilized for DME testing.

2.16.1 DME Setup

1. Connect the directional Antenna and follow the procedures as outlined in Paragraph 2.9.1.
2. Turn the Test Set “ON” by toggling the **ON/OFF** switch to the **ON** position. Verify the green LED is illuminated.
3. Select **DME** using the **UUT FUNCTION** switch and verify the following display: (note that DME velocity will be the last selected velocity).

108.00MHz	350K	0Hz
50.0nmi	Ident	Hold T

4. To select the appropriate frequency, place the **CHN/ALT-DIST-VERT SPEED** switch in the **CHN/ALT** position. Using the **UP/FWD-DOWN/REV** switch, select the desired DME channel. The operator may select any frequency from 108.00 to 117.95 MHz.
5. To select the range from the UUT, place the **CHN/ALT-DIST-VERT SPEED** switch in the **DIST** position and toggle the **UP/FWD-DOWN/REV** switch to the appropriate range. The Test Set range can be varied from 0 – 250 nmi, in 1 nmi increments (default distance is 50nmi).
6. Select the velocity of the scenario by toggling the **INCREASE-DECREASE VELOCITY** switch to **INCREASE** or **DECREASE** the AUT velocity (120-1200Kts in 10 Kt increments).
7. To begin testing, toggle the **TO/START-FROM/STOP** switch either “UP” or “DOWN”. By toggling the switch “UP”, the operator will select **TO** the AUT. The Test Set will begin decreasing the distance to the AUT at the selected velocity and display the UUT PRF in Hz.

108.00MHz	350K	18Hz
47.5nmi	Ident	ToT

8. At any point during the test, the operator may reverse the direction of the simulation by toggling the **TO/START-FROM/STOP** switch “*DOWN*” to the **FROM/STOP** position. The scenarios will then, stop and reverse direction. The *TO* display will change to *FROM* indicating FROM the AUT. The distance will track from the distance selected to zero nmi and back, repeatedly. The AUT DME indicator should be monitored to ensure correct distance and velocity measurements where applicable.

108.00MHz	350K	18Hz
48.0nmi	Ident	FromT

9. To halt the scenario at a selected distance, toggle the **TO/START-FROM/STOP** to the **FROM/STOP** position two times in succession. The simulation will stop at that distance and remain there until the **TO/START-FROM/STOP** switch is toggled to the **TO/START** position.

DME audio can be tested by listening to the AUT DME audio. The Test set will transmit appropriate Morse code station IDENT signal approximately every 40 seconds. The **IDENT** Tone can be switched OFF or ON by toggling the **IDENT** switch up.

To measure DME power and frequency, toggle the **AUTO/TEST/MANUAL** switch to the **AUTO** position. The test set listens for the DME transmissions.

Power	FrequencyT
Listening . . .	

12. The DME power and frequency will be displayed.

Power	FrequencyT
55dbm	1041.0Mhz

END OF DME TESTS

2.17 Mode S Enhanced Surveillance

NOTE

All illustrations shown are for demonstration purposes. Though the test results may be typical, they are not meant to replace manufacturer recommendations or ACTUAL results

The TR-220 is capable of testing Mode S Transponders with Enhanced surveillance (EHS) capability. Access to the EHS menu is as follows:

If utilizing the Directional Antenna, select **SETUP** using the **UUT FUNCTION** switch and complete the procedures in paragraph 2.9.1. Utilize paragraph 2.9.2 if using the supplied direct connect cable.

1. Connect the antenna or direct connect cable as appropriate.
2. Turn the Test Set "ON" by toggling the **ON/OFF** switch to the **ON** position. Ensure the green LED illuminates.
3. The Test Set commences the Self-Test. "PASS" is displayed briefly if no failures are detected.




Self Test
PASS

4. Turn the **UUT FUNCTION** switch to the **XPDR** position. The Test Set will automatically determine the transponder capability as being Mode S capable and display the appropriate start page with the COMM A, B, C & D capabilities also listed if applicable.



Capability COMM ABCD
Press AUTO/MANUAL

5. Press the **TO/START-FROM/STOP** switch upwards to the **TO** position to access the *EHS* menu.



Mode S Enh. Surv.
Using UF5/DF21 . . .

6. EHS testing can be carried out using 3 UF/DF combinations. Press the **UP-DOWN** switch to the "UP" position to select UF5/DF21, UF21/DF21, and the UF0/DF16 as applicable. The results displayed will be the same for each selection.

7. Press the **AUTO/TEST/MANUAL** switch to continue. The Roll angle will be displayed in degrees. Part of the BDS5 Track and Turn report.

BDS5 Roll Angle +90 D

8. Press **AUTO/TEST/MANUAL** to move to the next test. The True track angle will be displayed in degrees and the Track Angle rate will be displayed in degrees per second. Part of the BDS5 Track and Turn report.

BDS5 True Trk Angle An E120 D Rt + 8 D/s

9. Press **AUTO/TEST/MANUAL** to move to the next test. The True Airspeed and Ground Speed will be displayed in Knots. Part of the BDS5 Track and Turn report.

BDS5 Tru ASpd 600K Gnd Speed 550K

10. Press **AUTO/TEST/MANUAL** to move to the next test. The Indicated Airspeed will be displayed in Knots, the Heading in degrees and the Mach number. Part of the BDS6 Heading and Speed report.

BDS6 Ind Aspd 600K Hdg E120 D Mch 1.000
--

11. Press **AUTO/TEST/MANUAL** to move to the next test. The Barometric Altitude Rate and Inertial Vertical Velocity will be indicated in feet per minute. Part of the BDS6 Heading and Speed report.

BDS6 Balt +6000'/M In VertVel +6000'/M

12. Press **AUTO/TEST/MANUAL** to move to the next tests. Subsequent screens will display the values contained in registers BDS 1,0; 1,7; 1,8; and 1,9. The decoded register values are shown in Hexadecimal.

BDS 10 Datalink 10 00 00 80 E0 00 00

The TR-220 will decode and display parameters contained in the BDS 1,0 register. The parameters include, Mode S Subnet Network Number = "Sub Net=0" (Decode and display IAW with ICAO Annex X Volume 3 Sect. 5.2.9 (page 279) 0,1,2, 3, etc.); Transponder enhanced protocol indicator = "TC Lvl= 2-4" (Decode and display 0=2-4 and 1=5); DTE Sub address = "DTE= NO" (Decode and display 0=NO, 1=YES)

BDS1	SubNet=1	A
TC Lvl=	DTE=	

Mode S Specific Services Capability = "SPC SV CP=YES" (Decode and display 0=NO, 1=YES); Continuous Flag = "Cont Flg=NO" (Decode and display 0=NO, 1=YES); Surveillance Identifier = "SI=YES" (Decode and display 0=NO and 1=YES)

BDS1	SPC SV CP=
Cont Flg=	SI=

Aircraft Identification Capability = "Flt ID=YES" (Decode and display 0=NO and 1=YES); Squitter Capability Subfield = "Sq=YES" (Decode and display 0=NO and 1=YES); Common usage GICB capability = "COM GICB=YES" (Decode and display 0=NO and 1=YES)

BDS1	Flt ID=
Sq=	COM GICB=

Uplink UELM capability = "UEL=NO" (0=NO, 1=1, 2=2, etc. ICAO Annex X Volume 3 Sect. 5.2.9 page 280); Downlink DELM capability = "DELM=NO" (0=NO, 1=1, 2=2, etc. ICAO Annex X Volume 3 Sect. 5.2.9 page 280)

BDS1	UEL=
	DELM=

BDS 1,7	Co Use GICB
FA 81 01 00 00 00 00	

BDS 1,8 MS Sp Sv GICB
00 00 00 81 C0 81 F0

BDS 1,9 MS Sp Sv GICB
00 00 80 00 80 00 80

13. Press **AUTO/TEST/MANUAL** to move to the next test. The display will indicate if TCAS has issued a Resolution Advisory. BDS3 ACAS Active Resolution Advisory.

NOTE

A second TR-220 may be necessary to simulate a TCAS intruder in order to cause the TCAS system to issue a Resolution Advisory

BDS Resolution Adv:
Active RA FFFFFFFF

14. Press **AUTO/TEST/MANUAL** to move to the next test. The display will indicate the Selected Altitude in feet. Part of the BDS4 Aircraft Intention report.

BDS4 FMC Alt 25000'
MCP/FCU Alt

Barometric Pressure Setting = "Press Set = 1015".0; Target Altitude Source = "Tgt Alt=UNK" (00=UNK, 01=ALT, 10=BOTH, 11=FMS); Status of Target Alt Source Bits = "Src=NO" (0=NO and 1=YES);

BDS4 Press Set=800.1mb
Tgt Alt= UNK Src=No

VNAV Mode = "VNAV=NA" (0=NA, 1=ACT); ALT Hold Mode = "ALT HD=NA" (0=NA, 1=ACT; Approach Mode = "APRHL=NA" (0=NA and 1=ACT)


BDS4 VNAV = NA
Alt Hld= NA Appr= NA

END OF MODE S ENHANCED TESTS

2.18 ADS-B and TIS Testing

The TR-220 Test Set provides operators with the capability to test ADS-B and TIS functions that are now standard in many models of Transponders. This is an enhancement over standard MODE S transponder that provides operators with unique information previously not available.

2.18.1 ADS-B TX



All illustrations shown are for demonstration purposes. Though the test results may be typical, they are not meant to replace manufacturer recommendations or ACTUAL results.

The TR-220 provides test capability for Mode S Transponders capable of DF17 Extended Squitters or ADS-B. The TR-220 ADS-B TX test can be accessed as follows.

1. Utilize either the Direct Connect Method, Directional Antenna, or the optional TAP-200 for ADS-B and TIS Tests. Utilize paragraph 2.9 for instructions.
2. Turn the Test Set "ON" by toggling the **ON/OFF** switch to the **ON** position. Ensure the green LED illuminates.
3. The Test Set commences the Self-Test. "PASS" is displayed briefly if no failures are detected.

Self Test
PASS

4. Turn the **UUT FUNCTION** switch to ADS-B TX. If no ADS-B squitters are received, the following screen will appear:

DF-17/18 Message
Decoding

5. If a DF17 or DF18 squitter is detected, the display will show the following information. Use the **AUTO/TEST/MANUAL** switch to toggle between screens.

Position . . .

If the Transponder is in the Air and is transmitting a BDS 0,5 Extended Squitter Airborne Position Report, the following screen will be displayed:

Air	5200'	B	0.5s
39	17 51N	94 42	50W

The information displayed includes Squitter Type (Airborne), Altitude in Feet, Altitude Source (Barometric or GNSS), squitter period and encoded latitude and longitude.

NOTE

For certain TR-220 functions, you must store the latitude/longitude of the test set in the SETUP FUNCTION. This is called the HOME POSITION. The latitude/longitude of the Test Set can be entered manually or automatically stored using the latitude/longitude information being transmitted by the aircraft under test. When you have the above screen displayed, press the IDENT switch, wait for the test set prompt and press the AUTO_TEST_MANUAL switch to MANUAL. This will store the latitude and longitude information in the test set HOME POSITION.

To set the Lat & Lon positional information into the TR-220, proceed as follows. Turn the test set **ON** with the **UUT FUNCTION** switch in the set up position.

Use the **AUTO/TEST/MANUAL** switch to scroll the display to the Lat/Lon screen

Latitude:	Longitude:
39> 17 51N	94 42 50W

Use the **TO/START-FROM/STOP** switch to move the > cursor to the field which needs to be set and then use the **UP/FWD-DOWN/REV** switch to change the values to those desired.

If the Transponder is on the Surface (Ground) and is transmitting a BDS 0,6 Extended Squitter Surface Position Report, the following screen will be displayed. The information displayed includes Squitter Type (Surface), Movement in knots, Ground Track (True) in Degrees, squitter period, and encoded latitude and longitude. The proper decoding of the Surface Position requires that the test set latitude and longitude (HOME POSITION) is set to current position.

Gnd	1.0K	+120D	5.0s
39	17 51N	94 42	50W

6. Press the **AUTO/TEST/MANUAL** switch to select the next screen:

Identification . . .

If the Transponder is transmitting a BDS 0,8 Extended Squitter Aircraft Identification and Type Report, the following screen will be displayed. The information displayed includes Aircraft Type, Squitter Period, and Flight ID.

Aircr. Cat: A2 5.0s
 Flight ID: T200ZC

7. Press the **AUTO/TEST/MANUAL** switch to select the next screen:

Airborne velocity

If the Transponder is Airborne (simulated) and is transmitting a BDS 0,9 Extended Squitter Airborne Velocity Report, the following screen will be displayed. The information displayed includes Velocity Type, East/West Velocity (knots), North/South Velocity (Knots), Geometric Height Difference between Barometric and GNSS Height (Feet), and Barometric or GNSS Vertical Rate (Up or Down in Feet/min).

Vel: 1 E 71K N 71K
 Hd: 125' BVR: 600'

8. Press the **AUTO/TEST/MANUAL** switch to select the next screen:

Mode S Address . . .

The TR-220 will decode and display the Aircraft Mode S Address as shown in the following display. In addition, the TR-220 decodes and displays the Interrogator Identifier (II) field.

DF17 MS Addr:A40001
 USA: N357NG II=0

9. Press the **AUTO/TEST/MANUAL** switch to select the next screen:

Latitude & Longitude

The TR-220 will display the encoded latitude and longitude information with more resolution. The display will indicate whether the information is from an Airborne Squitter (A) or Surface Position Squitter (G).

Lat: 39 17 51.30N
Lon: 94 42 50.14W A

2.18.2 ADS-B RX

The TR-220 ADS-B RX Function allows transmission of the following information:

- Mode S Extended Squitter (DF17/DF18), Airborne or Surface Position, for 4 intruder aircraft.
- Traffic Information System (TIS) for 4 intruder aircraft

ADS-B Intruder simulations DF17/DF18 can be accessed as follows:

1. Turn the **UUT FUNCTION** switch to ADS-B RX and use the **AUTO/TEST/MANUAL** switch to select the following screen.

4 DF17 Targets
A00001 Airborne

2. Set the **ATCRBS/AIR-MODE S/GND** Intruder switch to Airborne or Ground.
3. Press the IDENT switch to select DF17 or DF18 target type.
4. Set a Mode S Address for the first intruder by selecting **SETUP** using the **UUT FUNCTION** and using the **AUTO/TEST/MANUAL** switch to select Mode S Address (The Mode S address for the other 3 targets will be incremented by 1). The TR-220 will transmit the DF17 or DF18 information for 4 intruder aircraft that have the following parameters when AIRBORNE intruder is selected:
- Altitude = 10,000 feet
 - Distance = 10 miles from the test set **HOME POSITION**
 - Velocity = 250 knots
 - Target locations are NE, SE, SW, and NW of the test set **HOME POSITION**
 - The Flight ID for the targets are TEL1, TEL2, TEL3, and TEL4

The TR-220 will transmit the DF17 or DF18 information for 4 intruder aircraft that have the following parameters when GND intruder is selected:

- a. Distance = 1 mile from the test set **HOME POSITION**
- b. Velocity = 5 knots
- c. Target locations are NE, SE, SW, and NW of the test set **HOME POSITION**
- d. The Flight ID for the targets are TEL1, TEL2, TEL3, and TEL4

TIS intruder simulations can be accessed as follows:

1. Select ADS-B RX on the TR-220 **UUT FUNCTION** switch
2. Use the **AUTO/TEST/MANUAL** switch to select the following screen:



3. The TR-220 will decode and display the Mode S Address of the Transponder under test.
4. The TR-220 will transmit Comm A (UF21) information for 4 intruders.

The transmitted information for the 4 intruders is as follows:

Target	Bearing	Range	Altitude	VS	Heading	Status
1	0	0.5	+200	LVL	0	TA
2	60	1.5	-500	CLB	45	TA
3	120	3.0	-1500	DES	-45	PA
4	240	5.0	+2000	LVL	90	PA

TIS Intruders

Table 2-6

END OF TIS TEST

2.19 **RS-232 Download Procedures**

The TR-220 contains memory to down load results received during the **AUTOMATIC** sequence of tests to a PC thru the use of the RS-232 port located on the front panel of the Test Set. Once downloaded, the information can be displayed in an Excel file to be viewed and saved for future reference. The following Tests and results are captured to the Test Set's memory:


1. **MODE A & SLS**
Re: Mode A Reply, Mode A Code, MA SLS
2. **MODE C**
Re: Mode C Reply, Mode C Altitude
3. **MODE A & SLS**
MA SLS, P1 > P2, Reply, P1 = P2
4. **MODE A ALL CALL**
Re: Mode A & C Reply, MA and C Address
5. **MODE C ALL CALL**
Re: MC & A Reply, Mode A & C Address
6. **MODE A ONLY**
Re: Results
7. **MODE C ONLY**
Re: Results
8. **MODE S SURVEILLANCE IDENTITY**
Re: DF5 Reply, DF5 ID, DF5, Flight Status
9. **MODE S SI LOCKOUT**
Re: Results
10. **MODE S SUVEILLANCE ALTITUDE**
Re: DF4 Reply, DF4 Altitude, DF4 Flight Status
11. **MODE S SURVEILLANCE SHORT**
Re: DF0 Reply, DF0 Altitude, DF0 VS, Tail Number
12. **MODE S COMM IDENTITY**
Re: DF21 Reply, DF21 ID, DF21 Flight ID
13. **MODE S COMM ALTITUDE**
Re: DF20 Reply, DF20 Altitude
14. **UNDESIRED REPLIES**
Re: Results
15. **SQUITTER**
Re: ACQ Per, ACQ Address, Ext PER, Extended Address
16. **DIVERSITY**
Re: Results, Diversity Attenuation
17. **SENSITIVITY**
MA, MC, & MS Sensitivity
18. **POWER AND FREQUENCY**
Re: Power (in dB), Power (in Watts), and Frequency

The Test Set Captures up to 32 series of tests, after capturing the 32th test, the Test Set will then begin overwriting the oldest captured data. The software required to download the stored information is part of the Test Set memory. No external software is required to be loaded onto the PC to accomplish the transfer.

Results are transferred via a RS-232 Cable (not supplied) to a COMM port on the computer at a 4800-baud rate. With the computer HyperTerminal, the data is downloaded as a comma delimited file, which can be opened in an Excel spreadsheet program. The operator may also choose to put it in another file of their choice.

2.19.1 Setting Up Your Computer for RS-232 Download

It is necessary to configure your computer to correctly display the data downloaded. Once this is accomplished, the operator can then sort the data in the excel file in any way they prefer. The TR-220 Test Set utilizes a Hyper Terminal Program that is part of the Microsoft Windows Operating System. If this is not installed on your computer, you can obtain the program from the Microsoft Website or from your Windows Software the was supplied with your Computer. The following describes a suggested way to configure your computer to properly display the data.



The following procedures are abbreviated and may not match your operating system exactly; contact your computer administrator or computer manufacturer for assistance.

1. Select *START* on the computer desktop.
2. Select *PROGRAMS*.
3. Select *ACCESSORIES*.
4. Select *COMMUNICATIONS*.
5. Select *HYPER TERMINAL*.
6. Enter a name for the Terminal Connection (e.g. – TR-220).
7. Select *CONNECT TO* and pick the correct COM port you will be utilizing on your computer. For most users, this will be *COM1*.
8. Set the Port Settings to the following.
 - a. BIT PER SECOND – 4800
 - b. DATA BITS – 8
 - c. PARITY – None
 - d. STOP BITS – 1
 - e. FLOW CONTROL – Hardware
9. Select *APPLY*.
10. Select *OK*.

Close the Program. You have not created a permanent short cut configured for the TR-220 RS-232 download feature. You will not be required to repeat this procedure. When preparing to download data, select the TR-220 Hyper Terminal that should be located within the Hyper Terminal program selection dropdown.

2.19.2 Downloading the Data

Ensure the Test Set is **OFF** before connecting the Test Set to your computer.

1. Connect a standard RS-232 extension cable (not supplied) to the RS-232 connector located on the front panel of the Test Set and connect the other ends to the COM Port that was selected paragraph 2.15.1 step 7 (typically COM1).
2. On the computer, select the TR-220 Short Cut that was created in the paragraph 2.15.1.
3. Select *TRANSFER* from the Hyper-Terminal drop down menu.
4. Select *CAPTURE TEXT* and save the file to your desktop (recommended) and name the file to your preference but utilize a .csv extension (for example - [Serial Number 2345Date.csv](#)). Select *START*.
5. Press the **MANUAL** toggle switch on the Test Set to begin downloading the data and observe the following:

TEL-INSTRUMENT
Transferring Data . . .

The data will download to the Hyper-Terminal program and can then be observed on the computer display. Once all of the data has been transferred, the Test Set will indicate:

Output Completed
Press MAN To Erase

Select *TRANSFER* on the Hyper-Terminal drop-down menu, then *CAPTURE TEXT* and *STOP*. The data is now saved to the file. The operator may now choose to erase the stored data on the Test Set by toggling the **MANUAL** switch on the Test Set. Simply turn the Test Set *OFF* if you desire to keep the file in the memory.

6. Turn OFF the Test Set and disconnect the RS-232 cable.

2.19.3 Loading the Data to a Microsoft Excel File

1. Open up Microsoft Excel; do not double click on the file stored on the computers Desktop. Select *FILE* then *OPEN*. Locate the file on the Desktop (or wherever it was saved to) and open the file.
2. Depending on the edition of Microsoft Excel you currently have, the file may directly open and can then be organized as necessary. If the *IMPORT WIZARD* opens, follow step 3, if the file opened properly, skip to step 4.
3. If the *IMPORT FILE WIZARD* opens, select a *DELIMITED* file then click *NEXT*. Select *COMMA-DELIMITED* and deselect all others. Select *NEXT* and *FINISH*.
4. Once the file is loaded onto the Excel Spreadsheet, the operator can choose how to organize and display the information. By selecting "Auto Fit" options and selecting the appropriate Text, the operator can modify the spacing between each block. Refer to the Excel help file for further information.

CHAPTER III

THEORY OF OPERATION

3.1 General

The Test Set is comprised of four circuit boards which are controlled by and results displayed on the front panel. The Digital PCB interfaces with the Power Supply PCB and RF PCB and with the panel-mounted switches, connectors, and LCD display. An eight bit microprocessor is used to control the digital logic to perform the functions used to interact with the UUT.

The RF PCB generates the UUT stimulus signals and receives the UUT responses for measurement. The RF frequencies when transmitted are modulated by signals produced from the Digital PCB and passed to the antenna connector.

The connector on the front panel provides the power used to run the Test Set, charge the battery, and supply power and connection to the KIR/KIT encryption computers


3.2 Subassemblies

The Test Set consists of the assemblies shown in Figure 3-1; the functions of these assemblies are contained in the following paragraphs:

Para	Subassembly	Function
3.3	Panel & Display Assembly	Operator Interface
3.4	RF PCB Assembly & Attenuator Assembly	Receive/Transmit
3.5	Digital PCB Assembly	Signal Generation/Processing
3.6	Power Supply PCB Assembly and Battery	Power Generation/Distribution
3.7	Case Assembly	Instrument Housing
3.8	over & Accessories Assembly	Accessories Housing
3.9	Directional Antenna Assembly	Antenna

3.3 Panel and Display Assembly

Operation of the Test Set is achieved with a user friendly panel which uses toggle and rotary switches coupled with an easy to read, large character, LCD display. The display has 2 lines of up to 20 characters, a character height of 0.5 inches, and is observable from a distance of ten feet in bright sunlight. The Test Set antenna, with an integral optical sight, can be mounted on the instrument case, hand held, or mounted on a tripod to be aimed at the aircraft antenna. The Test Set instrument can be hand held or hung by a neck strap to give hands free operation.



Test Set System Basic Functional Diagram

Figure 3-1

The Test Set is contained in a case with heavy wall construction and includes a pressure relief valve. The front panel has a continuous gasket and all front panel components are sealed. The Test Set has been designed to meet the environmental requirements of the PRTS specification. The front panel, which is the “backbone” of the unit, is made of 0.187 thick aluminum to which the EMI chassis is mounted. The RF and Digital PCB assemblies are installed inside the EMI chassis and are separated by a shielding plate. The RF PCB also has separate shields around the synthesizer and transmitter. Digital circuits are connected through two ribbon cables terminated with EMI filter connectors. The battery cavity is brazed to the front panel along with the Power Supply PCB assembly support plate brazed between them. When the panel is installed in the case, sockets on the back panel structure engage with guide pins mounted to the bottom of the case.

The Test Set was designed to withstand the rigors of weather and to operate in close proximity of aircraft. Normally operated with the cover removed, the Test Set will not be adversely affected by rain, salt air, or fumes. The cover stores all the ancillary items and, when closed.

3.4 RF PCB Assembly & Attenuator Assembly


The RF PCB is connected to the Attenuator Assy. and then to the Direct Connect connector or the removable antenna through coax cables. The RF PCB is mounted in its own shielded enclosure that is connected directly to the Digital PCB and includes the transmitter, switching matrix, receiver and video processing. Figure 3-2 is the Test Set RF function diagram for both the transponder and interrogator test modes.

3.4.1 Transmitter

The transmitter phased locked loop (PLL), comprised of U8, U9, U10 and Q1 are capable of generating a 1030MHz signal for transponder testing and at 1090MHz, a signal for interrogator testing. The processor through the serial data bus controls the synthesizer U10 divide ratio. A portion of the oscillator signal is compared with the 10 MHz reference signal and generates an error voltage which is filtered by U8 and applied to the voltage controlled oscillator Q1. The 10 MHz reference signal is counted down (U29) from the 40MHz oscillator, U16, on the digital board.

3.4.2 Modulator

The double balanced mixer U1, amplitude and phase modulates the RF signal with the analog signal, DPSK MOD. This modulating signal is generated on the digital board. A balance resistor R1 is provided to compensate for the match between diodes in the balanced mixer. It needs to be adjusted for maximum P6 Flatness (In Mode S) ratio whenever U1 is replaced.



RF Functional Diagram

Figure 3-2

3.4.3 Gain Control

The peak modulated output transmitted level is capable of generating +7 dBm (at Sum Port) nominal and is stable to +/- 2 dB. Two voltage controlled RF amplifiers, U2 and U3 control it. A calibrated digital signal stored in the processor and converted to an analog signal using the D/A converter U8, located on the digital board, sets the gain of the RF amplifier. The output power is controlled over a range greater than 50 dB. The variable gain control amplifier is followed by a fixed gain (17dB) gated amplifier, U4.

3.4.4 Antennas, RF Switching, & Attenuator

The RF transmitter and receiver are connected thru the RF PCB mounted switching matrix and associated cables to either the antenna or thru a high power 50 dB attenuator directly connected to the UUT. The attenuator will dissipate peak powers up to 67 dBm allowing a direct connection between UUT and TR-220, without damage. A 10 foot RG-223/U coax with M39012/26-001 TNC connectors is provided for the direct connect testing.

When testing transponders, the transmitted P2 is switched to the difference antenna to generate an effective antenna Beamwidth of 20° (nominal). When testing transponders with the ISLS pulse present, the switch will not be activated and the resultant output level of P2 will be equal to P1 and P3. The magnitude of the signals received on the sum channel is scaled and are compared to the signals received on the difference channel to provide an effective receive Beamwidth of 10° (nominal).

The RF switches U34, U36 and U37, switch the modulated RF signal from the transmitter TR-220 to either the directional antenna, direct connect connector, or directly to the TR-220 receiver. The switching circuits also switch the received signal to the sum and difference receiver. When using the directional antenna during transponder testing, the side lobe suppression pulse P2 is switched by U34 to the difference antenna, while P1 and P3 are directed to the sum antenna. U36 and U37 are transfer switches. In the first state, Pin 2 is connected to Pin 8 and Pin 4 is connected to Pin 6 and in the second state, Pin 2 is connected to Pin 4 and Pin 8 is connected to Pin 6. U36-8 is connected to the sum port of the antenna, and Pin 6 is connected to the sum receiver. U37 pin 8 is connected to the difference port of the antenna and Pin 6 is connected to the difference receiver. The maximum rated input power to U36 and U37 from the antenna is +27 dBm continuous modulation (Antenna Port).

The signals controlling U40 are derived from a switch divider, which includes 10K termination for the direct connect connector. If the termination is connected, the directional antenna ports are active. If the termination is removed, direct connect is the active port. The signal SLS, derived on the digital board, controls U34 via U35 and U31 causing the P2 pulse to be directed to the difference antenna. A transmit/receive switch consisting of transfer switches U36 and U37 is controlled by the signal, TRANSMIT, and ST GATE, generated on the digital board.

3.4.5 Receiver

The receiver has a sensitivity of -50 dBm (nominal) and in testing has withstood greater than 1.6 watts/foot² peak pulsed power. The receiver consists of two mixers

(U50, U57), a local oscillator PLL (U44, 45, 46, 47), 2 band pass filters, two log amplifiers (U52, U59), a threshold comparator (U67), a sum and difference comparator (U56), a SLS detector and (P1/P2) comparator (U60, 64, 65, 66), a limiting amplifier (U55, 61, 63), a 60MHz discriminator frequency measuring circuit, a sum power measuring circuit (U60, 64), a difference power measuring circuit (U53, 62), and a DPSK demodulating circuit for Mode S.

The local oscillator PLL is identical to the transmitter PLL. It is set at 1030 MHz when testing transponders and 1090 MHz when testing interrogators. It is tuned in 100 kHz steps about the selected frequency for frequency measuring. The two mixers are double balanced and are connected thru the transfer switches to the sum and difference antennas.

The received sum and difference signals are mixed with the local oscillator output that produces a 60 MHz IF. The direct connect input is first attenuated by 50 dB and then follows the same path as the sum signal. The two log amplifiers, one for sum signals and one for difference signals, have a video output that is proportional to the log of the input over a range of 70 dB. The slope is adjusted (R121) so that the two amplifiers track over the range within +/-2dB.

The video sum signal out of the video amplifier U60 is connected to U67, a threshold circuit, to U56, a sum and difference comparator, and through U64, U60 to U65, SLS detector. Sample and hold amplifier U64, sum and difference comparator U65 are driven by the CPLD Digital PCB, which provides a 300 μ sec sample pulse from DATA RX pulse. SLS INH accrues at P2 pulse time, blanks U64 to store P1 power level and activates U65 to hold the results of P1 and P2 comparison. If P2 is greater than -9dB of the P1 signal, the signal SLS INH will be high and will display that SLS is present.

The sum and difference video signals are applied to the sum and difference comparator U56. The difference signal is adjusted with R127 so that any signals within the center line of the difference antenna will be processed and those outside the ± 5 degrees will be inhibited. The signal DS INH will be high and will result in a display indicating "TURN". The operator must reposition the antenna until the "TURN" is no longer displayed.

3.4.6 Power, Frequency, & Sensitivity Measurement

The video signal from the sum and difference amplifiers (U53, 60) are stored in the sample-and-hold amplifiers and applied to the A/D converter on the digital board. The power measurement is provided by using a look up table in the processor.

The 60 MHz saturated signal out of the limiting amplifier (U55, 61, 63) is applied to the frequency discriminator U24 and to the DPSK demodulator (U20, 23, 21) through matching attenuators (20dB). The output of the frequency discriminator is compared in U26 whose output is either high or low depending on whether the signal out of the Log Amp is above or below 60MHz. The local oscillator will then be incremented in 0.1 MHz steps until the comparator changes state. At this point the offset of the local oscillator from nominal (1030, 1090 MHz) is the offset of the UUT transmitter and the frequency is calculated and displayed.

Sensitivity of the transponder under test is measured by increasing the RF power from minimum (U2, 3) until the percent response drops below 80%. The voltage provided by the D/A converter on the digital board is converted to power out by using a calibrated look-up table stored in the processor.

3.4.7 DPSK Demodulator

The DPSK demodulator receives a 60 MHz signal from the limiting amplifier. This signal is converted to 12 MHz by U20 and applied to discriminator U21 through delay line U23. The output of the phase discriminator compares the phase relationship of the direct signal and one that is delayed by 250 nsec. If the input changes phase, indicating a “1”, the comparator U22 will change state. The comparator U22 is enabled by DPSK PLS pulses from the digital board and its output is connected to the receiver FIFO on the digital board. The FIFO stores the information for evaluation by the processor.


3.5 Digital PCB Assembly

The digital printed circuit board function diagram is shown in Figure 3-3.

3.5.1 Microprocessor Control Logic

The microprocessor U10 is an 8-bit CPU used to read and write instructions through hardware and firmware addressing. Special features of the 80C31 processor include extensive Boolean processing, 64 k byte programming memory address space, 64 k data memory address space, 32 bi-directional and individually addressable I/O lines, and two 16-bit timer/counters. A 12 MHz crystal clock, Y1, is used to synchronize the timing of the processing. Assembly language programming generates instructions, in the form of machine language to the processor, which are stored in U7. A high-speed 64K UV erasable and electrically reprogrammable CMOS EPROM, U7, is used for fast turn around and low power consumption. An 8 k RAM, U6, with battery backup is used to store accessible memory for the CPU interaction.

In order for the microprocessor to control the input/output signals, a 4-to-16 line decoder, with latch P/O U29, is utilized for memory address decoding and data routing applications. When the latch enable input, LE, is high, the outputs will change with the inputs. When LE goes low, the data on the select inputs are stored in the latches. The outputs of the decoder are used to select which register (U1, U2, U5, U35, U37, U38 or inside registers of U29) is selected. U1, U37, and U38 are used for various control functions, such as MODE 4 code select A or B, Mode-4 verification bit, strobes and data for the RF synthesizers and self-test functions.



Digital PCB Functional Diagram

Figure 3-3

3.5.2 Clock Frequencies & Range Counter

The 40 MHz crystal controlled clock controls all timing, except for CPU timing. 20MHz, 10 MHz and 4 MHz clock signals are produced from the 40 MHz clock by counters. The range counter is a pre-loadable 16 bit counter which is used in generating range delay in interrogator testing.

3.5.3 First-In/First-Out(FIFO)

Two FIFO's are used to transmit and receive data for all modes. The receive FIFO, U22, is used to receive the serial reply data from the UUT as well as self-test data. Once the data is received, it is unloaded by the CPU for analysis through one of the U29 registers.

The transmit FIFO, U19, is loaded by the CPU through U2 register. Once the transmit data is loaded in the FIFO, it is transmitted through U29 and under U29 control. The read rate of the FIFO sets the pulse shape and pulse spacing within the required tolerances. U30 transforms the transmitted data from digital form to levels suitable for RF modulation.

3.5.4 Operator Interface

Operation of the Test Set is achieved with a user friendly panel, with switches for ON/OFF and test mode controls and a heavy duty, large character, liquid crystal display. The display has two lines of characters, each with 20 symbols which are 0.5 inch high, an ON/OFF backlight control for night viewing, and can be read in direct sunlight from a distance of ten feet. The display viewing angles are +/- 30 degrees in both the up-down and left-right viewing directions. The information displayed includes the mode, the reply code, the UUT data, and Test Set status. To support UUT fault isolation, detailed test data from each step in the test sequence can also be displayed, at operator discretion. Refer to Section 2 for a complete description of the operating procedures and associated displays.

An optical sight permits the operator to aim at the desired UUT antenna. A LED, which is visible when viewing through the optical sight, is illuminated when test is in progress. The results of the test are displayed on the Test Set panel LCD display.

The Test Set can be handheld by the operator or supported by a neck strap. The antenna configuration allows the option of being handheld, mounted on the Test Set, or supported by a tripod using a fitting located at the unit's center of gravity.

3.5.5 Digital/Analog Converter

The digital to analog converter, U13 is loaded from the processor through the FIFO U13 and is used to control the transmitted RF power. The D/A converter are a 12 bit, 4096 levels, under processor control which will control the gain of two RF amplifiers. The gain can be controlled manually with a front panel control or automatically.

In the transponder automatic mode, the converter increases the RF output power until the transponder responds to more than 80% of the interrogations. At this time, the voltage level out of the converter is interpolated to the sensitivity of the UUT.


3.6 Power Supply PCB Assembly

3.6.1 Power Distribution

The power distribution is shown in the Power Distribution Function Diagram, Figure 3-4. The Test Set will operate from 115 - 230VAC, 50 to 400 Hz, from 28VDC, or from its own 6VDC internal battery. The Test Set has an internal battery charger, which operates from either the 28VDC or 115 - 230 VAC inputs. The Test Set can be operated and the battery charged at the same time. An input line filter is mounted to the input connector to filter out voltage spikes and RF interference.

When operating the Test Set on battery power, the battery voltage is monitored by the processor and a low voltage display is provided when the battery voltage reaches 5.8 volts. Under this condition, approximately 15 minutes of operating time are left. The Test Set will automatically turn OFF when the battery voltage is less than 5.4 volts to prevent deep discharge of the battery. The battery can be disconnected and replaced through the Test Set panel without erasing any stored codes or measured data.

The unit is capable of operating from the battery for 8 hours at a 20 percent duty cycle over the entire temperature range. At 25° C the unit will operate 8 hours at a 50 percent duty cycle.



Power Distribution

Figure 3-4

3.6.2 Power Functions

The power supply board, which will operate when energized by electrical systems, converts the AC or DC inputs to a nominal 6.5VDC which charges the battery and operates the system.

The battery voltage is provided to the Digital and RF PCBs. Two regulators, -5V (U8) and +5V (U9) and associated filters are located on the digital board provide DCV for the digital boards. Regulators U16, U18 and U19 on the RF board provide -5V, +5V and +15V respectively to the RF board circuits.

The power input is connected through the front panel: the AC ground is connected to the Test Set chassis and the four power lines, 2 AC and 2 DC, are switched with the PWR/CHG switch and fused with F1, 2, 3, and 4, located on the front panel. The AC supply and AC return are isolated from the Test Set by the transformer T1 that reduces the RMS voltage from 115VAC to 28 VAC. A series diode D9 in the 28VDC line protects the Test Set from reversing the 28VDC polarity and also removes the rectified voltage from the connected output pins.

3.6.3 Power Control

The Test Set control circuit consists of an OR Gate U2 connected as a latch turned on by momentarily turning the TEST switch to ON. An output high from the latch turns on Q1 that closes K1 providing 6 VDC to the Test Set. The Test Set is turned off in the following ways:

- 1) Momentarily turn the TEST SWITCH to the OFF position.
- 2) When the Test Set is battery operated and the battery drops below 5.4 volts, the TEST SET will turn off; the battery voltage is also monitored on the digital board, indicating to the operator when there is approximately 15 minutes of operating time remaining; it should be noted that the battery can be disconnected and replaced at any time without losing the stored code.
- 3) Shut down occurs after 15 minutes of non-use automatically; if the TEST switch is momentarily pressed to MANUAL or AUTO, the timer is reset; the timer is disabled whenever an external AC or DC source is connected to the Test Set.

3.6.4 Elapsed Time Indicator

The nonvolatile RAM on the digital board has a built-in real time clock supported by a battery with a 10 year life. Operating hours are retained in a non-volatile RAM and displayed when the Test Set is turned ON.

3.7 Case Assembly

The Test Set is housed in a case which is suitable for use in rugged environments. The case bottom contains the panel behind which are mounted the instrument SRA's. The case cover contains the accessories. The Test Set case bottom also contains the RF transmitter and receiver connected thru the RF PCB-mounted RF switching network and associated cables to

either the directional antenna or directly to the UUT. The direct connect UUT cable is 10 feet long, RG-223/U with TNC male connectors type M39012/26-001. All parts and attachments to the Test Set are safe from electro-static discharge.

3.8 Directional Antenna Assembly

The directional antenna is designed to be utilized in one of three test configurations:

- 1) Hand Held, for manual operator pointing at the target aircraft using the optical sighting device.
- 2) Tripod mounted, to be used as a remote antenna.
- 3) Mounted to the Test Set Case.

In all configurations, the remote antenna is connected to the Test Set by means of a pair of coax cables, sleeved together, one end of which are permanently fastened to the antenna structure with strain relief, and the other end connected to a pair of coax connectors on the Test Set panel. An extender cable is supplied for the hand held and tripod mounted configurations. Since the coax connectors can be interchanged, they are color coded. If they are interchanged a fault will be indicated on the display. The directional antenna is a micro strip rectangular probe-fed patch antenna generating a sum and difference pattern. The antenna assembly, without the detachable handle, is 5" x 10" x 2" and is enclosed in its own sealed radome. The optical sight has reticules at both ends for accurate pointing of the antenna boresight. The boresight scope also has a LED display indication of test activity to alert the operator of active test.

CHAPTER IV

GENERAL MAINTENANCE AND SERVICING INSTRUCTIONS

4.1 General

The use of the current generation of electronic components has dramatically decreased the cost of maintaining and calibrating test equipment. Tel has recommended an annual calibration and alignment interval and periodic checks to keep the TR-220 in operational condition. Performing preventative maintenance checks of the Test Set and Test Set verification checks if a failure is suspected will reduce down time by detecting and correcting potential problems at their onset. This chapter is broken down in three sections.

1. Routine Maintenance (Section A).
2. Test Set Verification and Acceptance Checks (Section B).
3. Annual Calibration and Alignment (Section C).

Routine Maintenance: By routinely cleaning and inspecting the TR-220 Test Set, the operator will be able to reduce down time due to unexpected failures. Routine Maintenance, as outlined in *Section A*, consists of checks and observations performed to maintain the Test Set in a serviceable and ready condition. They should be accomplished each time the Test Set is utilized and after extended storage.

Test Set Verification and Acceptance Checks: If the Test Set passes the Test Set Verification and Acceptance Check, a Calibration and Alignment is not necessary. This Test verifies all hardware related tests to ensure the Test Set is operating at manufacturers specifications.

If during normal operation a failure is suspected or unusual or erratic results are displayed, perform the procedures as listed in *Section B*. By conducting and verifying the Test Sets condition when abnormal results occur, the operator will be able to determine if the Test Set is malfunctioning or the UUT is at fault. Periodic checks will also alert the operator to possible problems and ensure the Test Set is in full operational condition before it is used.

If by completing the Test Set Verification and Acceptance Checks and the Test Set continues to exhibit unusual or erroneous information, the Test Set may require the Full Alignment as outlined in *Section C*.

Calibration and Alignment: A full Calibration and Alignment of the Test Set shall be performed under the following conditions:

1. Tel-Instrument Corporation recommends an Annual Test Set Verification Acceptance Check to determine if a Calibration or Alignment is necessary, and to ensure accurate test results and improved performance.

2. If any failure occurs or is suspected during *Routine* or *Test Set Verification Checks*, a full Calibration and Alignment shall be performed.
3. If any major assembly is replaced.
4. If during normal operation, the Test Set fails to meet any specification outlined in Chapter 1, Section B.

4.1.1 **Safety Precautions**


The following are general safety precautions that are not related to a particular test or procedure. These are recommended procedures that all personnel must apply during many phases of operation and maintenance. It is assumed that the operator has general knowledge of electrical theory and the dangers associated with it.

1. When performing any of the preceding tests thoroughly read and understand all procedures before actually performing them.
2. The various front panel connectors, switches, and controls specified can be located by referring to Figure 2-1 on page 2-3.
3. Take the time to learn the proper operation and function of the Test Set as outlined in Chapters 1, 2, and 3. Through knowledge of the Test Set and its capabilities greatly improves the time it takes to complete the tests.
4. Pay particular attention to **NOTES** and **WARNINGS** that may accompany some test procedures.



WARNINGS

Alerts the operator to potential dangers associated with a particular test. Thoroughly understand the warning before proceeding to prevent a potentially dangerous situation or damage to the Test Set.



NOTES

Provides supplemental information that enhances the test procedure.

5. Observe all standard safety procedures when working with live voltages. The potential for electric shock exists any time the Test Set is removed from its case.
6. DO-NOT service the unit or make adjustments alone. Always be in the presence of another person when working with live voltages.
7. Be familiar with general first aid procedures and CPR (Cardiopulmonary Resuscitation). Contact your local Red Cross for more information.
8. Ensure the test equipment and the tools you utilize are in good operational condition and not damaged in any way.

4.1.2 Preliminary Considerations

1. Test Equipment- Recommended test equipment is listed before each test. An equivalent type may be substituted in lieu of the listed equipment.
2. Environmental Considerations- Test and align the equipment in conditions similar to the conditions the Test Set will be utilized in.
3. Calibration Test Reports- Test reports are located in Appendix A & Appendix B. Make copies of the test reports before commencing alignment to properly log results.
4. The Test Set should be allowed to warm up for a period not to exceed 10 minutes before testing begins.
5. Always begin with a fully charged battery.

SECTION A

ROUTINE MAINTENANCE

4.2 General

By routinely cleaning and inspecting the TR-220 Test Set, the operator will be able to reduce down time due to unexpected failures. Routine Maintenance consists of checks and observations performed to maintain the Test Set in a serviceable and ready condition. They should be accomplished each time the Test Set is utilized and after extended storage.

Routine maintenance consists of the following:

1. Cleaning of the TR-220 Test Set exterior case.
2. Inspection of all connectors, cables and the Test Set assembly.
3. Inspection of the Hand Held Antenna and Connections.
4. Battery check and charging.

4.2.1 Cleaning Procedure

Keep the Test Set clean by removing any loose dirt, mildew or mild corrosion with a soft cloth moistened with warm water and a mild detergent. Do not spray any cleaning detergent or water directly on the Test Set. Ensure to dry off the Test Set with a Lint free cloth to remove all deposits and remaining cleaning solution. Strong cleaners and chemicals shall be avoided to prevent damage to the display, silk-screening, and switches.

4.2.2 Inspection of all Connectors, Cables, and Test Set Assembly

By inspecting the cables, connectors, and the Test Set periodically, potential inaccurate test results will be alleviated.

1. Check each cable for kinks, crushed insulation, frayed cables, and rusty connectors.
2. Check each antenna supplied with your Test Set for obvious signs of rust, dents and loose parts.
3. Inspect the Test Set case for signs of abuse. Large dents and cracked displays may render the Test Set inoperable.
4. Toggle and push each switch for proper operation. Sticking switches may result in erroneous test results.
5. Inspect for loose bolts, nuts, and screws; tighten if necessary.
6. Ensure all supplied antennas and cables are properly stowed when not in use.

4.2.3 Battery Check and Charging

Check the Lead Acid battery before each use to ensure a sufficient charge is available to complete the required tests. By charging the battery a few hours each week, you will keep the Lead Acid battery in a fully charged state ensuring a significant charge is available for extended testing. Follow the procedures in Paragraph 2.8 to fully charge the battery before calibrating the Test Set.

SECTION B

TEST SET VERIFICATION AND ACCEPTANCE CHECKS

4.3 General

These procedures will be performed on an Unopened Test Set, except where noted, by measuring inputs/outputs. If the Test Set results are not within tolerances, the Test Set will require a full Calibration and Alignment as outlined in *Section C*. The tests are broken down into individual sections to allow the operator to verify proper operation of individual functions when a discrepancy may arise or repair was accomplished.

4.3.1 Test Equipment Required

The following support equipment (or their equivalent) is necessary to perform the Test Set Verification and Acceptance Checks:

Name	Designation/Description
Oscilloscope	Infinium 54835A
Signal Generator	Hewlett Packard 8648B
Spectrum Analyzer	HP 8558B
Digital Voltmeter	Fluke 8000A
Oscilloscope	Hewlett Packard 54615B
Pulse Generator	Agilent 81101A
Crystal Detectors W/Load Resistor	Hewlett Packard P423B
Copy of Data Sheet (Appendix A) ¹	
Assorted Connectors and Adapters	
Assorted Cables with calibrated loss	

Support Equipment

Table 4-1

¹ To ensure accuracy and for simplicity, the Data Sheet is written and organized to reference each step by paragraph and step number. Make a photocopy, review and become familiar with the datasheet before beginning the tests.


4.3.2 Test Set Initial Settings

Set the TR-220 front panel switches to the following positions before each test, unless otherwise instructed:

Function/Rotary Switch	Position
UUT FUNCTION	XPDR
CHNALT/DIST/VERT SPEED CODE/ALT – ATTN	Centered
UP – DOWN/FWD – REV	Centered
TO/FROM – START/STOP	Centered
IDENT	Default
ATCRBS/AIR – MODE S GND	ATCRBS/AIR
INCREASE – DECREASE	Default
AUTO/TEST/MANUAL	Default
BACK LIGHT	Default
ON/OFF	OFF
Power Charge Rocker Switch	OFF
DIRECT CONNECT PORT	Termination Cap On
SUM – DIFF Connectors	Capped

Initial Settings


Table 4-2




Initial Settings

Figure 4-1

4.4 Display Operation, Self Test and Initial Start Verification



Due to different Software revisions, displays and procedures may vary slightly.



Pictured Test results in this procedure are for reference only. Due to numerous types of equivalent test equipment, your actual results may vary.

1. Connect the Test Set to an appropriate power source.
2. Turn the AC Rocker switch to the **ON** position and ensure that the green LED illuminates.
3. Turn the Test Set **ON/OFF** switch to the **ON** position and verify the green LED illuminates.
4. The TR-220 Self Test will initiate will be displayed **briefly**, verify the following:

Tel-Instrument	TR-220
REV X.XX	00001 hrs

The Rev Level will display the current software installed. Hours will indicate the total hours the Test Set has been in operation.

Self Test Testing . . .

Self Test PASS

ANTENNA Connections Missing or reversed
--

The Test Set will Stop at this display.

5. The Test Set will indicate the current software version and total hours the Test Set has been "ON". Log this and the Self Test results on the Data Sheet.
6. Toggle the **BACKLIGHT** switch *down* and verify the backlighting remains illuminated.
7. Toggle the **BACKLIGHT** switch *Up* to the **MOM** position, hold momentarily, and release. Verify the backlighting illuminates briefly, and then extinguishes.
8. Turn the Test Set "OFF" by toggling the **ON/OFF** switch *down*. The Test Set will turn "OFF".

9. Disconnect the AC Power Cord and turn the Test Set back “ON” and ensure the Test Set turns “OFF” after approximately 15 minutes of inactivity (AC power not connected).
10. Remove the **DIRECT CONNECT** Termination Cap, Connect the Directional Antenna to the **SUM/DIFF** ports and turn the Test Set back “ON”. Verify the following Display:

Direct Connection
REMOVE ANTENNA

11. Remove the Directional Antenna and ensure that the Test set progresses to the following display:


TRANSPONDER test
Press AUTO/MANUAL

12. Turn the Test Set “OFF”.

4.4.1 **Transponder, Transmitter/Frequency Verification Tests**

These Tests will verify the Test Set RF output to ensure the Test Set is properly transmitting with the appropriate power at the correct frequency.

1. Set all Test Set Initial settings IAW Table 4-2.
2. Connect the Spectrum Analyzer to the Test Set **SUM** connector, ensure the **DIRECT CONNECT** termination Cap is installed.



Any time that tests are conducted utilizing the **SUM and DIFF** ports and the Test Set is turned on, a message indicating “ANTENNA Connections Missing or reversed” may be displayed. To bypass this, simply short the center pin of the **DIFF** connector to advance.

3. Turn the Test Set “ON” with the **UUT FUNCTION** switch in the **SETUP** position. Locate the **ANT GAIN** menu by toggling the **AUTO/MANUAL** switch. Observe the Antenna gain menu and set the Antenna gain to **0 dB** for the 1030 and 1090 MHz positions. At the **CABLE LOSS** menu, set the cable loss also to **0 dB**.

At the **T/S Distance Menu** page, set the distance for **25 ft** and select **AUTO**.

T/S Distance:	25 ft
Chg:Up/Dn Cont:	AUTO

Return the **UUT FUNCTION** switch to the **XPDR** position and turn the Test Set “OFF”.

4. With the **FUNCTION SWITCH** in the **XPDR** position and turn the Test Set “ON” while holding “Down” the **TO/START – FROM/STOP** switches. This will disable the LED power and the display will briefly indicate this.

Antenna LED is OFF

5. Toggle the **AUTO/MANUAL** switch to **AUTO**. At the Transponder Test page, select the **MANUAL** Tests by toggling **AUTO/MANUAL** switch “Down” and continue to toggle down until reaching the *M A Menu* page.

TRANSPONDER test Press AUTO/MANUAL

M A No reply

Set the Spectrum Analyzer to the following positions:

Function	Setting
Frequency	1030 MHz
Span	0 MHz
Amplitude	0 dBm
Res BW	3 MHz
Video BW	3 MHz
Sweep	500 ms

Connect the **SUM** port to the Spectrum Analyzer. Measure the output power of the Test Set ensuring to add the cable loss from the **SUM** to the Spectrum Analyzer to the total. The output power shall be **7dBm / ± 2 dB**. *Note the actual reading on the Data sheet.*


6. Without turning Off the Test Set, disconnect the Spectrum Analyzer connector at the **SUM** port and connect it to the **DIFF** port.

Verify that the output power has reduced at least minimum of **20 dB** from that in step #5, remembering to take into account cable loss.

7. Select **SETUP** on the **UUT FUNCTION** switch and select the **T/S Distance Menu**: Set the distance to **35 feet**. Return the **UUT FUNCTION** switch to **XPDR** and return to the **M A Test** and ensure that the power is **9 db LOWER / ± 2 db** than what was measured at the **SUM** port Step 5.
8. Repeat the same procedure in Step 8, but set the *Distance Menu* to **75 feet**. Verify that the peak power off the **DIFF** port is **5 db LOWER / ± 2 db** than the **SUM** port measurement in Step 5.
9. Remove the Spectrum Analyzer from the **DIFF** port and reattach it to the **SUM** port.
10. Turn the Test Set “OFF” and then back “ON” and return to the *MODE 3A Menu Display*.
11. Set the Spectrum Analyzer for the Following:

Function	Setting
Frequency	1030 MHz
Span	1 MHz
Amplitude	0 dBm
Res BW	10 kHz
Video BW	10 kHz
Sweep	100 ms

12. Measure the center frequency of the Spectrum Analyzer Display (Figure 4-2). Verify that the Center Frequency is **1030 MHz / ± 0.2 MHz**.



Transponder Output Frequency

Figure 4-2

13. Turn the Test Set “OFF” and disconnect test equipment.

4.4.2 TCAS Verification

These Tests will verify the Test Set TCAS modes are properly transmitting with the appropriate power at the correct frequency.

1. Set all Test Set Initial settings IAW Table 4-2.
2. Connect the Signal Generator output, to the Pulse "IN" connector on the rear of the Signal Generator. Set the Pulse Generator to the following:

Adjust the Pulse Generator for 2 *Continuous Double Pulses* and the following (simulates a M3A Interrogation):

Function	Setting
Frequency	100 Hz
DbI Delay	8.0 μ s
Pulse Width	800 ns
Leading Edge Rise	5 ns
Amplitude	+4 V HI / + 0 V Low
Input Impedance	50 Ω Out / 1 K In

Adjust the Signal Generator to the following:

Function	Setting
Frequency	1030 MHz
Amplitude	0.00 dBm
Modulation	Pulse Modulated
Rear In	ON

3. Connect the output of the Pulse Generator directly to the **SUM** port of the Test Set. Place the Test Set **FUNCTION** switch in the **SETUP** position and turn the Test Set "ON".
4. At the Set Distance Menu, set the distance for 25 feet by toggling the **TO/FROM** switch. Toggle the **AUTO** switch UP when finished.

Set Distance: 25 ft.
Chg:Up/Dn Cont: AUTO

5. Place the **FUNCTION** switch in **TCAS** and toggle the **AUTO/MANUAL** switch to **AUTO**.


Power	Frequency /
Listening . . .	

Power 50 dBm	Frequency / 1030.0 MHz	} Results Shown are typical, your display may slightly vary. Output Power displayed is "don't care". A "FAIL" display or incorrect frequency measurement is considered a fail.
Power FAIL	Frequency /	

6. Vary the Frequency output of the Signal Generator in 0.1 MHz steps (1033.0 to 1027.0 MHz). Ensure that the displayed frequency follows ± 200 kHz at each step.
7. Set a Spectrum Analyzer for the Following:

Function	Setting
Frequency	1090 MHz
Span	1 MHz
Amplitude	-10 dBm (approx)
Res BW	10 kHz
Video BW	10 kHz
Sweep	1 sec

8. Disconnect the Signal generator from the **SUM** port. Connect a "T" connector to the **SUM** port and reconnect the Signal Generator, Connect the other output to the Spectrum Analyzer.
9. Measure the output frequency of the Test Set and ensure output is **1090 MHz ± 200 kHz** (See Figure 4-3). Turn the Test Set "OFF".



Center Frequency of Oscillator


TCAS Output Frequency

Figure 4-3

4.4.3 DME Verification

1. Set all Test Set Initial settings IAW Table 4-2 and connect the UUT to the Test Equipment IAW the following diagram.

NOTE A crystal detector must be utilized at the input of the O'Scope to eliminate noise. If utilized, ensure that the LED function of the UUT is disabled before connecting the detector.



DME Test Se- up

Figure 4-4

Adjust the Pulse Generator for 2 *Continuous Double Pulses* and the following:

Function	Setting
Frequency	100 Hz
Delay	12 μ s
Pulse Width	3.5 μ s
Leading Edge Rise	5 ns
Amplitude	+4 V HI / + 0 V Low
Input Impedance	50 Ω Out / 1 K In


2. Connect the output of the Pulse Generator to the "*Pulse IN*" port of the Signal Generator. On the UUT, Select **DME** on the UUT using the **FUNCTION SWITCH** and turn the Test Set "**ON**" by holding the **TO/FROM** and **UP/DOWN** switches at the same time; this removes the LED power through the **SUM** port.

Select the Test Set Channel to 108.00 MHz (17X) with a 2 nmi range. Set the Signal Gen. to 1041 MHz at 0 dB.

Adjust the O' Scope for the following:

Function	Setting
Horizontal	20 μ s
Vertical	50mV/Div
Trigger	Aux
Utilize the Auto Function for best results	

Observe on the scope the Interrogation Pulses and Reply Pulses (utilize the Averaging Mode if necessary).



DME Interrogation and Reply Pulses

Figure 4-5

Verify the following:

- Each Interrogation Pulse is **3.5 μ s / $\pm$.5 μ s** spaced **12.0 μ s $\pm$.5 μ s**
- Verify that the Test Set Reply Pulses spacing are **12 μ s / $\pm$.25 μ s.**
- Change the Test Set to **108.05** (17Y) and verify the spacing at **30 μ s / $\pm$.25 μ s.**

Return the UUT to 108.00. Record the results on the data sheet.

- DME Range Verification, utilizing the Infinium O' scope and markers. Place Marker "A" on the 50% rise of the first Interrogation Pulse. Place the Second Marker on the 50% rise of the first Reply pulse (See Figure 4-5). Measure the distance IAW with Table 4-3 changing the Test Set distance and frequency when needed:

	Range	DME 108.00		DME 108.05	Tolerance
		50 μs delay		56 μs delay	
a.	2	74.72 μ sec	d.	80.72 μ sec	$\pm 6.18 \mu$ sec
b.	130	1656.66 μ sec	e.	1662.66 μ sec	$\pm 6.18 \mu$ sec
c.	250	3140.00 μ sec	f.	3146.00 μ sec	$\pm 6.18 \mu$ sec


DME Range Verification

Table 4-3

4. DME Frequency verification is conducted by connecting the UUT **SUM** port to a Spectrum Analyzer. Turn on the UUT holding the **TO/FROM – START/STOP** and **UP/DOWN** Switches at the same time to disable the LED. Ensure Channel 108.00 MHz is selected. Set the Spectrum Analyzer to the following:

FUNCTION	SETTING
Frequency	978 MHz
Span	10 MHz
Amplitude	0 dBm
Res BW	10 kHz
Video	AUTO
Averaging	OFF
Sweep	1 sec

Verify a Center frequency of **978 MHz / ± 0.5 MHz** (Figure 4-6) and continue to test the frequency IAW Table 4-4.



DME Frequency

Figure 4-6

X Channels		Y Channels	
a.	108.00 MHz – 978 MHz	d.	108.05 MHz – 1104 MHz
b.	112.60 MHz – 1160 MHz	e.	112.65 MHz – 1034 MHz
c.	117.50 MHz – 1209 MHz	f.	117.55 MHz – 1083 MHz


DME Frequency Verification

Table 4-4

Log on the Data Sheet DME Frequency Test results.

4.4.4 Final Checks

1. Place the Test Set Function Switch in the **SETUP** position.
2. Turn the Test Set “ON”. Locate the *ANT GAIN* menu by toggling the **AUTO/MANUAL** switch.
3. Locate the Hand-Held Antenna located in the Test Set cover. Find the Antenna Gains Label located on the back of the Antenna (Figure 4-7).



Directional Antenna Gain

Figure 4-7

4. Enter the correct gains for the appropriate frequencies as listed on the back of the antenna.
5. Turn the Test Set “OFF”.


SECTION C

CALIBRATION AND ALIGNMENT

4.5 General and Frequency of Calibration

A full Calibration and Alignment of the Test Set shall be performed under the following conditions:

1. Tel-Instrument Corporation recommends an Annual Test Set Verification Acceptance Check to determine if a Calibration or Alignment is necessary, and to ensure accurate test results and improved performance.
2. If any failure occurs or is suspected during *Routine* or *Test Set Verification Acceptance Checks*, a full Calibration and Alignment shall be performed.
3. If any major assembly is replaced.
4. If during normal operation, the Test Set fails to meet any specification outlined in Chapter 1, Section B.



At any time during the Annual Calibration, the Test Fails to meet the correct specification and alignment of the Test Set fails to bring the unit within tolerance. The Test Set will require repair at the factory level. Contact Tel-Instrument Electronics Corp. for further guidance.

These procedures will be performed on an opened box to allow access to test points and alignment controls to align the Test Set to manufacturer's specifications. If these adjustments fail to return the Test Set to the specified parameters, the unit may require repair and additional maintenance. By utilizing the following procedures and referring to the schematics (Chapter VI), a qualified technician should be able to troubleshoot the problem. **Do not make adjustments for results that meet the specification.**



WARNING

Any time you are working with exposed wiring, the potential for electrical shock increases. Ensure all standard electrical safety procedures are strictly enforced to prevent injury.

Utilize APPENDIX B to log all data where indicated. The Appendix is conveniently labeled by Test and paragraph number to ensure that pertinent data is tracked and logged.

Utilize Figure 4-14 at the end of the Chapter for Locations of Test and Adjustment Points.

4.6 Test Equipment Required and Test Set Initial Settings

The following support equipment (or their equivalent) is necessary to perform the *Calibration and Alignment* of the TR-220 Test Set.

Name	Designation/Description
Oscilloscope	Infinium 54835A
Signal Generator	Hewlett Packard 8648B
Spectrum Analyzer	Agilent E4401B
Digital Voltmeter	Fluke 8000A
Pulse Generator	Agilent 81101A
Crystal Detectors W/Load Resistor	Hewlett Packard P423B
RF Splitter	Mini-Circuits ZFSC-2-5
0-30 dB Attenuator (1 dB steps)	JFW, 50DR-010
0 – 1 dB (.1 dB steps)	JFW, 50R-249
Standard Digital Multimeter	
DC Power Supply	0 – 28 VDC
Copy of Data Sheet (Appendix B) ²	
Assorted Connectors and Adapters	
Assorted Cables with calibrated loss	

Test Set Annual Calibration Equipment List

Table 4-5


Set the TR-220 front panel switches to the following positions before each test, unless otherwise instructed:

Function/Rotary Switch	Position
UUT FUNCTION	XPDR
CHNALT/DIST/VERT SPEED CODE/ALT – ATTN	Centered
UP – DOWN/FWD – REV	Centered
TO/FROM – START/STOP	Centered
IDENT	Default
ATCRBS/AIR – MODE S GND	ATCRBS/AIR
INCREASE – DECREASE	Default
AUTO/TEST/MANUAL	Default
BACK LIGHT	Default
ON/OFF	OFF
Power Charge Rocker Switch	OFF
DIRECT CONNECT PORT	Termination Cap On
SUM – DIFF Connectors	Capped

Initial Settings

Table 4-6

² To ensure accuracy and for simplicity, the Data Sheet is written and organized to reference each step by paragraph and step number. Make a photocopy, review and become familiar with the datasheet before beginning the tests.



Initial Settings

Figure 4-8

**WARNING**

Any time you are working with exposed wiring, the potential for electrical shock increases. Ensure all standard electrical safety procedures are strictly enforced to prevent possible injury.

4.7 Disassembly of the Test Set and Procedures

The TR-220 Test Set was designed for ease of maintenance and access. Disassembly of the Test Set requires only the use of simple hand tools. Ensure that the tools that are utilized are in good working condition.

Electrostatic discharge may also pose a concern. When ever opening the Test Set, be sure to follow standard grounding principles. When ever a potential exists for static electricity to build, damage to the Test Set and the internal electronic components may result.

1. Remove the Test Set from the Case by loosening the eight (8) lock bolts located on the front panel of the Test Set (Figure 4-9). Do not remove the bolts as they are a captive type. Only loosen them enough to release their grip on the anchor nuts.
2. Grasp the Test Set Handles and slowly remove the Test Set assembly from the case. Ensure that you do not use force to pull the Test Set from the case; you may have to slightly angle the Test Set to allow for free movement of the assembly and attached hardware and cables.






Figure 4-9

3. Access to the individual circuit boards is accomplished by removing the attaching hardware and covers. Ensure that all attaching cables and connectors remain attached and undue stress is not put on them.
4. Reassembly of the Test Set is accomplished by reversing the order of disassembly. Ensure that all of the connectors, cables and mounting hardware is tight and secure.

4.8 Calibration & Alignment




Due to different Software revisions, displays and procedures may vary slightly.



Pictured Test results in this procedure are for reference only. Due to numerous types of test equipment, your actual results may differ slightly.

4.8.1 Sub-Assembly Adjustments

1. Gain Access to the TR-220 Digital PCB, locate U17 (Figure 4-10) and set position 1, 2, 5, 6 on the Dip Switch to "ON" and remaining switches to "OFF". Ensure the **FUNCTION** switch is in the **XPDR** position and turn the Test Set "ON" while holding the **MANUAL** switch in the "DOWN" position, then release.




U-17

Figure 4-10

Record the **Installed CPLD Version** as shown on the display. Toggle the **TO** switch to advance to normal operation and turn the Test Set “OFF”.

2. Turn the Test Set “ON” while holding the **MANUAL** switch “Down”, place the **FUNCTION** switch in the **SETUP** position and observe the following:



IF desired, the operator may ZERO the RAM. This would only be necessary if any major assembly has been replaced, or significant failure was detected during the Acceptance and Verification Checks.

Initialize RAM
INIT: Press Manual

3. Place the **FUNCTION** switch in **DME** to advance to the Clock reset page (user preference but typically completed when an update to software is installed at the factory).

Initialize RTC
INIT: MAN'L SKIP:AUTO

4. Turn the Test Set “OFF” and “ON” and place the **FUNCTION** switch to **SETUP**, and by using the on screen prompts change the setup values according to the following Table 4-7 (Following page). (Utilize the **UP/DOWN** and **TO/FROM** switches to make changes).

Turn the Test Set “OFF” when complete (Settings will be saved automatically).

PARAMETER	VALUE
TCAS Scenario	1
Start Alt	2500'
Velocity	250 nmi/h
Vert Speed	+000 fpm
TCAS dist	5 nmi
Mode S Address	A00001
Antenna	Hand-Held
Ant Gain 1030	0 dB
Ant Gain 1090	0 dB
T/S Distance	25 ft
Cable Loss	3.0 dB
Power in	dBm
Latitude: Longitude:	40 51 N 74 6 W

Initial Setup


Table 4-7

5. Place the **FUNCTION** switch in **XPDR**, remove the *Termination Cap* from the **DIRECT CONNECT** port, and turn the Test Set "ON".

Tel-Instrument	TR-220
REV X.XX	00001 hrs

Self Test
Testing . . .


6. Log and Record the Test Set SW Version, then Turn the Test Set "OFF".
7. Remove the Digital/RF boards from the Chassis to gain access to the attenuator. Disconnect the **ATT** connector located on the Attenuator Assembly. Connect an Oscilloscope directly to **TP-17**.
8. Turn the Test Set "ON" while holding the **MANUAL** switch "Down". After the **CPLD** revision Screen is displayed, Toggle the **UP/FWD – DOWN/REV** switch "Up" and Observe the "DPSK Test" display.
9. Set your O'Scope to observe the following Display (Figure 4-11, following page) and ensure that the Base Line Voltage is set at **0 VDC / $\pm 2mv$** .



DPSK Ripple Check

Figure 4-11

10. Adjust **R1 ONLY IF NECESSARY**. Record the results and remove the O' Scope.
11. Turn the Test Set "**OFF**". Connect a Spectrum Analyzer directly to the same **ATT** port. Turn the Test Set back "**ON**" in the **XPDR** mode and access the Manual Sequence of transponder tests and advance to the **M A** test by toggling the **AUTO/MANUAL** switch "**Down**".



All information Shown is
"Don't Care".

12. Set the Spectrum analyzer to the following initial settings and measure the output power at the **ATT** port (ensure to take in account any cable loss).

Function	Setting
Frequency	1030 MHz
Span	0 MHz
Amplitude	Approx 8 db
Res & Video BW	5 MHz
Sweep	1 sec
Scale per Div	1 dB

Verify **8 dbm / ± 0.2 dBm**. Adjust **R-125** on the RF board only if necessary. Turn the Test Set "**OFF**", connect the **DIRECT CONNECT** termination cap and place a shorting plug on the Test Set **DIFF** connector.


13. Disconnect the spectrum analyzer and connect it directly to the **SUM** port. Turn the Test Set back "**ON**" while holding the **FROM** switch "**Down**". This disables the Antenna LED power.

Antenna LED is OFF

Advance once again to the *M A* Manual test by toggling the **AUTO/MANUAL** switch to **MANUAL**. Measure the power at the **SUM** port and ensure **7 dBm / ± 1 dBm**. Log this on the Data Sheet.

14. Move the Spectrum Analyzer to the **DIFF** port and terminate the **SUM** port. Turn the Test Set “OFF” and then back “ON”, at the “Set Distance Menu” page, set the distance for 25 feet, return to **XPDR** and advance to the *M A* test using the **MANUAL** switch.

Verify that the Output Power at the **DIFF** port is **20 dB less** than at the **SUM** connector (See Figure 4-12) (Measured value in Step 13).



DIFF Power Measurements

Figure 4-12

15. Without turning the Test Set “OFF”, turn the **FUNCTION** switch to **SETUP**; locate the **SET DISTANCE** menu and change the Distance from 25 ft to 35 ft. Return the **FUNCTION** switch to **XPDR** and advance back to the *Manual MA* test.
16. Verify that the output power at the **DIFF** port is now only **9 dB / ± 2 dB LOWER** than at the **SUM** port (Measured value in Step 13).
17. Without turning the Test Set “OFF”, turn the **FUNCTION** switch to **SETUP**; locate the **SET DISTANCE** menu and change the Distance from 35 ft to 75 ft. Return the **FUNCTION** switch to **XPDR** and advance back to the *Manual MA* test.
18. Verify that the output power at the **DIFF** port is now only **5 dB / ± 2 dB LOWER** than at the **SUM** connector (Measured value in Step 13).
19. Turn the Test Set “OFF”, remove the load from the **DIRECT CONNECT** port and reconnect the spectrum analyzer to the **ATT** port.
20. Remove the cable from the **DIFF** port and turn the Test Set “OFF”.

4.8.2 DAC Table (Transmit)

1. Remove the Termination Load from the **DIRECT CONNECT** port. Connect a Spectrum Analyzer to the **ATT** cable which is disconnected from the attenuator. Place the **FUNCTION** switch in the **TCAS** position and turn the Test Set back "ON" by holding the **MANUAL** switch down at the same time to enter the "Calibrate TX POWER" menu (the LED Power will automatically be removed).

TEST FUNCTIONS
Calibrate TX POWER

NOTE

If the operator zeroized the RAM as in Paragraph 4.8.1, Step 2; the following display **MAY** be shown when ever turning the Test Set "ON" without entering a calibration mode. Advance to the next step by toggling the **AUTO** switch.

Self Test
DAC table Xsum FAIL


2. Toggle the **AUTO** switch and observe the following:

POWER CALIBRATION:
-00 dB DAC=0000h

3. Set the Spectrum Analyzer to the following initial settings:


Function	Setting
Frequency	1030 MHz
Span	0 MHz
Amplitude	Approx 10 db
Res & Video BW	3 MHz
Sweep	50 ms
Scale per Div	1 dB

4. Observe a straight line power measurement. Adjust the Spectrum Analyzer so the measured pulse is even on any line. This will be the same reference line used for each measurement which ensures linear adjustments are made to the DAC table. The initial **0 dB DAC setting of 0000h** shall not be adjusted. After each adjustment, reposition the signal back to this same line before making another adjustment.




Set your reference at any point

- Toggle the **UP/DOWN** switch “Down”. This will change the -00 dB display by -02 dB. The Spectrum Analyzer display will decrease by approx. -02 dB.



Measurement drops approx -2 dB


- Utilize the **TO/FROM** to adjust the level in 1 dB steps and the **IDENT/EMERG** for 16 dB steps to place the spectrum Analyzer measurement -2 dB from the original reference. Test Sets Containing Software Version 3.43 or greater adjust the levels by utilizing the **TO/FROM** switch and the **CHN/ALT – DIST – VERT SPEED** switch to select 4 or 1 bit steps.



Original reference point

Make adjust to - 2 dB less than the reference line set in step #4.

7. Readjust the Spectrum Analyzer to set the measured pulse back on the reference line as set up in Step #4. Toggle the **UP/DOWN** switch "*Down*" to advance to the next step (-04 dB). Continue to adjust the measurements in **- 2 dB steps to -48 dB**. Once complete, toggle the **AUTO** switch to save the DAC table to the Test Set RAM. Turn the Test Set "*OFF*".



During this Process, if you do not save by toggling the **AUTO** switch the data will not be saved and the DAC tables will have to be reset from the beginning.

Record on the data sheet each 2 dB step.

4.8.3 RX Gain Calibration



When In Diagnostic Mode, each time the Test Set is turned “OFF”, then back “ON”, the Test set may begin at the **INITIALIZE RAM** menu. Ensure you bypass this by toggling **AUTO**, or the DAC table will have to be reset.


1. Modulate a Signal Generator utilizing the Pulse Generator triggered by TP3 of the RF Board ensuring **0 dBm** at the output of the Signal Generator.

Function	Setting
Triggered Burst of 2 Single pulses	
Period	20.3 μ s
Delay	12 μ s
Pulse Width	450.0 ns
Leading Edge Rise	5 ns
Trailing Edge Rise	Lead E.
Amplitude	+4 V HI / + 0 V Low
Input Impedance	50 Ω at 1 K In
Triggered by	Rising edge of ext In
Trigger Level	2.0 V / 10 k Ω

Set the Signal Generator to the Following:

Function	Setting
Frequency	1090 MHz
Modulation	Pulse Modulation
Input	Rear In
Output	0 dBm (measured at the cable end)

2. Disconnect the Spectrum Analyzer, and connect the Signal Generator to the **ATT** connector. Turn the Test Set back “ON” while holding the **IDENT** switch “UP”.



Holding the **IDENT** switch “UP” when turning the Test Set “ON”, enables a 4 millisecond or 200 μ sec (software dependent) receive window that ensures that the Test Set will *Hear* the simulated replies.

Advance to the Manual *M A* test by toggling the **MANUAL** switch down. Verify a *100% Reply* is observed on the Display.

M A		
0000	100%	FAIL

SLS, FAIL, Ident, and EMERG may be seen, but have no effect and are “Don’t Care” during the calibration. Display may differ dependent on Software installed.

3. Set the **FUNCTION** switch to the **ADS-B TX** position and turn the Test Set “OFF” then “ON” while holding the **MANUAL** switch “Down”.

TEST FUNCTION:

Release the **MANUAL** switch to enter the “*Calibrate Receiver Gain Menu*”.

Calibrate RX GAIN SUM: XXX DIFF: YYY
--

4. Adjust **R-143** (RF Board) until the Display indicates **210 / ±1**.

Calibrate RX GAIN SUM: 210 DIFF: YYY
--

5. Reduce the Signal Generator output by -25 dB. Adjust **R-140** (RF Board) until the Test Set indicates **145 / ±1**.

Calibrate RX GAIN SUM: 145 DIFF: XXX
--

6. Return the Signal Generator output to **0 dBm** level set in step #4, and verify that the display still measures **210 / ±1**.

Repeat this procedure until both measurements can be obtained without adjustment.

7. Increase the Signal Generator 5 dB and verify that the display indicates **222 / ± 2**.

8. Turn the Test Set “OFF”, select **XPDR** using the **FUNCTION** switch, then turn the Test Set back “ON” while holding the **IDENT** switch “UP”. Ensure 0 dB at the output of the signal generator Advance to the “POWER and FREQUENCY” Test in the MANUAL Mode of tests.

Power 58 dB	Frequency 1090.0 MHz
----------------	-------------------------

Ensure 58 dB is displayed ± 1 dB. All others “Don’t Care”.


9. Set the Signal Generator Output to 0 dB, Test Set Display will indicate **53 dB ± 2.**

Power	Frequency
53 dB	1090.0 MHz

10. Vary the Output from +10 dBm to -20 dBm, and verify the display tracks accordingly **±1 dB** at each 1 dB step. Turn the Test Set “OFF” and disconnect the test equipment.
11. Reconnect the **ATT** connector back to the attenuator, connect a Spectrum Analyzer (set to the following initial settings) to the **DIRECT CONNECT** Port, turn the Test Set “ON” and advance to the *Manual M A* transponder test.

Function	Setting
Frequency	1030 MHz
Span	0 MHz
Amplitude	-40 dBm
Res BW	5 MHz
Video BW	3 MHz
Sweep	500 ms

12. Measure **- 42 dBm / ± 1 dB** (1030 MHz) taking into account any cable loss. Disconnect the Spectrum Analyzer.
13. Reconnect the Termination Load, back on to the **DIRECT CONNECT** port. Restart the Test Set while holding “UP” the **IDENT** switch. Advance to the *M A Manual* Transponder test.
14. Ensure that the Pulse Generator is still synchronized by the same procedures as outlined in Step #1. Connect the RF Splitter to the output of the Signal Generator. Set the Generator for 1090 MHz and amplitude at 0.0 ± 0.2 dBm as measured from both ends of the splitter one at a time using a Spectrum Analyzer.




When measuring the two outputs of the splitter, it is necessary to terminate the end not being set with a 50 Ω load. The **SUM** or **DIFF** port may be utilized as the load. Setting the output at the end of the cable to 0 dBm must be done.

Turn “OFF” the Test Set, and connect *ONE* of the RF Splitter outputs to the **SUM** connector (See Figure 4-13, following page). This test is conducted without the Variable Attenuator.

15. Place the Test Set **FUNCTION** switch in the **XPDR** position, and turn “ON” the Test Set while holding “UP” the **IDENT** switch, then release. Continue to the Manual MA Test and observe a **100% reply**.

M A		
0000	100%	FAIL

SLS, FAIL, Ident, and EMERG may be seen, but have no effect and are “Don’t Care” during the calibration. Display may differ dependent on Software installed.



SUM/DIFF Set-up

Figure 4-13

Turn the Test Set “OFF”, place the **FUNCTION** switch in **ADS-B TX**; connect the remaining Splitter output to the **DIFF** connector, and restart the Test Set while holding “DOWN” the **MANUAL** switch. Release the switch and observe the “Calibrate RX Gain” menu.

Calibrate RX GAIN		
SUM: XXX	DIFF: XXX	

16. Adjust the Signal Generator output until the **SUM: XXX** is **202 / ± 2** . Adjust **R-124** (RF Board) until the **DIFF: YYY** on the Display indicates **240 / ± 2** .
17. Reduce the Signal Generator output by -25 dB. Verify that the **SUM: XXX** is **138 / ± 2** and the **DIFF: XXX** is **175 / ± 2** . Adjust **R-121** (RF Board) if necessary.

18. Return the Signal Generator Output back + 25 dB and verify the **DIFF** and **SUM** readings are the same as measured in **Step # 16, ± 2** . If not, continue to adjust the measurements until no adjustment is necessary when toggling back and forth by 25 dB increments.
19. Turn the Test Set "OFF", place the **FUNCTION** switch in the **XPDR** position. Turn the Test Set back "ON" while holding the **IDENT** switch "UP". At the "Set Distance Menu", (Select **SETUP**, and return to **XPDR**)) select **35 ft**. Advance to the *Manual M A XPDR* test.

Set Distance: 35 ft.
TO/FROM Cont: AUTO

20. Disconnect the **DIFF** connector and connect the variable attenuator (see Figure 4-13) between the RF Splitter and the **DIFF** Port. Verify that the output of the Signal Generator is set at -15 dBm / $\pm .2$ dBm at the connection for the **SUM** port.
21. Adjust the variable Attenuator to provide a signal that is **10 dB / $\pm .2$ dBm** less at the Diff port connector than at the **SUM** port connector.
22. Connect one oscilloscope probe and monitor **TP-16**. Connect another probe to **TP-27** and ensure that the signal at **TP-27** occurs at the same time as **TP-16** (Figure 4-14). If not there is possible interference from other equipment and the test may not be accurate.

The Test Set Display should indicate **100% Reply**.





Figure 4-14

23. Using **R-127** (RF Board), find the position where the **100% Reply** shown on the Test Set display changes to **=TURN=**. At **TP-27**, verify that the High/Low signal Changes State (Figure 4-15). This is a fine adjustment and care should be made to adjust this just to the point that the State of TP-27 changes.



M A	=TURN=
No Reply	

Decrease the Variable Attenuator by 1 dB, Verify that the pulses change state and the **=TURN=** display remains ON.

24. Increase the variable Attenuator by 2 dB, Verify that the **=TURN=** indicator message is OFF and that the signal at **TP-27 Changes State**. The Display will indicate 100% reply.

M A	SLS
0000	100% FAIL

SLS, FAIL, and EMERG may be seen, but have no effect on the calibration.

25. Toggle the **SLEW UP/DOWN** switch **UP** to return to the "*Set Distance Menu*". Change the distance to **25 ft.** and toggle the **AUTO** switch to return to the previous display. Verify that the **=TURN=** display now occurs at **6 / + 1 dB less** than at the level as seen in Step #24 by varying the attenuator ± 2 dB.
26. Turn "**OFF**" the Test Set, disconnect AC Power, and at DIP Switch U17, return all positions to **OFF** with the exception of Dip **Position #2**; which will remain **ON**.

Reassemble the RF and Digital boards back to the Test Set Chassis, leaving the Digital Board Cover OFF.

4.8.4 **Power Supply Test**

1. Remove the Front Panel Battery Cover and disconnect the Connection Terminals. Verify **7.2 VDC / $\pm$ 0.3 VDC** at the removed terminals.

Disconnect the Power Supply.

2. Connect the Power supply to the Test Set Battery terminals and adjust for **6.5 VDC**. Monitor **TP3** (Power Supply) with a DVM; turn the Test Set "ON", readjust the Power Supply, if necessary, and advance to the Manual XPDR M A test.
3. Slowly decrease the Power Supply DC Voltage until the Test Set Display indicates:

LOW BATTERY
Press AUTO to Continue

The voltage of the Power Supply should indicate **5.6 VDC / $\pm$.05 VDC**. Toggle the **AUTO/MANUAL** switch to **MANUAL** switch. Continue to lower the Power Supply to **5.4 VDC / $\pm$.05 VDC**. Toggle the **MANUAL** switch once and the Display should not indicate "LOW BATTERY RECHARGE REQUIRED".

4. Continue the MA test by toggling **AUTO** and lower the power supply voltage to **5.2 VDC / $\pm$.05 VDC**. Toggle the **AUTO/MANUAL** switch to **MANUAL** and the Test Set shall shut down.
5. Press and Hold the **TEST SET PWR** switch to "ON". The Test Set should indicate:


LOW BATTERY
SHUTTING DOWN

Release the toggle switch, the Test Set shall Shut OFF.

6. Reconnect the Battery leads and reassemble the Test Set back into the chassis and case.

4.8.5 **Final Test**

1. Conduct an **ACCEPTANCE and VERIFICATION Check IAW Section B**. This is the Final Test to ensure and verify proper operation and alignment. Log all results on the Data Sheet and maintain a copy in your records for future reference.




Test Point Locations

Figure 4-14


CHAPTER V

SCHEMATICS







A	ERN 0002: INITIAL RELEASE	L.S.	4-4-00	JWW 4-4-00
REV	DESCRIPTION	CHG INIT	DATE	APPROVED
Title SCHEMATIC DIAGRAM SENSE LINE FILTER PCB				
Size B	Number 80 169 003			Rev A
Checked: JW 4-4-00	Date 3-23-00		Drawn by L.S.	
Issued: JW 4-4-00	Filename 80169003A.sch		Sheet 1 of 1	

Thu Jan 29, 2004 10:49:33



PART NO.	DIAGRAM
80 208 003-01	A
80 208 003-02	B
80 208 003-03	C
80 208 003-04	D



- 1 SCHEMATIC DIAGRAM FOR 80208001-01
- 2 SCHEMATIC DIAGRAM FOR 80208001-02
- 3 SCHEMATIC DIAGRAM FOR 80208001-03
- 4 SCHEMATIC DIAGRAM FOR 80208001-04

A	ECO1684-08: INITIAL RELEASE	L.S.	030310	M.G.
REV	DESCRIPTION	CHG INIT	DATE	APPROVED


SCHEMATIC DIAGRAM
ANTENNA ATTENUATOR


80 208 003

A

Checked: M.G. 030310
Issued: B.R. 030310

030123
80208003A.SCH
Thu Jan 29, 2004 15:08:06
L. SASS
1
1





A	ERN0058-03: INITIAL RELEASE	L.S.	030612	O.P. 030612
REV	DESCRIPTION	CHG INIT	DATE	APPROVED


SCHEMATIC DIAGRAM
IF FILTER

80 212 003 A


Checked: O.P. 030612
Issued: D.M. 030612

021210
80212003A.sch
10:50:16

L. SASS
1
Thu Jan 29, 2004




REVISION HISTORY ON SHEET 2			
Title		SCHEMATIC DIAGRAM POWER SUPPLY PCB	
Size	Number	Rev	
B	80 180 003	G	
Checked: D.M. 4/9/01		Date 8-9-00	Drawn by L.S.
Issued: D.M. 4/9/01		Filename 80180003G.sch	Sheet 1 of 2
Fri May 13, 2005		14:58:53	



G	ECO 1865-05: INCLUDED 80 221 001 CKT. AS P/O 80 180 003 SCHEMATIC.	L.S.	040416	D.M. 040416
F	ECO 1833-5: ADD SWITCH PCB.	L.S.	031102	B.R. 031102
E	ECO 1788: U3 PART CHG.	L.S.	030924	B.R. 030924
D	ECO 1586: D9,D10 PART CHG.	L.S.	10-16-01	D.M. 10-16-01
C	ECO 1571: R21 VALUE CHG.	L.S.	6-11-01	D.M. 6-11-01
B	ERN 0013: INITIAL RELEASE	L.S.	4-9-01	D.M. 4-9-01
REV	DESCRIPTION	CHG INIT	DATE	APPROVED
Title SCHEMATIC DIAGRAM POWER SUPPLY PCB				
Size	Number 80 180 003			Rev G
Checked: D.M. 4-9-01		Date 9-8-00		Drawn by L.S.
Issued: D.M. 4-9-01		Filename 80180003G.sch		Sheet 2 of 2

Fri May 13, 2005 14:59:07

HIGHEST REFERENCE DESIGNATONS USED							
C21	D11	E3	L1	Q1	R24	TP3	U5
REFERENCE DESIGNATONS NOT USED							
C1–C3 C8–C19	D1–D9				R1–R18		U1–U4



NOTES:
1. UNLESS OTHERWISE SPECIFIED RESISTOR
VALUES ARE IN OHMS. CAPACITANCE VALUES
ARE IN MICROFARADS.
2. ALL INTERGRATED CIRCUITS ARE IDENTIFIED
BY GENERIC PART TYPE FOR REFERENCE ONLY.

B	ECO 1715: ADD Q1, R23, R24	L.S.	030429	BR
A	ERN 0028: INITIAL RELEASE	L.S.	020319	BR
REV	DESCRIPTION	CHG INIT	DATE	APPROVED

SCHEMATIC DIAGRAM
REGULATOR PCB

80 191 003

B

Checked: BR
Issued: 020319

8-24-01
80191003B.sch
Fri May 13, 2005

L.S.
1
14:58:10

REVISIONS			
REV	DESCRIPTION	DATE	APPRVD
A	ECO 1621-60:INITIAL REL.	020329	WR
B	ECO 1868-59:REMOVE TAP-135 FROM TITLE BLOCK.	040507	DM

ANTENNA

AT1
A-210-020-125

R2
27

R5
61.9
1%

R4
18

R6
18

R9
33

J2

C3
2.8-12.5

NOTES:


UNLESS OTHERWISE SPECIFIED:

1. RESISTOR VALUES ARE IN OHMS.

2. CAPACITOR VALUES ARE IN PICO FARADS.

80198001	TR-210	CONTRACT NO.		TEL-INSTRUMENT ELEC. CORP.			
80198001	TR-220			SCHEMATIC DIAGRAM ANTI-RADIATION HAT (10 FT. CABLE)			
80198001	T-48A						
80198001	T-48	APPROVALS	DATE	SIZE B	FSCM NO. 92606	DWG. NO. 80198003	REV B
80198001	T-49CA	DRAWN D.MCMAHON	020329				
80198001	T-49C	CHECKED WR	020329				
NEXT ASSY	USED ON	ISSUED		SCALE	NONE	SHEET OF	1
APPLICATION							

TR-220 INTERNAL (FRONT PANEL) INTERCONNECT




C	ECO1719-06 ADDED THMS 1 AND THMS2	BR	030522	B.R.
B	ECO1656-07 REV S14 SW TXT	L.S.	020911	B.R.
A	ERN 0028: INITIAL RELEASE	L.S.	020319	B.R.
REV	DESCRIPTION	CHG INIT	DATE	APPROVED


TR-220 INTERNAL (FRONT PANEL)
INTERCONNECT DIAGRAM


89 003 135 C


Checked: B.R. 020319
Issued: B.R. 020319

8-27-01
89003135C.sch
1
L.S.
1
Fri May 13, 2005
14:57:16












SCHEMATIC DIAGRAM
MULTI-MODE DIGITAL BOARD
80 210 003 REV B 030804
SHEET 4 OF 4







SCHEMATIC DIAGRAM
MULTIMODE RF BOARD
80 211 003 REV E 031031
SHEET 2 OF 5

R184 SHEET 4








CHAPTER VI


ILLUSTRATED PARTS BREAKDOWN PARTS LIST



TR-220 Test Set and Accessories

Figure 6-1

TR-220 Test Set & Accessories				90 000 088		
#	QTY	Tel Desig.	Nomenclature	Ref Designator	Resource	Vendor P/N
	1	75010186	CABLE ASSY, DIRECT CONNECT			
	1	75010025	CABLE ASSY, AC POWER CORD			
	1	75010078	EXTENDER CABLE ASSY., DIRECTIONAL ANTENNA			
	1	75010208-02	DIRECTIONAL ANTENNA CABLE ASSEMBLY			
	1	89001158-07	DIRECTIONAL ANTENNA ASSEMBLY			
	1	88001002	DIRECTIONAL ANTENNA HANDLE ASSEMBLY			
	1	89000166	ANTI-RADIATION COUPLER ASSY, TAP-200 (10 FT.)			




TR-220 Front Panel Assembly

Figure 6-2

Front Panel Assembly				89 000 135		
#	QTY	Tel Desig.	Nomenclature	Ref Designator	Resource	Vendor P/N
1	1	61060051	FRONT PANEL			
2	1	57005039	SILK SCREEN, FRONT PANEL			
3	1	88000017	CHASSIS ASSY	A4		
4	1	89001077	ATTENUATOR ASSY	A10		
5	1	88000028	POWER SUPPLY ASSY	A5		
6	1	80189000	PCB ASSY, FRONT PANEL SWITCH BOARD	A9		
7	1	88000018	BATTERY COVER ASSY	A15		
8	1	62020071	BRACKET, FRONT PANEL			
9	1	62020072	BRACKET, BATTERY			
10						
11	1	48000113	CONNECTOR, SUB D TYPE, 9 PIN		AMP	747905-2
12	1	43015003	FILTER, DISPLAY			
13	2	31000011	TAPE, FOAM, 1/4" X 8"		3M	4032
14	AR	31010001	SILICONE SEALANT, RTV			
15						
16						
17	2	31016005	TRIM MOLDING, ADHESIVE BACKED			
18	1	45010001	LCD DISPLAY		IEE	03857-03-040
19						
20	1	46027520	SWITCH, TOGGLE, SPDT	S11	C&K	7101-TCWZQE
21	5	46027516	SWITCH, TOGGLE, SPDT	S1, S5, S10, S13, S14	C&K	7105-TCWZQE
22	1	46027517	SWITCH, TOGGLE, SPDT	S7	C&K	7108-TCWZQE
23	1	46027526	SWITCH, TOGGLE, SPDT	S4	C&K	7103-TCWZQE
24	1	46027521	SWITCH, TOGGLE, SPDT	S15	C&K	7107-TCWZQE
25	1	46020019	SWITCH, ROTARY	S2	GRAYHILL	26ASD45-01-1-AJS
26	1	57025023	KNOB	S2	MS91528-1II1B	MS91528-1II1B
27	9	52063004	WASHER (.477 ID)	S1,S4,S5,S7,S10,S11,S13-S15	ASMCO	396-.020-SS-0
28	9	52063003	WASHER, SEALING, SWITCH	S1,S4,S5,S7,S10,S11,S13-S15	MFS	60064
29	1	48035010	AC RECEPTACLE		SCHURTER	KD14.110 1.151
30	1	48035008	FUSE DRAWER		SCHURTER	4303.2401
31	2	45100026	FUSE, 500mA/250V, SUPER TIME LAG		SCHURTER	34.504
32	1	88000034	ASSEMBLY, THERMISTOR (BLUE)			
33	1	88000035	ASSEMBLY, THERMISTOR (BROWN)			
34						
35	2	45001015	LED INDICATOR, SNAP-IN (GREEN)		DIALIGHT	559-2201-007

Front Panel Assembly				89 000 135		
#	QTY	Tel Desig.	Nomenclature	Ref Designator	Resource	Vendor P/N
38	1	88001014	TERMINATION ASSY	A14		
39	1	48072001	INVERTER		IEE	46013-01
40	1	62020075	BRACKET, INVERTER			
41	2	52400053	STANDOFF, FEMALE, 1/4 HEX X 15/16 LG		RAF	2111-440- SS-20
42						
43						
44						
45						
46	1	75010165	CABLE ASSY, DIGITAL/PANEL DISPLAY	W1		
47	1	75010166	CABLE ASSY, DIGITAL/F.P. SWITCH PCB	W2		
48	1	75010075	CABLE ASSY, RF/ANTENNA (SUM)	W3		
49	1	75010079	CABLE ASSY, ATTEN/DIRECT CONNECT	W4		
50	1	75010081	CABLE ASSY, RF/ANTENNA (DIFF)	W5		
51	1	75010082	CABLE ASSY, ANTENNUATOR/RF	W6		
52	1	75010142	CABLE ASSY, SENSE LINE FILTER	W7		
53	1	48071006	BATTERY			
54	1	55008006	BELT, BATTERY		McMASTER- CARR	6082K33- 12
55	1	55001007	STRAIN RELIEF, BLACK		HEYCO	1017
56	2	56025007	HANDLE		VEMALINE PROD.	BZ130-1
57	2	31020035	FERRULE		PROMPTUS	288- 09ALC
58	7	50400002	SCREW, CAPTIVE			
59	8	52061001	"O" RING		McMAS OR ASMCO	9464K11 OR #AS568A- 006
60	8	50500002	RETAINER			
61	6	52400054	STANDOFF, FEMALE, 5/16 HEX X 2.688 LG		ASMCO	1240H-SS 2.688-12
62	4	52400008	STANDOFF, FEMALE, 1/4 HEX X 5/16 LG		RAF	2101-440- SS-20
63	9	52400052	STANDOFF, FEMALE, 1/4 HEX X 5/8 LG		RAF	2106-440- SS-20
64	1	55082017	GASKET, PANEL		TECKNIT	89-01080
65	1	57031011	LABEL, SAFTY FUNCTION		PANDUIT	PESC-H- EC
66	1	55008004	STRAP, ATTACHING		GLENAIR	G3.5-05
67	1	57030017	NAMEPLATE			


#	QTY	Tel Desig.	Nomenclature	Ref Designator	Resource	Vendor P/N
68	2	52400049	3/16 HEX JACK SCREW		RAF	4750-3
69	2	50120005	SCREW, FLAT HD, #6-32 X .31 LG		MS24693-C25	MS24693-C25
70	13	50110007	SCREW, PAN HD, #4-40 X .25 LG		MS51957-13	MS51957-13
71						
72	13	50110001	SCREW, PAN HD, #6-32 X .31 LG		MS51957-27	MS51957-27
73						
74	6	50110013	SCREW, PAN HD, #8-32 X .38 LG		MS51957-43	MS51957-43
75	17	52020002	WASHER, LOCK, #4		MS35338-135	MS35338-135
76	20	52020001	WASHER, LOCK, #6		MS35338-136	MS35338-136
77	6	52020003	WASHER, LOCK, #8		MS35338-137	MS35338-137
78						
79	2	53010011	NUT, HEX, EXTRA SMALL PATTERN #4-40		TOWER	4CNESS
80	7	53010001	NUT, HEX, #6-32		MS35649-264	MS35649-264
81	2	50140015	SCREW, FLAT HD, 82 DEG., #4-40 X .38 LG		MS51959-15	MS51959-15
82	4	50140014	SCREW, FLAT HD, 82 DEG., #8-32 X .50 LG		MS51959-45	MS51959-45
83	1	75010163	CABLE ASSY, POWER SUPPLY (4 PINS)	W8		
84	1	75010193	CABLE ASSY, POWER SUPPLY (18 PINS)	W9		
85	1	50400004	CAPTIVE SCREW			
86	1	48077022-21	PROGRAMMED MEMORY			
86	1	40200104	IC PROM, ERASABLE			
87	1	48078006-02	CPLD, PROGRAMMABLE			
		90006088	TEST PROCEDURE, COMPOSITE			
		79000037	WIRING DIAGRAM, FRONT PANEL			
		89003135	INTERCONNECT DIAGRAM, INTERNAL			



Termination Cap

Figure 6-3


Termination Cap				88 001 014		
#	QTY	Tel Desig.	Nomenclature	Ref Designator	Resource	Vendor P/N
1	1	43003001	TERMINATION CAP, 9.386K		ALAN	9400T- 1940
2	1	55008004	STRAP, ATTACHING			



RF Digital Chassis

Figure 6-4

RF/Digital Chassis				88 000 017		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	62000033	CHASSIS, RF/DIGITAL			
2	1	62040037	COVER, DIGITAL CHASSIS			
3	1	62040038	COVER, RF CHASSIS			
4	AR	55060001	SHIELD, SPIRAL		SPIRA	SS-06
5	1	80211001	PCB ASSY, MULTIMODE RF BOARD			
6	1	80210001	PCB ASSY, MULTIMODE DIGITAL BOARD			
7	1	62070052	PLATE, SMA			
8	5	52400029	STANDOFF, MALE/FEMALE		RAF	4534-632-SS-20
9	5	52400030	STANDOFF, MALE/FEMALE		RAF	4537-632-SS-20
10	12	50110015	SCREW, PAN HD, #6-32 X .25 LG			MS51957-26
11	12	52020001	WASHER, LOCK, #6			MS35338-136
12	4	52400032	STANDOFF, 3/16 HEX, "D" CONN		RAF	4750-2
13	2	50110021	SCREW, PAN HD, #4-40 X .125 LG			MS51957-11
14	2	50110008	SCREW, PAN HD, #4-40 X .19 LG			MS51957-12
15	4	52020002	WASHER, LOCK, #4			MS35338-135
16						
17	1	31004012	STIFFENER BOARD			



Multimode Digital Board


Figure 6-5


Multimode Digital PCB				80 210 001		
#	QTY	Tel Desig.	Nomenclature	Ref Designator	Resource	Vendor P/N
1	1	80111002	PCB DRILLING AND FABRICATION (REV B)			
2	1	48000055	CONNECTOR. HEADER, 36 PIN	J5	SAMTEC	SSW-118-01-G-D
3	1	48000033	CONNECTOR RT. ANGLE, 37 PIN	J3	AMP	FCC17-C37PC-44B
4	1	48000054	CONNECTOR RT. ANGLE, 50 PIN	J2	AMP	747497-4
5	1	48000022	CONNECTOR, HEADER, 10 PIN	J4	SPECTRUM	842-800-560-010
6	1	40040016	CRYSTAL, 12MHz	Y1		
7	1	55080002	CRYSTAL MOUNT	XY1		
8	1	48075008	CRYSTAL OSCILLATOR, 40MHz	U16	RALTRON	CO1025-40.000
9	1	46025003	8 PIN DIP SWITCH-SM	U17	C & K	TD08H0S K1
10						
11	1	40200027	I.C.	U10	INTEL	TP80C31 BH-1
12						
13						
14	1	48064006	SOCKET, IC., 28 PIN	XU7	AUGAT	528-AG11D-ES
15	1	48078006-01	CPLD, PROGRAMMABLE	U29		
15	1	40201137	IC-PLD-SM; 208 PIN	U29	ALTERA	EPM9560 RI208-20
16						
17	1	40201138	IC-SM	U6	BENCHMARK	BQ4830Y MA-85
18	1	40200111	I.C.	U15	ANALOG DEVICES	AD7828B R
19	1	40201105	IC-SM	U33	NAT'L SEMI	DS14C23 2C
20	1	40201136	IC-SM	U8	MAXIM	MAX660E SA
21	1	40201139	IC-SM		OLYMPIC	461-4
22	A/R	72628001	WIRE, KYNAR, INSULATED 28 AWG.	U9	TEXAS INST.	TPS76750 QPWP
23	1	56060019	VOLT. REGULATOR; SM	U21	NAT'L SEMI	MC74HC0 0D
24	1	40201038	IC-SM	U12	FAIRCHILD	MC74HC0 4D
25	1	40201019	IC-SM			
26						
27	1	40201011	IC-SM			
28						
29	1	40201014	IC-SM	U1, U2, U5, U35, U37, U38, U11	FAIRCHILD	MM74HC5 74WM
30	7	40201013	IC-SM	U19, U13, U22	IDT	7204L25J 1


Multimode Digital PCB				80 210 001		
#	QTY	Tel Desig.	Nomenclature	Ref Designator	Resource	Vendor P/N
31	3	40201153	IC-SM-FIFO	U40	TEXAS INST.	TL082CD
32	1	40201008	IC-SM	CR13-CR28	VISHAY	BAT54S
33	16	40010044	DIODE-SM (DUAL)	CR29	MOTOROLA	1SMA591 8BT3
34	1	40010045	DIODE-SM 5.1V ZENER	CR1-CR10	FAIRCHILD	MMBD914
35	10	40010014	DIODE-SM			
36						
37	11	55025008	TERMINAL, POST	TP1-TP11	COMP. CORP	TP-105- 01-09
38	1	43011029	INDUCTOR, 3.3uhy	L2	NYTRONICS	WEE-3300
39	2	40001012	TRANSISTOR	Q4, Q8	SILICONIX	VN10LM
40						
41	4	40001017	TRANSISTOR-SM	Q6, Q9, Q14, Q16	FAIRCHILD	MMBT918 L
42						
43						
44						
45						
46	2	41150002	RES. CHIP, ARRAY 742- 10K	R53, R54	DIGI-KEY	742C1631 03JCT-ND
47	2	41150001	RES. CHIP, ARRAY 742- 1K	R55, R56	DIGI-KEY	742C1631 02JCT-ND
48	14	41160015	RES. CHIP; RC1206; 10K	R6, R12-R16, R18, R20, R24, R29, R48, R58, R59, R68		
49	1	41160013	RES. CHIP; RC1206; 4.7K	R19		
50	1	41160096	RES. CHIP; RC1206; 39K	R41		
51	44	41160003	RES. CHIP; RC1206; 1K	R1-R4, R7-R9, R11, R25-R28, R33, R47, R50- R52, R64-R67, R94, R96, R100- R104, R73, R77, R119, R122, R123, R125- R132, R137- R139		
52	1	41160041	RES. CHIP; RC1206; 15K	R92		
53	3	41160030	RES. CHIP; RC1206; 2K	R39, R91, R93		
54	1	41160008	RES. CHIP; RC1206; 2.2K	R62		
55	1	41160029	RES. CHIP; RC1206; 3.3K	R89		
56	5	41160021	RES. CHIP; RC1206; 470 OHMS	R49, R63, R76, R117, R121		
57	4	41160007	RES. CHIP; RC1206; 33 OHMS	R133-R136		
58	1	41160032	RES. CHIP; RC1206; 82 OHMS	R44		
59	2	41160077	RES. CHIP; RC1206; 1.6K	R42, R43		

Multimode Digital PCB				80 210 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
60	1	41101260	RES. CHIP; RC1206, MF 1%; 4.99K	R60		
61	A/R	31006001	TAPE, ISULATING			KAPTON
62	2	41101222	RES. CHIP; RC1206, MF 1%; 2K	R71, R81		
63	1	41101289	RES. CHIP; RC1206, MF 1%; 10.0K	R61		
64	2	41101251	RES. CHIP; RC1206, MF 1%; 4.02K	R78, R79		
65	5	41101239	RES. CHIP; RC1206, MF 1%; 3.01K	R30, R70, R72, R80, R82		
66	2	41101193	RES. CHIP; RC1206, MF 1%; 1K	R74, R75		
67	1	41101297	RES. CHIP; RC1206, MF 1%; 12.1K	R17		
68	3	42025037	CAP. CHIP; CC1206, NPO; 1000pF	C23, C80, C90		
69	1	42026001	CAP. CHIP; CC1210; 1uF	C89		
70	1	42025033	CAP. CHIP; CC1206; NPO; 470pF	C83		
71	2	42025019	CAP. CHIP; CC1206, NPO; 33pF	C4, C5		
72	1	42025028	CAP. CHIP; CC1206; 180 pF	C81		
73	1	42100006		C6		
73					LEMET (ALT)	C322C102KIR5CA
74	37	42020001	1	C2, C7, C8, C10-15, C17, C18, C21, C25, C27-35, C37, C42, C47, C48, C51-54, C57, C58, C85-87, C88, C99		
75	8	42480009	CAP. TANT-SM; 22uF/25V;	C9, C16, C22, C40, C41, C43, C44, C60	PANASONIC	ECS-T1ED226R
	ALT				AVX (ALT)	TAJ-D-226K-025R
76	1	42185019	CAP. ALUM ELECT-SM; 3.3uF/50V	C59	PANASONIC	ECE-V1HV3R3SR
77	3	42480008	CAP. TANT-SM; 100uF/10V	C1, C3, C93		TAJD107K010R
78	1	42185030	CAP. ALUM ELECT-SM; 10uF/16V	C45		ECE-V1CA100R
79	1	50110009	SCREW, PAN HD. 4-40X5/16 LG.			MS51597-14
80	1	52020002	WASHER, LOCK NO. 4			MS35338-135


Multimode Digital PCB				80 210 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
81	1	52010002	WASHER, FLAT NO. 4			MS15794-804
82	1	53010002	NUT, HEX NO. 4			MS35649-244
83	2	42020014	CAP. CHIP; CC1206; X7R; 22pF	C82		
84	1	42020013	CAP. CHIP; CC1206; X7R; .1uF	C84, C94		
85	A/R	31010005	WIRE TACKING ADHESIVE			TAKPAK 444
		80210003				







Multimode RF Board
(3 of 4)
Figure 6-6c



NOTES:

13

PRIOR TO INSTALLATION OF I.F. FILTER PCB ASSY'S (A22 AND A23) 80212001 ITEM 135, DRILL OUT VIA'S LABELED "AL" AND "AN". DRILL OUT USING .052 DIAMETER DRILL. INSTALL JUMPER WIRES PER JUMPER WIRE TABLE. INSULATION MUST BE REMOVED ON ALL JUMPER WIRES USED ON THE I.F. FILTER BOARDS (A22 AND A23) EXCEPT THE WIRES GOING TO VIA'S THAT ARE LABELED "AL" AND "AN". THE WIRES THAT GO TO VIA'S "AL" AND "AN" MUST PASS THROUGH HOLE ON REAR OF PCB TO COMPONENT SIDE. INSULATION MUST STAY ON THESE WIRES ONLY.

14

APPLY A THIN LAYER OF ADHESIVE CEMENT (ITEM 132) BETWEEN RF PCB 80 211 001 AND I.F. FILTER PCB'S 80 212 001. (2 PLACES ASSY'S A22 AND A23) .

CONTRACT NO.		TEL-INSTRUMENT ELEC. CORP.			
APPROVALS		DATE		PCB ASSEMBLY, MULTI MODE RF BOARD	
DRAWN	D.MCMAHON	030804	SIZE	FSCM NO.	DWG. NO.
CHECKED	WR	030804	D	92606	80 211 001
ISSUED	WR	030804	SCALE	NTS	SHEET 4 OF 4

REV	F
-----	---

Multimode RF Board
(4 of 4)
Figure 6-6d

Multimode RF PCB				80 211 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80114002	PCB Drill and Fab. RF			
2	5	40200113	Comparator, AD790AQ, DIP	U22, U26, U56, U65, U67	Analog Devices	AD790AQ
3	1	40201142	Delay Line, 250 nSec	U23	Data Delay Dev.	250NSEC 2211-250BC4
4	1	40201139	Regulator, -5VDC, MAX660ESA, SO-8	U16	Maxim	MAX660ESA
5	2	40201143	Op-Amp, Dual TL082ID, SO-8	U8, U44		TL082ID
6	1	40201144	Regulator, +15VDC, MAX643BESA, SO-8	U19	Maxim	MAX643BESA
7	2	40201084	Strathesizer, MB1507PF, SO-16	U10, U45		MB1507PF
8						
9	3	40201145	Freq. Discr, SA602AM, SO-8	U20, U21, U24		SA602AM
10	2	40201149	Log Amp, AD307AR SO-8	U52, U59	Analog Devices	AD8307AR
11	2	40201088	RF Amp, UPC2713T, SO-8	U55, U61	NEC	UPC2713T
12	2	40201150	Op-Amp, Dual AD8032AR, SO-8	U53, U60	Analog Devices	AD8032AR
13	1	40201113	RF Amp, VNA-25, SO-8	U4	Mini-Circuits	VNA-25
14	1	40201114	RF Switch, MSWA-2-20, SO-8	U34	Mini-Circuits	MSWA-2-20
15	2	40201115	RF Switch, MSWT-4-20, SO-8	U36, U37	Mini-Circuits	MSWT-4-20
16	1	40201116	Comparator, Quad, LM2901N, SO-8	U40		LM2901M
17	2	40201112	IF Amp, IVA-05208, SO-8	U2, U3	Hewlett Packard	IVA-05208
18	2	40201011	Switch, CMOS, MM74HC4516WM, SO-16	U32, U35		MM74HC4316WM
19	2	40201117	Sample & Hold, AD783JR, SO-8	U62, U64	Analog Devices	AD783JR
20	1	40201038	Nand, Quad, 74HC00M, SO-14	U39		74HC00M
21	3	40201086	MIXER, RMS-11F	U1, U50, U57	Mini-Circuits	RMS-11F
22	1	56060006	Regulator, SUDC, LM2940T-5.0	U18	National Semi.	LM2940T-5.0
23						
24	2	40201128	RF Amp, MSA0786	U51, U58	Hewlett Packard	MSA0786
25	2	40201132	RF Amp, MSA2111	U46, U47	Hewlett Packard	MSA2111
26	1	40201147	RF Amp, UPC2708T	U9	NEC	UPC2708T
27	1	40200112	FILTER, 60MHz, PBP-60	U63	Mini-Circuits	PBP-60
28	1	40201047	Op Amp, Dual, LM-2904, SO-8	U5		LM2904M
29	1	40201005	XOR, Quad, 2 input, 74HC86M, SO-14	U31		74HC86M
30	1	40201053	NOR, Triple, 3 input, 74HC27M, SO-14	U33		74HC27M


Multimode RF PCB				80 211 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
31	2	40001013	Transistor, RF, NPN, NE02133, Sot-23	Q1, Q3	NEC	NE02133
32	1	40001012	Transistor, MOSFET, VN10LM	Q2		VN10LM
33	2	40001014	Transistor, PNP, MMBT2907, Sot-23	Q4, Q6		MMBT2907A
34	1	40001011	Transistor, NPN, MMBT2222A, Sot-23	Q5		MMBT2222A
35	3	40010014	Diode, SM, MMBD914, Sot-23	CR2, CR5, CR6		MMBD914
36	2	40010011	Diode, Varactor, PF, KV3201	CR1, CR3		KV3201
37	2	40010016	Diode, Shotky, ZC2800, Sot-23	CR4,CR8		ZC2800
38	3	43011057	Inductor-SM; .56uHy	L16, L17, L19	Toko	300NS-R56M
39	4	48000056	Connector-SMA, Female	J1-J4	E.F. Johnson	142-0701-501
40	1	48000065	Connector; 36 pin	P5	Samtec	ZSS-118-03-G-D-715
41	24	55025008	Terminal	TP1-TP9,TP11-TP19,TP24-TP29	Component Corp	TP-105-01-09
42	2	43011053	Inductor Variable; 340nHy	L6, L11	Standex	957106J2
43	2	43011047	Inductor-SM; 2.2uHy	L4, L5	Toko	300LS-2R2K
44	5	43011019	Inductor-SM; 1uHy	L1, L3, L12, L13, L14	Toko	300LS-1R0K
45	1	43011078	Inductor-SM; 220uHy	L2	Delevan	2474-29L
46	5	43011031	Inductor-SM; 4.7uHy	L7, L8, L9, L15, L18	Toko	300LS-4R7K
47	A/R	71110006	Cable Coax		Olympic	53284
48	1	42025029	Cap Chip NPO CC1206; 220pF	C194		
49	7	42480009	Cap -Tant-SM; 22uF/25V	C171-172, C174-176, C178-179	Panasonic	ECS-T1ED226R
50	70	42025037	Cap Chip NPO CC1206; 1000pF	C4-15, C21, C24, C29, C31-32, C36-37, C39, C40, C42-43, C45-49, C52-53, C56, C59-C62, C75, C77, C80, C83-84, C89, C90-91, C94, C97, C103, C105, C107-109, C114-115, C117-119, C124, C131, C139, C141-142, C149, C161, C166, C169, C173, C182-185, C193		
51	4	42025013	Cap Chip NPO CC1206; 10pF	C76, C78, C92-C93		

Multimode RF PCB				80 211 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
52	9	42020013	Cap Chip X7R CC1206; 0.1uF	C22,C27,C98-99,C120, C123,C188, C195, C196		
53	3	42025015	Cap Chip NPO CC1206; 15pF	C41, C100, C136		
54	5	42020001	Cap Chip X7R CC1206; 0.01uF	C79,C95,C132,C152,C177		
55	7	42025025	Cap Chip NPO CC1206; 100pF	C54,C85,C134,C156,C159, C163,C170		
56	2	42025007	Cap Chip NPO CC1206; 3.3pF	C25, C102		
57	2	42025005	Cap Chip NPO CC1206; 2.2pF	C26, C104		
58	9	42025021	Cap Chip NPO CC1206; 47pF	C33-35,C44,C81-82, C111-113		
59	38	42026001	Cap Chip X7R CC1210; 1uF	C1,C17-20,C28,C30,C38, C55,C57-58,C63, C96,C106,C110,C116, C121,C126,C130,C133,C13 5, C138,C140,C144,C146-148, C150,C151, C153-155, C157-158,C162,C164-165, C187		
60	1	42025019	Cap Chip NPO CC1206; 33pF	C88		
61	6	42025016	Cap Chip NPO CC1206; 18pF	C87, C122, C128, C129, C137, C192		
62	2	42025017	Cap Chip NPO CC1206; 22pF	C127, C145		
63						
64						
65	1	41050009	Potentiometer-SM; 5K	R125	Bourns	3314G-1- 502E
66	1	40010007	Diode, Shottky	CR7		1N6263
67	5	41050010	Potentiometer-SM; 10K	R1,R121,R127,R140,R1 51	Bourns	3314G-1- 103E
68	2	41050013	Potentiometer-SM; 100K	R124, R143	Bourns	3314G-1- 104E
69	1	41163001	Thermistor-SM; 10K	TR1	Tone Metric	060412- 6011-84-C1
70	1	41000033	Res. MF 1%, 10K RN55C1002F	R184		
71	1	41101064	Res. Chip 1% RC1206; 45.3 Ohm	R117		
72	1	41101213	Res. Chip 1% RC1206; 1.62K	R185		
73						
74	1	41101261	Res. Chip 1% RC1206; 5.11K	R60		
75	1	41101191	Res. Chip 1% RC1206; 953 Ohm	R63		

Multimode RF PCB				80 211 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
76	1	41101110	Res. Chip 1% RC1206; 137 Ohm	R136		
77	2	41101108	Res. Chip 1% RC1206; 130 Ohm	R118, R119		
78	2	41101240	Res. Chip 1% RC1206; 3.09K	R84, R162		
79	2	41101292	Res. Chip 1% RC1206; 10.7K	R83, R178		
80	2	41101301	Res. Chip 1% RC1206; 13.3K	R130, R153		
81	9	41101289	Res. Chip 1% RC1206; 10.0K	R59,R61,R64,R85-86,R112, R176,R179-180		
82	2	41101159	Res. Chip 1% RC1206; 442 Ohm	R4, R10		
83	2	41101083	Res. Chip 1% RC1206; 71.5 Ohm	R137, R138		
84	2	41101315	Res. Chip 1% RC1206; 18.7K	R128, R152		
85						
86	2	41101251	Res. Chip 1% RC1206; 4.02K	R156, R181		
87	2	41101268	Res. Chip 1% RC1206; 6.04K	R157, R182		
88	2	41101280	Res. Chip 1% RC1206; 8.06K	R62, R155		
89	1	41101263	Res. Chip 1% RC1206; 5.36K	R134		
90	1	41101135	Res. Chip 1% RC1206; 249 Ohm	R93		
91	4	41101077	Res. Chip 1% RC1206; 61.9 Ohm	R32, R56, R57, R92		
92	2	41101245	Res. Chip 1% RC1206; 3.48K	R129, R154		
93	4	41101073	Res. Chip 1% RC1206; 56.2 Ohm	R5, R6, R9, R11		
94	2	41101258	Res. Chip 1% RC1206; 4.75K	R110, R141		
95	2	41101222	Res. Chip 1% RC1206; 2.00K	R160, R171		
96	2	41160045	Res. Chip 5% RC1206; 240 Ohm	R15, R16		
97	2	41160021	Res. Chip 5% RC1206; 470 Ohm	R44, R79		
98	1	41160070	Res. Chip 5% RC1206; 390 Ohm	R39		

Multimode RF PCB				80 211 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
99						
100	5	41160062	Res. Chip 5% RC1206; 47 Ohm	R3,R105,R114,R122,R144		
101	2	41160086	Res. Chip 5% RC1206; 7.5K	R123, R142		
102	1	41160006	Res. Chip 5% RC1206; 180 Ohm	R26		
103	1	41160036	Res. Chip 5% RC1206; 470K	R14		
104						
105	2	41160004	Res. Chip 5% RC1206; 2.7K	R22, R101		
106	2	41160007	Res. Chip 5% RC1206; 33 Ohm	R120, R132		
107	10	41160011	Res. Chip 5% RC1206; 100 Ohm	R23, R27, R40, R67-R69, R80, R104, R109, R139		
108	5	41160001	Res. Chip 5% RC1206; 270 Ohm	R163, R172-R175		
109	4	41160042	Res. Chip 5% RC1206; 33K	R28, R30, R106, R107		
110	8	41160043	Res. Chip 5% RC1206; 51 Ohm	R7,R8,R12,R31,R78,R103,R113,R177		
111	4	41160145	Res. Chip 5% RC1206; 0 Ohm	R41, R55, R190, R191		
112	6	41160025	Res. Chip 5% RC1206; 100K	R19,R29,R47,R48,R97,R108		
113	2	41160041	Res. Chip 5% RC1206; 15K	R24, R98		
114	2	41160047	Res. Chip 5% RC1206; 22K	R25, R102		
115	2	41160022	Res. Chip 5% RC1206; 3.9K	R21, R100		
116						
117	11	41160015	Res. Chip 5% RC1206; 10K	R17-18,R42-43,R45,R54,R58,R91,R95-96, R164		
118	35	41160003	Res. Chip 5% RC1206; 1K	R2,R20,R33,R36-38,R46,R49-52,R65,R66,R77,R87-89,R94,R99,R111,R116,R126,R135,R145-148,R150,R161,R165-170		
119	2	41160082	Res. Chip 5% RC1206; 5.1K	R35, R90		
120	6	41160029	Res. Chip 5% RC1206; 3.3K	R72-R75, R81, R82		
121	4	42480008	Cap-Tant-SM; 100uF/10V	C23, C101, C180, C181	AVX	TAJD107K010R
122	4	52062002	Washer, Nylon		Seastrom	5610-214-20
123	1	53010002	Nut, Hex No.4			MS35649-244

Multimode RF PCB				80 211 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
124	1	50110009	Screw, P.H. 4-40 X 5/16 LG			MS51957-14
125	1	52010002	Washer, Flat, No. 4			MS15795-804
126	1	52020002	Washer, Lock, No. 4			MS35338-135
127	1	41160089	Res. Chip 5% RC1206; 12K	R183		
128	1	42025033	Cap Chip NPO CC1206; 470pF	C2		
129	AR	31010005	Adhesive, Wire Tacking		Loctite	TAK-PAK 444
130	2	31020085	Shield Isolation			
131	1	31020084	Shield Isolation			
132	AR	31010001	Adhesive, Silicone, RTV		Dow Corning	732
133	1	31020086	Shield Isolation			
134	AR	31010011	RTV, Silicone		Loctite	5145
135	2	80212001	Pcb Assembly, I.F. Filter			
136	1	62040040	Cover, Shield Isolation			
137	2	62040039	Cover, Shield Isolation			
138	AR	72628001	Wire, Kynar, Insulated, 28 AWG		Olympic	461-4
139	AR	31006002	Tape, Low Static Polyimide Film		3M	5149
140	1	40201078	OR; Quad, 2 Input; MC74HC32M; SO-14	U38		
141	AR	80211006	TP, Multimode RF PCB			



Attenuator Assembly

Figure 6-7


Attenuator Assembly				89 001 077		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1						
2	1	65000019	BLOCK ATTENUATOR			
3						
4	8	50110009	SCREW, PAN HD. 4- 40 X 5/16			MS51957-14
5	1	57031020	DECAL, ATTENUATOR			
6	1	80173001	PCB ASSEMBLY, ATTENUATOR BOARD			
7	8	52010007	FLAT WASHER			NAS620C-4L
8	8	52020002	WASHER, SPLIT- LOCK NO. 4			MS35338-135
9	1	57031021	DECAL, MOD			
10	1	57030013	DECAL, SERIAL NO.			

Attenuator PCB Assembly

(Drawing unavailable)

Attenuator PCB				80 173 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1						
2	1	80173002	Drilling and Fabrication (REV A)			
3	1	41130016	Resistor Power; Termination;50 Ohm	R7	RF Power	RFP-250-50TC
4	2	42025037	Cap Chip, NPO; CC1206; 1000PF	C1, C2		
5	1	41160015	Res Chip 5%; RC1206; 10K	R1		
6	1	41101261	Res Chip 1%; RC1206; 5.11K	R6		
7	1	41101068	Res Chip 1%; RC1206; 49.9 Ohm	R2		
8	2	48040052	Connector-SMA; Straight (.200 Foot print)	J1, J2	E.F. Johnson	142-0701-231
9	1	48040059	Connector-SMA; Right Angle (.200 Foot print)	J3	E.F. Johnson	142-0701-301
10	2	41161009-80	Res Chip 1%; RC0805; 66.5 Ohm	R3, R5		
11	1	41101118	Res Chip 1%; RC1206; 165 Ohm	R4 S.A.T.		
11	SUB	41101117	Res Chip 1%; RC1206; 162 Ohm	R4 S.A.T.		
11	SUB	41101119	Res Chip 1%; RC1206; 169 Ohm	R4 S.A.T.		
11	SUB	41101120	Res Chip 1%; RC1206; 174 Ohm	R4 S.A.T.		
11	SUB	41101121	Res Chip 1%; RC1206; 178 Ohm	R4 S.A.T.		
11	SUB	41101122	Res Chip 1%; RC1206; 182 Ohm	R4 S.A.T.		
11	SUB	41101123	Res Chip 1%; RC1206; 187 Ohm	R4 S.A.T.		
11	SUB	41101124	Res Chip 1%; RC1206; 191 Ohm	R4 S.A.T.		
12	1	42020001	Cap. Chip, X7R, CC1206, 0.01uF	C4		
13	1	48065005	Ferrite Chip	L1	Steward	MI1206K900R-00
14	2	50110009	Screw, Pan Hd. 4-40 X 5/16 Lg.			MS51957-14
15	2	52010007	Washer, Flat , Small Pattern No. 4			NAS620C-4L
16	2	52020002	Washer, Splitlock No. 4			MS35338-135
17	2	53010011	Nut, Hex, Extra Small Pattern No.4		Tower Fasteners	4CNESS

#	ITEM #1	CABLE WIRE	ITEM #4	ITEM #3
1	--	BRN	1	--
2	--	RED	2	--
3	--	ORG	3	--
4	--	YEL	4	--
5	1	GRN	5	--
6	20	BLU	6	--
7	2	VIO	7	--
8	21	GRY	8	--
9	3	VHT	9	--
10	22	BLK	10	--
11	4	BRN	11	--
12	23	RED	12	--
13	5	ORG	13	--
14	24	YEL	14	--
15	6	GRN	15	--
16	25	BLU	16	--
17	7	VIO	17	--
18	26	GRY	18	--
19	8	VHT	19	--
20	27	BLK	20	--
21	9	BRN	21	--
22	28	RED	22	--
23	10	ORG	23	--
24	29	YEL	24	--
25	11	GRN	25	--
26	30	BLU	26	--
27	12	VIO	--	1
28	31	GRY	--	2
29	13	VHT	--	3
30	32	BLK	--	4
31	14	BRN	--	5
32	33	RED	--	6
33	15	ORG	--	7
34	34	YEL	--	8
35	16	GRN	--	9
36	35	BLU	--	10
37	17	VIO	--	11
38	36	GRY	--	12
39	18	VHT	--	13
40	37	BLK	--	14
41	19	BRN	--	15
42	--	RED	--	16




NOTES:

1. DISCARD WIRES ORANGES THRU BLACK (43-50)
 2. SEE ASSOCIATED PARTS LIST 75 010 165

Cable Assembly, Dig/Panel Display

Figure 6-8


Cable Assembly, Dig/Panel Display				75 010 165		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48 000 039	CONNECTOR, 37 PIN		AMP #747303-1	
2	A/R	75 000 019	CABLE, FLAT, 50 CONDUCTORS		3M #3302-50	
3	1	48 000 059	CONNECTOR, 16 PIN		T&B #622-1600	
4	1	48 000 016	CONNECTOR, 26 PIN		T&B #622-2630	



Cable Assembly, Dig/FP Switch PCB

Figure 6-9


Cable Assembly, Dig/FP Switch PCB				75 010 166		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48000069	CONNECTOR, RIBBON, 50 PIN		AMP	746789-1
2	1	48000068	CONNECTOR, RIBBON, 50 PIN		AMP	111564-4
3	AR	75000019	CABLE, 50 COND., 28 AWG		3M	3302-50
4	2	52400032	JACKSCREW, 4-40, 3/16 HEX X 3/16 LG.		RAF	4750-2



Cable Assembly, RF/Antenna Diff

Figure 6-10

Cable Assembly, RF/Antenna DIFF				75 010 081		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48040043	CONNECTOR, BNC		HUBER-SUHNER	24BNC-50-2-20
2	AR	71111002	WIRE, COAX		HUBER-SUHNER	EZ-FLEX-086
3	1	48040045	CONNECTOR, RT. ANGLE, SMA		HUBER-SUHNER	16SMA-50-2-3
4	AR	73000009	SHRINK TUBING, CLEAR, 1" LG.		ALPHA	FIT-221-3/16
5	AR	73000019	SHRINK TUBING, WHITE, 1" LG.		RAYCHEM	TMS-SCE-1/4-2.0-9
6	AR	73000008	SHRINK TUBING, CLEAR, 3/32		ALPHA	FIT-221-3/32
7	AR	73000010	SHRINK TUBING, CLEAR, 1/8		ALPHA	FIT-221-1/8
	AR	SN60/63	SOFT SOLDER			QQ-S-571




NOTES:

1. SHRINK TUBING (ITEM NUMBER 6) SHOULD BE INSTALLED OVER THE ENTIRE LENGTH OF CABLE (ITEM NUMBER 2) AND CONNECTOR ENDS OF CONNECTORS (ITEM NUMBERS 1 AND 3). SHRINK TUBING IN PLACE BY HEATING TO A TEMPERATURE OF APPROXIMATELY 220°F USING A HOT AIR GUN.
2. INSTALL TWO PIECES OF SHRINK TUBING (ITEM NO. 7) OVER FERRULE OF CONNECTOR (ITEM NO. 3). FIRST INSTALL A .50 INCH LONG PIECE OF SHRINK TUBING (ITEM NO. 7) OVER FERRULE AND SHRINK IN PLACE BY HEATING TO A TEMPERATURE OF APPROXIMATELY 220°F USING A HOT AIR GUN. INSTALL THE SECOND PIECE OF SHRINK TUBING (ITEM NO. 7) APPROXIMATELY .43 INCH LONG OVER THE .50 INCH LONG PIECE. SHRINK TUBING IN PLACE BY HEATING TO A TEMPERATURE OF APPROXIMATELY 220°F USING A HOT AIR GUN.
3. PLACE SHRINK TUBING (ITEM NO. 4) OVER ITEM NUMBERS 6 AND 7.
4. MARK SHRINK TUBING (ITEM NO. 5) ".50M" .08 HIGH CHARACTERS USING BLACK INK. INSTALL OVER ITEM NO. 6 AT CONNECTOR ITEM 1.
5. MARK SHRINK TUBING "75010075" .08 HIGH CHARACTERS USING BLACK INK. INSTALL AFTER ASSEMBLY OF ALL OTHER ITEMS. CUT LENGTH OF LABEL TO SUIT ASSEMBLY.
6. SHRINK TUBING IN PLACE BY HEATING TO A TEMPERATURE OF APPROXIMATELY 220°F USING A HOT AIR GUN.

Cable Assembly, RF/Antenna (SUM)

Figure 6-11


Cable Assembly, RF/Antenna SUM				75 010 075		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48040043	CONNECTOR, BNC		HUBER-SUHNER	24BNC-50-2-20
2	AR	71111002	WIRE, COAX		HUBER-SUHNER	EZ-FLEX-086
3	1	48040045	CONNECTOR, RIGHT ANGLE, SMA		HUBER-SUHNER	16SMA-50-2-3
4	1	73000012	SHRINK TUBING, WHITE 1" LG.		ALPHA	FIT-221-3/16 WHITE
5	1	73000019	SHRINK TUBING, WHITE 1" LG.		RAYCHEM	TMS-SCE-1/4-2.0-9
6	AR	73000008	SHRINK TUBING, CLEAR, 3/32		ALPHA	FIT-221-3/32
7	AR	73000010	SHRINK TUBING, CLEAR, 1/8		ALPHA	FIT-221-1/8



Antenna/DIR Connect Cable Assembly

Figure 6-12


Antenna/DIR Connect Cable Assy				75 010 079		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48040044	CONNECTOR, TNC		SUHNER	24TNC-50-2-31
2	AR	71111002	CABLE, COAX		EZ FORM CORP	EZ-FLEX-086
3	1	48040040	CONNECTOR, SMA		EFJ	142-0693-001
4	AR	73000008	SHRINK TUBING, CLEAR		ALPHA	FIT-221-3/32
5	AR	73000010	SHRINK TUBING, CLEAR		ALPHA	FIT-221-1/8
6	AR	73000009	SHRINK TUBING, WHITE		ALPHA	FIT-221-3/16
7	AR	73000019	SHRINK TUBING, WHITE		RAYCHEM	TMS-SCE-1/4-2.0-9
	AR	SN60-63	SOFT SOLDER			QQ-S-571



Attenuator/RF Cable Assembly

Figure 6-13

Attenuator/RF Cable Assembly				75 010 082		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48040040	CONNECTOR, STRAIGHT		E.F. JOHNSON	142-0693-001
2	AR	71111002	WIRE, COAX		HUBER-SUHNER	E-Z-FLEX086
3	1	48040045	CONNECTOR, RIGHT ANGLE, SMA		HUBER-SUHNER	16SMA-50-2-3
4	1	73000019	SHRINK TUBING, WHITE, 1" LONG		RAYCHEM	TMS-SCE-1/4-2.0-9
5	AR	73000009	SHRINK TUBING, CLEAR 3/16		ALPHA	FIT-221-3/16
6	AR	73000008	SHRINK TUBING, CLEAR, 3/32		ALPHA	FIT-221-3/32
7	AR	73000010	SHRINK TUBING, CLEAR, 1/8		ALPHA	FIT-221-1/8
	AR	SN60-63	SOFT SOLDER			QQ-S-571



Cable Assembly, Sense Line

Figure 6-14


Cable Assembly, Sense Line				75 010 142		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80169001	SENSE FILTER PCB ASSEMBLY	A26		
2	1	31020096	BOX, SENSE FILTER			
3	1	62040050	COVER, SENSE FILTER			
4	1	48040045	CONNECTOR, RIGHT ANGLE, SMA	J2	HUBER-SUHNER	16SMA-50-2-3
5	1	48040040	CONNECTOR, STRAIGHT, SMA	J1	E.F. JOHNSON	142-0693-001
6	1	73000018	SHRINK TUBING, WHITE, 1" LG.		RAYCHEM	TMS-SCE-3/16-2.0-9
7	1	73000012	SHRINK TUBING, WHITE, 1" LG.		ALPHA	FIT-221-3/16 WHITE
8	AR	71111003	WIRE, COAX		HUBER-SUHNER	S-FORM 86 FEP
9	AR	73000011	SHRINK TUBING, BLACK, 1-1/2" LG.		ALPHA	FIT-221-1/2 BLACK

Sense Line Filter

(Drawing unavailable)

Sense Line Filter				80 169 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80169002	PCB Drilling and Fabrication (Rev A.)			
2	2	48065005	Ferrite Chip, SM	L1, L3	Steward	#MI1206K900R-00
3	1	43011020	Inductor, SM 10 uHy +/-10%	L2	TOKO	#300LS-100K
4	2	42026001	Cap, Chip, CC1210 Z5U; 1uF	C1,C2		

PIN NO.	WIRE COLOR	WIRE ITEM NO.
1	BRN	3
2	BRN	3
3	BLU	4
4	BLU	4



NOTES:


1. SEE ASSOCIATED PARTS LIST 75 010 163.

Cable Assembly, Power Supply

Figure 6-15

Cable Assembly, Power Supply				75 010 163		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48 000 089	CONNECTOR, RECEPT, ASSY, SINGLE ROW		AMP	#104257-3
2	4	46 053 002	CONTACT, RECEPTACLE		AMP	#104480-8
3	AR	72 722 002	WIRE, TEFLON INSUL, 22 AWG, BRN		OLYMPIC	#307-1
4	AR	72 722 007	WIRE, TEFLON INSUL, 22 AWG, BLU		OLYMPIC	#307-6

PIN NO.	WIRE COLOR	WIRE ITEM NO.
1	WHT/GRY	12
2	WHT/VIO	11
3	WHT/GRN	10
4	WHT/YEL	9
5	WHT/ORN	8
6	WHT	7
7	NOT USED	-
8	VIO	6
9	RED	3
10	RED	3
11	BLK	2
12	GRN	5
13	NOT USED	-
14	NOT USED	-
15	NOT USED	-
16	NOT USED	-
17	NOT USED	-
18	ORN	4




NOTES:

1. SEE ASSOCIATED PARTS LIST 75 010 193.

Power Supply Cable, 18 Pin

Figure 6-16

Power Supply Cable, 18 Pin				75 010 193		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	48000074	CONNECTOR, RECEPT, ASSY, SINGLE ROW		AMP	#1-103644-7
2	AR	72722001	WIRE, TEFLON INSUL, 22 AWG, BLK		OLYMPIC	#307-0
3	AR	72722003	WIRE, TEFLON INSUL, 22 AWG, RED		OLYMPIC	#307-2
4	AR	72722004	WIRE, TEFLON INSUL, 22 AWG, ORN		OLYMPIC	#307-3
5	AR	72722006	WIRE, TEFLON INSUL, 22 AWG, GRN		OLYMPIC	#307-5
6	AR	72722008	WIRE, TEFLON INSUL, 22 AWG, VIO		OLYMPIC	#307-7
7	AR	72722010	WIRE, TEFLON INSUL, 22 AWG, WHT		OLYMPIC	#307-9
8	AR	72722014	WIRE, TEFLON INSUL, 22 AWG, WHT/ORN		OLYMPIC	#307-93
9	AR	72722015	WIRE, TEFLON INSUL, 22 AWG, WHT/YEL		OLYMPIC	#307-94
10	AR	72722016	WIRE, TEFLON INSUL, 22 AWG, WHT/GRN		OLYMPIC	#307-95
11	AR	72722018	WIRE, TEFLON INSUL, 22 AWG, WHT/VIO		OLYMPIC	#307-97
12	AR	72722019	WIRE, TEFLON INSUL, 22 AWG, WHT/GRY		OLYMPIC	#307-98




NOTES:

1. ADHERE TO ENDS OF CENTER STRUT APPROX .50 FROM INSIDE EDGE TO CENTER OF BUMPER, EACH SIDE.

Battery Cover Assembly

Figure 6-17


Battery Cover Assembly				75 010 029		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	62040061	COVER, BATTERY			
2	4	50500001	RETAINER, CAPTIVE		ASMCO	#400006SS12
3	4	50400003	SCREW, CAPTIVE		ASMCO	#702-.7505512
4	2	31016010	BUMPER, ROUND, SELF ADHESIVE		McMASTER-CARR	#9723K15
5	1	55082026	GASKET, LEAD BATTERY			



Direct Connect Cable Assembly

Figure 6-18


Direct Connect Cable Assembly				75 010 186		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	2	48040055	CONNECTOR, CRIMP, TNC		HUBER-SUHNER	11TNC-50-3-115/133NE
2	10'	71110005	WIRE, COAXIAL, RG-223/U		OLYMPIC	6273
3	1	73000021	PRINTABLE HEAT SHRINK, WHITE		RAYCHEM	TMS-SCE-3/4-2.0-9
4	2"	73000006	SHRINK TUBING		ALPHA	FIT-221-1/4
		75006080	TEST PROCEDURE, DIRECT CONNECT RF CABLE			



Directional Antenna Assembly

Figure 6-19


Directional Antenna Assembly				89 001 158 07		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	AR	BLK	INK MARKING EPOXY			AA56032-IBLK
2	1	62070037	BACK PLATE ANTENNA-DIP BRAZE			
3	1	65000020	COVER, ANTENNA			
4	2	65000021	STANDOFF, ANTENNA			
5	2	50140001	SCREW, FLAT HD. 6-32 X 3/8 82 DEGREE			MS51959-28
6	32	50140010	SCREW, FLAT HD. 3-48 X 1/4 82 DEGREE		McMASTER-CARR	91771A092
7	1	50600001	INSERT, THREADED		McMASTER-CARR	90247A012
8	1	31008001	RADOME ANTENNA			
9	1	80201001-01	PCB ASSEMBLY, DIRECTIONAL ANTENNA	A14		
9	1	80201001-02	PCB ASSEMBLY, DIRECTIONAL ANTENNA			
9	1	80201001-04	PCB ASSEMBLY, DIRECTIONAL ANTENNA			
9	1	89000104	PCB ASSEMBLY, DIRECTIONAL ANTENNA			
10	1	52100004	SIGHT			
11	1	57030013	DECAL, SERIAL NUMBER			
12	1	56000010	CLAMP, CABLE		McMASTER-CARR	3225T63
13	1	52010001	WASHER, FLAT NO. 6			MS15795-805
14	1	53200004	LOCK NUT W/NYLON NO. 6		TOWER	6CNNMS
15	1	57031021	DECAL, MOD			
16	AR	31010001	RTV SILICONE ADHESIVE		DOW CORNING	732
17	1	57031007	LABEL, DATA			
18	AR	31010006	LOCTITE		LOCTITE	454
19	2	48040046	CONNECTOR, SMA		EF JOHNSON	142-0901-401
20	AR	31010008	SIL-711, NON CORROSIVE ADHESIVE		MASTERBOND	SIL-711



Directional Antenna/PCB (Not all Parts are shown)

Figure 6-20



Directional Antenna PCB				80 201 001 04		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80201002	DRILLING AND FABRICATION			
2	2	48040040	CONNECTOR, SMA		EFJ	142-0693-001
3	1	71111002	WIRE, SEMI-RIGID COAX, 2.5" LONG		EZ- FORM CORP	EZ-FLEX-086
4	1	71111002	WIRE, SEMI-RIGID COAX, 3.0" LONG		EZ- FORM CORP	EZ-FLEX-086
5	1	45001013	LAMP -LED (RED)	D1	AGILENT	HLMP-EG15-RU000
6	AR	70000001	WIRE, ELECT., SOLID COND.,TIN. COPPER, #24 AWG		ALPHA	299
7	1	42025025	CAP CHIP, NPO, CC1206, 100pF	C1		
8	4	41161001-32	RES CHIP, 5%, RC0805, 18 OHMS	R1, R2, R3, R4	PANASONIC	ERJ-6GEYJ180V
9	1	41161001-67	RES CHIP, 5%, RC0805, 510 OHMS	R5	PANASONIC	ERJ-6GEYJ511V
10	2	41161009-80	RES CHIP, 5%, RC0805, 66.5 OHMS	R6, R7	PANASONIC	ERJ-6ENF66R5V
11	2	41161001-58	RES CHIP, 5%, RC0805, 220 OHMS	R8, R9	PANASONIC	ERJ-6GEYJ221V
12	AR	73000033	TUBING,TEFLON, #22 AWG, CLEAR		ALPHA	TFT-200-22
13	AR	SN60-63	SOFT SOLDER			QQ-S-571
14	AR	72001007	20 AWG TINNED COPPER BUS WIRE		OLYMPIC	755
15	AR	31010004	LOCTITE			



Antenna Attenuator PCB

Figure 6-21

Antenna Atten, PCB Assembly				80 208 001-03		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80208002	DRILLING AND FABRICATION			
2	2	75010207	CABLE ASSEMBLY, RF			
3	1	45001013	LAMP -LED (RED)	D1	AGILENT	HLMP-EG15-RU000
4	1	42025025	CAP CHIP, NPO, CC1206, 100pF	C1		
5	4	41161001-01	RES, CHIP, 5%, 0805, 0 OHMS	R1, R2, R3, R4	PANASONIC	ERJ-6GEYJ0R0V
6	1	41161001-67	RES CHIP, 5%, RC0805, 510 OHMS	R8	PANASONIC	ERJ-6GEYJ511V
8	AR	73000033	TUBING,TEFLON, #22 AWG, CLEAR		ALPHA	
9	AR	SN60-63	SOFT SOLDER			QQ-S-571
10	AR	73000010	3/16" HEAT SHRINK, CLEAR		ALPHA	FIT-221-1/8 CLEAR
11	AR	31010006	TAC-PAC 454		LOCTITE	454
13	1	80208003	ANTENNA ATTENUATOR SCHEMATIC DIAGRAM			



CABLE PREPARATION


NOTES:

1. UNLESS OTHERWISE SPECIFIED; 2 PLACE DECIMAL TOLERANCES ARE $\pm .12$.
2. SOLDER IAW ANSI/J-STD-001 USING SOLDER QQ-S-571 COMP 60-63 TYPE RMA CORE 66. REMOVE RESIDUAL FLUX AS NECESSARY.
3. PREPARE AND ASSEMBLE IAW E. F. JOHNSON COMPONENTS ASSEMBLY INSTRUCTIONS ATTACHED TO SPEC/CONTROL DWG. 48040040 (USE OF EQUIVALENT TOOLS AND ASSEMBLY INSTRUCTIONS ACCEPTABLE).
4. MARK 92606ASSY75010207 ON PACKAGE OR TAG. DO NOT MARK PART.
5. SHRINK TUBING IN PLACE BY HEATING TO A TEMPERATURE OF APPROXIMATELY 220 DEGREES F USING A HOT AIR GUN.

Cable Assembly RF

Figure 6-22


Cable Assembly, RF				75 010 207		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	2	48040040	CONNECTOR, SMA, STRAIGHT		E. F. JOHNSON	142-0693-001
2	AR	71111002	WIRE, SEMI-RIGID COAX		EZ-FORM CORP	EZ-FLEX-086
3	AR	73000009	SHRINK TUBING, CLEAR, 3/16		ALPHA	FIT-221-3/16
4	AR	SN-60-63	SOLDER			QQ-S-571



Directional Antenna Cable Assembly

Figure 6-23

Directional Antenna Cable Assy.				75 010 208 02		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	2	48040066	Connector, BNC, Male		Huber-Suhner	11BNC-50-3-16/133NE
2	1	73000035	Taper Sleeve, Yellow		Huber-Suhner	78Z-4-3-5
3	1	73000036	Taper Sleeve, White		Huber-Suhner	78Z-9-3-5
4	1	49000001	Snap-Hook		Baron Manuf.	7340-1 3/4" (McMaster 3960T)
5	1	55006003	Crimp-On		McMaster	69405K57
6	AR	73000006	Shrink Tubing, Black, 1/4" Dia		Alpha	FIT-221-1/4
7	1	73000004	Shrink 3-Way Sleeve		Hellerman	306-1
8	AR	73000005	Braided, Expandable Sleeving		Teckflex	FLEXO-PET-1/4
9	1	56001001	Label, 1/2" White			
10	AR	71110005	Wire, Coax, RG223/U		Olympic	6273
11	AR	73000003	Shrink Tubing, Yellow, 1/4" Dia		Alpha	FIT-221-1/4
12	AR	73000002	Shrink Tubing, White, 1/4" Dia		Alpha	FIT-221-1/4
13	2	48040067	Connector, SMA, Male		Huber-Suhner	11SMA-50-3-6/111NE
		75006080	Test Procedure, Direct Connect RF Cable			



NOTES:


- 1.
2. ITEM 6- BRAID CONTINUOUS THRU 3-WAY SLEEVE

Directional Antenna Extension Cable Assembly

Figure 6-24

Directional Antenna Extension Cable Assy.				75 010 078		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	2	48040038	Conn., Straight BNC Plug		Amphenol	31-320
2	2	48040039	Conn., Straight BNC Jack		Amphenol	36800, USE with Crimp Sleeve 31-1357-2G
3						
4	1.5"	73000002	Shrink Tubing, White		Alpha	71-94-5226-6953
5	1.5"	73000003	Shrink Tubing, Yellow		Alpha	71-94-5226-6428
6	A/R	73000005	Braided EXP. Sleeve		Teckflex	Flexo-pet-1/4
7	12.5'	71110005	Cable, Coax, RG223U			RG-223/U
8	2	73000004	Shrink 3-way Sleeve		Hellermann	306-1
9						
10						
11	1	56001001	Cable Tie/Text			
12	1	55006002	Crimp-on		McMaster-Carr	69405K56
13	2"	73000006	Shrink Tubing, Black		Alpha	FIT-221-1/4
14	2	55006003	Crimp-on		McMaster-Carr	69405K57
15	2	49000001	Snap Hook		Baron Mfg.	7340-1-3/4" (MCM #3960T5)

TAP-200 Assembly				89 000 166		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	64050014	CAN			
2	1	64050015	FRAME, INNER			
3	13	52020002	WASHER, LOCK, #4			MS35338-135
4	2	50110002	SCREW, PAN HEAD, #4-40 X 1/2" LONG			MS51957-17
5	11	50110009	SCREW, PAN HEAD, #4-40 X 5/16" LONG			MS51957-14
6						
7	1	40030006	ANTENNA, TUBE ASSEMBLY			
8	1	80198001	PCB ASSEMBLY, ARC			
9	1	64030023	POUCH (OPTIONAL)			
10	1	48040066	CONNECTOR, COAXIAL, BNC MALE		HUBER-SUHNER	11BNC-50-3-16-3
11	10'	71111001	WIRE, COAXIAL, FLEXIBLE		BELDEN	8262 OR EQUIVALENT
12	1	48040033	CONNECTOR, COAX, 1/2 HEX		AMPHENOL	31-1356-2G
13	1	31020071	FERRULE, CRIMP SLEEVE			
14	2	55082007	GASKET, RF FILTER, LARGE			
15	2	55082009	GASKET, RF FILTER, SMALL			
16	AR	31010002	ADHESIVE		3M	1300 YELLOW
17	2	55082010	GASKET, DURO 50, 1/2" X 1/4"			
18	1	62070026	PLATE, FIXED, PHENOLIC			
19	1	62070027	PLATE, MOVABLE, PHENOLIC			
20	2	53700002	RING, KEY		WORTH	KR-4-Z
21	1	51009002	ROD, PULL			
22	2	52400017	STANDOFF, 3/16" HEX		RAF	4515-440-SS-40
23	1	31016001	STREAMER, WARNING		AUW	30042
24	1	55001002	STRAIN RELIEF, MODIFIED		HEYCO	3237 (MODIFIED)
25	2	56023001	SPRING		ASSOCIATED	C0300-030-1000-S
26	1	55010004	LUG, GROUND		ZIERICK	334-.375-.020
27	1	57005074	SILKSCREEN, TAP-200			
		89006145	TEST PROCEDURE, ANTI-RADIATION COUPLER			




PCB Power Supply

Figure 6-26


PCB Assembly, Power Supply				80 180 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80180002	PCB Drilling and Fabrication	U3	Fairchild Philips Texas Inst.	MM74HC4060M 74HC4060 CD74HC4060M
2	1 ALT ALT	40201071	I.C.-SM	U2	Philips	HEF4002BT
3	1	40201154	Nor Gate 4002-SM	U1	Philips	LM2903D
4	1	40201023	Comparator 2903-SM	VR1,VR2	Harris	V175LA2
5	2	42230002	Varistor (MOV)	C4,C10	Sprague	30LVSD47
6	2	42100002	Cap.,Cerm. Disc 4700pF, 250V	C6,C7	Sprague	440LD22
7	2	42100004	Cap.,Cerm. Disc .0022uF/250V	T1	Astrodyne	MSCA-0303
8	1	48092003	Converter, AC/DC	J2	AMP	1-103670-7
9	1	48000066	CONN., 18 PIN	J1	AMP	103670-3
10	1	55050010	CONN., HEADER, 4 POS. SIN. ROW	N/A	RAF	7829-632-B-SS-20
11	7	52300005	FASTENER	TP1- TP9,TP11,TP12	Comp. Corp	TP-105-01-09
12	10	55025008	TERMINAL	U6	Texas Inst.	LM285D-2.5
13	1	40201157	I.C.-SM DIODE-285 (2.5V)	U6	ON Semi.	LM285D-2.5
14	ALT	40201157	I.C.-SM DIODE-285 (2.5V)	F1	Schurter	PFST.200
15	1	45100024	Fuse-Strap, Resettable	C1, C3, C8, C9		
16	4	42026001	CAP. CHIP; CC1210 Z5U; 1uF	C2		
17	1	42020065	CAP. CHIP; CC1206 X7R; .22uF/25V	C16, C23		
18	2	42020013	CAP. CHIP; CC1206 X7R; 0.1uF	C17, C18, C19	Panasonic	ECE-V1EA220P
19	3	42025037	CAP. CHIP; CC1206 NPO; 1000pF	C5		
20	1	42185036	CAP. ALUM-ELECT- SM; 22uF/25V			
21				R16		
22	1	41165002	RES. CHIP; RC1210 5%; 2K	R1		
23	1	41160013	RES. CHIP; RC1206 5%; 4.7K	R15, R20, R22, R35, R37, R41		
24	6	41160025	RES. CHIP; RC1206 5%; 100K	R13, R14		
25	2	41160035	RES. CHIP; RC1206 5%; 240K	R3, R24, R25, R40		
26	4	41160003	RES. CHIP; RC1206 5%; 1K	R9, R11, R17, R19, R23, R28, R29, R31, R32, R34		
27	10	41160015	RES. CHIP; RC1206 5%; 10K	R4, R5		

PCB Assembly, Power Supply				80 180 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
28	1	41160011	RES. CHIP; RC1206 5%; 100 Ohms	R10		
29	1	41160029	RES. CHIP; RC1206; 5%; 3.3K	R2		
30	1	41101245	RES. CHIP; RC1206; 1%; 3.48K	R8		
31	1	41160021	RES. CHIP; RC1206; 470 Ohms	R12		
32	1	41160024	RES. CHIP; RC1206; 5% 27K	R33		
33	2	40001030	TRANSISTOR- SM	Q1, Q3	Vishay	VN10KC
34	3	40001031	TRANSISTOR- SM	Q2, Q4, Q5	Motorola	MMSF5P02HD
35	1	43011059	INDUCTOR; 100uHy	L3	RENCO	RL-1284-100
36	2	40010036	DIODE 360-SM	D9, D10	MOTOROLA	MBRS360T3
37	1	40010037	DIODE 4625- (5.1V)	D12	MOTOROLA	1N4625
38	7	40010014	DIODE 914-SM	D2,D3,D8,D13,D14,D17,D19	NAT'L SEMI.	MMBD914
39	1	40010016	DIODE 2800-SM	D20	SCHOTTKY	ZC2800
40	2	48065005	Chip, Ferrite	L1,L2	STEWART	MI1206K900R-00
41	2	41160145	RES. CHIP, RC1206: 0 OHMS	R21, R36		
42	AR	31010001	SILICONE ADHESIVE (RTV)		DOW CORNING	732



Panel Switch Assembly


Figure 6-27 (a)



Panel Switch Assembly

Figure 6-27 (b)

Panel Switch Assembly				80 189 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80189002	DRILLING AND FABRICATION	J2	AMP/TYCO	6-1437063-3
2	1	55050019	HEADER, 16 POS., DOUBLE ROW, LATCHING	J3	AMP/TYCO	104313-9
3	1	55050007	HEADER, 50 POS., DOUBLE ROW	D1-D3, D6-D8, D10, D11, D14-D17, D21-25	NAT'L SEMI.	MMBD914
4	17	40010014	DIODE-SM	L1	RENCO	RL-6010-2.2-6.0
5	1	43013005	INDUCTOR, TOROID 2.2mH	C2	SPRAGUE	199D107X9020FE2
6	1	42470021	CAP., TANT., 100uF/20V	C1	PANASONIC	ECK-DRS101MBY
7	1	42100005	CAP., CERM. DISC 100pF/400V	C3-C6	ELCON	ECR152GJ
8	4	42250008	CAP., POLYCARB .0015uF/250V	J2	AMP/TYCO	6-1437063-3



PCB Assembly, Regulator				80 191 001		
#	Qty	Tel Desig.	Nomenclature	Ref Desig.	Resource	Vendor P/N
1	1	80191002	PCB DRILLING AND FABRICATION (REV A.)			
2	1	56060021	VOLTAGE REGULATOR-SM	U5	NAT'L SEMI.	LM2673S-ADJ
3	3	55025008	TERMINAL	TP1-TP3	COMP. CORP.	TP-105-01-09
4	2	42000032	CAPACITOR, CERM 1uF/50V	C4, C5	PANASONIC	ECU-S1H105KBB
5	1	42020065	CAPACITOR, CHIP; CC1206 X75; .22uF/25V	C20		
6	1	42025037	CAPACITOR, CHIP; CC1206 NPO; 1000pF	C21		
7	1	42190024	CAPACITOR, ALUM-ELECT.; 560uF/50V	C7	PANASONIC	EEU-FC1H561B
8	1	42190023	CAPACITOR, ALUM-ELECT.; 560uF/35V	C6	PANASONIC	ECA-1VFQ561L
9	1	41101193	RESISTOR, CHIP; RC1206 1%; 1.0K	R20		
10	1	41101260	RESISTOR, CHIP; RC1206 1%; 4.99K	R21		
11	1	41101268	RESISTOR, CHIP; RC1206 1%; 6.04K	R19		
12	1	43013003	INDUCTOR; 48uHY	L1	RENCO	RL-6100-48-3-H3(HORIZONTAL)
13	2	40010036	DIODE 360-SM	D10, D11		MBRS360T3
14	AR	31010001	SILICONE ADHESIVE (RTV)		DOW CORNING	732
15		80191003	SCHEMATIC DIAGRAM			
16	1	41101289	RESISTOR, CHIP; RC1206 1%; 10.0K	R23		
17	1	41101318	RESISTOR, CHIP; RC1206 1%; 20.0K	R24		
18	1	40001030	TRANSISTOR-SM, SOT-23, N-CHANNEL	Q1	VISHAY	VN10KC
19	AR	72722001	WIRE, TEFLON, 22AWG, BLACK		OLYMPIC	307-0

APPENDIX A

TR-220 Test Set Verification and Acceptance Checks Data Sheet

DATE
Model
Serial #
Technician

4.4 Display Operation, Self Test, and Initial Start Verification					
Step #	Test Description	Expected Value Log the result	Result Circle		Initial
2	PWR/CHG, Verify Green LED	LIT	PASS	FAIL	
3	ON/OFF, Verify Green LED	LIT	PASS	FAIL	
5	Self Test	PASS	PASS	FAIL	
	Verify Current Software	Rev			
	Total Test Set Hours	Hours			
6	Backlighting, Constant	Illuminated	PASS	FAIL	
7	Backlighting, Momentary	Momentarily Illuminated	PASS	FAIL	
9	Auto Shut Off	15 Minutes ± 2 Min	PASS	FAIL	
10	Verify “Direct Connect” Display	Displayed	PASS	FAIL	
		Displayed	PASS	FAIL	
11	Display Returns	“Transponder Test”	PASS	FAIL	

4.4.1 Transponder, Transmitter/Frequency Verification Tests					
Step #	Test Description, Expected Value	Measured Value Log the result	Result Circle		Initial
5	XPDR Power Out, SUM Port 5 to 9 dBm	dBm	PASS	FAIL	
6	Power Out, DIFF Port Min 20 dB Lower	dBm	PASS	FAIL	
7	Power Out, DIFF Port, 35 Feet 9 dB ± 2 dBm, Lower than Step 5	dBm	PASS	FAIL	
8	Power Out, DIFF Port, 75 Feet 5 dB ± 2 dBm, Lower than Step 5	dBm	PASS	FAIL	
12	Frequency 1030 MHz / ± 0.2 MHz	MHz	PASS	FAIL	

4.4.2 TCAS Verification				
Step #	Test Description, Expected Value	Measured Value Log the result	Result Circle	Initial
5	Verify Interrogator Display "Power & Frequency" are displayed	Checked	PASS FAIL	
6	Vary Frequency Measurements 1033 to 1027 MHz $\pm$.2 MHz	Checked	PASS FAIL	
9	TCAS Output Frequency 1090 MHz $\pm$ 200 kHz	MHz	PASS FAIL	

4.4.3 DME Verification				
Step #	Test Description, Expected Value	Measured Value Log the result	Result Circle	Initial
2	a. Interrogation Pulse Width 3 to 4 μs	μ s	PASS FAIL	
	b. Reply Pulse Spacing 11.75 to 12.25 μs	μ s	PASS FAIL	
	c. Interrogation Pulse Width, Y 29.75 to 30.25 μs	μ s	PASS FAIL	
3	a. DME 108.00 MHz, Range 2 74.72 μsec / $\pm$ 6.18 μsec	μ s	PASS FAIL	
	b. DME 108.00 MHz, Range 130 1656.66 μsec / $\pm$ 6.18 μsec	μ s	PASS FAIL	
	c. DME 108.00 MHz, Range 300 3757.700 μsec / $\pm$ 6.18 μsec	μ s	PASS FAIL	
	d. DME 108.05 MHz, Range 2 80.72 μsec / $\pm$ 6.18 μsec	μ s	PASS FAIL	
	e. DME 108.05 MHz, Range 130 1662.66 μsec / $\pm$ 6.18 μsec	μ s	PASS FAIL	
	f. DME 108.05 MHz, Range 300 3763.700 μsec / $\pm$ 6.18 μsec	μ s	PASS FAIL	
4	a. DME Frequency 108.00 MHz 978 MHz / $\pm$ 0.5 MHz	MHz	PASS FAIL	
	b. DME Frequency 112.60 MHz 1160 MHz / $\pm$ 0.5 MHz	MHz	PASS FAIL	
	c. DME Frequency 117.50 MHz 1209 MHz / $\pm$ 0.5 MHz	MHz	PASS FAIL	
	d. DME Frequency 108.05 MHz 1104 MHz / $\pm$ 0.5 MHz	MHz	PASS FAIL	
	e. DME Frequency 112.65 MHz 1034 MHz / $\pm$ 0.5 MHz	MHz	PASS FAIL	
	f. DME Frequency 117.55 MHz 1083 MHz / $\pm$ 0.5 MHz	MHz	PASS FAIL	

4.4.4 Antenna Gain				
Step #	Test Description, Expected Value	Measured Value Log the result	Result Circle	Initial
4	1030 MHz Antenna Gain Set	Checked		
	1090 MHz Antenna Gain Set	Checked		

DATE
PASS/FAIL
Technician

FAILED TEST RESULTS LOG			
Step #	Failed Test	Value Measured	Initial

Unit Disposition - _____

APPENDIX B

TR-220 Test Set Calibration and Alignment Data Sheet

4.8.1 Sub Assembly Adjustments				
Step #	Test Description	Specification	Initial Result	Final Adjusted (If applicable)
1	Record CPLD Version		Version	
6	Record Software Revision		Revision	
10	DPSK Base Line Voltage	0 V $\pm$ 2 mv	mv	mv
12	ATT Peak Power	8 / $\pm$ 0.2 dBm	dBm	dBm
13	SUM port Peak Power	7 / $\pm$ 1 dBm	dBm	dBm
14	Peak Power at DIFF , 25 ft.	Power Diff > 20 dB	dB	dB
16	Peak Power at DIFF , 35 ft.	Power Diff -9 / $\pm$ 2 dB	dB	dB
18	Peak Power at DIFF , 75 ft.	Power Diff -5 / $\pm$ 2 dB	dB	dB

4.8.2 DAC Table Adjustments				
Step #	Test Description	Specification	Initial Result	Final Adjusted (If applicable)
7	DAC TABLE	2	Hex Value	Hex Value
	DAC TABLE	4	Hex Value	Hex Value
	DAC TABLE	6	Hex Value	Hex Value
	DAC TABLE	8	Hex Value	Hex Value
	DAC TABLE	10	Hex Value	Hex Value
	DAC TABLE	12	Hex Value	Hex Value
	DAC TABLE	14	Hex Value	Hex Value
	DAC TABLE	16	Hex Value	Hex Value
	DAC TABLE	18	Hex Value	Hex Value
	DAC TABLE	20	Hex Value	Hex Value
	DAC TABLE	22	Hex Value	Hex Value
	DAC TABLE	24	Hex Value	Hex Value
	DAC TABLE	26	Hex Value	Hex Value
	DAC TABLE	28	Hex Value	Hex Value
	DAC TABLE	30	Hex Value	Hex Value
	DAC TABLE	32	Hex Value	Hex Value
	DAC TABLE	34	Hex Value	Hex Value
	DAC TABLE	36	Hex Value	Hex Value
	DAC TABLE	38	Hex Value	Hex Value
	DAC TABLE	40	Hex Value	Hex Value
	DAC TABLE	42	Hex Value	Hex Value
	DAC TABLE	44	Hex Value	Hex Value
	DAC TABLE	46	Hex Value	Hex Value
	DAC TABLE	48	Hex Value	Hex Value

4.8.3 Receiver Gain				
Step #	Test Description	Specification	Initial Result	Final Adjusted (If applicable)
2	Verify 100% Reply	100%	Verify	
4	Receiver Gain SUM / 0 dBm	210 / ± 1		
5	Receiver Gain SUM / -25 dBm	145 / ± 1		
6	Receiver Gain SUM / 0 dBm	210 / ± 1		
7	Receiver Gain SUM / + 5 dBm	222 / ± 1		
8	Power Measurement Display	58 dB		
9	Power Measurement Display	53 dB		
10	Output Tracking +10 to -20	Tracks ± 1 dB	Verify	
12	Direct Connect Out	- 42 dBm / 1 dB		
16	Receiver Gain DIFF	240 / ± 2		
17	Receiver Gain DIFF / - 25 dB	175 / ± 2		
18	Receiver Gain Verification	Verify		
23	DIFF/SUM @ 35 ft	Verify Pulse State Change	Check	Check
24	DIFF/SUM @ 35 ft	Verify Pulse State Change at 2 dB less	Check	Check
25	DIFF/SUM @ 25 ft	Verify Pulse State Change at 6 dB / ± 1	dB	dB

4.8.4 Power Supply Test				
Step #	Test Description	Specification	Initial Result	Final Adjusted (If applicable)
1	Power Supply Voltage at Batter Leads	7.2 VDC / ± 0.3 VDC	VDC	
3	Low Battery Display	5.6 VDC / $\pm .05$ VDC	VDC	
	NO Low Battery Display	5.4 VDC / $\pm .05$ VDC	VDC	
4	Test Set Shuts Down	5.2 VDC / $\pm .05$ VDC		
5	"LOW BATTERY SHUTTING DOWN"	Verify Display	Checked	

4.8.5 Acceptance and Verification Check FINAL STEP				
Step #	Test Description	Specification	Initial Result	Final Adjusted (If applicable)
1	Complete Acceptance and Verification Test	PASS		PASS FAIL

Date of Calibration	
Technician	
Signature or Stamp	

FAILED TEST RESULTS LOG			
Step #	Failed Test	Value Measured	Initial

Unit Disposition - _____

APPENDIX C

TR-220/210/211 Series of Test Sets

TAP-200 Calibration Procedures

1.0 **PURPOSE**

To Provide Owner and Operators of TR-220 and TR-210 Test Sets additional information and procedures to test and verify the TAP-200 Antenna Coupler.

The TAP-200, which is available in both 10' and 50' lengths, is available as an optional accessory and the following procedures are applicable to both.

2.0 **EQUIPMENT REQUIRED**


The following equipment list is necessary to calibrate and certify the TAP-200.

- a) *Agilent 8757D, Scalar Network Analyzer, or equivalent*
- b) L-Band Transponder antenna mounted on a 3'x3' metallic base
- c) An assortment of connector adapters
- d) Plastic, non metallic, tuning tools

Please refer to your Maintenance Manual which will detail Safety concerns, disassembly procedures, and drawings that may assist the operator/technician in completing these tests.

3.0 **PROCEDURES**

1. Connect the TAP-200 to a Network Analyzer and L-BAND Antenna IAW Figure A-1.




TAP-200 Calibration Setup

Figure A-1

2. Ensure that the TAP-200 is centered and flush to the base directly over the L-Band Antenna.
3. Set the Network Analyzer to the following:


Start Frequency	1020.0 MHz
Stop Frequency	1100.0 MHz
Scale Ref. Level	-50 dB (Take into account calibrated cable)
Ref. Position	5
Scale/Div	1.0 dB
Power Level	10 dBm
Averaging	"ON"
Marker 1	1030.0 MHz
Marker 2	1090.0 MHz

4. Observe a display similar to Figure A-2. Patterns may vary slightly.




Do not make an adjust if the measured display is in specification

5. Adjust **C4** (located on top of the TAP-200) so that the displayed measurement can be adjusted in an approx ± 3 dB. There is two positions in which **C4** might provide results. Select the location which provides the minimal slope and allows smooth adjustability around its range.
6. Fine tune **C4** so that at *MARKER 1*, the display is at -50 dB/ ± 1 dB, at the same time, *MARKER 2* is also at -50 dB/ ± 1 dB (see Figure A-3). Ensure that the cable loss from Port 2 to the L Band antenna was accounted for. Variations in the displayed measurement are not linear. Do not adjust the measurement in the center, only at the markers.
7. Record the results on the Data sheet as provided at the end of this supplement and seal the adjustment access for **C-4** to provide dust and rain protection.




TAP-200 Network Analyzer Display

Figure A-2



INCORRECTLY ADJUSTED



CORRECT

TAP-200 Adjustment Examples

Figure A-3

TAP-200 Calibration/Verification Check Data Sheet

DATE
Model
Serial #
Technician

3.0 TAP-200 Adjustment				
Step #	Test Description	Expected/Measured Value Log the result	Final Adjusted	Initial
6	Marker A -50dB / ± 1 dB	dB	dB	
6	Marker B -50dB / ± 1 dB	dB	dB	

FAILED TEST RESULTS LOG			
Step #	Failed Test	Value Measured	Initial

Unit Disposition - _____