

Keysight Technologies

CX3300 Current Waveform Analyzer

Quick Operation Guide

How to perform a Skew adjustment

The skew between the channels on the measurement device can be adjusted.

1. Preparation

- 1-1. Connect the Current Sensor (CX1101A/CX1102A/CX1103A) or the Passive Probe Interface Adapter (CX1151A) to the device.
- 1-2. Execute the measurement.

2. Settings

- 2-1. Click on the “Setting” icon.
- 2-2. The “Setting” dialog box opens.
- 2-3. Click on “Setting>Channels>Skew”.
- 2-4. The Skew setup panel opens and the waveforms for the effective channels are shown behind the “Setting” dialog box.
- 2-5. Adjust the skew of the other channels to the triggered channel while observing the waveforms behind the “Setting” dialog box.

