

Keysight Technologies

CX3300 Current Waveform Analyzer

Quick Operation Guide

How to use the waveform memory

1. Click on the “Analysis” icon to open the “Analysis” dialog box.
2. Select “Waveform Memories”.
3. Select “ON”.
4. Select “Memory X” (X is a number. X=1 in this case.)
5. Press [Load]. The waveform is loaded from Memory X.
6. Change the color, if necessary.

