

****Please read through this instruction carefully before using the tool. Use the tool for its intended purpose only.**

Item# 400-D69 : 0-22" Digital Depth Indicator Set



Parts:

1. 2 Thread Positions Depth Base
2. Connector (installed on indicator)
3. Digital Indicator (item# 35-128)
4. Depth Rods: 1,2,3,4,5,6"
5. Measuring points:
(flat, needle, ball, spline)
6. Full set with case

• Specifications

Indicator range: 0-1"/25mm Depth gauge range: 0-22"
 Indicator resolution: 0.0005" / 0.01mm / 1/128th
 Indicator accuracy: ± 0.001 " / 0.03mm
 Indicator repeatability: 0.0005" / 0.01mm
 Indicator power: 3V, CR2032 Battery
 Indicator battery life: 1/2~ 1 year under normal operation



Zero Setting

• Operations

Indicator: Please refer to iGAGING digital indicator 35-128 instruction on indicator usage.

Zero setting: 1. After secure the indicator on base with flat or ball points (without any rod attachment); push down the indicator against a flat surface and make sure base is tightly against the surface; press the ZERO key on the indicator to set zero. Rods can be added to the indicator after zero setting.


2. For using needle and spline points: zero setting the indicator using an setting master.

Depth base: 2-position base for easy position exchange.

Connector: screw and un-screw to change position of the indicator on the base.

Depth rods: 1" to 6" rods can add up to 22" in range.

Measuring tips: 4 different measuring tips to use in different applications.



Smart phone scan

- Do not disassemble the instrument.
- Do not subject the instrument to blows or shock.
- Do not store the instrument under direct sun light.
- Avoid exposing unit to strong magnetic fields and live voltage.
- Use soft cloth to clean instrument before and after usage. Never use organic solvents such as acetone or benzene to clean.