

Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

17e

PITTSBURGH

63613

1" Digital Indicator



Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright© 2017 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠ WARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Specifications

Indicator	0-1"
Dial Range	0-1"
Battery	SR44 - 1.5 Volt Silver Oxide Battery (extra battery included)
Accuracy	+/- .001"
Operating Temperature	32°F to 104°F
Face Diameter	2-1/4"
Ball Diameter	.118"
Stem Length	.75" L x .375" diameter
Resolution	.0005"
Dial Readings	Inches/mm

IMPORTANT SAFETY INFORMATION

- 1. Keep work area clean.** Cluttered areas invite injuries.
- 2. Observe work area conditions.** Keep work area well lighted. Always keep children out of work area.
- 3. Store idle equipment.** When not in use, the Indicator must be stored in a dry location. Always lock up products and keep out of reach of children.
- 4. Use the right product for the job.** There are certain applications for which the Indicator was designed. Do not modify the Indicator and do not use the Indicator for a purpose for which it was not intended.
- 5. Check for damaged parts.** Before using any product, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for any broken or damaged parts and any other conditions that may affect its operation. Repair damaged or worn parts immediately.
- 6. Do not operate product if under the influence of alcohol and drugs.** Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the product.
- 7. Use eye protection.** Always wear ANSI-approved impact safety goggles.
- 8. Battery strength will affect readings.** Use fresh battery at all times.
- 9. Keep out of reach of children.** Contains button cell battery that may be swallowed by small children. Discard used batteries immediately.
- 10.** The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Operating Instructions



Read the **ENTIRE IMPORTANT SAFETY INFORMATION** section at the beginning of this document including all text under subheadings therein before set up or use of this product.

Do not bump or shock the tool when applying it to any work piece. Rough treatment may damage the highly sensitive mechanism.

Note: There are many applications for the Digital Indicator. The following is one example of how this product can be used: testing brake rotors for true.

1. Clean off all brake components with brake parts cleaner before testing.
2. Push the "On/Off" Button (see Figure A) to turn the meter "ON".
3. Clamp the Indicator (clamp sold separately) in place so that only the needle contacts the brake rotor. Push the Zero Button to set the dial to zero. Do not clamp the Indicator too forcefully against the object being measured. There must be room for the needle to move in and out while under pressure.
4. Spin the rotor by hand to see if it is true. As the rotor spins, the needle will move in and out. The display will indicate the amount of difference in true; the measurements which are above and below the baseline you established at the beginning.
5. Press the inch/mm Button to have the Indicator display switch between inches or millimeters.



Figure A

Replacing the Battery

1. Remove the battery cover located directly on the top of the Digital Indicator by gently prying it off - see Figure B.
2. Replace the battery with the type specified on Page 2. Insert into the compartment with the positive polarity facing the front of the product.
3. Replace the battery cover. Dispose of the old battery immediately in accordance with local ordinances for proper disposal.



**Battery
Compartment**
Figure B

Record Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

PITTSBURGH

3491 Mission Oaks Blvd. • PO Box 6009 • Camarillo, CA 93011 • 1-888-866-5797